



Heinzmann GmbH & Co. KG

Engine & Turbine Management

Am Haselbach 1
D-79677 Schönau (Schwarzwald)
Germany

Telefon +49 7673 8208-0
Telefax +49 7673 8208-188
E-Mail info@heinzmann.com
www.heinzmann.com
USt-IdNr.: DE145551926

HEINZMANN®
Digital Electronic Speed Governors

Digital Basic Systems

ARCHIMEDES – ORION
PRIAMOS – HELENOS
PANDAROS – XIOS

Control devices
for conventional injection
with actuators

Copyright 2019 by Heinzmann GmbH & Co. KG All rights reserved.
This publication may not be reproduced by any means whatsoever or passed on to any third parties.

 <p>NOTICE</p>	<p>Please observe the following for electronically controlled injection (MVC):</p> <ul style="list-style-type: none"> – For common rail systems each injector line must be equipped with a separate mechanical flow-rate limiter – For unit pump (PLD) and pump-injector unit (PDE) systems, the fuel enable is first made possible by the solenoid valve’s control plunger motion. This means that in the event of the control plunger sticking, the fuel supply to the injection valve is stopped.
 <p>WARNING</p>	<p>As soon as the positioning device receives power, it can actuate the controller output shaft automatically at any given time. The range of the controller shaft or control linkage must therefore be secured against unauthorised access.</p>
	<p>HEINZMANN expressly rejects any implied guarantee pertaining to any marketability or suitability for a special purpose, including in the event that HEINZMANN was notified of such a special purpose or the manual contains a reference to such a special purpose.</p>
	<p>HEINZMANN shall not be held liable for any indirect and direct damage nor for any incidental and consequential damage that results from application of any of the examples, data or miscellaneous information as given in this manual.</p>
	<p>HEINZMANN shall not provide any guarantee for the design and planning of the overall technical system. This is a matter of the operator its planners and its specialist engineers. They are also responsible for checking whether the performances of our devices match the intended purpose. The operator is also responsible for a correct initial start-up of the overall system.</p>

Contents

	Page
1 Safety instructions and related symbols.....	1
1.1 Basic Safety Measures for Normal Operation.....	2
1.2 Basic Safety Measures for Servicing and Maintenance	2
1.3 Before Putting an Installation into Service after Maintenance and Repair	2
2 General	3
2.1 General system description.....	3
2.2 Firmware.....	3
2.2.1 HEINZMANN basic software	4
2.2.2 Custom firmware	6
2.3 Further information	6
2.4 Functional block diagram	8
2.5 Conventions.....	10
2.6 Parameter lists	10
2.7 Level.....	13
3 Parameterization of HEINZMANN control units.....	14
3.1 Possibilities of parameterization.....	14
3.2 Saving data	15
3.3 DcDesk 2000	15
3.4 ARGOS.....	16
3.5 Parameter value ranges.....	17
3.6 Activation of functions	18
3.7 Parameterization of characteristics	18
3.8 Parameterization of maps	19
3.9 Examples of parameterization	20
3.10 Reset of control unit	20
4 Starting the engine	22
5 Starting fuel limitation.....	38
5.1 Fixed starting fuel limitation	39
5.2 Variable starting fuel limitation.....	40
5.3 Temperature dependent starting fuel limitation.....	42
5.4 Starting sequence with starting speed ramp	44
5.5 Forced actuator opening	45
6 Speed sensing	38
6.1 Speed parameters.....	38
6.2 Speed measurement	38

6.3 Speed pickup monitoring	40
6.3.1 Failure monitoring	40
6.3.2 Gradient monitoring	41
6.3.3 Difference monitoring	42
6.4 Overspeed monitoring	42
6.5 Speed switching points	43
7 Speed setpoint determination	44
7.1 General application	45
7.1.1 Speed setpoint limitation	49
7.2 Vehicle operation	49
7.2.1 Freezing the speed setpoint	51
7.2.2 Work machine application with up/down steps	51
7.3 Locomotive operation	52
7.3.1 Digital notch switches	54
7.3.2 Digital potentiometer	54
7.4 Generator operation	55
7.5 Marine operation	58
7.5.1 Setpoint adjuster with directional information	60
7.5.2 Digital potentiometer	63
7.6 Temperature dependent idle speed	64
7.7 Speed ramp	65
7.7.1 Fixed speed ramp	65
7.7.2 Sectional speed ramp	66
7.8 Droop	68
8 Optimizing control circuit stability	72
8.1 Adjustment of PID parameters	72
8.2 PID map	73
8.2.1 Speed dependent correction of PID parameters	74
8.2.2 Load dependent correction of PID parameters	75
8.2.3 Stability map	78
8.3 Second PID parameter set	79
8.4 Temperature dependent correction of stability	79
8.5 Correction of PID parameters for static operation	80
8.6 Load jump regulation in generator systems (DT1 factor)	81
8.7 Load shedding in generator systems	83
9 Limiting Functions	85
9.1 Speed dependent fuel limitation	86
9.1.1 Temperature dependent reduction of full-load characteristic	88
9.1.2 Other temperature dependent reductions of full-load characteristic	89
9.2 Boost pressure dependent fuel limitation	90

9.3 Forced limitation	92
9.3.1 Fixed limit.....	92
9.3.2 Variable limit	93
9.4 Zero fuel delivery characteristic	93
9.5 Reduction of the full-load characteristic with XIOS	95
10 Warning and emergency shutdown functions	99
10.1 Coolant temperature warning	99
10.2 Charge air temperature warning	99
10.3 Oil temperature warning.....	100
10.4 Exhaust gas temperature warning.....	100
10.5 Forced idle speed in locomotive applications.....	101
10.6 Speed dependent oil pressure monitoring.....	101
10.7 Speed dependent coolant pressure monitoring	104
10.8 Misfire monitoring in generator operation	105
10.8.1 Single cylinder recognition	107
10.9 Alternator charge monitoring	109
10.10 Electronics monitoring	109
10.10.1 Voltage references	110
10.10.2 RAM test.....	110
10.10.3 Application memory test.....	110
10.10.4 Stack depth test	111
10.10.5 Programme sequence test.....	111
10.10.6 Monitoring of power supply	111
11 Additional functions	112
11.1 Engine operating hours counter	112
11.2 Jet Assist.....	112
11.3 Starting request.....	113
12 Vehicle operation.....	114
12.1 Idle/maximum speed control	114
12.1.1 Fuel Setpoint.....	114
12.1.2 Drive map	115
12.1.3 Controlling idle and maximum speeds	116
12.1.4 On-load idle speed	118
12.1.5 Fuel ramp	118
13 Locomotive operation	119
13.1 Speed notch switches.....	119
13.2 Generator excitation	123
13.2.1 Excitation control.....	123
13.2.2 Excitation governing.....	127

13.2.3 Power limitation.....	130
13.3 Low idle speed.....	132
13.4 Slide protection.....	133
13.4.1 Reduction of excitation by digital slide signal.....	133
13.4.2 Reduction of excitation by analogue slide signal	134
13.4.3 Speed reduction by digital slide signal	135
13.4.4 Speed reduction by analogue slide signal	136
14 Generator operation.....	137
14.1 Synchronization	137
14.1.1 Digital synchronization.....	138
14.1.2 Synchronization using the HEINZMANN Synchronizing Unit	139
14.2 Load control.....	140
14.2.1 Load control using the HEINZMANN Load Measuring Unit.....	141
14.2.2 Load control by a preset value	142
14.2.3 Integrated power governor	145
14.3 Digital generator management THESEUS	147
14.4 Automatic or manual operation	148
14.5 PANDAROS variants	150
14.5.1 DC 6-01: Standard Generator	150
14.5.2 DC 6-03: Extended Generator 1	150
14.5.3 DC 6-04: Extended Generator 2	151
14.5.4 DC 6-14: Extended Generator 3	152
15 Marine operation.....	154
15.1 Master/slave operation.....	154
15.2 Multiple engine set with directional information	156
15.2.1 CAN communication	157
15.2.2 Common setpoint adjustment	158
15.2.3 LED indicators.....	159
16 Speed control for dual fuel engines (ARTEMIS)	160
16.1 Gas speed control	161
16.2 Diesel reduction control	161
16.2.1 Diesel reduction by diesel fuel quantity control	162
16.2.2 Diesel reduction by diesel power control	164
16.3 Determining the ignition oil quantity	164
16.4 Determining the power proportions.....	166
16.4.1 Applications for locomotive operation	166
16.4.2 Generator applications	167
16.4.3 Maritime applications	168
16.5 Configuring the gas output	170
16.5.1 Own actuator (DC 1-04)	170

16.5.2 Own actuator (XIOS).....	171
16.5.3 HZM-CAN periphery module: Actuator or solenoid valves	172
16.5.4 HZM-CAN add-on module: ELEKTRA Flow-Control.....	172
16.5.5 Analogue or PWM output of gas setpoint	173
16.6 Enabling and disabling dual fuel operation	173
16.6.1 Conditions for enabling dual fuel operating mode	174
16.6.2 Conditions for terminating dual fuel operating mode.....	178
16.7 Monitoring functions	183
16.7.1 Gas section test	183
16.7.2 Monitoring the power	185
16.7.3 Monitoring the exhaust temperature	186
16.7.4 Coolant temperature monitoring.....	189
16.7.5 Charge air temperature monitoring.....	190
16.7.6 Gas temperature monitoring	191
16.7.7 Oil pressure monitoring	192
16.7.8 Boost pressure monitoring	193
16.7.9 Gas rail pressure monitoring.....	194
16.7.10 External gas pressure monitoring	195
16.7.11 Speed monitoring	195
16.7.12 Ignition oil quantity monitoring.....	196
16.7.13 Gas quantity monitoring	198
16.7.14 Engine knocking monitoring	199
16.7.15 External gas alarm monitoring.....	201
16.7.16 Monitoring the gas output device	201
16.7.17 Compressed status indication.....	204
16.8 Gas speed control loop	206
16.8.1 Setting the PID parameters	208
16.8.2 Switching ramps from diesel to dual fuel operation	209
16.8.3 Switching ramp from gas to diesel operation	210
16.8.4 Diesel support in gas control operation	211
16.8.5 Integrated power governor.....	214
16.9 Diesel reduction control loop	215
16.9.1 Determining the diesel setpoint	216
16.9.2 Setting the PID parameters	217
16.9.3 Diesel setpoint ramp	218
16.10 Gas limitation	219
16.10.1 Gas speed governor.....	219
16.10.2 Diesel reduction governor (maritime application).....	222
16.10.3 Diesel reduction governor (generator and locomotive application)	223
16.10.4 Temperature dependent reduction	227
16.11 Gas fuel quantity correction	230

16.12 Residual gas combustion	231
16.12.1 Engine stop request	232
16.12.2 Gas speed governor	232
16.12.3 Diesel reduction governor	233
17 Configuration of sensors	234
17.1 Overview of all sensors	234
17.2 Configuration of sensors	237
17.3 Assigning the inputs to the sensors and setpoint adjusters	239
17.4 Measuring ranges of sensors	240
17.5 Configuration of power sensors	242
17.5.1 Load measurement	242
17.5.2 Value ranges	242
17.5.3 Configuration example with kilowatt entry	243
17.5.4 Configuration example with percent entry	244
17.6 Influence on reaction to sensor errors	244
18 Configuration of switching functions	248
18.1 Complete overview of all switching functions	248
18.1.1 Engine start request	251
18.1.2 Engine stop request	251
18.2 Assignment of hardware inputs	252
18.2.1 Assignment of binary inputs	252
18.2.2 Assignment of other inputs	254
18.3 Assignment of communication modules	257
18.4 Value of a switch function	258
19 Inputs and outputs	260
19.1 General	260
19.1.1 Selectable inputs and outputs	260
19.1.2 Pickup inputs	260
19.1.3 Analogue inputs	261
19.1.4 PWM inputs	261
19.1.5 Digital inputs	261
19.1.6 Analogue outputs	261
19.1.7 PWM outputs	261
19.1.8 Digital outputs	262
19.2 ARCHIMEDES (DC 5)	262
19.2.1 Selectable inputs/outputs	262
19.2.2 Analogue inputs	262
19.2.3 PWM input	263
19.2.4 Digital inputs	263
19.2.5 Analogue output	264

19.2.6 PWM outputs	264
19.2.7 Digital outputs.....	265
19.3 HELENOS (DC 2-01)	266
19.3.1 Selectable inputs/outputs	266
19.3.2 Analogue inputs	267
19.3.3 PWM inputs	268
19.3.4 Digital inputs.....	269
19.3.5 Analogue outputs	269
19.3.6 PWM outputs	270
19.3.7 Digital outputs.....	270
19.3.8 Fixed alarm outputs	271
19.4 ORION (DC 9)	272
19.4.1 Selectable inputs	272
19.4.2 Pickup 2 input	273
19.4.3 Analogue inputs	273
19.4.4 PWM input.....	273
19.4.5 Digital inputs.....	274
19.4.6 Digital outputs.....	274
19.5 PANDAROS (DC 6)	275
19.5.1 Selectable inputs/outputs	275
19.5.2 Pickup 2 input	276
19.5.3 Analogue inputs	276
19.5.4 PWM inputs	277
19.5.5 Digital inputs.....	277
19.5.6 Analogue outputs	277
19.5.7 PWM outputs	278
19.5.8 Digital outputs.....	278
19.6 PRIAMOS (DC 1-03).....	279
19.6.1 Selectable inputs/outputs	279
19.6.2 Analogue inputs	279
19.6.3 PWM inputs	280
19.6.4 Digital inputs.....	281
19.6.5 Analogue outputs	281
19.6.6 PWM outputs	282
19.6.7 Digital outputs.....	282
19.6.8 Fixed alarm outputs	282
19.7 PRIAMOS III (DC 1-04).....	284
19.7.1 Selectable inputs/outputs	284
19.7.2 Analogue inputs	284
19.7.3 PWM input.....	285
19.7.4 Digital inputs.....	286
19.7.5 Analogue outputs	286

19.7.6 PWM outputs	286
19.7.7 Digital outputs.....	287
19.7.8 Fixed alarm outputs	287
19.8 XIOS	288
19.8.1 Module types.....	289
19.8.2 A module versions	290
19.8.3 Maximum number of inputs and outputs	292
19.8.4 Minimum configuration for speed governors and positioners.....	293
19.8.5 Pin assignment	294
19.8.6 Port configuration	295
20 Configuring the control's inputs and outputs.....	306
20.1 Digital inputs	306
20.2 Analogue inputs.....	306
20.2.1 Calibration of current/voltage inputs	306
20.2.2 Calibration of temperature inputs	308
20.2.3 Filtering of analogue inputs	308
20.2.4 Error detection for analogue inputs	309
20.2.5 Overview of the parameters associated with analogue inputs	310
20.3 PWM inputs.....	311
20.3.1 Error detection at PWM inputs	312
20.4 XIOS.....	312
20.4.1 Current/voltage inputs.....	312
20.4.2 Temperature inputs	313
20.4.3 PWM input.....	313
20.4.4 Binary inputs.....	314
20.4.5 Frequency inputs.....	314
20.5 Analogue outputs.....	315
20.5.1 Assignment of output parameters to analogue outputs	315
20.5.2 Value range of output parameters	315
20.5.3 Value range of analogue outputs	317
20.6 PWM outputs.....	318
20.6.1 Assignment of PWM outputs.....	318
20.6.2 Value range of output parameters	318
20.6.3 Value range of PWM outputs	319
20.7 Dedicated alarm outputs	320
20.8 Digital outputs	320
20.8.1 Simple allocation	321
20.8.2 Multiple allocation.....	321
20.8.3 Logical operators	321
20.8.4 XIOS	323
20.8.5 Other control units	324

21 Technical data.....	326
21.1 ARCHIMEDES	326
21.1.1 General.....	326
21.1.2 Inputs and outputs	326
21.2 HELENOS	327
21.2.1 General.....	327
21.2.2 Inputs and outputs	327
21.3 PANDAROS.....	328
21.3.1 General.....	328
21.3.2 Inputs and outputs	329
21.4 ORION	330
21.4.1 General.....	330
21.4.2 Inputs and outputs	330
21.5 PRIAMOS	331
21.5.1 General.....	331
21.5.2 Inputs and outputs	332
21.6 PRIAMOS III	333
21.6.1 General.....	333
21.6.2 Inputs and outputs	334
21.7 XIOS.....	335
21.7.1 Terminal 15.....	335
21.7.2 Terminal RC	335
22 Integrated control elements.....	336
22.1 Push buttons in PANDAROS and ORION series	336
22.2 Rotary switches in PRIAMOS series.....	336
23 Bus Protocols	337
23.1 CAN protocol HZM-CAN.....	338
23.2 CAN protocol HZM-CAN customer module	339
23.3 CAN protocol SAE J1939	339
23.4 CAN protocol CANopen	340
23.5 CAN protocol DeviceNet	340
23.6 CAN protocol WAGO® (CANopen) and AXIOMATIC® (CANopen)	340
23.7 CAN protocol ICENI® (CANopen)	342
23.8 Serial protocol Modbus	344
23.9 Summary of bit values.....	344
23.9.1 BitCollection.....	344
23.9.2 Error status.....	344
23.10 CAN or Modbus networks.....	345
24 Actuator trigger with position feedback	347
24.1 Actuator control.....	347

24.2 Actuator feedback.....	350
24.3 Calibrating the actuator	352
24.3.1 Manual calibration	353
24.3.2 Automatic calibration	354
24.3.3 Automatic zero-position calibration at each engine stop.....	355
24.3.4 Saving the calibration data.....	356
24.3.5 Error detection during feedback	356
24.4 Limiting the actuator stroke.....	357
24.5 Servo loop.....	358
24.5.1 Actuator curve.....	358
24.5.2 Pump map	359
24.5.3 Servo control loop.....	359
24.5.4 Actuator current	361
24.6 Positioner mode	364
24.7 Actuators on HZM-CAN periphery modules	365
25 Current-controlled valves on hydraulic actuators	367
25.1 DC 6 and DC 8	367
25.1.1 Current setpoint.....	367
25.1.2 Monitoring	367
25.2 XIOS.....	368
25.2.1 Current setpoint.....	368
25.2.2 Monitoring	369
26 Data management.....	371
26.1 Serial number of control unit.....	371
26.2 Identification of control unit.....	371
26.3 Identification number of PC-programme / handheld programmer.....	371
27 Error Handling.....	373
27.1 General.....	373
27.2 Error types	373
27.3 Alarm display	373
27.3.1 Common alarm output	374
27.3.2 Error outputs of the control units DC 1 and DC 2.....	375
27.3.3 Seven-segment display of the DC 1 series.....	375
27.3.4 Error indication by LEDs.....	376
27.4 Error memory	379
27.4.1 Operating data memory and extended error memory	379
27.5 Bootloader	380
27.5.1 Bootloader start tests.....	380
27.5.2 Bootloader communication.....	382
27.5.3 Bootloader error	383

27.6 Configuration errors	383
27.7 Emergency shutdown errors	390
27.8 Error parameter list.....	391
27.8.1 XIOS	408
27.9 Watchdog processor CPU2 in PRIAMOS series.....	428
28 Parameter description.....	431
28.1 List 1: Parameters	434
28.1.1 DC 1	473
28.1.2 DC 5.....	474
28.1.3 DC 10.....	474
28.1.4 XIOS	475
28.1.5 Dual fuel	479
28.1.6 ICENI.....	487
28.1.7 WAGO	488
28.1.8 CANopen	490
28.1.9 Modbus	491
28.1.10 DeviceNet	492
28.1.11 SAE J1939	492
28.1.12 HZM-CAN customer module	493
28.2 : List 2: Measured values and display values	494
28.2.1 DC 1	542
28.2.2 DC 2.....	544
28.2.3 DC 5.....	545
28.2.4 DC 6.....	547
28.2.5 DC 7.....	548
28.2.6 DC 8.....	549
28.2.7 DC 9.....	552
28.2.8 DC 10.....	553
28.2.9 DC 11.....	555
28.2.10 DC 12.....	557
28.2.11 XIOS	558
28.2.12 CANopen	578
28.2.13 Modbus	579
28.2.14 DeviceNet	580
28.2.15 SAE J1939	581
28.3 List 3: Functions	583
28.3.1 DC 1	608
28.3.2 DC 2.....	609
28.3.3 DC 5.....	611
28.3.4 DC 6.....	612
28.3.5 DC 7.....	613

28.3.6 DC 8.....	615
28.3.7 DC 9.....	615
28.3.8 DC 10.....	616
28.3.9 DC 11.....	617
28.3.10 XIOS.....	619
28.3.11 Dual fuel.....	620
28.3.12 ICENI.....	623
28.3.13 WAGO.....	623
28.3.14 CANopen.....	623
28.3.15 Modbus.....	624
28.3.16 DeviceNet.....	624
28.3.17 SAE J1939.....	625
28.3.18 HZM-CAN customer module.....	627
28.4 List 4: Characteristics and maps.....	628
28.4.1 Dual fuel.....	640
28.4.2 CANopen.....	644
28.4.3 Modbus.....	645
28.4.4 DeviceNet.....	646
28.4.5 SAE J1939.....	646
28.4.6 HZM-CAN customer module.....	648
29 Illustrations.....	650
30 Tables.....	652
31 Download of manuals.....	660

1 Safety instructions and related symbols

This publication offers wherever necessary practical safety instructions to indicate inevitable residual risks when operating the engine. These residual risks imply dangers to

- Personnel
- Product and machine
- The environment

The primary aim of the safety instructions is to prevent personal injury!

The signal words used in this publication are specifically designed to direct your attention to possible damage extent!



DANGER indicates a hazardous situation the consequence of which could be fatal or severe injuries if it is not prevented.



WARNING indicates a hazardous situation which could lead to fatal injury or severe injuries if it is not prevented.



CAUTION indicates a hazardous situation which could lead to minor injuries if it is not prevented.



NOTICE indicates possible material damage.



Safety instructions are not only denoted by a signal word but also by hazard warning triangles. Hazard warning triangles can contain different symbols to illustrate the danger. However, the symbol used is no substitute for the actual text of the safety instructions. The text must therefore always be read in full!



This symbol does not refer to any safety instructions but offers important notes for better understanding the functions that are being discussed. They should by all means be observed and practiced.

1.1 Basic Safety Measures for Normal Operation

- The installation may be operated only by authorized persons who have been duly trained and who are fully acquainted with the operating instructions so that they are capable of working in accordance with them.
- Before turning the installation on please verify and make sure that
 - only authorized persons are present within the working range of the engine;
 - nobody will be in danger of suffering injuries by starting the engine.
- Before starting the engine always check the installation for visible damages and make sure it is not put into operation unless it is in perfect condition. On detecting any faults please inform your superior immediately!
- Before starting the engine remove any unnecessary material and/or objects from the working range of the installation/engine.
- Before starting the engine check and make sure that all safety devices are working properly!

1.2 Basic Safety Measures for Servicing and Maintenance

- Before performing any maintenance or repair work make sure the working area of the engine has been closed to unauthorized persons. Put on a sign warning that maintenance or repair work is being done.
- Before performing any maintenance or repair work switch off the master switch of the power supply and secure it by a padlock! The key must be kept by the person performing the maintenance and repair works.
- Before performing any maintenance and repair work make sure that all parts of engine to be touched have cooled down to ambient temperature and are dead!
- Refasten loose connections!
- Replace at once any damaged lines and/or cables!
- Keep the cabinet always closed. Access should be permitted only to authorized persons having a key or tools.
- Never use a water hose to clean cabinets or other casings of electric equipment!

1.3 Before Putting an Installation into Service after Maintenance and Repair

- Check on all slackened screw connections to have been tightened again!
- Make sure the control linkage has been reattached and all cables have been reconnected.
- Make sure all safety devices of the installation are in perfect order and are working properly!

2 General

2.1 General system description

HEINZMANN control units are universally applicable control units for diesel engines, gas engines and other prime movers. In addition to their basic purpose of controlling speed, these governors are capable of performing a multitude of other tasks and functions.

At the core of the control unit is a very fast and powerful microprocessor (CPU). The controller programme itself, the so-called firmware, on which the microprocessor operates is permanently stored in a so-called Flash-ROM. Application dependent configuration data are saved in an E²PROM.

In addition to the main processor, the HEINZMANN control units of the PRIAMOS/PRIAMOS III series are equipped with an auxiliary processor (CPU2) that performs two monitoring functions. On the one hand, the auxiliary processor will monitor engine speed for overspeeding and signals to the actuator independently of the main processor, on the other hand, it will supervise the operability of the main processor itself. Whenever the auxiliary processor registers an error, it triggers an emergency engine shutdown.

Actual engine speed is measured by a magnetic pickup on the starter gear.

At any system a redundant speed pickup can be installed additionally thus, there will be no interruption of operation if the first pickup should happen to fail. In vehicle applications, the control can use the alternator signal from terminal *W* as a default speed signal.

Engine speed is set by one or more setpoint adjusters. These adjusters can be designed to be analogue or digital ones. Additional digital inputs permit to switch functions on and off or to change over to other functions.

Various sensors are provided to transmit to the control the data it needs to adjust the engine's operating state. As an example, it is possible to have several temperature and pressure signals transmitted from the engine.

The actuator regulating fuel supply to the engine is driven by a PWM signal. By this, both 2-quadrant actuators (electrically working one way) and four-quadrant actuators (electrically working both ways) can be driven.

The control generates analogue and digital output signals which are used to indicate the engine's operating conditions or serve other purposes and functions. Communication with other units is established via a serial interface and, optionally, a CAN bus.

2.2 Firmware

The control unit's software is conceived both for universal applicability and a wide range of functions. This means that the firmware contains many more functions than those actually used for a specific application. Both the configuration of the input/output channels of the control unit and the activation and parameter setting of functions may be carried out by the customer.

Each control unit contains a boot loader (\uparrow **27.5 Bootloader**) for loading the firmware into the unit. HEINZMANN usually delivers the devices with a so-called HEINZMANN basic software that contains the standard delivery functions.

Starting from this basic software many diverse custom firmware variants are prepared.

The software version number $xx.y.zz$ or $xxxx.yy.zz$ in parameter 3842 *SoftwareVersion* consists of the following elements:

Customer number xx or $xxxx$
 Variant y or yy
 Modification index zz .

2.2.1 HEINZMANN basic software

In each device, the HEINZMANN basic software carries the customer number $x = 0$.

It is delivered in different basic variants $y = 0..99$.

The modification index $z = 0..99$ is a serial index increased by a unit with each software modification for each variant. Each higher index completely includes the preceding lower one and replaces it. At each moment in time there is only one valid version of a basic software variant, the one with the currently highest modification index.

At the moment, the following variants of HEINZMANN basic software are delivered. The variants in the first table are described in this manual, along with their functionality. The variants listed in the second table are explained in separate documents.

Software version	Variant	Control unit	Meaning
00.0.zz	0	HELENOS PRIAMOS	General variant, includes variants 1 to 4
		ARCHIMEDES ORION PANDAROS	General variant, includes variants 1, 3 and 4
00.1.zz	1	ARCHIMEDES HELENOS PRIAMOS	Vehicle application
		PANDAROS	Standard Generator
00.2.zz	2	HELENOS PRIAMOS	Locomotive application
		PANDAROS	Standard general
00.3.zz	3	ARCHIMEDES HELENOS PRIAMOS	Generator application
		PANDAROS	Extended Generator 1

00.4.zz	4	ARCHIMEDES HELENOS PRIAMOS	Marine application
		PANDAROS	Extended Generator 2
00.5.zz	5	HELENOS PRIAMOS	Marine application for multiple-engine systems via HZM-CAN with coupled pre-defined setpoint and direction
		PANDAROS	Extended general
00.6.zz	6	HELENOS PRIAMOS	Marine application for twin-engine systems via HZM-CAN with master/slave operation on a single shaft
		PANDAROS	Extended Generator 3 with connection to THESEUS via HZM-CAN
00.9.zz	9	HELENOS PRIAMOS	Generator application with connection to THESEUS via HZM-CAN

Table 1 Basic firmware variants

Software version	Variant	Control unit	Meaning
00.7.zz	7	HELENOS	Hydro turbine application
		PANDAROS	Vehicle dual-fuel application with connection of periphery module via HZM-CAN
00.8.zz	8	HELENOS	Steam turbine application
		PANDAROS	Generator dual-fuel application with connection of periphery module and THESEUS via HZM-CAN
00.10.zz	10	HELENOS	Gas engine generator application within system KRONOS 30 with connection of THESEUS and ELEKTRA via HZM-CAN

00.11.zz	11	HELENOS PRIAMOS	Vehicle dual-fuel application with connection of periphery module via HZM-CAN
00.12.zz	12	HELENOS PRIAMOS	Locomotive dual-fuel application with connection of periphery module via HZM-CAN
00.13.zz	13	HELENOS PRIAMOS	Generator dual-fuel application with connection of periphery module and THESEUS via HZM-CAN
00.14.zz	14	HELENOS	Gas addition in CR engine with measurement of injection time

Table 2 Special firmware variants

2.2.2 Custom firmware

Custom firmware always has a definite customer number $x > 0$. Once assigned, the customer number remains assigned to the customer and is used for every custom software he orders, independently from the control device used.

Different software variants $y = 0..99$ are programmed on the customer's request, e.g., for different engine types or different applications with one and the same control device.

The modification index $z = 0..99$ is a serial index increased by a unit with each software modification for each variant. Each higher index completely includes the preceding lower one and replaces it. At each moment in time there is only one valid version of a custom software variant, the one with the currently highest modification index.

HEINZMANN communication modules such as the PC programme $\hat{\uparrow}$ 3.3 *DcDesk 2000* or the handheld programmer HP03 allow the customer to access the general HEINZMANN basic software 00.y.zz and their own custom software. This means that many customers have access to the so-called 0-software but only one customer (and, eventually, others he may have authorized) has access to his own custom software. If an application, therefore, is to be protected against access by other HEINZMANN customers, a custom firmware must be ordered from HEINZMANN.

2.3 Further information

This manual contains a brief presentation of the different adjustment parameters and characteristics. Error handling will be discussed in detail.

The functionality of speed governing in general, the specifications and connections of the control electronics, sensors, setpoint adjusters and actuators are described in detail in the manuals:

HELENOS

Title	Order number
Digital Basic System HELENOS I	DG 95 102-e
Digital Basic System HELENOS II	DG 95 100-e
Digital Basic System HELENOS III	DG 96 005-e
Digital Basic System HELENOS IV	DG 96 003-e
Digital Basic System HELENOS V	DG 97 014-e

Table 3 HELENOS basic Systems

ORION

Title	Order number
ORION low-cost speed governor KG-LC-D/DC 9	DG 06 005-e

Table 4 ORION basic systems

PANDAROS

Title	Order number
PANDAROS for generator applications	DG 02 007-e
Digital Basic System PANDAROS I	DG 00 006-e
Digital Basic System PANDAROS II	DG 01 002-e
Digital Basic System PANDAROS IV	DG 01 003-e
Digital Basic System PANDAROS V	DG 01 004-e
Digital Basic System PANDAROS VI	DG 03 006-e

Table 5 PANDAROS basic systems

PRIAMOS

Title	Order number
Digital Basic System PRIAMOS I	DG 93 101-e
Digital Basic System PRIAMOS II	DG 94 111-e
Digital Basic System PRIAMOS III	DG 95 111-e
Digital Basic System PRIAMOS IV	DG 96 004-e
Digital Basic System PRIAMOS V	DG 97 013-e
Digital Basic System PRIAMOS VI	DG 06 009-e

Table 6 PRIAMOS basic systems

Dual-fuel systems

Title	Order number
ARTEMIS II digital control units for small to medium dual-fuel engines	DG 03 005-e
ARTEMIS III dual-fuel system with mechanical diesel governor and digital gas governor	DG 04 001-e
ARTEMIS VI dual-fuel addition module for vehicles with electronic diesel injection system	DG 06 008-e

Table 7 Dual-fuel basic systems

HEINZMANN control units are shipped tailored to custom requirements and have been configured as far as possible at the factory. To properly execute an order therefore it is absolutely necessary that the customer completes and returns to **HEINZMANN** the following form.

Title	Order number
Ordering Information for Digital Controls	DG 96 012-e

Table 8 Ordering information for digital controls

The sensors available from **HEINZMANN** are described in the manual

Title	Order number
Product Overview Sensors	E 99 001-e

Table 9 Product overview sensors

The functionality of the communication programme DcDesk 2000 both as on-site and as remote control communication variant is described in the following manuals and in the online help of the programme.

Title	Order number
Operating Instructions Communication Programme DcDesk 2000	DG 00 003-e
Basic Information Remote Communication Programme DcDesk 2000/Saturn	DG 05 008-e
Basic Information Remote Communication Programme SATURN	DG 05 006-e

Table 10 Communication programmes

2.4 Functional block diagram

The functional block diagram provides a simplified view of the control structure of **HEINZMANN** control units, showing their basic functions as well as the signal flow of various important functions.




Fig. 1 Functional block diagram

2.5 Conventions

Throughout this manual the following typographic conventions have been adopted:

<i>100 Gain</i>	Parameter names (identifiers) are always italicized. No difference is made between the four \uparrow 2.6 <i>Parameter lists</i> .
\uparrow <i>100 Gain</i>	An arrow preceding a parameter name is to signal that this parameter is explained in detail in some other section. For a brief description see chapter \uparrow 28 <i>Parameter description</i> . In this chapter you will also find references to the pages containing a detailed discussion of the respective parameter.
<100>	In diagrams, numbers enclosed by pointed brackets are used to indicate that the position thus specified corresponds to a parameter number.
[500..501]	There are certain parameters for which the limits of their respective value ranges cannot be specified explicitly in chapter \uparrow 28 <i>Parameter description</i> but have to be communicated to the control as values of specific parameters. For any such parameters with variable value ranges, the parameter numbers defining their specific range limits are enclosed in square brackets.
\uparrow	An arrow followed by italicized text refers to a chapter where the respective function is described in more detail.

2.6 Parameter lists

For each function of the firmware a certain number of parameters must be adjusted. A system was needed to conveniently organize the great number of parameters that would inevitably result from the numerous functions to be implemented. For the sake of clarity and easy access, the parameters have therefore been grouped into four lists.

1. Parameter Parameters used for adjusting the control and the engine
(parameter numbers 1..1999, 10000..11999, 20000..21999)
2. Measurements
Parameters for indicating the actual states of the control and the engine (parameter numbers 2000..3999, 12000..13999, 22000..23999)
3. Functions Parameters used for activating and switching over functions
(parameter numbers 4000..5999, 14000..15999, 24000..25999)
4. Curves Parameters used for parameterization of characteristic curves and maps
(parameter numbers 6000..9999, 16000..19999, 26000..29999)

Each parameter has been assigned a number and an abbreviation (identifier). The parameter number also indicates which list the parameter belongs to. Within these lists, the parameters are arranged by groups to facilitate identification and reference for more detailed information.

No. Parameter		No. Measurements		No. Functions		No. Curves	
1	No. of teeth, speed	2000	Speed pickup, speed	4000	Speed pickup, speed	6000	Misfire recognition
50	Misfire recognition	2050	Misfire recognition	4050	Misfire recognition		
100	Stability, droop	2100	Stability, droop	4100	Stability, droop	6100	Stability map, speed governor (speed values)
						6150	Stability map, speed governor (fuel values)
200	Ramp	2200		4200	Ramp	6200	Stability map, speed governor (correction values)
250	Start	2250		4250		6250	
300	Actuator travel	2300	Actuator travel	4300		6300	Stability curve, power governor
						6350	Stability map, speed governor (power values)
400	HZM-CAN	2400	HZM-CAN	4400	HZM-CAN	6400	Boost pressure dependent fuel and load limitation
500	Oil pressure, boost pressure, temperatures	2500		4500	Oil pressure, boost pressure, temperatures	6500	Oil pressure and coolant pressure monitoring
600	Excitation control	2600	Excitation control	4600	Excitation control	6600	Excitation control
700	Limitations	2700	Limitations	4700	Limitations	6700	Speed-dependent fuel limitation 1
800	Digital switch functions	2800	Digital switch functions	4800	Configuration of digital input/output channels	6800	Speed-dependent fuel limitation 2
850	Digital outputs (simple assignment)	2850	Digital outputs	4850	Digital outputs (multiple assignment)	6850	
900	Setpoint adjuster and sensors	2900	Setpoint adjuster and sensors	4900	Setpoint adjuster and sensors	6900	Notches, speed dependent load limitation
1000	Error handling	3000	Current errors part I	5000	Setpoint adjusters and sensors	7000	
1100		3100	Error memory part I	5100	Error handling	7100	
1200	Generator	3200	Generator	5200	Generator	7200	Zero fuel characteristic or pump map
1250	Marine	3250	Marine	5250	Marine		
1300		3300	KRONOS 30 M	5300		7300	Actuators map
1350	Locomotive	3350	Locomotive	5350	Locomotive		
1500	Analogue inputs	3500	PWM inputs analogue inputs	5500	Configuration analogue input/output channels	7500	
1600	PWM outputs analogue outputs	3600	Internal measurement values, feedback digital outputs	5600	Analogue outputs	7600	
1700	Positioner	3700		5700	Positioner	7700	
1800	Status	3800	Status	5800		7800	Temperature sensors

No. Parameter		No. Measurements		No. Functions		No. Curves	
1900	Servo loop	3900	Servo loop	5900	Servo loop	7900	Temperature sensors
1950	Feedback	3950	Feedback	5950	Feedback	7980	Feedback
						8100	Speed map
						8800	Digital outputs (multiple assignment)
						9000	HZM-CAN
						9900	Stability map 2 (correction values)
1000	Dual fuel	12000	Dual fuel	14000	Dual fuel	16000	Dual fuel
		13000	Current errors part II				
		13100	Error memory part II				
2080	Communications switching functions			24800	Communications switching functions		
		23000	Current errors part III				
		23100	Error memory part III				
		23700	Bit collections				
2175	CANopen	23750	CANopen	25750	CANopen		
2180	Modbus	23800	Modbus	25800	Modbus		
2185	DeviceNet	23850	DeviceNet	25850	DeviceNet		
2190	SAE J1939	23900	SAE J1939	25900	SAE J1939		
2195	HZM-CAN customer module			25950	HZM-CAN customer module		
						29000	CANopen
						29200	Modbus
						29400	DeviceNet
						29600	SAE J1939
						29800	HZM-CAN customer module
						29900	Bit collections

The present manual contains explanations of all functions performable by the basic systems ARCHIMEDES, HELENOS, ORION, PANDAROS, PRIAMOS and PRIAMOS III. For specific applications, however, part of these functions will be of no relevance and may be ignored. In such cases, the parameters associated with these functions will also be omitted. The varying hardware requirements of specific devices mean that some functions could not be integrated due to the number or required inputs and outputs. Some of the described functions are implemented in the firmware only on request. All such exceptions are indicated in the text.

Furthermore, customer specific applications may contain new or extended functions which will be documented in separate brochures.

2.7 Level

As it is the control unit's primary function to control the operational behaviour of the engine with regard to speed, power, etc., parameterization should remain entrusted exclusively to the engine manufacturer. However, to let the end customer participate in the advantages of the digital control, the parameters of the HEINZMANN digital control have been classified according to seven levels.

- **Level 1: Level for the end customer**
On this level, it is possible to have the basic operational values (e.g., set values and current values of speed and injection quantity) and errors displayed. This level does not allow any manipulations of the control data or the engine data.
- **Level 2: Level for the device manufacturer**
The device manufacturer can set speeds within the permissible ranges. Besides, the control's dynamic parameters and the dynamics map may be modified and power output reduced.
- **Level 3: Level for servicing**
Except for the most significant engine specific parameters, such as engine output and boundaries of various characteristic diagrams, all types of modifications are permitted on this level.
- **Level 4: Level for the engine manufacturer**
On this level, all parameters are accessible that are needed to adjust the engine's operational performance.
- **Level 5: Level for manufacturers of engines with specific software**
This level includes parameters that are required for customer specific software modifications or expansions.
- **Level 6: Level for the control unit manufacturer**
On this level, the control functions may be manipulated directly. Therefore, access remains reserved to HEINZMANN.
- **Level 7: Level for development department**
This level remains reserved to the HEINZMANN development department.

As can be seen from this survey any superior level is a proper superset of the previous level. For each individual parameter the respective level is listed in the section \uparrow 28 *Parameter description*. The maximum level is determined by the diagnostics device used (PC or handheld programmer) and cannot be changed. However, the option of reducing the currently valid level by means of a special menu item of the PC-programme or via parameter \uparrow 1800 *Level* is provided, thus allowing to reduce the number of visible parameters and functions at any given time.

3 Parameterization of HEINZMANN control units

The following chapters describe the functions of the **HEINZMANN** control units and their adjustment. Certain functions will work only in combination with others or can be affected by other functions (e.g. *↑ 5.2 Variable starting fuel limitation* with *↑ 5.4 Starting sequence with starting speed ramp*). When parameterizing or optimizing any such function, it will frequently be advisable to disable other functions so that the effect of the specific function can be examined in isolated state. How these functions are to be adjusted will be described in the respective chapters.

3.1 Possibilities of parameterization

There are various ways to set the parameters for **HEINZMANN** control units. For testing and initial commissioning **HEINZMANN** recommend to use the PC software *↑ 3.3 DcDesk 2000* as a tool for diagnostics and parameterization. DcDesk 2000 can also be used for servicing purposes where, in addition, the handheld programmers PG 02 and HP 03 are available. The remote connection option DcDesk 2000/Saturn is another important aid for servicing.

The following list gives an overview of all available options of parameterization:

- **Parameterization by HEINZMANN**
During final inspection at the factory, the functionality of the control is checked by means of a test programme. If customer specific operational data is available, the test programme is executed using those data. When mounted on the engine, only the dynamic values and, if necessary, the fuel quantity limitations and the sensors remain to be calibrated.
- **Parameterization with a handheld programmer.**
Depending on the level, parameterization can be completely conducted using the handheld programmers PG 02 or HP 03. These handy devices are particularly suited for maintenance and servicing.
- **Parameterization with display panel ARGOS.**
The display and control panel ARGOS allows to carry out the complete setting of parameters for the accessible levels.
- **Parameterization using DcDesk 2000 or DcDesk 2000/Saturn, respectively**
Using the PC programme DcDesk 2000, it is possible to have several parameters continuously displayed and accessible to modification. Besides, the PC-programme is capable of displaying limitation curves, characteristics, etc. in graph form, and of adjusting them easily and quickly. The control data can be stored by the PC or downloaded from the PC to the control. A further advantage of the PC programme is its ability to visualize in high-resolution measured values (such as speed, injection quantity) as functions of time or as functions of each other (e.g., fuel versus speed).
- **Parameterization with user mask**
Parameterization can always be conducted by means of user masks that are provided

by **HEINZMANN** or can easily be created by the user himself. A user mask will display only the parameters that are really needed for the specific application.

- **Downloading data sets**

Once parameterization has been completed for a specific engine type and its application, the data set can be stored within the handheld programmer or on a disk. For future applications of the same type, any such data sets can be downloaded to the new controls.

- **End-of-line parameterization**

This type of parameterization is performed by the engine manufacturer during the final bench tests of the engine. During these tests, the control unit is adjusted to the requirements of the engine's applicative context. With a command line call from DcDesk 2000 both the control unit's firmware and a delivery data record may be programmed without operator intervention during check-out.

3.2 Saving data

On principle, the above mentioned communication programmes and -devices will modify parameters only in the volatile memory of the control unit. Although the control unit will immediately operate using the new values these modifications will get lost as soon as the voltage supply is switched off. In order to permanently save the parameter adjustments in the control unit a storing command must be given. To execute this command, DcDesk 2000 uses the function key F6, whereas the handheld programmers use the key or menu item "Save Parameters", and it is this operation that is meant whenever it is required in this manual that the parameters be saved.

3.3 DcDesk 2000

The **HEINZMANN** PC programme DcDesk 2000 serves for adjustment and transmission of operating data for all digital **HEINZMANN** systems, and, in particular, for the systems described in this manual.

The connection between PC and control unit can be established using a serial interface or the CAN bus with the HEINZMANN-CAN protocol. The remote communication variant allows access via internet, intranet or a direct modem connection.

Designed as a Windows® programme, it offers all numerical and graphical features required for testing, initial commissioning and servicing, and helps with preparing the respective documentations.

DcDesk 2000 also allows to produce hardcopy printouts of its screens and of its data records. The data are recorded in a standard text format for further processing and for incorporation into reports, etc.

The data set of any connected control unit can be processed, and, at the same time, the responses to parameter changes can be observed. Even without a control unit connected, it will be possible to process a parameter set and evaluate the recorded data. Any parameter set generated that way can later on be downloaded to the control unit.

Any adjustment can be made by directly accessing the respective parameter numbers. Special windows simplify the adjustment of specific functions, in particular the configuration of the system and the parameter setting of characteristics and maps.

Actual measurement data is displayed numerically and/or graphically. In a separate window, up to ten freely selectable measuring values can be displayed simultaneously as functions of time. There is a further window that permits to have nine measurements represented in dependence of a tenth. All of these records can be logged to be evaluated later on and eventually printed out.

Any of the characteristics and maps available within the control unit can be displayed two- or three-dimensionally in separate windows. By this, the profile and shape of any specific characteristic or map can immediately be viewed. The actual point within the characteristic or map at which the system is currently operating will be displayed online. To make an adjustment it is not necessary to know the precise interrelation between the parameter numbers and the points of the characteristic or map since a special input section has been provided offering assistance with regard to the peculiarities of parameterizing characteristics and maps. This feature will prove very helpful to avoid erroneous inputs.

DcDesk 2000 is being continuously updated and enhanced by additional functions.

HEINZMANN recommend the use of DcDesk 2000 for testing and initial commissioning. Similarly, when servicing the system, DcDesk 2000 will prove a decisive advantage for diagnosis and troubleshooting.

3.4 ARGOS

The display and control panel ARGOS features a menu command structure and can be used either for continuous display of measuring values or for parameter setting.

The measuring values shown on the display are entered stably in the control unit and cannot be changed.

In addition, the device is equipped with light emitting diodes that can be assigned configuring the control unit with ARGOS itself or with DcDesk 2000.

The positioning of the LED's is as follows. LED 1 is orange, LED 5 is red, all other LED's are green.




Fig. 2: ARGOS front cover

The field index of parameters starting from 29950 *ArgosLEDParamSet(0)* corresponds to the LED number. In these eight parameters the parameter of any measurement value with range 0/1 can be entered, resulting in the according value to be displayed.

The LED's can be marked by inserting small strips of paper under the transparent covering.

3.5 Parameter value ranges

Each parameter is assigned a specific range of values. Since there is a multitude of parameters and functions, there also exists a great number of value ranges. In chapter [↑]28 *Parameter description* the value ranges are listed for each individual parameter. Besides, the parameter value ranges can be viewed by means of the PC or the handheld programmer ([↑]3.1 *Possibilities of parameterization*).

For speed parameters a common value range is provided. As a standard, it covers the range from 0 to 4,000 rpm and allows to run engines up to maximum speeds of approx. 3,500-3,600 rpm (There must be some reserve for [↑]6.4 *Overspeed monitoring*).

Throughout this manual the standard value ranges are 0..4000 rpm for speed parameter and 0..100 % fuel for actuator position. Note that selection of any other value range will imply changes of the range limits. These changes are explained in the chapter [↑]28.3 *List 3: Functions* and should be carefully taken account of.

For certain parameters the value ranges cannot be explicitly specified in advance, but must be communicated to the control by the user. This applies to all parameters indicating physical measurements such as readings from pressure or temperature sensors.

Some parameters have a value range that is capable of two states only, viz. 0 or 1. This type of parameter is used to activate or switch over particular functions or to indicate error

conditions or states of external switches, etc. Parameters with this value range are confined to the lists 2 and 3.

With these parameters, state "1" signifies that the respective function is active or that the respective error has occurred, whereas state "0" signals the function to be inactive resp. that there is no error.

The identifiers of change-over switches or of parameters selecting between two functions always include an "Or" (e.g.: 2812 *SwitchDroop2Or1*). The function preceding "Or" will be active when the parameter value is = 1 whilst the function after "Or" will be active when the parameter value is = 0.

3.6 Activation of functions

As regards activation of functions, the following alternatives are provided:

- **permanently active**
These functions cannot be turned off (e.g., [↑] **6.4 Overspeed monitoring**).
- **Parameter**
Parameters contained in list 3 ([↑]28.3 *List 3: Functions*) enable functions that will remain permanently active when selected by the user (e.g., [↑]9.1 *Speed dependent fuel limitation*).
- **Switch functions**
By means of external switches ([↑]18 *Configuration of switching functions*) the control can be instructed to adopt certain requested operational states that are subject to frequent changes during operation (e.g., switch-over [↑]7.8 *Droop*). The states of the switching functions can be read from the parameters numbering from 2810 on upward.



Note

The control units are equipped with several inputs that can be configured at the user's option. The number of functions that can be activated by external switches is, however, considerably larger than the number of inputs. Therefore, depending on the device version and on customer demands, the digital inputs can be assigned to different functions. In the following chapters, it is presumed that with regard to any function that is to be activated or switched over by external switches, the respective switch has been accordingly implemented and/or activated via a communication module.

3.7 Parameterization of characteristics

Parameterization of characteristic curves follows a specific procedure that remains the same for all characteristics. The number of pairs of variates, however, will be different for each function. A pair of variates consists of one x-value and one y-value both with the same index. Intermediary values between adjacent pairs of variates will be interpolated by the control.

When parameterizing a characteristic, the following instructions must be observed:

- The characteristics must always begin with the pair of values indexed 0.
- The x-values must be sorted in ascending order.
- Each x-value may occur only once.
- For unused pairs at the end of the characteristic, the x-variate must be set to the smallest possible value.

Parameterization of any characteristic does not require all pairs of variates to be assigned a value. It will suffice to assign values only to as many parameters (beginning with index 0) as will be needed. Similarly, it will not be necessary that the distances between the base points be the same.

When the current x-value of any characteristic is below the first supporting point, the value of the characteristic will be set to the y-value of the first supporting point (base point), and when it is beyond the last supporting point, the y-value of this supporting point will be used. In other words, the first and last of the y-values will be retained in case the current x-value is outside the characteristic's domain. DcDesk 2000's graphic display shows this.

3.8 Parameterization of maps

Parameterization of maps will always follow the same procedure. The number of base points, however, will be different for different functions. A supporting point consists of one x-value and one y-value and the associated z-value. Intermediary values between adjacent pairs of variates will be interpolated by the control.

When parameterizing a map, the following instructions must be observed:

- The x- and y-values must always begin with index 0.
- The x- and y-values must be arranged by ascending order.
- Each x- and y-value may occur only once.
- For unused base points at the end of the map, the x- and y-variates must each be assigned their respective smallest possible values.

Parameterization of any map does not require all pairs of variates to be assigned a value. It will suffice to assign values only to as many parameters (beginning with index 0 for the x- and y-values) as will be needed. Similarly, it will not be necessary that the distances between the base points be the same.

As an illustration of how parameter indexes are assigned to a map, the following example shows a map table with a domain of 5 times 5 base points:

y-values	x-values				
	x index 0	x index 1	x index 2	x index 3	x index 4
y index 0	z index 0	z index 1	z index 2	z index 3	z index 4
y index 1	z index 5	z index 6	z index 7	z index 8	z index 9
y index 2	z index 10	z index 11	z index 12	z index 13	z index 14
y index 3	z index 15	z index 16	z index 17	z index 18	z index 19
y index 4	z index 20	z index 21	z index 22	z index 23	z index 24

Table 11: Map structure

If the current values in direction of the x- and/or y-axes are outside the domain of the map as defined by the base points, the respective border value of the map will be used instead. DcDesk 2000's graphic display shows this.

If it should prove necessary to restrict dependence to only one direction this can be achieved by setting the base points for the other direction to their minimum value. In other words, if there is functional dependence only in direction of the y-axis, all x index values are to be set to minimum value. The base points for z will then be those of the series with x-index 0.

HEINZMANN recommend to use $\hat{\uparrow}$ 3.3 *DcDesk 2000* for parameterizing maps and characteristics as this programme will take care of all particulars to be paid attention to and will simplify parameterization considerably. Thus, the above table is included in DcDesk 2000 in identical form and offers easy access to any of the base points. Furthermore, the characteristics and maps can be represented graphically by this tool.

3.9 Examples of parameterization

For the majority of functions, an example has been provided of how parameterization is to be conducted. These examples will include all the parameters needed for the function being discussed. The values, however, will be different ones for different engines and applications and must be understood to be adduced merely as examples. When adjusting any function, it will, therefore, be necessary to use reasonable values suiting the engine and the application.

3.10 Reset of control unit

A reset is tantamount to powering down the control and restarting it. This can be achieved by shortly turning off the power supply or else by a specific command from DcDesk 2000 or from the handheld programmer HP 03. Control units of the types PRIAMOS and HELENOS are equipped with an additional reset button located close to the rotary switch or the 48-pin connector on the printed circuit board, respectively.

**Note**

A reset will clear any data that has not been saved in the control's permanent memory. It is, therefore, imperative that before executing a reset all data be transferred to the control's permanent memory if this data is to be preserved.

Certain functions of the control unit require a reset for activation. These are mostly functions that serve the purpose to put the control into some other operating state, or parameters that cannot be modified during operation for safety reasons. The parameters and functions belonging to this category will be explained in detail in the respective chapters.

**Warning**

Since during each reset the control is de-energized for a short time, a reset may be executed only when the engine is not running!

4 Starting the engine

On first commissioning the control on the engine, the following instructions should be strictly followed. This is the only way to ensure that the engine can be started without any problems.

These instructions, however, can give only some brief information on how to commission the control. For more detailed information, please refer to the respective chapters or manuals.

The instructions cover all parameters that must be adjusted to start the engine. It should be noted, however, that the parameter values used in these instructions are adduced only by way of example. For actual operation they must be replaced by appropriate values suiting the engine and the specific application.

- **Adjust distance of speed pickup**

The distance between the pickup and the top of the teeth should be approx. 0.5 to 0.8 mm. For more detailed information see the manuals for the basic systems (*↑ 2.3 Further information*).

- **Check linkage.**

The linkage must operate smoothly and easily, and it must be capable of moving to the stop and maximum fuel positions.

- **Check cabling**

On actuating any switch, the respective indication parameter should reflect the change. If several switches are provided this check must be conducted for all of them.

↑18 Configuration of switching functions.

On first commissioning the engine, it is only the setpoint adjusters that are needed since the functions operating by signals from the analogue inputs (such as boost pressure dependent fuel limitation, speed dependent oil pressure monitoring, etc.) must not yet be activated. Nevertheless, all analogue inputs should be checked.

↑17 Configuration of sensors and ↑20.2 Analogue inputs

Example:

Let us assume the setpoint adjuster 1 is connected to analogue input 1. When altering the set value, the parameter 3511 *AnalogIn1_Value* is expected to change accordingly. If there is no change, the cabling of the setpoint adjuster must be at fault. Together with 3511 *AnalogIn1_Value*, the parameter 3510 *AnalogIn1* and the specific setpoint adjuster parameter 2900 *Setpoint1Extern* are also bound to change from 0 to 100 % when the setpoint adjuster is turned from minimum into maximum position. If this is not the case, the input needs to be normalized (*↑20.2.1 Calibration of current/voltage inputs*).

- **Adjust and check the actuator**

Calibration of the actuator can be performed with the aid of the PC program or the handheld programmer. For control units of the type PANDAROS or ORION auto adjustment can also be started by pressing a push-button on the printed circuit board, for control units of the type PRIAMOS by putting the rotary switch in position 1 before the restart of the control unit.

Automatic calibration of the actuator is to be carried out with the linkage removed from the governor and the injection pump or the gas mixer, respectively, to make sure that the actuator is capable of travelling to its minimum and maximum positions.

Checking the actuator can be enabled by setting the parameter 5700 *PositionerOn* = 1. By this procedure, the actuator position can be preset directly by 1700 *PositionerSetpoint* and then checked by having the actual actuator position indicated by parameter 2300 *ActPos*. Again, the actuator should be able to move across its total displacement range from 0 % to 100 %. To perform this check, the actuator is activated by setting 5910 *ActuatorOn* = 1. This check cannot be performed if a speed signal is coming in, i.e. positioning is not possible unless the engine is at a standstill.

<u>Number</u>	<u>Parameter</u>	<u>Value</u>	<u>Unit</u>
1700	<i>PositionerSetpoint</i>	50	%

Activation:

5910	<i>ActuatorOn</i>	1	
5700	<i>PositionerOn</i>	1	

Indication:

2300	<i>ActPos</i>	50	%
------	---------------	----	---

- **Parameterizing the most significant parameters.**

Begin by parameterizing number of teeth, minimum and maximum speeds, and overspeed (\uparrow 7 *Speed setpoint determination*):

<u>Number</u>	<u>Parameter</u>	<u>Value</u>	<u>Unit</u>
1	<i>TeethPickup1</i>	160	
10	<i>SpeedMin1</i>	700	rpm
12	<i>SpeedMax1</i>	2100	rpm
21	<i>SpeedOver</i>	2500	rpm

Preset the PID values (\uparrow 8.1 *Adjustment of PID parameters*):

<u>Number</u>	<u>Parameter</u>	<u>Value</u>	<u>Unit</u>
100	<i>Gain</i>	15	%
101	<i>Stability</i>	10	%
102	<i>Derivative</i>	0	%

Parameterize the absolute limits of actuator travel

Number	Parameter	Value	Unit
310	<i>ActPosSecureMin</i>	3	%
312	<i>ActPosSecureMax</i>	97	%

Adjust starting fuel (type 1 [↑] 5.1 *Fixed starting fuel limitation*):

Number	Parameter	Value	Unit
250	<i>StartType</i>	1	
251	<i>LimitsDelay</i>	3	s
255	<i>StartSpeed1</i>	10	rpm
256	<i>StartSpeed2</i>	400	rpm
260	<i>StartFuel1</i>	60	%

Save the values to the control device [↑] 3.2 *Saving data* and restart with a [↑] 3.10 *Reset of control unit*.

- **Check speed pickup and determine starter speed**

Operate the engine stop switch so that the engine cannot be started.

Indication:

Number	Parameter	Value	Unit
2810	<i>SwitchEngineStop</i>	1	

NOTICE

Before starting the engine ensure separate overspeed protection independent of the rpm controller!

Operate starter and check the measured speed as indicated by 2000 *Speed*. At this point, the parameter should indicate cranking speed.

Check starter speed, i.e. the minimum speed at which the governor recognizes that the engine has started (256 *StartSpeed2*). This speed must be above cranking speed.

- **Start the engine and adjust control circuit stability**

Disable engine stop switch.

Indication:

Number	Parameter	Value	Unit
2810	<i>SwitchEngineStop</i>	0	

Start the engine and run it up to rated speed using the setpoint adjuster.

Optimize the PID-values ([↑] 8.1 *Adjustment of PID parameters*).

- Increase gain (P-factor) 100 *Gain* until the engine becomes unstable, then reduce it until stability is restored.
- Increase stability (I-factor) 101 *Stability* until the engine becomes unstable, then reduce it until stability is restored.
- Increase derivative (D-factor) 102 *Derivative* until the engine becomes unstable, then reduce it until stability is restored.

With this adjustment, disturb engine speed shortly and observe the transient response.

- **Perform this checking procedure across the entire speed range.**

If for minimum and maximum speeds this checking procedure results in values differing from the programmed ones, the setpoint adjuster needs to be calibrated (↑ **20.2.1 Calibration of current/voltage inputs**). The parameter 2031 *SpeedSetp* will indicate whether the value has been set correctly.

- **Correction of PID parameters**

Adjustment of speed and/or fuel dependent correction of PID parameters over the whole speed range (↑ **8 Optimizing control circuit stability**).

- **Adjusting the remaining functions**

Adjustment of functions such as ↑ **7.7 Speed ramp** and ↑ **9.1 Speed dependent fuel limitation** etc.

- **Save the data thus determined by storing them in the control**

↑ **3.2 Saving data**, ↑ **3.10 Reset of control unit**

5 Starting fuel limitation

To start properly, naturally aspirated diesel engines and engines with low pressure charging need to be fed an excess quantity of fuel; in other words, for start-up a larger amount of fuel must be injected than for full load.

Diesel engines fitted with more powerful turbochargers will operate during start-up by a reduced starting injection quantity to prevent smoke bursts.

The **HEINZMANN** control units comply with these stipulations by de-activating the control's limiting functions during start-up. This allows to freely programme the adjustment of starting fuel quantity. For this purpose, three options are available that can be selected by the parameter 250 *StartType* as follows:

250 <i>StartType</i> = 1:	fixed starting fuel
250 <i>StartType</i> = 2:	variable starting fuel
250 <i>StartType</i> = 3:	temperature dependent starting fuel limitation (not for ORION)

The single phases of engine start and of the speed governor are indicated in parameter 3830 *Phase* and, in the PRIAMOS system, also in the seven-segment display ([↑ 27.3.3 Seven-segment display of the DC 1 series](#)).

- 0: Waiting for engine start
- 1: Starting phase 1
- 2: Starting phase 2
- 3: Starting phase 3
- 4: Speed control enabled, limiting functions disabled
- 5: Speed control enabled, limiting functions enabled
- 6: Speed control enabled, lower limit enabled
- 7: Speed control enabled, upper limit enabled
- 8: Autoadjustment
- 9: Positioner

In the control units of the type ARCHIMEDES, PANDAROS and ORION each engine start is counted in 2250 *EngineStartCounter*. Operating hours of the running engine are recorded in 3871 *OperatingHourMeter* and 3872 *OperatingSecondMeter*. By request, the control unit HELENOS can be equipped with an external memory for operative data and errors, too.

The current engine states are indicated by the following parameters:

3802 <i>EngineStopRequest</i>	A request for stopping the engine is being applied, the running engine stops, engine start is not possible
3803 <i>EngineStopped</i>	Engine stopped
3804 <i>EngineStarting</i>	Engine is being started
3805 <i>EngineRunning</i>	Engine is running
3806 <i>EngineReleased</i>	Injection enabled

Injection is released only if there is no engine stop request and no fatal error.

5.1 Fixed starting fuel limitation

On reaching the speed set by 255 *StartSpeed1* the control recognizes that the engine is being cranked, and releases the starting quantity as set in 260 *StartFuel1*. At this point, the speed setpoint is set from 0 rpm to minimum speed 10 *SpeedMin1*.

On reaching speed as set by 256 *StartSpeed2*, the control recognizes that the engine is running. At this point, there is a change-over to the externally applied speed setpoint 2031 *SpeedSetp*. Starting fuel limitation 260 *StartFuel1*, however, is sustained for the duration set by 251 *LimitsDelay*. After that, the control passes over to using the governor's normal limiting functions.

The successive stages of the speed setpoint during start-up can be viewed in the parameter 2031 *SpeedSetp* (↑ *Fig. 3: Fixed starting fuel limitation*). Below starting speed 1, the setpoint is set to 0. During cranking (with the speed ranging between starting speeds 1 and 2), control is to idle speed. It is only after the engine is running (i.e., at speeds higher than starting speed 2) that the actually preset setpoint will be active.

Parameterizing Example:

The engine is supposed to start using a pre-defined maximum fixed starting fuel amount of 50%. Furthermore, on reaching a speed of 10 rpm the engine is to be recognized as being cranked, and at 400 rpm as being running. Once the engine has started off, starting quantity limitation is supposed to be active for 5 more seconds.

Number	Parameter	Value	Unit
250	<i>StartType</i>	1	
251	<i>LimitsDelay</i>	5	s
255	<i>StartSpeed1</i>	10	rpm
256	<i>StartSpeed2</i>	400	rpm
260	<i>StartFuel1</i>	50	%




Fig. 3: Fixed starting fuel limitation

5.2 Variable starting fuel limitation

Variable starting fuel adjustment is mainly used for diesel engines with little or medium output. In these cases, two starting fuel amounts are provided. The first start quantity 260 *StartFuel1* is set to the value by which the warm engine will start properly, whilst the start quantity 261 *StartFuel2* is set to the value by which the cold engine is sure to start even at extremely low temperatures (↑ Fig. 4: *Variable starting fuel limitation*).



Note

In case a temperature sensor is provided, it is recommended to use ↑ 5.3 Temperature dependent starting fuel limitation.

If within the time defined by *265 StartDuration1* the engine should not start off with starting fuel set to *260 StartFuel1*, the control will increase the fuel quantity to *261 StartFuel2* for the time defined in *266 StartDuration2*. This fuel quantity is sustained until the engine starts off or cranking is aborted.

On reaching speed as set by *256 StartSpeed2*, the control recognizes that the engine is running. At this point, there is a change-over to the externally applied speed setpoint *2031 SpeedSetp*. The starting quantity, however, with which the engine had started off is sustained as a fuel limitation for the duration set by *251 LimitsDelay*. After that, the control passes over to using the governor's normal limiting functions.




Fig. 4: Variable starting fuel limitation

Parameterizing Example:

The engine is supposed to start using the initially pre-defined maximum starting fuel quantity of 60%. At speeds of 10 rpm and higher the engine is to be recognized as being cranked, and at a speed of 400 rpm as being running. If the engine is not running after 3 seconds, the initially pre-defined maximum starting fuel quantity is raised until it reaches a maximum starting fuel quantity of 90% after further 7 seconds. The starting fuel quantity limitation stays on this level if the engine has not started to run yet. Once the engine has started off, starting quantity limitation is supposed to be active for 5 more seconds.

Number	Parameter	Value	Unit
250	<i>StartType</i>	2	
251	<i>LimitsDelay</i>	5	s
255	<i>StartSpeed1</i>	10	rpm
256	<i>StartSpeed2</i>	400	rpm
260	<i>StartFuel1</i>	60	%
261	<i>StartFuel2</i>	90	%
265	<i>StartDuration1</i>	3	s
266	<i>StartDuration2</i>	7	s

5.3 Temperature dependent starting fuel limitation

With this mode of starting fuel adjustment, starting fuel is adjusted in dependence on temperature. By means of a temperature sensor the engine temperature 2907 *CoolantTemp* is determined and used by the control to determine the most adequate starting quantity for this temperature. For the rest, the cranking procedure works the same way as with fixed starting fuel adjustment; the only difference is that the fixed starting quantity is derived from the current engine temperature.




Note

This function is not available in control units of the ORION type.

As long as the cold engine's temperature is below 271 *StartTempCold* the starting fuel quantity 261 *StartFuel2* is released. As engine temperature increases, starting fuel is decreased, until at the temperature set in 270 *StartTempWarm* the starting fuel defined in 260 *StartFuel1* is reached (↑ *Fig. 5: Temperature dependent starting fuel*).

On attaining 255 *StartSpeed1* the control will, as before, recognize that the engine is being cranked, and on reaching 256 *StartSpeed2* that the engine is running. At this point, there is a change-over to the externally applied speed setpoint 2031 *SpeedSetp* (↑ *Fig. 6: Temperature dependent starting fuel limitation*). The starting quantity, however, with which the engine had started off is sustained as a fuel limitation for the duration set by 251 *LimitsDelay*. After that, the control passes over to using the control unit's normal limiting functions.


Fig. 5: Temperature dependent starting fuel

Parameterizing Example:

The engine is supposed to start at an engine temperature of -10°C with temperature dependent maximum starting injection quantity of 70%. If the engine temperature is higher during start-up, the starting injection quantity is to be reduced accordingly. If, however, engine temperature has already risen above 40°C , starting fuel quantity is no longer to be reduced, but to be held at 50%. Furthermore, on reaching a speed of 10 rpm the engine is to be recognized as being cranked, and at 400 rpm as being running. Once the engine has started off, starting quantity limitation is supposed to be active for 5 more seconds.

Number	Parameter	Value	Unit
250	<i>StartType</i>	3	
251	<i>LimitsDelay</i>	5	s
255	<i>StartSpeed1</i>	10	rpm
256	<i>StartSpeed2</i>	400	rpm
260	<i>StartFuel1</i>	50	%
261	<i>StartFuel2</i>	70	%
270	<i>StartTempWarm</i>	40	$^{\circ}\text{C}$
271	<i>StartTempCold</i>	-10	$^{\circ}\text{C}$




Fig. 6: Temperature dependent starting fuel limitation

5.4 Starting sequence with starting speed ramp

Once the engine has started, it may be desirable to have it ramp slowly to its ultimate speed value. This helps to protect the engine from premature wear and to avoid overshooting. This function is activated by the parameter 4240 *StartSpeedRampOn*.

When starting the engine now and on attaining speed 255 *StartSpeed1*, the control recognizes that the engine is being cranked, and the speed setpoint is raised from 0 rpm to speed 257 *StartSpeed3* (↑ Fig. 7: Starting behaviour when starting speed ramp is enabled). The parameterized speed must lay between the speed at which the control recognizes that the engine is being cranked 256 *StartSpeed2* and the minimum speed 10 *SpeedMin1*. If engine start-off is detected the speed setpoint is increased by the ramping rate as pre-

defined by 240 *StartSpeedRampUp* until the externally applied speed setpoint is attained. Actual speed will follow these changes of set speed.

The starting is independent of the normal \uparrow 7.7 *Speed ramp*. It is only used to start the engine, and its priority is superior to that of the normal speed ramp. If both the starting speed and the normal speed ramps are enabled, the set normal speed ramp will remain inactive until after engine start the desired speed has been reached via the starting speed ramp.




Fig. 7: Starting behaviour when starting speed ramp is enabled

Parameterizing Example:

In addition to the settings in the preceding examples, the speed setpoint is to ramp after start-off from 600 rpm to the externally applied setpoint by a ramping rate of 100 rpm/s (rpm per second). To achieve this, the following parameters must be additionally programmed:

Number	Parameter	Value	Unit
240	<i>StartSpeedRampUp</i>	100	<i>rpm/s</i>
257	<i>StartSpeed3</i>	600	<i>rpm</i>
4240	<i>StartSpeedRampOn</i>	1	

5.5 Forced actuator opening

In certain applications, it may be required that with the engine stopped the actuator delivers starting fuel without having detected speed. By using the switch function 2833 *SwitchForcedStart* the control enables this function.

2833 *SwitchForcedStart* = 1 Forced start required

2833 *SwitchForcedStart* = 0

Forced start not required



Note

*If the switch function 2833 *SwitchForcedStart* is enabled automatic calibration cannot be activated or will immediately be de-activated.*

On activating forced start the control will always go to starting fuel 1 (260 *StartFuel1*). After that, engine start should occur, i.e. speed signals must be detected, within the time period set by 252 *ForcedStartSupvTime*. If this is not the case, a pickup error is generated and engine start is aborted. Otherwise, the starting procedure will continue in accordance with the preset start type.

NOTICE

For reasons of safety, this function should be used only if a backup speed pickup has been installed. For if the engine is started and there is no speed detected due to some pickup fault (e.g., poor contact of the pickup cable), starting fuel will be maintained even if the engine exceeds preset speed. In such cases, there is the risk that overspeeding will not be recognized by the HEINZMANN control due to the pickup fault. Therefore, the check time 252 *ForcedStartSupvTime* has to be set as short as possible

6 Speed sensing

6.1 Speed parameters

For speed parameters a common value range is provided. As a standard, it covers the range from 0 to 4000 rpm and allows to run engines up to maximum speeds of approx. 3,500-3,600 rpm (There must be some reserve for [↑] 6.4 *Overspeed monitoring*). Other speed ranges are possible on request, limited by the maximum admissible frequency on the pickup input [↑] 6.2 *Speed measurement*.

Current speed is indicated by the following parameters, whereby for control devices of the types PANDAROS and ORION the second pickup input must be activated separately ([↑] 19.4.2 *Pickup 2 input* and [↑] 19.5.2 *Pickup 2 input*) :

2000 <i>Speed</i>	Current engine speed.
2001 <i>SpeedPickUp1</i>	Speed as read by speed pickup 1
2002 <i>SpeedPickUp2</i>	Speed as read by speed pickup 2
2003 <i>SpeedPickUp1Value</i>	Speed as read by speed pickup 1 unfiltered.
2004 <i>SpeedPickUp2Value</i>	Speed as read by speed pickup 2 unfiltered.
2005 <i>PickUp2Or1Active</i>	Indication of currently active speed pickup

Depending on which speed pickup is active, actual speed 2000 *Speed* will coincide with either 2001 *SpeedPickUp1* or 2002 *SpeedPickUp2*. This speed value is used by other functions like speed control, fuel limitations, etc. The unfiltered speed value is needed only for [↑] 6.3.2 *Gradient monitoring*, otherwise it is for information only.



Note

The measured speeds are filtered with a special process to eliminate engine speed variations due to the coefficient of cyclic variation.

6.2 Speed measurement

Whenever possible, the pickup should be mounted to the starter gear.

For safe operation, an independent second speed pickup can be connected to take over sensing engine speed in case the first pickup should fail. Speed pickup 1 is always the one to be used under normal operation whereas the second serves as a backup speed probe only.

The alternator signal (terminal W) can also serve as a redundant speed sensing signal in place of a second pickup. For further information on how to connect the pickups please refer to the manuals of the basis systems.

When parametrizing, in parameter 1 *TeethPickUp1* and 2 *TeethPickUp2*, the number of teeth the respective pickup sees during one complete revolution of the engine is to be entered. If the second redundant pickup is connected to terminal W, the frequency is to be entered for the signal from terminal W, and the control must be instructed via the parameter 4003 *PickUp2AtAlternator* that terminal W is being used.



The decimal places of the number of teeth for speed pickup 2 will be used only when connected to terminal W of the alternator (4003 $PickUp2AtAlternator = 1$).

Filtering of the speed signal is normally done using the measurement data of one crankshaft revolution. This allows a very quick reaction to speed changes. For engines with an odd number of cylinders or irregular advance angles it may be convenient to filter over two crankshaft revolutions to eliminate speed irregularities.

4001 $PickUpFilter2Or1Rev = 0$ filtering over one revolution

4001 $PickUpFilter2Or1Rev = 1$ filtering over two revolutions



Filtering of speed signals is on principle always done over two crankshaft rotations when misfire monitoring is implemented in the firmware. (↑ 10.8 Misfire monitoring in generator operation)

The measurement frequency resulting from teeth number and maximum speed/overspeed may not exceed the following values:

Control unit	Maximum frequency
ARCHIMEDES	9,000 Hz
HELENOS	12,000 Hz
ORION	9,000 Hz
PANDAROS	9,000 Hz
PRIAMOS	9,000 Hz

Table 12 Maximum frequency

The control device monitors this and sends out a configuration error message (↑ 27.6 Configuration errors) in case of error. In addition, 3004 $ErrOverSpeed$ is activated in order to prevent engine starting.

Parameterizing Example:

Number	Parameter	Value	Unit
1	$TeethPickUp1$	160	
2	$TeethPickUp2$	60.0	

Activation:

4002	$PickUp2On$	1
4003	$PickUp2AtAlternator$	0



The second speed pickup must be activated separately. All these parameters will be active only after ↑ 3.2 Saving data in the control unit followed by a ↑ 3.10 Reset of control unit.

6.3 Speed pickup monitoring

For either speed pickup, identical monitoring functions have been separately implemented. It should be noted, however, that on starting the engine other conditions will have to be observed than in normal operation. Failure of a speed pickup is indicated by these parameters:

3001 <i>ErrPickUp1</i>	Speed pickup 1 at fault
3002 <i>ErrPickUp2</i>	Speed pickup 2 at fault

6.3.1 Failure monitoring

If on starting the engine one of the speed pickups is sensing some speed above the starting speed 255 *StartSpeed1* the other pickup must detect some speed not equal to zero within 0.5 seconds. Otherwise, this pickup will be assumed to be at fault. When commissioning the engine, care should be taken to preset 255 *StartSpeed1* in such a way that both speed pickups will be able supply a reliable signal for this speed. This monitoring mode requires implementation of two speed pickups

With the engine running, speed monitoring will commence as soon as the upper starting speed 256 *StartSpeed2* is exceeded. Both speed pickups are continuously monitored for failures. Failure of a speed pickup is reported if for a certain time period depending on the number of teeth and on the current speed there is no measuring pulse received from the pickup.

If only one speed pickup is connected (or only one pickup can be connected), an emergency engine shutdown will immediately be executed in case of its failure. With two pickups connected, speed sensing will continue by means of the healthy pickup. The following parameter provides information on the active pickup by which the control is currently operating:

2005 <i>PickUp2Or1Active</i> = 0	Pickup 1 is relevant
2005 <i>PickUp2Or1Active</i> = 1	Pickup 2 is relevant

If the second speed pickup fails too, the engine will be immediately shut down.

If pickup errors turn up after engine stop, the reason may be the backward rotation of the engine. In this case it is recommended to prolong the duration of engine stop request.

Should both speed pickups be faulty before the engine is started, the control unit will not be able to detect any fault. Neither will it be possible to start the engine since no speed is being measured. In order to make it possible for the service staff to recognize this problem, on the PRIAMOS and HELENOS type control units the speed pickup

inputs are monitored by means of LEDs. The respective LEDs light up when the engine is still and go off when speed is recognized (↑ 27.3.4 *Error indication by LEDs*)



Note

A pickup error can be cleared only when the engine is still. If speed pickup 1 is at fault and the engine is operating by speed pickup 2, any attempt at clearing the error would result in a switch-back to pickup 1. Before it is again recognized to be at fault, it will take a short time during which speed cannot be controlled and may lead to undesirable speed and load variations.

6.3.2 Gradient monitoring

The speed signals can generally be monitored with regard to an admissible change rate (gradient). This will require information on free engine acceleration as depending on engine size, torque, etc. The parameters of the gradient monitoring should be very carefully adjusted to the engine used.

The currently valid change rate can be read from the parameter 2025 *SpeedGradient*. This value is determined by means of the currently active speed pickup, but only after the engine is running, i.e., above starting speed 256 *StartSpeed2*. To determine this value, unfiltered speeds are used (2003 *SpeedPickUp1Value* and 2004 *SpeedPickUp2Value* respectively).

Gradient monitoring is motivated as a possibility of detecting additional wrong pulses during speed sensing. This is why only increase of speed (acceleration) is being checked. There is no need for monitoring decrease of speed as this will be done by ↑ 6.3.1 *Failure monitoring*.

It may happen, however, that the engine's gradient is by itself so large and unstable that no appropriate monitoring will be possible. So, before activating this function the gradient should be carefully observed and the admissible change rate set to a value in sufficient distance from the actual maximum change rate.

For gradient monitoring the following parameters are provided:

25 <i>SpeedGradientMax</i>	Admissible change rate
26 <i>SpeedGradientTime</i>	Time window for the number of admissible excesses
27 <i>SpeedGradientMaxCnt</i>	Number of admissible excesses
2025 <i>SpeedGradient</i>	Current change rate
4025 <i>SpeedGradientOn</i>	Activation of gradient monitoring

An error message will be generated only if within the time as set by 26 *SpeedGradientTime* more than 27 *SpeedGradientMaxCnt* excesses of 25 *SpeedGradientMax* have occurred. If there is an excess it is not the value measured together with the excess that is used for speed but the last valid measurement plus the speed resulting from the admissible gradient 25 *SpeedGradientMax*.

For error messages, the same parameters are used as for [↑]6.3.1 *Failure monitoring*.

<u>Number</u>	<u>Parameter</u>	<u>Value</u>	<u>Unit</u>
3001	<i>ErrPickUp1</i>	1	
<u>and/or:</u>			
3002	<i>ErrPickUp2</i>	1	

6.3.3 Difference monitoring

When two speed pickups are connected, the difference between the speeds measured by the two devices may be monitored.

To do so, the variation of measured values from a maximum admissible value 14 *PickUpSpeedDiffMax* is monitored. It may be exceeded for no longer than the time indicated in 15 *PickUpSpeedDMaxTime*. After this time is exceeded, error 3001 *ErrPickUp1* or error 3002 *ErrPickUp2*, respectively, are output for the pickup showing the lower value, while operation is continued with the pickup showing the higher value.

Current speed difference is shown in 2014 *PickUpSpeedDiff*, this function is activated with 4014 *CheckPickUpDiffOn*.

Monitoring is carried out only if both pickups have exceeded start speed 256 *StartSpeed2* and no engine stop request is active.

6.4 Overspeed monitoring

Overspeed is set with parameter 21 *SpeedOver*. This value will be valid for speed pickup 1 as well as for speed pickup 2 even though their speed signals are monitored independently of each other.

Regardless of which speed pickup is currently active, exceeding overspeed will always prove a fatal error and cause an emergency engine shutdown. If this occurs the parameter 3004 *ErrOverSpeed* is set to 1. To restart the engine, it will be necessary to clear the error and to execute a [↑]3.10 *Reset of control unit* or turn the supply voltage off.

Overspeed monitoring cannot be disabled. Control devices of the PRIAMOS type have a second independent overspeed monitoring system ([↑]27.9 *Watchdog processor CPU2 in PRIAMOS series*).

6.5 Speed switching points

All **HEINZMANN** control units except the ORION system offer the possibility of signalling via digital outputs that certain speeds have been attained.

For this purpose three (in PANDAROS only two) speed switching points are provided which can be parameterized:

90	<i>SpeedSwitch</i>	Speed switching point 1
91	<i>SpeedSwitch2</i>	Speed switching point 2
92	<i>SpeedSwitch3</i>	Speed switching point 3

If the respective speed is exceeded a signal is triggered.

2090	<i>SpeedSwitchActive</i>	1 = Switching point speed 1 is reached
2091	<i>SpeedSwitch2Active</i>	1 = Switching point speed 2 is reached
2092	<i>SpeedSwitch3Active</i>	1 = Switching point speed 3 is reached

The signal is deactivated if speed is lower than 90% of switching point speed.

These signals can be assigned to digital outputs ([↑ 20.8 Digital outputs](#)) and evaluated by an external control, e.g., the starter may be de-activated when cranking speed is reached or synchronization activated when generator frequency is reached. The digital control itself does not require these signals.

7 Speed setpoint determination

HEINZMANN control units may be configured for a wide variety of different applications. Any such configuration will make specific functions available for the respective application of the engine, but will also require that determination of the speed setpoints be conducted in a suitable manner. Presently, the following applications are provided:

Application	Mode	ARCHIMEDES PANDAROS	HELENOS PRIAMOS	ORION	Chapter
General	0	●	●	●	↑7.1 <i>General application</i>
Vehicle	1	●	●	●	↑7.2 <i>Vehicle operation</i>
Locomotive	2		●		↑7.3 <i>Locomotive operation</i>
Generator	3	●	●	●	↑7.4 <i>Generator operation</i>
Marine	4	●	●		↑7.5 <i>Marine operation</i>

Table 13: Applications

The application mode must to be entered in parameter 1810 *OperationMode*. If this parameter is not provided, the parameter 3810 *OperationMode* will display the permanently preset application mode of the firmware version actually used.

Once the application specific speed setpoint has been determined, it may additionally be delayed by a speed ramp (↑7.7 *Speed ramp*) and modified by droop (↑7.8 *Droop*). The following chapters will begin by explaining application-specific determination of speed setpoints and then deal with application-independent speed setpoint functions such as speed ramps, droop and temperature dependent raising of idle speed.

The PANDAROS system is available in a freely configurable variant and with fixed configurations for specific applications. The variants DC 6-01, DC 6-03, DC 6-04, DC 6-08, DC 6-11 and DC 6-14 are generator applications. The setpoint is determined according to ↑7.4 *Generator operation* (also ↑14.5 *PANDAROS variants*). The variants 6-02 and 6-05 are general applications, here the setpoint is determined as described in ↑7.1 *General application*. Variant 6-10 is for ↑7.2 *Vehicle operation*.



Note

Before reading the chapter dealing with setpoint determination for the particular application, it is recommended to work through the chapter on general application as this chapter describes the influences that can affect setpoint determination and may therefore be of importance for the various applications.

7.1 General application

For general application, the parameter 1810 *OperationMode* must be set to "0" resp. the parameter 3810 *OperationMode* must display "0".

Setpoints may be pre-defined by means of setpoint adjusters (potentiometers, foot throttle, current signal, etc., see ↑ 17 *Configuration* of sensors or ↑ 18 *Configuration* of switching functions for fixed speed values. Switching functions that have not been assigned an external switch will always enter into determination of speed setpoints with value "0" or "no" respectively.

The following switching functions are provided for general determination of speed setpoints:

Indication parameter	Meaning
2810 <i>SwitchEngineStop</i>	1 = Engine stop
2811 <i>SwitchIdleSpeed</i>	1 = Idle speed active
2812 <i>SwitchDroop2Or1</i> ORION: 2812 <i>SwitchDroopOn</i>	0 = Droop 1 active 1 = Droop 2 active 0: Droop inactive, 1 = droop active
2815 <i>SwitchSpeedFix1</i>	1 = Fixed speed 1 active
2827 <i>SwitchSetpoint2Or1</i> (not in PANDAROS)	0 = Setpoint 1 active (in PANDAROS always active) 1 = Setpoint 2 active

Table 14: Speed setpoint switching functions 1

The following switching functions and respective parameters are not provided in the systems PANDAROS and ORION, for which speed range 1 applies always.

Indication parameter	Meaning
2816 <i>SwitchSpeedFix2</i>	1 = Fixed speed 2 active
2814 <i>SwitchSpeedRange2Or1</i>	0 = Speed range 1 active 1 = Speed range 2 active

Table 15: Speed setpoint switching functions 2



Note

To facilitate commissioning, it is possible to directly pre-define a setpoint by means of a PC or handheld programmer without having to modify the inputs that have already been parameterized. This function is activated by the parameter 4020 *SpeedSetpPCOn*, and the setpoint is adjusted by means of the parameter 20 *SpeedSetpPC*. This function is non-latching, i.e., it will not store

that value. Following a $\hat{\uparrow}$ 3.10 Reset of control unit, the original value will be active again.

As the control may see several signals coming in at the same time, the signal sources have been assigned different priorities with respect to the determination of setpoints. For applications in general, the determination of the speed setpoint 2031 *SpeedSetp* is illustrated by the diagram below.

Strictly speaking, the function "Engine stop" (zero speed) does not represent a setpoint adjustment; it is, however, assigned higher priority than any of the other functions. The parameter 4810 *StopImpulseOrSwitch* permits to decide by way of configuration whether the stop command is to be in effect for the period the command is being applied via the switch or whether a pulse will suffice to activate the command until the engine comes to a standstill.

- | | |
|-------------------------------------|---|
| 4810 <i>StopImpulseOrSwitch</i> = 0 | engine stop is active only as long as the stop command is coming in |
| 4810 <i>StopImpulseOrSwitch</i> = 1 | engine stop is activated by a single switching pulse until the engine stops |

The parameter 3802 *EngineStopRequest* serves to indicate that the engine is being stopped by some internal or external stop command. External engine stop is executed by means of the switch 2810 *EngineStop* while for an internal engine stop the shutdown command is issued by the control itself (e.g., in case of $\hat{\uparrow}$ 6.4 *Overspeed monitoring*). The parameter 3803 *EngineStopped* is provided to indicate that the engine has stopped.

Setpoint adjustment by analogue adjusters (2900 *Setpoint1Extern* and 2901 *Setpoint2-Extern*) is possible only if there is no setpoint coming in from the PC and if none of the switches for fixed speed values has been actuated. Otherwise, the control will operate according to the speed setpoint selected from among 20 *SpeedSetpPC*, 10 *SpeedMin1/2*, 17 *SpeedFix1* or 18 *SpeedFix2* (in this order of priority – exception $\hat{\uparrow}$ 7.5.1 *Setpoint adjuster with directional information*).

In other words, though setpoint adjustment by the PC has topmost priority but it is used only during commissioning. Therefore, it is the switching function for idle speed that has highest priority in normal operation. It is followed by the switching function for fixed speed 1 which, in its turn, is ranking before fixed speed 2 and the setpoint adjusters.



Note

In the systems PANDAROS and ORION the request for fixed speed 2 is always answered by a "No" and in PANDAROS the speed setpoint is always selected by "Speed setpoint 1" in the following diagram.




Fig. 8: Speed setpoint determination for general purposes

The setpoint 2033 *SpeedSetpSelect* thus determined can be delayed by activated ramp functions (\uparrow 7.7 *Speed ramp*) before droop is applied. The intermediary value attained after ramping can be read from the parameter 2032 *SpeedSetpRamp*. The final setpoint used by the speed governor after addition of droop is indicated in parameter 2031 *SpeedSetp*.



Note

Parameter 2031 SpeedSetp is equal to zero when the engine is at a standstill or is to be shut down. On starting the engine, control is first by idle speed. The actual setpoint will be active only when the engine has started off and is running (\uparrow 5 Starting fuel limitation).

As an adaptation to the engine's operating modes, two different speed ranges can be provided, e.g., one for driving and one for stationary operation – except for PANDAROS and ORION. For driving operation the speed range is normally defined with regard to the requirements of the prime mover, and for stationary operation with regard to those of the working machine.

These speed ranges are parameterized by means of the following parameters. These limit values apply to all speed setpoint adjustments except for droop.

10	<i>SpeedMin1</i>	Minimum Speed for range 1
12	<i>SpeedMax1</i>	Maximum Speed for range 1
11	<i>SpeedMin2</i>	minimum speed for range 2
13	<i>SpeedMax2</i>	maximum speed for range 2

Parameterizing Example:

Speed range is assumed to be from 700 rpm to 2,100 rpm for driving operation, and from 1,000 rpm to 1,800 rpm for stationary operation. Besides, there are fixed speeds to be provided for stationary operation at 1,200 rpm and at 1,500 rpm.

Number	Parameter	Value	Unit
10	<i>SpeedMin1</i>	700	rpm
11	<i>SpeedMin2</i>	1000	rpm
12	<i>SpeedMax1</i>	2100	rpm
13	<i>SpeedMax2</i>	1800	rpm
17	<i>SpeedFix1</i>	1200	rpm
18	<i>SpeedFix2</i>	1500	rpm

The speed range switch as defined by the selector switch function 2814 *SwitchSpeedRange2Or1* serves to select the speed range by which the control is supposed to operate.

2814 *SwitchSpeedRange2Or1* = 0 Control is operating by speed range 1

2814 *SwitchSpeedRange2Or1* = 1 Control is operating by speed range 2

If no selector switch is provided (PANDAROS and ORION or 814 *FunctSpeedRange2Or1* = 0 and 20814 *CommSpeedRange2Or1* = 0 or both parameters not available) the control will always operate using speed range 1.

When the speed range is changed while the engine is running it may happen that the old set value – and the current speed along with it – lies out of range of the new speed range. In such a case, the engine runs up to the new setpoint inside the new speed range using the speed ramp (\uparrow 7.7 *Speed ramp*), if the latter is active.



Note

*Minimum and maximum speeds can be increased by \uparrow 7.8 *Droop*.*

For variable operating conditions, it is in general possible to make use of two different setpoint adjusters. The selector switch defined by the switching function 2827 *SwitchSetpoint2Or1* is provided to select by which setpoint adjuster the control is going to operate.

2827 *SwitchSetpoint2Or1* = 0 Control is operating by setpoint adjuster 1

2827 *SwitchSetpoint2Or1* = 1 Control is operating by setpoint adjuster 2

If no selector switch is provided (PANDAROS or 827 *FunctSetpoint2Or1* = 0 and 20827 *CommSetpoint2Or1* = 0 or both parameters not available) the control will always operate using setpoint adjuster 1.

The setpoint values of the setpoint adjusters are indicated by the parameters

2900 *Setpoint1Extern* Setpoint adjuster 1

2901 *Setpoint2Extern* Setpoint adjuster 2

7.1.1 Speed setpoint limitation

The speed setpoint may be limited via communication modules. The limit set can be viewed in 2035 *SpeedSetpLimit*. Whether the limit is currently active is indicated in 2730 *SetpLimitExtActive*.

7.2 Vehicle operation

For vehicle operation the value of the parameter 1810 *OperationMode* must have been set to "1" resp. the parameter 3810 *OperationMode* must display "1".

Vehicle operation provides the additional option of having the control unit configured as an \uparrow 12.1 *Idle/maximum speed control*. In this operating mode, the determination of speed setpoints will define only idle and maximum speeds and possibly required intermediary speeds.




Fig. 9: Determination of speed setpoints for vehicle operation

7.2.1 Freezing the speed setpoint

For particular vehicle applications, it may be desirable to freeze the current speed setpoint via a switch and to continue operation using this setpoint (variable fixed speed – not featured in PANDAROS and ORION). To this purpose, the two switching functions

2829 *SwitchFreezeSetp1* = 1 Value of setpoint 1 has been frozen

2830 *SwitchFreezeSetp2* = 1 Value of setpoint 2 has been frozen

are used. The setpoint coming in when the function is activated will be frozen. As long as the function is active, the current setpoint will be compared with the stored setpoint. If the set value coming from the setpoint adjuster exceeds the frozen value, operation will continue using the current value of the setpoint adjuster; otherwise the frozen value is used. The frozen setpoint, however, will be abandoned only when the switch is opened.

The speed setpoint resulting from this method of speed setpoint determination can be read from the parameter 2033 *SpeedSetpSelect*.

7.2.2 Work machine application with up/down steps

In cranes and other industrial vehicles the same engine frequently changes over from driving to stationary working operation and back. While in driving operation the setpoint determination is achieved by means of the foot throttle, for working operation it might be required non to pre-determine the setpoint in analogue form but to change it with keys (speed higher/speed lower). This digital potentiometer always has additive effect, limited to setpoint adjuster 2 2901 *Setpoint2Extern*.

The use of the digital potentiometer makes sense only in the operational mode variable speed control. Using idle/maximum speed control for driving operation (speed adjuster 1) therefore at the same time operation is switched over to stationary work operation (speed adjuster 2) it must be switched to variable speed control: 2827 *SwitchSetpoint2Or1* = 1 and 2831 *SwitchIMOrAllSpeed* = 0. To this purpose, the same digital input with inverted sign may be used.

The states of the two switching functions of the digital potentiometer can be viewed by the parameters

2825 *SwitchSpeedInc* = 0 no increase of the speed setpoint

2825 *SwitchSpeedInc* = 1 increase of the speed setpoint

2826 *SwitchSpeedDec* = 0 no decrease of the speed setpoint

2826 *SwitchSpeedDec* = 1 decrease of the speed setpoint

There will be changes of the setpoint only if the two parameters read different values, i.e., if only one of the two functions is active. The ramping rate for the digital potentiometer is set by means of the parameter 1210 *DigitalPotSpeedRamp*. If the signals for changing the setpoint consist of pulses, these pulses must have a duration of at least 20 ms in order to be detected by the control circuit. The control electronics will respond to pulses for changing the setpoint only when the engine is running.

Setpoint changes will be possible until either maximum or minimum speed is attained. Furthermore, speed will be increased only if fuel quantity has not yet attained maximum limitation, and likewise decreased only, when fuel quantity has not yet attained minimum limitation. On switching back to setpoint adjuster 1 the value of the digital potentiometer is deleted. The offset from the digital potentiometer that is added to the current value of the setpoint adjuster 2 is indicated in 2041 *DigitalPotOffset*.

If it is desired to let the digital potentiometer start always with idle speed, the speed adjuster 2 does not have to be connected (901 *AssignIn_Setp2Ext* = 0). Wanting to start from another fixed speed, a fixed speed has to be defined with 17 *SpeedFix1* or 18 *SpeedFix2* respectively, that is activated together with the commutation to setpoint adjuster 2: 2827 *SwitchSetpoint2Or1* = 1 and 2815 *SwitchSpeedFix1* = 1 (resp.: 2816 *SwitchSpeedFix2* = 1). To this purpose, the same digital input may be used.

7.3 Locomotive operation

For locomotive operation the value of the parameter 1810 *OperationMode* must have been set to "2" resp. the parameter 3810 *OperationMode* must display "2".



Note

The control units ARCHIMEDES, PANDAROS and ORION are not suited for locomotive operation.

In locomotive operation, setpoint 1 can be determined either via digital speed notch switches, via setpoint adjuster 1 or via up/down keys serving as a digital potentiometer. Selection of setpoint adjuster 1 is made by software using the parameter

5350 *LocoSetpoint1Mode* = 0 Digital speed notch switches

5350 *LocoSetpoint1Mode* = 1 Setpoint adjuster

5350 *LocoSetpoint1Mode* = 2 Digital potentiometer.

It is also possible to switch over to setpoint 2 using the switch 2827 *SwitchSetp2Or1*. Setpoint 2, however, will always be an analogue setpoint adjuster.




Fig. 10: Determination of speed setpoints for locomotive operation

7.3.1 Digital notch switches

For operation by speed notch switches the parameter 5350 *LocoSetpoint1Mode* must be set to 0. The chapter [↑] 13.1 *Speed notch switches* contains a description of how to determine the actual speed notch 3350 *Notch* by means of the speed notch switches.

For each speed notch 0..15 the respective speed must be entered in the field parameters 6900 to 6915 *LocoSpeedLevel(x)*. The speed notch corresponds to the field index.

Parameterizing Example:

Using setpoint 1, the speeds for a locomotive are to be set from 500 rpm to 1200 rpm by means of 8 notch switches.

Number	Parameter	Value	Unit
5350	<i>LocoSetpoint1Mode</i>	0	
6900	<i>LocoSpeedLevel(0)</i>	500	rpm
6901	<i>LocoSpeedLevel(1)</i>	600	rpm
6902	<i>LocoSpeedLevel(2)</i>	700	rpm
6903	<i>LocoSpeedLevel(3)</i>	800	rpm
6904	<i>LocoSpeedLevel(4)</i>	900	rpm
6905	<i>LocoSpeedLevel(5)</i>	1000	rpm
6906	<i>LocoSpeedLevel(6)</i>	1100	rpm
6907	<i>LocoSpeedLevel(7)</i>	1200	rpm

7.3.2 Digital potentiometer

Setpoint 1 can also be implemented as a digital potentiometer so that setpoint adjustment can be made by push-buttons (Speed Up/Speed Down). To do so, parameter 5350 *LocoSetpoint1Mode* must be set to the value "2". In contrast to generator operation, the digital potentiometer will not be additive in locomotive operation as it is in generator operation, i.e., it will be the only operative setpoint adjuster.

The states of the switching functions of the digital potentiometer can be viewed by the parameters

2825 <i>SwitchSpeedInc</i> = 0	no increase of the speed setpoint
2825 <i>SwitchSpeedInc</i> = 1	increase of the speed setpoint
2826 <i>SwitchSpeedDec</i> = 0	no decrease of the speed setpoint
2826 <i>SwitchSpeedDec</i> = 1	decrease of the speed setpoint

There will be changes of the setpoint only if the two parameters read different values, i.e., if only one of the two functions is active. The ramping rate for the digital potentiometer is set by means of the parameter 1210 *DigitalPotSpeedRamp*. If the signals for changing the setpoint consist of pulses, these pulses must have a duration of at least 20 ms in order to be detected by the control circuit. The control electronics will respond to pulses for changing the setpoint only when the engine is running.

Setpoint changes will be possible until either maximum or minimum speed is attained. Furthermore, speed will be increased only if fuel quantity has not yet attained maximum limitation, and likewise decreased only, when fuel quantity has not yet attained minimum limitation. With the engine standing, the accumulated offset will be cleared.

When there is a change-over to the digital potentiometer (de-activation of fixed speed or change-over from setpoint 2 to setpoint 1) the currently set speed is used as an initial value for adjustment by the digital potentiometer. This avoids unwanted setpoint skips.

Parameterizing Example:

Speed is to be adjusted using the digital potentiometer. Speed change is supposed to be 25 rpmps throughout.

Number	Parameter	Value	Unit
1210	DigitalPotSpeedRamp	25	rpmps
5350	LocoSetpoint1Mode	2	

7.4 Generator operation

For generator operation the value of the parameter 1810 *OperationMode* must have been set to "3" resp. the parameter 3810 *OperationMode* must display "3".

For parallel generator operation, various devices are required to perform synchronization and real load sharing in isolated parallel operation or real load control when paralleled to the mains (\uparrow 14 *Generator operation*). All of these devices will affect the speed setpoint. It is for this reason that a setpoint value for synchronization and a setpoint value for load control are added to the delayed setpoint value as determined from the pre-defined setpoint. This offset is indicated by 2042 *GenSetOffset*.

In most cases, generator operation will not require variable speed setting as the engine is run at rated speed only. Starting from this condition, synchronization and load control can then be conducted.

For configuring speed setting it is therefore recommended to assign rated speed to fixed speed 1 and to preset this switching function inverted with respect to engine stop.

Number	Parameter	Value	Unit
10	SpeedMin1	700	rpm
17	SpeedFix1	1500	rpm
810	FunctEngineStop	1	
815	FunctSpeedFix1	-1	

Due to the priorities of setpoint determination fixed speed 1 will always be active when there is no engine stop (\uparrow 7.1 *General application*).

During cranking the engine, however, speed will automatically set to minimum speed (\uparrow 5 *Starting fuel limitation*). If after engine start rated speed is to be run up to via a \uparrow 7.7 *Speed ramp* it will suffice to parameterize and activate this ramp.

Number	Parameter	Value	Unit
230	<i>SpeedRampUp</i>	50	<i>rpm/s</i>
231	<i>SpeedRampDown</i>	50	<i>rpm/s</i>
4230	<i>SpeedRampOn</i>	1	

When the engine is supposed to run at idle speed for a certain time to warm up after start-up or to cool down before being stopped it will be necessary to use a specific switching function for changing over between idle speed and fixed speed besides the switching function for engine stop. The following example illustrates this change-over, but it is equally possible to use two separate inputs for the two switching functions. In this case, idle speed will have priority when both are simultaneously active.

Number	Parameter	Value	Unit
10	<i>SpeedMin1</i>	700	<i>rpm</i>
17	<i>SpeedFix1</i>	1500	<i>rpm</i>
810	<i>FunctEngineStop</i>	1	
811	<i>FunctIdleSpeed</i>	-2	
815	<i>FunctSpeedFix1</i>	2	

Even when the engine is running at rated speed only, the minimum and maximum speeds must have been set to reasonable values since by synchronization and load control a speed offset will be generated and added to rated speed.

As an orientation, minimum and maximum speeds should differ from rated speed by at least 5 % as in the following example:

Number	Parameter	Value	Unit
10	<i>SpeedMin1</i>	1425	<i>rpm</i>
12	<i>SpeedMax1</i>	1575	<i>rpm</i>
17	<i>SpeedFix1</i>	1500	<i>rpm</i>




Fig. 11: Determination of speed setpoints for generator sets

7.5 Marine operation

For marine operation the value of the parameter 1810 *OperationMode* must have been set to "4" resp. the parameter 3810 *OperationMode* must display "4".



Note

The control device ORION is not suited for marine operation.

The speed setpoint from the bridge (remote operation) is pre-determined with a 4..20 mA current signal. This signal is sent to an analogue input and assigned to setpoint 1 by parameter 900 *AssignIn_Setp1Ext*.

Two different variants are possible for setpoint adjuster 1. Either the 4...20 mA signal determines only the speed setpoint or, in addition, the signal transmits also a directional information.

In the first case, 4 mA correspond to 0% of the setpoint (idle speed) and 20 mA to 100% of the setpoint (maximum speed). In the second case, 4 to approx. 10 mA correspond to 100...0% in reverse direction and approx. 14 to 20 mA correspond to 0...100% of the setpoint in forward direction. The selection is carried out with

5253 ShipSetp1LeverOrPot = 0 setpoint without directional information

5253 ShipSetp1LeverOrPot = 1 setpoint with directional information

If the parameter does not exist the setpoint is to be understood always without directional information. Determination of the value of adjuster 1 with directional information is described in [↑ 7.5.1 Setpoint adjuster with directional information](#).

Adjustment by setpoint 2 is provided for manual or emergency operation to be conducted from the engine room (local operation).

The setpoint selector switch is defined by the switching function:

2827 SwitchSetpoint2Or1 = 0 Setpoint 1 active

2827 SwitchSetpoint2Or1 = 1 Setpoint 2 active

Setpoint 1 is always analogue and is indicated by the parameter 2900 *Setpoint1Extern*. Setpoint 2 can alternatively be configured as an analogue setpoint adjuster (indicated by parameter 2901 *Setpoint2Extern*) or as a digital potentiometer. The type of setpoint adjuster 2 is selected by means of the parameter

5250 ShipSetp2DigiOrAna = 0 Setpoint 2 = setpoint adjuster

5250 ShipSetp2DigiOrAna = 1 Setpoint 2 = digital potentiometer.




Fig. 12: Determination of setpoints for marine operation

If in marine operation there is a failure of speed adjustment by setpoint 1, normally the digital potentiometer is automatically activated to ensure that speed changes will still be possible for emergency operation.

This automatic switching does not happen when parameter 5252 *NoDigPotAtSetp1Err* is set. In this case, operation continues with the pre-defined setpoint without directional information (5253 *ShipSetp1LeverOrPot* does not exist or = 0) with the configured sensor error value (substitution or last valid value). In case of setpoint determination with directional information (5253 *ShipSetp1LeverOrPot* = 1), setpoint adjuster 1 is on principle substituted with 0%, i.e. idle speed. But it is also possible to continue operation with the last valid value. Direction and gear setting remain the same.

7.5.1 Setpoint adjuster with directional information

When 5253 *ShipSetp1LeverOrPot* = 1, setpoint adjuster 1 (remote setpoint) is controlled by a throttle lever with three lock-in positions. In the middle position 0 the engine is off shaft. Position I (forward from the middle position) inserts the forward gear. Position III (back from the middle position) inserts the reverse gear (↑ *Fig. 13: Setpoint determination with directional information*).

The range between positions I and III corresponds to 0% setpoint, i.e. idle speed. The end positions of the lever in both directions correspond to 100% of the setpoint (maximum speed). Returning from outside to inside to positions I or III respectively, the engine is disengaged.

7.5.1.1 Calibration of lever positions

As a first step, the two end positions of the lever must be entered in the reference parameters for the assigned analogue inputs 15x0 *AnalogInx_RefLow* and 15x1 *AnalogInx_RefHigh* (↑ 20.2.1 *Calibration of current/voltage inputs*). Parameter 2900 *Setpoint1Extern* then indicates 0..100%, accordingly to the 4..20 mA input.

Next, the three lock-in positions must be adjusted by reading out 2900 *Setpoint1Extern* at the respective position and entering the values in the following parameters.

1250 <i>PositionIUpperRef</i>	forward position of the lever in lock-in position I (forward direction)
1251 <i>Position0UpperRef</i>	forward position of the lever in lock-in position 0 (forward direction)
1252 <i>PositionIIILowerRef</i>	back position of the lever in lock-in position III (reverse direction)

Since the mechanical position of the lever throttle in the lock-in position is not exactly replicable, in

1253 <i>PositionIRange</i>	range of the lever in lock-in position I
----------------------------	--

- 1254 *Position0Range* range of the lever in lock-in position 0
- 1255 *PositionIIIRange* range of the lever in lock-in position III

the range must be entered that the lever covers within a lock-in position. For positions 0 and I the range towards the back (reverse direction) must be indicated and for position III the range forward (forward direction) – seen from the reference position.




Fig. 13: Setpoint determination with directional information

The settings must be checked by repeatedly driving through all positions of the lever throttle. Parameters 3254 *SetpointPositionI*, 3255 *SetpointPosition0* and 3256 *SetpointPositionIII* indicate with "1" that the control unit has recognized the respective lock-in position.

The effective setpoint after extraction of the directional information from 2900 *Setpoint1Extern* is indicated in 3250 *LeverSetpoint*. This value then determines the speed setpoint 2033 *SpeedSetpSelect*.

7.5.1.2 Clutch

Parameter 3251 *SetpointNeutralPos* indicates the neutral position with "1", that is the lever position between the locking positions I and III. When the lever is outside this range, 3251 *SetpointNeutralPos* = 0 and 3252 *SetpBackwOrForw* indicates the current direction of movement:

$$3252 \text{ SetpBackwOrForw} = 0 \quad \text{forward}$$

3252 *SetpBackwOrForw* = 1 reverse

Parameters 3295 *ForwardGearValve* and 3296 *BackwardGearValve* are enabled when the lever is shifted from the neutral position to positions I or III (except with [↑]7.5.1.3 *Clutch disabling*). These two values are connected via digital outputs with the respective valve for clutch functionality ([↑]20.8 *Digital outputs*).

When the lever is shifted from neutral position, setpoint transmission can be delayed by setting 1258 *PositionIDelay* or 1259 *PositionIIIDelay* resp. to a value greater than 0 s. When this function is used, it is recommended to enable the speed ramp, in order for the set speed to gently follow the movement of the lever after the end of the delayed interval.

The mechanical insertion of a gear can take long enough to break off speed. Parameters 1256 *PositionISpeedInc* and 1257 *PositionIIISpeedInc* are conceived expressly for the purpose of raising idle speed as soon as the gear is inserted. When the lever is brought back into neutral position, the increase is disabled and idle speed 10 *SpeedMin* as set in the parameter applies again.



Note

*In multiple engine operation ([↑]15.2 *Multiple engine set with directional information*) the common setpoint adjuster also supplies the signal for engaging the clutch to the other engines. 3295 *ForwardGearValve* and 3296 *BackwardGearValve* are therefore not determined by the lever throttle if the lever is not the active setpoint adjuster .*

7.5.1.3 Clutch disabling

To let the engine run to operating temperature at standstill the automatic clutch must be disabled. To this purpose, the switching function 2811 *SwitchIdleSpeed* is put into neutral position, i.e. the lever is between positions I and III or, put differently, 3251 *SetpointNeutralPos* = 1.

The lever throttle now can be moved in one of the two 100% directions without activating the clutch. The function “Clutch disabled” is terminated by switching off 2811 *SwitchIdleSpeed*.



When setpoint is determined with directional information, the setpoint priority “10 SpeedMin1 before 17 SpeedFix1 before 18 SpeedFix2 before external setpoint adjuster“ is suspended. Only the setpoint transmitter via PC and the engine stop switch have a higher priority than the setpoint adjuster with directional information. The indicated switching functions are therefore not handled as usual in this case.

Switching to setpoint adjuster 2 (remote operation → local operation) the clutch always disengages automatically. Switching from setpoint adjuster 2 to 1 (local operation → remote operation) the clutch remains disengaged until the lever throttle is shifted away from the neutral position, possibly requiring to shift it into that position first.



In multiple engine operation (↑ 15.2 Multiple engine set with directional information) the common setpoint adjuster also supplies the signal for disengaging the clutch to the other engines.

When the engine stands still or in case of an incoming engine stop request – for whatever reason, i.e., also in case of fatal error – the clutch is equally disengaged automatically.



In case of multiple engine operation (↑ 15.2 Multiple engine set with directional information), the engine receiving the engine stop command is taken out of the common setpoint determination. If this refers to the currently active setpoint adjuster, the common setpoint determination is automatically suspended and each of the two or four setpoint adjusters becomes active separately again.

3253 *GearShiftingOff* = 1 indicates every situation in which the clutch is disabled. This parameter can be connected to a visual indicator.

7.5.2 Digital potentiometer

If setpoint 2 has been configured as a digital potentiometer setpoint adjustment is made by push-buttons (Speed Up/Speed Down). In contrast to generator operation, the digital potentiometer will not be additive in marine operation, i.e., it will operate as the sole setpoint adjuster. If, e.g., the switch for fixed speed 1 is set, this speed will be directly run up to without any offset, and the digital potentiometer will be inactive.

The digital potentiometer is defined by the two switching functions 2825 *SwitchSpeedInc* and 2826 *SwitchSpeedDec*:

2825 <i>SwitchSpeedInc</i> = 0	no increase of speed setpoint
2825 <i>SwitchSpeedInc</i> = 1	increase of speed setpoint

2826 <i>SwitchSpeedDec</i> = 0	no decrease of the speed setpoint
2826 <i>SwitchSpeedDec</i> = 1	decrease of the speed setpoint

There will be changes of the setpoint only if the two parameters read different values, i.e., if only one of the two functions is active. The ramping rate for the digital potentiometer is set by means of the parameter 1210 *DigitalPotSpeedRamp*. If the signals for changing the setpoint consist of pulses, these pulses must have a duration of at least 20 ms in order to be detected by the control circuit. The control electronics will respond to pulses for changing the setpoint only when the engine is running.

Setpoint changes will be possible until either maximum or minimum speed is attained. Furthermore, speed will be increased only if fuel quantity has not yet attained maximum limitation, and likewise decreased only, when fuel quantity has not yet attained minimum limitation. The current offset value of the digital pot can be viewed by the parameter 2041 *DigitalPotOffset*. With the engine standing, the accumulated offset will be cleared.

When there is a change-over to the digital potentiometer (de-activation of fixed speed or change-over from setpoint 1 to setpoint 2) the currently set speed is used as an initial value for the adjustment by the digital potentiometer.

7.6 Temperature dependent idle speed

When the engine is cold idle speed can be increased in dependence of temperature. Engine temperature $\hat{2907}$ *CoolantTemp* is sensed by a temperature sensor. If engine temperature falls below 62 *SpeedMinTempHigh*, idle speed is increased linearly until, with the engine at temperature 61 *SpeedMinTempLow*, it reaches the value 60 *SpeedMinAtTempLow*.



Note

This function is not available in control units of the ORION type.

Temperature dependent raising of idle speed will also be in effect during engine start as long as idle speed is pre-defined as speed setpoint. This does not depend on the selected start type.

Temperature dependent idle speed is activated by the parameter 4060 *SpeedMinTempOn* = 1.

Parameterizing Example:

Number	Parameter	Value	Unit
10	<i>SpeedMin1</i>	700	<i>rpm</i>
60	<i>SpeedMinAtTempLow</i>	950	<i>rpm</i>
61	<i>SpeedMinTempLow</i>	-20	$^{\circ}\text{C}$
62	<i>SpeedMinTempHigh</i>	10	$^{\circ}\text{C}$

Activation:

4060 <i>SpeedMinTempOn</i>	1
----------------------------	---




Fig. 14: Temperature dependent idle speed

7.7 Speed ramp

For prime movers of ships, locomotives and certain types of vehicles, it will be frequently desirable to have the speed not change abruptly when the set value is altered, but to make it attain the new setpoint smoothly.

To achieve this, the control provides ramps to retard acceleration. The delay rate of increasing or decreasing the set value can be adjusted separately in either direction. Furthermore, it is possible to decide on the type of speed ramp by means of the parameter

4232 *SectionalOrFixedRamp* = 0 fixed speed ramp

4232 *SectionalOrFixedRamp* = 1 sectional speed ramp.

The ramp functions are activated by the parameter 4230 *SpeedRampOn*.

7.7.1 Fixed speed ramp

With the fixed speed ramp, the rate by which the setpoint is delayed will be the same for the entire speed range. The ramp rates for ramping upward and downward can be separately set by means of the parameters

230 *SpeedRampUp* ramping rate for upward ramp

231 *SpeedRampDown* ramping rate for downward ramp.

The unit of these parameters is again given by speed increase or speed decrease per second. Both ramps are enabled through the parameter 4230 *SpeedRampOn*. For the fixed speed ramp, the parameter 4232 *SectionalOrFixedRamp* must in addition have been set to "0". If ramping is desired in one direction only, the maximum value (4000 rpm) is to be entered for the other direction.

The speed setpoint as delayed by the ramp can be viewed by the parameter 2032 *SpeedSetpRamp*. The parameter 2033 *SpeedSetpSelect* represents the speed setpoint that the ramp is supposed to ramp to.

Parameterizing Example:

It is wished to have a speed increase from 1000 rpm to 1,500 rpm within 20 seconds. This is equivalent to increasing speed by 500 rpm within 20 seconds or by 25 rpm per second. Deceleration is to work without a ramp.

Number	Parameter	Value	Unit
230	<i>SpeedRampUp</i>	25	<i>rpm/s</i>
231	<i>SpeedRampDown</i>	4000	<i>rpm/s</i>

Activation:

4230	<i>SpeedRampOn</i>	1
4232	<i>SectionalOrFixedRamp</i>	0

7.7.2 Sectional speed ramp

For certain applications, such as asynchronous generators or ship manoeuvring operation, it is desirable that the ramping rate be not the same over the entire speed range. To achieve this, the control offers the option to split the full speed range up into 3 sections and to set different ramping rates for each respective section. This also implies that the ramping rate will depend on the current setpoint value 2031 *SpeedSetp*.

The switch points where the ramping rate is to change are determined by these parameters

236	<i>SpeedSwitchToRamp2</i>	rate change from section 1 to section 2
237	<i>SpeedSwitchToRamp3</i>	rate change from section 2 to section 3

The various ramping rates by which the setpoint is to be delayed within the respective sections are set by means of the following parameters:

230	<i>SpeedRampUp</i>	ramp rate for ramping up in section 1
231	<i>SpeedRampDown</i>	ramp rate for ramping down in section 1
232	<i>SpeedRampUp2</i>	ramp rate for ramping up in section 2
233	<i>SpeedRampDown2</i>	ramp rate for ramping down in section 2
234	<i>SpeedRampUp3</i>	ramp rate for ramping up in section 3
235	<i>SpeedRampDown3</i>	ramp rate for ramping down in section 3

The unit of these parameters is again given by speed increase or -speed decrease per second. The ramps are enabled via the parameter 4230 *SpeedRampOn*, selection of the sectional speed ramp is made by setting 4232 *SectionalOrFixedRamp* = 1.

When only two ramp sections are to be used then the switching point 2, i.e. parameter 237 *SpeedSwitchToRamp3* must be set to maximum speed value.

The speed setpoint as delayed by the ramp can be viewed by the parameter 2032 *SpeedSetpRamp*. The parameter 2033 *SpeedSetpSelect* represents the speed setpoint that the ramp is supposed to ramp to.




Fig. 15: Speed profile of sectional speed ramp

Parameterizing Example:

The upward ramping rate between minimum speed and 800 rpm is supposed to be 100 rpm/s, and speed reduction to be performed as fast as possible. The upward ramping rate between 800 rpm and 1200 rpm is to be 50 rpm/s, the downward ramping rate 40 rpm/s. Between 1200 rpm and maximum speed both the upward and downward rates shall be 20 rpm/s.

Number	Parameter	Value	Unit
230	<i>SpeedRampUp</i>	100	<i>rpm/s</i>
231	<i>SpeedRampDown</i>	4000	<i>rpm/s</i>
232	<i>SpeedRampUp2</i>	50	<i>rpm/s</i>
233	<i>SpeedRampDown2</i>	40	<i>rpm/s</i>
234	<i>SpeedRampUp3</i>	20	<i>rpm/s</i>
235	<i>SpeedRampDown3</i>	20	<i>rpm/s</i>
236	<i>SpeedSwitchToRamp2</i>	800	<i>rpm</i>
237	<i>SpeedSwitchToRamp3</i>	1200	<i>rpm</i>

Activation:

4230	<i>SpeedRampOn</i>	1
4232	<i>SectionalOrFixedRamp</i>	1

7.8 Droop

Droop (also called proportional band) of an engine is defined as the permanent speed drop when the engine takes on load. It is desirable that droop and, hence, speed drop be equal to zero (isochronous operation). For certain applications, however, droop will be required, e.g. for

- ◆ Vehicle operation
- ◆ Isolated and mains parallel operation of generator sets, when no accessory units by **HEINZMANN** are being used
- ◆ special load sharing modes, e.g., parallel operation with mechanical governors.

The settings explained in the following section refer to variable speed operation. For vehicle operation by \uparrow 12.1 *Idle/maximum speed control*, droop can independently be adjusted for idle and maximum speed control.

In isochronous operation without droop, any fuel quantity may be set with a pre-defined fixed speed setpoint. When using droop, however, there is a close interrelation between speed and fuel quantity. In this case, the pre-defined speed setpoint corresponds to that for full load. Depending on current load, droop is used to calculate an offset which after being added to the given speed setpoint will yield the actual speed setpoint for the control unit.

Activation of droop is achieved by setting the parameter 4120 *DroopOn* = 1.



Note

*Droop is automatically disabled in generator operation when load control by an external device is enabled with 5230 *LoadControlOrPot* = 1 and 2835 *SwitchLoadEnable* is either not wired or = 1.*

To accommodate droop to the current operating state of the controlled engine, the possibility of choosing between two droops has been provided. A switching function 2812 *SwitchDroop2Or1* is provided to select the droop by which the control is supposed to operate. The respective selection is indicated by:

2812 *SwitchDroop2Or1* = 0 Control is operating by droop 1 (120 *Droop1*)

2812 *SwitchDroop2Or1* = 1 Control is operating by droop 2 (125 *Droop2*)

If measured power is available in 2918 *MeasuredPower* and 4121 *DroopLoadOrFuel* is active, droop is calculated on load-basis. 1232 *RatedPower* shows the value for 100 % load in the range of 2918 *MeasuredPower*.

If measured power is not available or the sensor is down, droop is calculated on the basis of the actuator reference values for zero load and full load – these should therefore always be parameterized even if they are not used during normal operation.

The reference point for the droop is determined by parameter 4122 *Droop@ZeroOrFullLoad*. The full load point is used whenever the parameter is 0 but the zero load point becomes active when the parameter is 1.




Fig. 16: Droop with full load reference




Fig. 17: Droop with zero load reference

The following section only explains the adjustment of droop 1, since the adjustment of droop 2 is identical. Frequently only one switch position of 2812 *SwitchDroop2Or1* is used with droop, and the other is assigned a value of 0%.

The following relation holds:

$$X_p = \frac{n_0 - n_v}{n_v} \cdot 100\%$$

Example:

Full-load speed: 1500 rpm

Zero-load speed: 1560 rpm

$$P - \text{Bereich} = \frac{1560 - 1500}{1500} * 100\% = 4\%$$

Any adjustment of droop refers to the reference speed as set by 123 *Droop1SpeedRef* (or 128 *Droop2SpeedRef* for droop 2). Thus, e.g., for a reference speed of 123 *Droop1SpeedRef* = 1500 rpm, a droop of 120 *Droop1* = 4 % will yield a speed change of 60 rpm.

This speed change, however, will apply only to the working range between full-load and zero-load. As reference values the measurements of 2918 *MeasuredPower* with 1232 *RatedPower* for full-load and 0 % (resp. 0 kW) for zero-load are used. If no load measurement data are available, the reference points of fuel quantities 122 *Droop1RefHigh* and 121 *Droop1RefLow* are used. For correct adjustment therefore the full-load fuel quantity 122 *Droop1RefHigh* and the zero-load fuel quantity 121 *Droop1RefLow* (resp. 127 *Droop2RefHigh* and 126 *Droop2RefLow* for droop 2) at reference speed must be known.

The droop offset will be the same over the entire speed range. Using the values of the above example, the offset for idle speed 700 rpm will also be 60 rpm between zero load and full load. The relative droop, however, as relating to the current speed setpoint will change within the speed range. In the example, it will be 8.6 % at 700 rpm, 4 % at reference speed 1500 rpm and, accordingly, 2.9% at maximum speed 2100 rpm, each time calculated from the fixed offset of 60 rpm.

The current relative droop as relating to the current speed setpoint is indicated by the parameter 2120 *DroopPresent*. The speed offset as calculated from droop can be viewed by the parameter 2040 *DroopOffset*. This offset is added to the speed setpoint value after the ramp 2032 *SpeedSetpRamp* thus yielding the speed setpoint 2031 *SpeedSetp* for the control unit.

Parameterizing Example:

Number	Parameter	Value	Unit
10	<i>SpeedMin1</i>	700	<i>rpm</i>
12	<i>SpeedMax1</i>	2100	<i>rpm</i>

120	<i>Droop1</i>	4	%
121	<i>Droop1RefLow</i>	20	%
122	<i>Droop1RefHigh</i>	80	%
123	<i>Droop1SpeedRef</i>	1500	<i>rpm</i>

Indication at minimum speed and zero-load quantity:

2031	<i>SpeedSetp</i>	760	<i>rpm</i>	
2032	<i>SpeedSetpRamp</i>	700	<i>rpm</i>	(independent of quantity)
2033	<i>SpeedSetpSelect</i>	700	<i>rpm</i>	(independent of quantity)
2040	<i>DroopOffset</i>	60	<i>rpm</i>	
2120	<i>DroopPresent</i>	2.9	%	
2812	<i>SwitchDroop2Or1</i>	0		

Activation:

4120	<i>DroopOn</i>	1	
------	----------------	---	--

Parameterizing Example 2:

Number	Parameter	Value	Unit
10	<i>SpeedMin1</i>	700	<i>rpm</i>
12	<i>SpeedMax1</i>	2100	<i>rpm</i>
120	<i>Droop1</i>	4	%
121	<i>Droop1RefLow</i>	20	%
122	<i>Droop1RefHigh</i>	80	%
123	<i>Droop1SpeedRef</i>	1500	<i>rpm</i>
4122	<i>Droop@ZeroOrFullLoad</i>	1	

Indication at minimum speed and zero-load quantity:

2031	<i>SpeedSetp</i>	700	<i>rpm</i>	
2032	<i>SpeedSetpRamp</i>	700	<i>rpm</i>	(independent of quantity)
2033	<i>SpeedSetpSelect</i>	700	<i>rpm</i>	(independent of quantity)
2040	<i>DroopOffset</i>	0	<i>rpm</i>	
2120	<i>DroopPresent</i>	0.0	%	
2812	<i>SwitchDroop2Or1</i>	0		

Activation:

4120	<i>DroopOn</i>	1	
------	----------------	---	--



Since droop offset is added to speed setpoint value, when droop is used the value range of minimum and maximum speed relates only to the full-load reference points. Below this quantity, or below 100% load respectively, droop increases minimum and maximum speed.

8 Optimizing control circuit stability

Once the engine is running, the first step should always be to optimize control circuit stability. With diesel engines operating permanently at constant speeds (e.g., generator operation), a basic adjustment of the PID parameters will do. For other applications, it may prove necessary to correct the PID parameters in dependence of speed or injection quantity. This may particularly be required for engines with large ranges of speed variation. The following chapters cover the adjustment of the PID parameters as well as the speed and fuel dependent correction of the PID values.

8.1 Adjustment of PID parameters

Adjustment of the PID parameters will always be the first step to be taken. The values defined at this stage will serve as a basis for all subsequent corrections. During adjustment, any other functions affecting control circuit stability must be de-activated.

When optimizing the PID parameters, the initial values are to be set as follows:

Number	Parameter	Value	Unit
100	Gain	15	%
101	Stability	10	%
102	Derivative	0	%

NOTICE

Before starting the engine ensure separate overspeed protection independent of the rpm controller!

With these values set, the engine is started and run up to the working point for which the adjustment is to be made. As a rule, this working point will be at rated speed and off-load. For optimization of the PID parameters, proceed by the following steps:

- ◆ Increase the P-factor 100 Gain until the engine tends to become unstable. Then, decrease the P-factor again until the speed oscillations disappear or are reduced to a moderate level.
- ◆ Increase the I-factor 101 Stability until the engine passes over to long-waved speed oscillations.
- ◆ Increase the D-factor 102 Derivative until the speed oscillations disappear. If the oscillations cannot be eliminated by the D-factor, the I-factor will have to be reduced.

With these values set, disturb engine speed for a short moment (e.g., by shortly operating the engine stop switch) and observe the transient response. Continue to modify the PID parameters until the transient response is satisfactory.

The fuel setpoint value as determined by the control circuit is indicated by the parameter 2110 *FuelSetpSpeedGov*. This value is limited by [↑]9 *Limiting Functions* and will then yield the fuel setpoint 2350 *FuelQuantity*.

8.2 PID map

As speed goes up, the engine's kinetic energy is equally bound to increase. With regard to the governor, this implies that its characteristic dynamics values (PID) may also have to be increased. When the engine takes on load, the remaining free engine acceleration is reduced which in turn may admit of another increase of the dynamic parameters.

Normally, the PID parameters are set at rated speed and off-load. As a consequence, it may be desirable to reduce the PID values for minimum speed and to increase the PID values for load. The PID parameters as set for rated speed and off-load (*↑ 8.1 Adjustment of PID parameters*) will serve as a basis for correction. Setting the correction value to 100 % will leave the PID parameters unaltered. Starting from this value, correction can be made in upward direction (maximum 400 %, which will be equivalent to increasing the PID parameters four times) as well as in downward direction (though 0 % is the minimum possible value, values below 10 % should never be entered).



Note

Although it is called PID map the correction will change only gain and stability (P and I) parameters.

The values for the stability map are stored under the following parameter numbers:

6100 to 6109 <i>PIDMap:n(x)</i> :	Speed values for stability map
6150 to 6159 <i>PIDMap:f(y)</i> :	Fuel quantity values for stability map
6200 to 6299 <i>PIDMap:Corr(z)</i> :	Correction values for stability map.



Note

*If the control unit in generator sets contains an integrated power governor in addition to the speed governor, the map parameters for the speed control circuit will be called *PIDMapSpGov* instead of *PIDMap*. The parameter numbers remain the same.*

Because of the pressure governor, in gas engines it is not advisable to relate the PID map to fuel quantities. In generator applications, if a measured power value can be made available in 2918 *MeasuredPower* it is advisable to use the speed- and load-dependent PID map

6100 through 6109 <i>PIDMap:n(x)</i> :	Speed values for stability map
6350 through 6359 <i>PIDMap:P(y)</i> :	Load values for stability map
6200 through 6299 <i>PIDMap:Corr(x)</i> :	Correction values for stability map.

In case of general activation of the map with 4100 *PIDMapOn* = 1, the map type is selected by

4101 <i>PIDMapPowOrFuel</i> = 0	dependent on speed and fuel quantity
4101 <i>PIDMapPowOrFuel</i> = 1	dependent on speed and load.

10 base points each are available for correction implying a maximum number of 100 correction values. A base point consists of a speed value and a fuel quantity/load value and

of the respective correction value. For adjacent correction values the intermediary values are interpolated by the control. If PID correction is performed in dependence of either speed or fuel quantity/load alone, any unused values must be set to zero (\uparrow 3.8 *Parameterization of maps*).

If the current working point of the engine lies outside the map as specified by the mapping parameters, the control will calculate the value which is located on the border of the map and take this as the associated correction value.

The actual correction value which is being used to correct the PID parameters with regard to the current working point can be viewed by the parameter 2100 *PID_CorrFactor*. With this correction value the parameters 100 *Gain* for the P-factor and 101 *Stability* for I-factor can be changed in per cent values and fed to the control circuit. The stability map is activated by means of the parameter 4100 *PIDMapOn*.

In the examples below, correction of PID parameters will be explained using two correction values for each case and correspondingly four values for the characteristic map



The HEINZMANN PC programme \uparrow 3.3 DcDesk 2000 provides an easy and comfortable way of adjusting the map as it allows to have the map displayed three-dimensionally and to view the adjustment values listed in tables.

8.2.1 Speed dependent correction of PID parameters

The PID values are entered for maximum speed, and on setting the engine into operation off-load they are adjusted accordingly. For minimum speed, a downward correction is entered and suitably adjusted on the engine.




Fig. 18: Speed dependent correction

Parameterizing Example:

Number	Parameter	Value	Unit
6100	PIDMap:n(0)	700	rpm
6101	PIDMap:n(1)	2100	rpm
6102	PIDMap:n(2)	0	rpm
:	:	:	:
6109	PIDMap:n(9)	0	rpm
6150	PIDMap:f(0)	0	%
:	:	:	:
6159	PIDMap:f(9)	0	%
6200	PIDMap:Corr(0)	60	%
6201	PIDMap:Corr(1)	100	%

Activation:

4100	PIDMapOn	1
------	----------	---

8.2.2 Load dependent correction of PID parameters

8.2.2.1 Diesel engine

Input of the values and adjustment with the engine running is done off-load. For full-load, an upward correction is provided. Normally, setting the actuator position values to 20 % for off-load and to 80 % for full-load will prove sufficiently accurate.




Fig. 19: Load dependent correction in diesel engines

Parameterizing Example:

Number	Parameter	Value	Unit
6100	PIDMap:n(0)	0	rpm
:	:	:	:
6109	PIDMap:n(9)	0	rpm

6150	PIDMap:f(0)	20	%
6151	PIDMap:f(1)	80	%
6152	PIDMap:f(2)	0	%
:	:	:	
6159	PIDMap:f(9)	0	%
6200	PIDMap:Corr(0)	100	%
6210	PIDMap:Corr(10)	150	%

Activation:

4100 PIDMapOn 1


8.2.2.2 Gas engine

Fig. 20: Performance graph of gas engine in dependence of throttle valve position

With gas engines, it is of particular importance that PID correction be carried out in dependence of load. The foregoing diagram \uparrow Fig. 20: *Performance graph of gas engine in dependence of throttle valve position* depicts the performance curve versus throttle valve position. The lower domain is characterized by a fast increase of power output, while in the upper domain there is only a modest rise. For optimum control, these facts must particularly be taken into account.




Fig. 21: Load dependent correction in gas engines

As explained in the previous section, adjustment of PID values is done for no-load and correction for full-load. For a majority of applications, the inflexion points for actuator travel can be set to 35 % and 60 %. It may, however, prove necessary to readjust these values with regard to specific requirements.

Parameterizing Example:


Number	Parameter	Value	Unit
6100	PIDMap:n(0)	0	rpm
:	:	:	
6109	PIDMap:n(9)	0	rpm
6150	PIDMap:f(0)	35	%
6151	PIDMap:f(1)	60	%
6152	PIDMap:f(2)	0	%
:	:	:	
6159	PIDMap:f(9)	0	%
6200	PIDMap:f(0)	100	%
6210	PIDMap:f(10)	200	%

Activation:

4100	PIDMapOn	1
------	----------	---

8.2.3 Stability map

When setting the PID parameters for the map, the parameters are to be modified depending on both speed and load. This may be required, e.g., for engines with large ranges of speed variation.



- 1 Setting the PID values at maximum speed and off- load
- 2 (-) Correction value at minimum speed and off- load
- 3 (+) Correction at maximum speed and full-load
- 4 (-) Correction at minimum speed and full-load

Fig. 22: Stability map

The basic setting is done at rated speed and off-load (point 1). Then the first correction (point 2) is made at minimum speed and off-load. The next correction (point 3) is carried out at rated speed and full load, and finally the last correction (point 4) is made at minimum speed and with the respective load.

Parameterizing Example:

Number	Parameter	Value	Unit	
6100	PIDMap:n(0)	700	rpm	
6101	PIDMap:n(1)	2100	rpm	
6102	PIDMap:n(2)	0	rpm	
:	:	:		
6109	PIDMap:n(9)	0	rpm	
6150	PIDMap:f(0)	20	%	
6151	PIDMap:f(1)	80	%	
6152	PIDMap:f(2)	0	%	
:	:	:		
6159	PIDMap:f(9)	0	%	
6200	PIDMap:Corr(0)	60	%	(point 2)
6201	PIDMap:Corr(1)	100	%	(point 1)
6210	PIDMap:Corr(10)	90	%	(point 4)
6211	PIDMap:Corr(11)	150	%	(point 3)

Activation:

4100	PIDMapOn	1
------	----------	---

8.3 Second PID parameter set

For certain generator applications it might be necessary to switch between two PID settings, for instance in case of emergency power sets with very large flywheel mass. This function is available on request.

The parameters of the second set are located in

105 <i>Gain2</i>	P-factor 2
106 <i>Stability2</i>	I-factor 2
107 <i>Derivative2</i>	D-factor 2
6100 to 6109 <i>PIDMap:n(x)</i>	speed values for stability maps 1 and 2
6150 to 6159 <i>PIDMap:f(y)</i> resp.	fuel values for stability maps 1 and 2
6350 to 6359 <i>PIDMap:P(y)</i>	power values for stability maps 1 and 2
9900 to 9999 <i>PIDMap2:Corr(z)</i>	correction values for stability map 2

For the second PID map the same supporting points as for the first map are used, whereby 4101 *PIDMapPowOrFuel* is also taken into account. Setting and optimization are performed in the same way as described in [↑ 8.1 Adjustment of PID parameters](#) and [↑ 8.2 PID map](#).

The switching between the two parameter sets occurs online with the switching function 2841 *SwitchPID2Or1*:

2841 <i>SwitchPID2Or1</i> = 0	the first PID set is used
2841 <i>SwitchPID2Or1</i> = 1	the second PID set is used.

8.4 Temperature dependent correction of stability

While the engine is still cold, it may show a tendency for speed oscillations regardless of the stability map. In this event, the stability map can be corrected in dependence of temperature.



This function is not available in ORION.

Note

Depending on the engine, the map is corrected in upward or downward direction.

Engine temperature [↑ 2907 CoolantTemp](#) is sensed by a temperature sensor. If engine temperature falls below the high value for the cold engine 162 *PID_CorrTempHigh* the entire characteristic map is corrected by the value calculated by the control in accordance with the following figure. If engine temperature falls below the low value for the cold engine 161 *PID_CorrTempLow* the characteristic map is corrected by the value given by 160 *PID_ColdCorr*.




Fig. 23: Temperature dependent correction of stability

This function is enabled by setting the parameter 4160 *PIDTempOn* = 1.

Parameterizing Example:

Number	Parameter	Value	Unit
160	<i>PID_ColdCorr</i>	60	%
161	<i>PID_CorrTempLow</i>	-20	°C
162	<i>PID_CorrTempHigh</i>	10	°C

Activation:


4160	<i>PIDTempOn</i>	1
------	------------------	---

8.5 Correction of PID parameters for static operation

When running engines with small load flywheel effects, load changes may result in considerable speed drops or speed rises. This is caused mainly by the fact that the control's P-factor (gain) required for the engine to run smoothly in steady-state operation is rather small. As a countermeasure, the HEINZMANN control units offer the option to adjust the PID values for dynamic operation and to reduce them for static (steady-state) operation. By this, it can be ensured that the engine runs properly after having attained steady-state operation and that the governor still remains capable of reacting quickly to load changes.

If speed deviation remains within the range of 111 *StaticCorrRange* the P and D parameters will be corrected by the value given by 110 *StaticCorrFactor*. Outside twice this range, the normal parameters will be valid. If speed deviation is somewhere in between, there will be interpolation to ensure smooth transition. This function is enabled by the parameter 4110 *StaticCorrOn* = 1.

The value of 110 *StaticCorrFactor* should be set to 40-70 %.


Fig. 24: Correction for static operation

Parameterizing Example:

Number	Parameter	Value	Unit
110	<i>StaticCorrFactor</i>	50	%
111	<i>StaticCorrRange</i>	20	<i>rpm</i>

Activation:

4110	<i>StaticCorrOn</i>	1
------	---------------------	---

8.6 Load jump regulation in generator systems (DT1 factor)

In addition to the factors P, I and D it is possible to pre-set a DT1 factor for the speed control circuit which allows to correct load jumps faster and better. To this purpose either a load jump detector or a speed jump detector is required.

For load jump detection, information on current load must be available in 2918 *MeasuredPower*. If current load is not measured, a load jump can alternatively be identified by a speed jump. Added load causes speed undershooting and dropped load causes speed overshooting. The function to use (load jump detection or speed jump detection) can be selected separately.

The reaction to load jumps must be observed at the engine, in order to derive the threshold values and the DT1 factor. The aim is a reduction of speed overshooting and undershooting and a shortening of transient time. The control circuit takes the DT1-factor into account only if the respective function is active.

It doesn't make sense to activate both functions at the same time, for this can result in an undesired amplification of speed deviation in the opposite direction. But it may be useful to test both variants in order to be identify the variant that is better suited. Depending on the load measurement unit used, it is possible that load jump recognition from load change takes longer than from speed change – and this is a matter where quick reaction is of crucial importance. The DT1-factor can be activated in addition to rapid power cut-off (↑ 8.7 *Load shedding in generator systems*).

Load and speed jump monitoring by principle becomes active only above the speed threshold 28 *DTISpeedThreshold*, which should be set far enough below rated speed to enable the registering of speed undershooting. Both the speed setpoint 2031 *SpeedSetp* and actual speed 2000 *Speed* must be above this threshold.

To prevent a false interpretation of speed setpoint jumps, an additional maximum admissible speed setpoint difference should be set in 29 *DTISpeedSpDiffThresh*. This condition becomes active only if load jump recognition by speed jump is active. Only if the speed setpoint changes by less than 29 *DTISpeedSpDiffThresh* the speed jump is reacted on in the sense of a load jump. It does not make sense to enter the value 0 since especially in generator systems the speed setpoint is changed continually for adjustment to the load.

Load gradient (load change rate) 2029 *LoadGradientDTI* is determined on the basis of 2918 *MeasuredPower* through the filter 35 *PowerGradDTIFilter* and speed gradient (speed change rate) 2028 *SpeedGradientDTI* is calculated from 2000 *Speed* through the filter 33 *SpeedGradDTIFilter*.

A load jump is recognized and indicated in 2122 *LoadJumpActive* if the value of the load gradient 2029 *LoadGradientDTI* is higher than 34 *LoadGradDTIThresh*. A speed jump is recognized and indicated in 2121 *SpeedJumpActive* if the value of the speed gradient 2028 *SpeedGradientDTI* exceeds 32 *SpeedGradDTIThresh*.

To the load gradient the amplification factor 104 *LoadDTI* is multiplied and transmitted as additive factor to the PID control circuit if the function has been activated with 4029 *LoadGradientDTIOn* = 1. To the speed gradient the DTI-factor 103 *SpeedDTI* is multiplied and transmitted to the PID control circuit as new additional part, if the function has been activated with 4028 *SpeedGradientDTIOn* = 1.

The load jump or the resulting speed jump are regarded as compensated when speed 2000 *Speed* stays within the range +/- 30 *DTISpeedDiffMax* around the current speed setpoint for the duration of 31 *DTISpeedDiffTime*.

Parameterizing Example:

Number	Parameter	Value	Unit
28	<i>DTISpeedThreshold</i>	1350	<i>rpm</i>
29	<i>DTISpeedSpDiffThresh</i>	25	<i>rpm</i>
30	<i>DTISpeedDiffMax</i>	10	<i>rpm</i>
31	<i>DTISpeedDiffTime</i>	3	<i>s</i>
32	<i>SpeedGradDTIThresh</i>	20	<i>rpm/s</i>
33	<i>SpeedGradDTIFilter</i>	8	
34	<i>LoadGradDTIThresh</i>	10	<i>%/s</i>
35	<i>LoadGradDTIFilter</i>	8	
103	<i>SpeedDTI</i>	30	<i>%</i>
104	<i>LoadDTI</i>	25	<i>%</i>
2028	<i>SpeedGradientDTI</i>	300	<i>rpm/s</i>
2029	<i>LoadGradientDTI</i>	150	<i>%/s</i>
2121	<i>SpeedJumpActive</i>	0/1	
2122	<i>LoadJumpActive</i>	0/1	

Activation:

4028	<i>SpeedGradientDT1On</i>	1
4029	<i>LoadGradientDT1On</i>	1

8.7 Load shedding in generator systems

Opening the generator contactor under load (e.g. during power failure) may lead to great speed overshoots. In order to react quickly in such cases and to minimize the overshoot, the opening of the contactor can be used to bring the speed control immediately to reduce to zero-load fuel quantity. To do so, the generator contactor must be connected to the switch function 2846 *SwitchGenBreaker*. Zero-load fuel quantity is set in 352 *FuelAtZeroLoad*. In addition, the control unit continually determines the effective value of minimal fuel quantity, which can be lower than the value of the parameter.

The function “Quick power cut-off” is an additional aid when it comes to reducing a considerable positive speed deviation very quickly. This function is used mainly to minimize speed overshoot during load shedding. Rapid power cut-off can be activated in addition to the speed-regulating DT1-factor (↑ 8.6 *Load jump regulation in generator systems (DT1 factor)*).

The quick power cut-off is most effective with actuators that respond to the 2Q output stage of the control unit, i.e. when 5911 *Amplifier2QOr4Q* is active. For actuators addressed by a 4Q output stage it is recommended to test the effect first and to activate the function only if the effect is positive. The function quick power cut-off is effective only if 1810/3810 *OperationMode* is set to 3 for generator systems.



Note

This function may not be activated when using the Bosch EDC pump or the HEINZMANN linear actuator type LStG 25 – in general, whenever an actuator with linear magnets is used.

When both the speed setpoint 2031 *SpeedSetp* and the current speed 2000 *Speed* have exceeded the threshold 28 *DTISpeedThreshold* and the current speed gradient 2025 *SpeedGradient* exceeds the threshold 320 *CurrShutOffGradient*, fuel feeding is stopped immediately by energizing the output stage addressing the actuator in direction 0%. 28 *DTISpeedThreshold* must be set far enough under rated speed to allow for the identification of speed undershoot.



Note

*The DT1-factor of the speed control becomes active when the filtered speed gradient 2028 *SpeedGradientDT1* exceeds a pre-set threshold. Quick power cut-off can react quicker since it monitors the unfiltered speed gradient 25 *SpeedGradient*. On the other hand, this also means that the gradient threshold 320 *CurrShutOffGradient* must be determined with greater accuracy since the unfiltered value can be very unstable.*

Attention must be paid to the fact that when the function quick power cut-off is active no control by output of a defined actuator position is possible and the time quick power cut-off lasts therefore should be not long enough to allow strong undershoot. Therefore the power cut-off is terminated automatically as soon as speed ceases to increase, at the latest after decurrence of the interval pre-set in 321 *CurrentShutOffTime*. After each quick power cut-off the function is interdicted for 500 ms. Within this time span the speed jump is compensated.

The current used for energizing the actuator in direction 0 % must be pre-set in 322 *CurrentShutOff*. Due to the relatively short duration of the quick power cut-off function this current may be higher than the maximum current 1917 *ServoCurrentMax*.

The function quick power cut-off is activated with parameter 4320 *CurrentShutOff* = 1.

Parameterizing Example:

Number	Parameter	Value	Unit
28	<i>DTISpeedThreshold</i>	1350	<i>rpm</i>
320	<i>CurrShutOffGradient</i>	300	<i>rpm/s</i>
321	<i>CurrentShutOffTime</i>	50	<i>ms</i>
322	<i>CurrentShutOff</i>	70	%
2025	<i>SpeedGradient</i>	55	<i>rpm/s</i>

Activation:

4320 *CurrentShutOffOn*

9 Limiting Functions

For optimum engine performance, it is necessary that the control provide various limitations of fuel injection quantity. The following figure gives an overview of the most significant limiting functions.




Fig. 25: Important limiting functions

If different limiting functions are operable, the one yielding the smallest fuel quantity value will override all others. The presently valid fuel quantity is indicated by the parameter 2350 *FuelQuantity*. In addition, unlimited fuel quantity is transmitted by parameter 2114 *FuelSetpointUnlimited*.

The parameter 711 *FuelLimitMaxAbsolute* can be used to define a fixed maximum injection limit. This limit value will always be active.



During start-up, the speed and boost pressure dependent fuel limitations are disabled (↑ 5 Starting fuel limitation).

Parameters 2700 through 2721 are provided to indicate the maximum fuel quantity admissible under the current operating conditions (speed, boost pressure) and to display which limiting function is presently enabled. These parameters are listed and described in ↑ *Table 16: Limiting functions*.

Indication Parameter	Meaning
2701 <i>FuelLimitMax</i>	Currently admissible maximum fuel
2702 <i>FuelLimitStart</i>	Currently admissible maximum starting fuel
2703 <i>FuelLimitSpeed</i>	Currently valid speed dependent fuel limit
2704 <i>FuelLimitBoost</i>	Currently valid boost dependent fuel limit
2705 <i>FuelLimitForced</i>	Currently valid fuel limit as resulting from forced limitation
2722 <i>FuelLimitAsymLoad</i>	Currently valid fuel limit as resulting from externally set asymmetrical load
2923 <i>FuelLimitExtern</i>	externally forced limitation
2710 <i>FuelLimitMinActive</i>	1 = for lower limit
2711 <i>FuelLimitMaxActive</i>	1 = for upper limit
2712 <i>StartLimitActive</i>	1 = for starting fuel limitation
2713 <i>SpeedLimitActive</i>	1 = for speed dependent limitation
2714 <i>BoostLimitActive</i>	1 = for boost pressure dependent limitation
2715 <i>ForcedLimitActive</i>	1 = for external forced limitation
2720 <i>FuelLimitExtActive</i>	1 = for externally set limitation
2721 <i>AsymLoadLimitActive</i>	1 = for externally set asymmetrical load limitation

Table 16: Limiting functions

When 4724 *CheckFuelLimitOn* is set, 2724 *NearFuelLimitActive* indicates when current fuel quantity is closer than 724 *FuelLimitDistance* from the current limit 2701 *FuelLimitMax*. If 2724 *NearFuelLimitActive* is fed into a digital output, it is possible to warn the operator when he is running the engine close to its load limit ($\hat{20.8}$ Digital outputs).

9.1 Speed dependent fuel limitation

The speed dependent full-load limiting characteristic determines the maximum admissible amount of fuel (actuator travel, and resulting torque) the engine may be supplied for at a certain speed.




Fig. 26: Speed dependent fuel limitation

For adaptation to engine operating conditions, two different speed dependent limiting functions can be provided as alternatives, e.g., one for driving operation and one for stationary operation – albeit not for the systems PANDAROS and ORION that feature only one full load characteristic. For driving operation limitation is normally defined with regard to the requirements of the prime mover, for stationary operation, however, with regard to the working machine.

A switching function $2817 \text{ SwitchSpeedLimit2Or1}$ serving as a selector switch between the two speed dependent limiting functions is provided to select the limiting function by which the control is supposed to operate. The currently active function is indicated by:

$2817 \text{ SwitchSpeedLimit2Or1} = 0$ Limiting function 1 is active.

$2817 \text{ SwitchSpeedLimit2Or1} = 1$ Limiting function 2 is active.

The values defining the full-load characteristics are stored at the following parameter positions:

6700 through 6729 $\text{SpeedLimit1:n}(x)$ Speed values for full-load curve 1

6750 through 6779 $\text{SpeedLimit1:f}(x)$ Fuel quantity for full-load curve 1

6800 through 6829 $\text{SpeedLimit2:n}(x)$ Speed values for full-load curve 2

6850 through 6879 $\text{SpeedLimit2:f}(x)$ Fuel quantity for full-load curve 2

Parameterization is to be conducted according to [↑ 3.7 Parameterization of characteristics](#). There are up to 30 pairs of programmable values available. The characteristics are enabled by setting the parameter $4700 \text{ SpeedLimitOn} = 1$.

Parameterization Example:

Parameterization is to be made for a full-load characteristic consisting of 6 pairs:

Number	Parameter	Value	Unit	Number	Parameter	Value	Unit
6700	SpeedLimit1:n(0)	500	rpm	6750	SpeedLimit1:f(0)	60	%
6701	SpeedLimit1:n(1)	700	rpm	6751	SpeedLimit1:f(1)	70	%
6702	SpeedLimit1:n(2)	1100	rpm	6752	SpeedLimit1:f(2)	80	%
6703	SpeedLimit1:n(3)	1500	rpm	6753	SpeedLimit1:f(3)	86	%
6704	SpeedLimit1:n(4)	2100	rpm	6754	SpeedLimit1:f(4)	82	%
6705	SpeedLimit1:n(5)	2500	rpm	6755	SpeedLimit1:f(5)	75	%
6706	SpeedLimit1:n(6)	0	rpm	6756	SpeedLimit1:f(6)	0	%
:	:	:	:	:	:	:	:
6729	SpeedLimit1:n(29)	0	rpm	6779	SpeedLimit1:f(29)	0	%

Activation:

4700 SpeedLimitOn 1

For speeds below the first of the parameterized speed values, the control will limit actuator travel to the first of the parameterized fuel values. Thus in the above example, actuator travel is limited to 60 % for the range from 0 to 500 rpm. Likewise, for speeds beyond the last of the parameterized speed values (in the above example 2,500 rpm) actuator travel will remain limited to the last parameterized fuel value (in the above example 75 %).

If this is not desirable, an additional pair of values should be programmed with the fuel value set to 0 %. This will be a counterpart of the absolute limit line as known from other controls (dashed line in $\hat{\uparrow}$ Fig. 26: *Speed dependent fuel limitation*).

Number	Parameter	Value	Unit	Number	Parameter	Value	Unit
6706	SpeedLimit1:n(6)	2510	rpm	6756	SpeedLimit1:f(6)	0	%

The parameter

2713 SpeedLimitActive = 0 Fuel limitation currently not enabled

2713 SpeedLimitActive = 1 Limitation currently enabled

permits to check upon whether or not this limitation is currently in effect. The actual limiting value is indicated by the parameter 2703 *FuelLimitSpeed*.

9.1.1 Temperature dependent reduction of full-load characteristic

To protect the engine against possible damages from high temperatures the full-load characteristic ($\hat{\uparrow}$ 9.1 *Speed dependent fuel limitation*) can be lowered in dependence of temperature.



Note

This function is not available in ORION systems.




Fig. 27: Temperature dependent reduction of full-load characteristic

Engine temperature ($\hat{\uparrow}$ 2907 *CoolantTemp*) is sensed by a temperature sensor. If engine temperature rises above the value 702 *SpeedLimitTempLow* the complete full-load characteristic is lowered in dependence on temperature. If engine temperature exceeds the value given by 703 *SpeedLimitTempHigh* there will be a constant decrease by the value 701 *SpeedLimitTempDec* (absolute fuel).

This function is activated by parameter 4701 *SpeedLimitTempOn*.

Parameterization Example:

Number	Parameter	Value	Unit
701	<i>SpeedLimitTempDec</i>	2	%
702	<i>SpeedLimitTempLow</i>	90	°C
703	<i>SpeedLimitTempHigh</i>	110	°C

Activation:

4701	<i>SpeedLimitTempOn</i>	1
------	-------------------------	---

In case further temperature-dependent reductions of full-load characteristic are implemented, the parameter names change from a temperature-dependent reduction to a coolant temperature-dependent reduction. *SpeedLimitTemp* becomes *SpeedLimCoolTemp*. This does not imply, however, any changes with respect to their meaning.

9.1.2 Other temperature dependent reductions of full-load characteristic

Whenever there are more temperatures to take into account, the firmware can on request be complemented with additional temperature dependent reductions of full-load

characteristic. This refers to charge air temperature, exhaust temperature and oil temperature.



Note

This function is not available in ORION systems.

Their functioning is identical to coolant temperature dependent reduction. The following parameters must be referred to:

Charge air temperature dependent reduction

690 *SpeedLimChAirTempDec*

691 *SpeedLimChAirTempLow*

692 *SpeedLimChAirTmpHigh*

2908 *ChargeAirTemp*

4690 *SpeedLimitChAirTmpOn*

Exhaust gas temperature dependent reduction

695 *SpeedLimExhTempDec*

696 *SpeedLimExhTempLow*

697 *SpeedLimExhTempHigh*

2911 *ExhaustTemp*

4695 *SpeedLimitExhTempOn*

Oil temperature dependent reduction

705 *SpeedLimOilTempDec*

706 *SpeedLimOilTempLow*

707 *SpeedLimOilTempHigh*

2909 *OilTemp*

4705 *SpeedLimitOilTempOn*

9.2 Boost pressure dependent fuel limitation

The boost pressure dependent limit characteristic (boost curve) defines the maximum admissible amount of fuel (actuator travel, i.e. torque) the engine may be supplied when a certain boost pressure has been attained. Current boost pressure (\uparrow 2904 *BoostPressure*) is determined by a boost pressure sensor and the respective maximum admissible fuel value calculated by means of the characteristic.




Fig. 28: Boost pressure dependent fuel limitation

The values of the characteristics are stored at the following parameter positions:

6400 to 6409 *BoostLimit:p(x)* Boost pressure values for boost curve

6420 to 6429 *BoostLimit:f(x)* Fuel values for boost curve.

To parameterize the boost pressure dependent limit characteristic, there are up to 10 pairs of values available. Each pair of values consists of one boost pressure value and one fuel value, both with the same index. Intermediary values between adjacent pairs of variates will be interpolated by the control (*↑ 3.7 Parameterization of characteristics*).

The characteristic is activated by setting the parameter 4710 *BoostLimitOn* = 1.

Parameterizing Example:

A boost pressure dependent limit characteristic supported by 3 pairs of values is to be parameterized.

Number	Parameter	Value	Unit	Number	Parameter	Value	Unit
6400	<i>BoostLimit:p(0)</i>	1.0	bar	6420	<i>BoostLimit:f(0)</i>	50	%
6401	<i>BoostLimit:p(1)</i>	2.0	bar	6421	<i>BoostLimit:f(1)</i>	65	%
6402	<i>BoostLimit:p(2)</i>	3.0	bar	6422	<i>BoostLimit:f(2)</i>	90	%

Activation:

4710 *BoostLimitOn* 1

For boost pressures below the first of the parameterized values, the control will limit the actuator travel to the first of the parameterized actuator positions. Thus in the above Basic Information for Control Units with Conventional Injection, Level 6

example, actuator position is limited to 50 % for the range from 0 to 1 bar boost pressure. Likewise, for boost pressure values higher than the last parameterized one (in the above example 3.0 bar) actuator travel will remain limited to the last parameterized value (in the above example 90 %).

The parameter

2714 *BoostLimitActive* = 0 Fuel limitation currently not enabled

2714 *BoostLimitActive* = 1 Limitation currently enabled

permits to check upon whether or not this limitation is currently in effect. The current limiting value is indicated by the parameter 2704 *FuelLimitBoost*.

9.3 Forced limitation

Regardless of speed and boost pressure dependent limitation, fuel can be restricted to a externally pre-set value. Two possibilities are provided to this purpose. Either a fixed value is set for use as a limiting value in specific conditions, or a variable limiting value is used.

9.3.1 Fixed limit

In parameter 715 *FuelLimitForced* a constant maximum injection quantity is defined. This function is enabled by activating the switching function 2813 *SwitchForcedLimit*.

Again, the rule holds that the least limitation value enabled will override any other limitation. The parameter

2715 *ForcedLimitActive* = 0 external limitation currently not enabled

2715 *ForcedLimitActive* = 1 external limitation currently enabled

therefore shows whether the fixed value indicated in 2705 *FuelLimitForced* is currently responsible for the resulting fuel limitation.

Parameterizing Example:

On closing the switch at digital input 4 actuator travel is to be limited to 78 % maximum.

Number	Parameter	Value	Unit
715	<i>FuelLimitForced</i>	78	%
813	<i>FunctForcedLimit</i>	4	




Fig. 29: Externally activated power limitation

9.3.2 Variable limit

The variable limitation pre-set is derived from sensor 2923 *FuelLimitExtern*. This value may be connected directly to an analogue or PWM input, as usually the case for sensors, or received via communication modules. For example, the telegram TSC1 of SAE J1939 CAN communication may be used to transmit this limit.

The value 2720 *FuelLimitExtActive* = 1 indicates that the externally pre-set limit is currently responsible for the actual fuel limitation.



Note

Especially in case of connection to an analogue input, it must be ensured that 2923 FuelLimitExtern reaches maximum value when this limit is not active.

9.4 Zero fuel delivery characteristic

The injection pump of a diesel engine will start delivering only from a certain speed dependent position onward. Knowledge of this zero fuel delivery characteristic can have a positive effect on speed setpoint adjustments in direction of lower speeds whenever some actuator setpoint position below the characteristic is being calculated.

The precise zero fuel delivery characteristic can be determined only on a pump test stand. As a simple equivalent the zero load delivery characteristic can be determined, i.e. the characteristic corresponding to the fuel quantity of the engine running off-load.

This zero load delivery characteristic can be determined without difficulty by running across the entire speed range using a very slow speed ramp with the engine off-load. To obtain the zero fuel delivery characteristic a safety distance is deducted from the zero load delivery characteristic as determined and entered together with the speed supporting points in the characteristic *7200 ZeroLoadFuel:n* or *7250 ZeroLoadFuel:Pos* respectively.

If inappropriate values have been entered for this characteristic, only the proportional part of the speed governor will be working which is bound to result in a permanent speed deviation. Therefore, great care should be taken in determining the characteristic.

On activating the characteristic by *4720 ZeroFuelCurveOn* the speed governor will take zero delivery into account and be capable of reacting faster when speed increases again. This will also have the effect that undershooting is reduced during downward speed jumps. The current actuator value as resulting from the zero fuel delivery characteristic is indicated by *2340 ActPosAtZeroFuel*.

Using DcDesk 2000 the zero fuel delivery characteristic can be determined as described below:

1. *4720 ZeroFuelCurveOn = 0*, i.e., de-activation of the zero fuel delivery characteristic.
 Activate speed ramp for 2 rpmps.
230 SpeedRampUp = 2
233 SpeedRampDown = 2
4230 SpeedRampOn = 1
4232 SectionalOrFixedRamp = 0
 Set speed setpoint to idle speed by *20 SpeedSetpPC = value as set by 10 SpeedMin*.
 Set speed adjustment by *4020 SpeedSetpPCOn = 1* to definition by PC.
2. Start and run engine up to idle speed off-load. If possible turn off any users (loads).
3. Open DcDesk 2000 "Curve over X".
 Assign speed 2000 *Speed* to x-axis.
 Assign actuator position *2300 ActPos* to y-axis.
 Set speed range to *10 SpeedMin*, *12 SpeedMax*.
4. Ramp up speed by setting the speed setpoint *20 SpeedSetpPC* to maximum speed.
 Record actuator position against speed using a ramp of 2 rpmps.
 Stop the graph as soon as maximum speed is attained.
5. Subtract 5 % from the recorded values at the selected supporting points and enter them as values for the zero fuel delivery characteristic from *7200 ZeroFuelCurve:n* and *7250 ZeroFuelCurve:Pos*. respectively onward (\uparrow **3.7 Parameterization of characteristics**).
 If it was not possible to turn all users off, 10 % should be deducted instead.




Fig. 30: Zero fuel delivery characteristic

9.5 Reduction of the full-load characteristic with XIOS

The reduction of the full-load characteristic (\uparrow 9.1 Speed dependent fuel limitation) can take place depending on the coolant temperature, the charge air temperature, the fuel temperature, the exhaust temperature and/or the ambient pressure. Each of these power reductions can be activated separately or combinations are used.

Of the temperature-dependent power reductions, only the largest power reduction is used, i.e. the one that results in the smallest limiting value. The ambient pressure dependent power reduction acts as an additional reduction independently of these temperature-dependent functions.

Parameter numbers 2716 to 2726 show whether and which power reduction is active. A value of 0 means that the relevant reduction is not active.

2716	<i>CoolantTempRedActive</i> = 1	active due to fuel temperature
2717	<i>ChAirTempRedActive</i> = 1	active due to charge air temperature
2718	<i>FuelTempRedActive</i> = 1	active due to fuel temperature
2719	<i>AmbPressTempRedActive</i> = 1	active due to ambient pressure
2726	<i>ExhaustTempRedActive</i> = 1	active due to exhaust temperature

All temperature-dependent functions act in the same way:




Fig. 31: Temperature dependent reduction of the full-load characteristic (XIOS)

9.5.1.1 Coolant temperature dependent reduction

The coolant temperature (\uparrow 2907 *CoolantTemp*) is determined via a temperature sensor. If the temperature is too high, the full-load characteristic can be reduced. A characteristic with 8 data points is available for this.

The values of the characteristic are stored at the following parameter positions:

7100 *CoolTempReduce:T(x)* Coolant temperature values of the reduction

7110 *CoolTempReduce:F(x)* Percentage reduction

With this curve, a factor by which the value of the speed-dependent limitation is reduced is determined based on the coolant temperature. The value resulting from the limitation and reduction is shown in parameter 2706 *FuelRedCoolantTemp*. If the fuel limitation is carried out with this value, this is signalled by parameter 2716 *CoolantTempRedActive*.

This function is activated by parameter 4706 *FuelRedCoolTempOn*.

Parametrization example:

Number	Parameter	Value	Unit
7100	<i>CoolTempReduce:T(0)</i>	90.0	°C
7101	<i>CoolTempReduce:T(1)</i>	110.0	°C
7110	<i>CoolTempReduce:F(0)</i>	0.0	%
7111	<i>CoolTempReduce:F(1)</i>	12.0	%

Activation:

4706	<i>FuelRedCoolTempOn</i>	1
------	--------------------------	---

9.5.1.2 Charge air temperature dependent reduction

The charge air temperature is determined via a temperature sensor (\uparrow 2908 *ChargeAirTemp*). If the temperature is too high, the full-load characteristic can be reduced. A characteristic with 8 data points is available for this.

The values of the characteristic are stored at the following parameter positions:

7120 *ChAirTempReduce:T(x)* Charge air temperature of the reduction

7130 *ChAirTempReduce:F(x)* Percentage reduction

With this curve, a factor by which the value of the speed-dependent limitation is reduced is determined based on the charge air temperature. The value resulting from the limitation and reduction is shown in parameter 2707 *FuelRedChargeAirTemp*. If the fuel limitation is carried out with this value, this is signalled by parameter 2717 *ChAirTempRedActive*.

This function is activated by parameter 4707 *FuelRedChAirTempOn*.

9.5.1.3 Fuel temperature dependent reduction

The fuel temperature is determined via a temperature sensor (\uparrow 2910 *FuelTemp*). If the temperature is too high, the full-load characteristic can be reduced. A characteristic with 8 data points is available for this.

The values of the characteristic are stored at the following parameter positions:

7140 *FuelTempReduce:T(x)* Fuel temperature values of the reduction

7150 *FuelTempReduce:F(x)* Percentage reduction

With this curve, a factor by which the value of the speed-dependent limitation is reduced is determined based on the fuel temperature. The value resulting from the limitation and reduction is shown in parameter 2708 *FuelRedFuelTemp*. If the fuel limitation is carried out with this value, this is signalled by parameter 2718 *FuelTempRedActive*.

This function is activated by parameter 4708 *FuelRedFuelTempOn*.

9.5.1.4 Exhaust-dependent reduction

If the exhaust temperature is too high, the full-load curve can be reduced. A characteristic with 8 data points is available for this. Depending on whether just one or multiple exhaust temperature sensors are installed, the value of 2911 *ExhaustTemp* or the highest value of all sensors 12573 *ExhaustTempMax* is used for the following function.

The values of the characteristic are stored at the following parameter positions:

7160 *ExhTempReduce:T(x)* Fuel temperature values of the reduction

7170 *ExhTempReduce:F(x)* Percentage reduction

With this curve, a factor by which the value of the speed-dependent limitation is reduced is determined based on the exhaust temperature. The value resulting from the limitation and reduction is shown in parameter 2725 *FuelRedExhaustTemp*. If the fuel limitation is carried out with this value, this is signalled by parameter 2726 *ExhaustTempRedActive*.

This function is activated by parameter 4705 *FuelRedExhaustTempOn*.

9.5.1.5 Ambient pressure dependent reduction

The ambient pressure ($\hat{\uparrow}$ 2906 *AmbientPressure*) is determined via an ambient pressure sensor. If the ambient pressure is too low, the full-load curve can be reduced dependent on the speed and ambient pressure. A map with 8x8 data points is available for this.

The values for the map are stored on the following parameter numbers:

7000 *AmbPressRedMap:n(x)* Speed values for the reduction

7010 *AmbPressRedMap:p(y)* Ambient pressure values of the reduction

7020 *AmbPressRedMap:F(z)* Percentage reduction

With this map, a factor by which the value of the speed-dependent limitation is reduced is determined based on the speed and ambient pressure. The value resulting from the limitation and reduction is shown in parameter 2709 *FuelRedAmbientPress*. If the fuel limitation is carried out with this value, this is signalled by parameter 2719 *AmbPressRedActive*.

This function is activated by parameter 4709 *FuelRedAmbPressOn*.


10 Warning and emergency shutdown functions

On exceeding a pre-defined coolant, boost air or oil temperature limit, a warning message can be issued via a digital output.



Control units of the ORION type feature no temperature input. The functions relating to or depending on temperature therefore are not available.

Likewise, if oil pressure falls below a programmable speed dependent oil pressure characteristic, a warning can be output, and if oil pressure continues to fall below a second programmable oil pressure characteristic, the control can trigger an emergency shutdown.



The variable assignment of digital outputs is dealt with in chapter ↑ 20.8 Digital outputs.

10.1 Coolant temperature warning

For coolant temperature monitoring a temperature threshold for warning is set with parameter 510 *CoolantTempLimit*. If current coolant temperature exceeds this threshold, a warning message is output by setting the parameter 3032 *ErrCoolantTempWarn* = 1. If coolant temperature falls below the warning threshold by more than 5°C the parameter is set to 0 again, and the error is cleared.

The actual temperature is indicated by the parameter 2907 *CoolantTemp*. The function itself is activated by means of the parameter 4510 *CoolantTempWarnOn*.

Parameterizing Example:

Number	Parameter	Value	Unit
510	<i>CoolantTempLimit</i>	90	°C

Indication:

2907	<i>CoolantTemp</i>	90	°C
3032	<i>ErrCoolantTempLimit</i>	0/1	

Activation:

4510	<i>CoolantTempWarnOn</i>	1	
------	--------------------------	---	--

10.2 Charge air temperature warning

For charge air temperature monitoring a temperature threshold for warning is set with parameter 515 *ChargeAirTempLimit*. If current charge air temperature exceeds this threshold, a warning message is output by the parameter 3033 *ErrChargeAirTempWarn* being set to 1. When the charge air temperature is again below the warning threshold by more than 10°C the parameter is set to 0, and the error is cleared.

The actual temperature is indicated by the parameter 2908 *ChargeAirTemp*. The function itself is activated by means of the parameter 4515 *ChargeAirTempWarnOn*.

Parameterizing Example:

Number	Parameter	Value	Unit
515	<i>ChargeAirTempLimit</i>	120	°C

Indication:

2908	<i>ChargeAirTemp</i>	90	°C
3033	<i>ErrChargeAirTempLimit</i>	0/1	

Activation:

4515	<i>ChargeAirTempWarnOn</i>	1	
------	----------------------------	---	--

10.3 Oil temperature warning

For oil temperature monitoring a temperature threshold for warning is set with parameter 520 *OilTempLimit*. If current oil temperature exceeds this threshold, a warning message is issued by setting the parameter 3034 *ErrOilTempWarn* to 1. When oil temperature drops below the warning threshold by more than 5°C the parameter is set to 0 again, and the error is cleared.

The actual temperature is indicated in parameter 2909 *OilTemp*. The function itself is activated by means of parameter 4520 *OilTempWarnOn*.

Parameterizing Example:

Number	Parameter	Value	Unit
520	<i>OilTempLimit</i>	90	°C

Indication:

2909	<i>OilTemp</i>	90	°C
3034	<i>ErrOilTempWarn</i>	0/1	

Activation:

4520	<i>OilTempWarnOn</i>	1	
------	----------------------	---	--

10.4 Exhaust gas temperature warning

For exhaust gas temperature monitoring a temperature threshold for warning is set with parameter 525 *ExhaustTempLimit*. If current exhaust gas temperature exceeds this threshold, a warning message is output by setting the parameter 3041 *ErrExhaustTempWarn* = 1. When exhaust gas temperature drops below the warning threshold by more than 10°C the parameter is set to 0 again, and the error is cleared.

The actual temperature is indicated by the parameter 2911 *ExhaustTemp*. The function itself is activated by means of the parameter 4525 *ExhaustTempWarnOn*.

Parameterizing Example:

Number	Parameter	Value	Unit
525	<i>ExhaustTempLimit</i>	700	°C

Indication:

2911	<i>ExhaustTemp</i>	650	°C
3041	<i>ErrExhaustTempWarn</i>	0/1	


Activation:

4525	<i>ExhaustTempWarnOn</i>	1	
------	--------------------------	---	--

10.5 Forced idle speed in locomotive applications

On exceeding the limit temperature 510 *CoolantTempLimit*, in addition to the error message 3032 *ErrCoolantTempWarn* (\uparrow 10.1 *Coolant temperature warning*) it is possible to force the engine to run at idle speed. This function is enabled by means of the parameter 4511 *CoolantTempWarnIdleOn*. The delay time between exceeding the temperature limit and changing over to idle speed is set via the parameter 511 *CoolantTempIdleDelay*. As soon as the error 3032 *ErrCoolantTempWarn* is cleared forced idle speed is de-activated, too.

On exceeding the limit temperature 520 *OilTempLimit*, in addition to the error message 3034 *ErrOilTempWarn* (\uparrow 10.3 *Oil temperature warning*) it is possible to force the engine to run at idle speed. This function is enabled by means of the parameter 4521 *OilTempWarnIdleOn*. The delay time between exceeding the temperature limit and changing over to idle speed is set via the parameter 521 *OilTempIdleDelay*. As soon as the error 3034 *ErrOilTempWarn* is cleared, forced idle speed is de-activated too.



The control units ARCHIMEDES, PANDAROS and ORION are not suited for locomotive operation.

10.6 Speed dependent oil pressure monitoring

With rising speed the engine will need higher oil pressure. For monitoring oil pressure, two characteristics are provided. Actual oil pressure (\uparrow 2905 *OilPressure*) is checked by a pressure sensor.

After starting the engine, a certain time will have elapsed before oil pressure builds up. This can be taken account of by delaying the beginning of oil pressure monitoring after engine start by means of the parameter 500 *OilPressStartDelay*.

If oil pressure remains below the oil pressure warning characteristic for a period longer than defined by 501 *OilPressWarnDelay*, a warning message will be output by the parameter 3030 *ErrOilPressWarn* = 1. This oil pressure warning is automatically cleared as soon as oil pressure returns to a value above the oil pressure warning characteristic.

If oil pressure remains below the emergency stop characteristic for a period longer than preset by 502 *OilPressEcyDelay* an engine emergency shutdown will be executed and indicated by the parameter 3031 *ErrOilPress-Ecy* = 1.

Once the engine has stopped, the errors are cleared with a time delay of approximately one second to enable the engine to be restarted. If after restarting the engine oil pressure should

again be outside its normal working range, another warning is output if necessary or another emergency shutdown is executed.

The messages issued by the control are displayed by the following parameters:

3030 <i>ErrOilPressWarn</i>	0 = oil pressure above warning characteristic 1 = oil pressure below warning characteristic
3031 <i>ErrOilPressEcy</i>	0 = oil pressure above emergency stop characteristic 1 = oil pressure below emergency stop characteristic, engine shutdown has been executed.


The values for the oil pressure characteristics are stored at these parameter positions

6500 to 6509 <i>OilPressWarn:n(x)</i> :	speed values for oil pressure warning curve
6520 to 6529 <i>OilPressWarn:p(x)</i> :	oil pressure values for oil pressure warning curve
6550 to 6559 <i>OilPressEcy:n(x)</i> :	speed values for oil pressure emergency stop curve
6570 to 6579 <i>OilPressEcy:p(x)</i> :	oil pressure values for oil pressure emergency stop curve.

Parameterization is to be conducted according to \uparrow 3.7 *Parameterization of characteristics*. 10 pairs of values are available for each curve.

The characteristics are activated by setting the following parameters:

4500 <i>OilPressWarnCurveOn</i> = 1	for the oil pressure warning characteristic
4501 <i>OilPressEcyCurveOn</i> = 1	for the oil pressure emergency stop characteristic.


Fig. 32: Oil pressure characteristics

Parameterizing Example:

The oil pressure warning characteristic and the oil pressure emergency stop characteristic are to be parameterized using 3 pairs of values for each. No monitoring is provided below minimum speed of 700 rpm. This is achieved by setting the first values of both characteristics to 0 bar. For values beyond the last parameterized speed value (in this example index 3) the oil pressure value associated with this last value shall be retained. Oil pressure monitoring is supposed to become active after a time delay of 45 seconds. When pressure has been below the oil warning characteristic for more than 3 seconds a warning is to be issued. If pressure remains below the oil pressure emergency stop characteristic for more than 1 second, an emergency shutdown is to be executed.

Number	Parameter	Value	Unit
500	<i>OilPressStartDelay</i>	45.0	s
501	<i>OilPressWarnDelay</i>	3.0	s
502	<i>OilPressEcyDelay</i>	1.0	s

Number	Parameter	Value	Unit	Number	Parameter	Value	Unit
6500	<i>OilPressWarn:n(0)</i>	699	rpm	6520	<i>OilPressWarn:p(0)</i>	0	bar
6501	<i>OilPressWarn:n(1)</i>	700	rpm	6521	<i>OilPressWarn:p(1)</i>	1.8	bar
6502	<i>OilPressWarn:n(2)</i>	1200	rpm	6522	<i>OilPressWarn:p(2)</i>	3.3	bar
6503	<i>OilPressWarn:n(3)</i>	2100	rpm	6523	<i>OilPressWarn:p(3)</i>	4.5	bar
6504	<i>OilPressWarn:n(4)</i>	0	rpm	6524	<i>OilPressWarn:p(4)</i>	0	bar
6550	<i>OilPressEcy:n(0)</i>	699	rpm	6570	<i>OilPressEcy:p(0)</i>	0	bar
6551	<i>OilPressEcy:n(1)</i>	700	rpm	6571	<i>OilPressEcy:p(1)</i>	1.5	bar
6552	<i>OilPressEcy:n(2)</i>	1000	rpm	6572	<i>OilPressEcy:p(2)</i>	2.5	bar
6553	<i>OilPressEcy:n(3)</i>	2100	rpm	6573	<i>OilPressEcy:p(3)</i>	4.0	bar

The characteristics are activated by setting the following parameters:

4505 *CoolPressWarnCurveOn* = 1 coolant pressure warning curve

4506 *CoolPressIdleCurveOn* = 1 coolant pressure monitoring, forced idle speed




Fig. 33: Coolant pressure characteristics

10.8 Misfire monitoring in generator operation

Misfire monitoring can be implemented in the firmware on request. It is based on the observation of the speed variation caused by each ignition.

Although misfire monitoring is conceived primarily for gas engines, it can be used with diesel engines too, for example when conditions require the use of very bad quality fuel.

When 4050 *SpeedVarDetectOn* is active, the control unit calculates a unit for speed variance on the basis of 2000 *Speed* and the sampling value 50 *SpeedVarSampleSize* while the engine is running and indicates it as 2050 *SpeedVariance*. The value changes if single cylinders misfire. Since speed change is load-dependent even if the engine ignites correctly, for the error message both a warning and a shutdown characteristic are defined, both of which are load-dependent.



Note

Should the speed pickup 1 fail and the redundant speed pickup 2 take over its task, misfire monitoring can continue only if pickup 2 is mounted on the same toothed gear as pickup 1.

To determine the parameter for misfire monitoring, on the engine test stand single cylinders must be switched off and the sampling value 50 *SpeedVarSampleSize* must be determined in relation to 2050 *SpeedVariance*.

1. Let the engine run at rated speed and rated load under normal conditions. All cylinders must ignite correctly. The function 4050 *SpeedVarDetectOn* must be active and the functions 4055 *MisfireWarnCurveOn* and 4056 *MisfireEcyCurveOn* must be disabled.
2. Raise parameter 50 *SpeedVarSampleSize* step by step from 3 to max. 20. Good results were recorded for the values 9 and 12. Record the value of 2050 *SpeedVariance* for each step.
3. Switch off one cylinder, maintaining the load as far as possible.
4. Repeat step 2 for this load and this switched-off cylinder. In doing so, optimize the filter constant 51 *SpeedVarFilterConst* used for determining 2050 *SpeedVariance*. The value of 2050 *SpeedVariance* must increase in comparison to normal conditions.
5. Record the value of 50 *SpeedVarSampleSize* for which the relative increase of 2050 *SpeedVariance* is highest. The best sensibility is found when the relation between 2050 *SpeedVariance* on misfiring and normal ignition is highest.
6. Now determine parameter 50 *SpeedVarSampleSize* for the other switched-off cylinders and, if required, for different loads by repeating steps 2 to 5.
7. Choose the value of parameter 50 *SpeedVarSampleSize* which yields the clearest relative variation in 2050 *SpeedVariance* under all conditions and represents the best compromise for the measurements taken under different loads and with different inactive cylinders.



Filtering of speed signals for is on principle always done over two crankshaft rotations when misfire monitoring is implemented in the firmware (↑ 6.2 Speed measurement).

To determine the thresholds for monitoring and error messages proceed as follows:

1. Using the identified value for 50 *SpeedVarSampleSize*, run the engine to several load points both under normal conditions and with selected cylinders switched-off. Two different load-dependent curves for 2050 *SpeedVariance* result, one representing the "good" and the other the "bad" operating conditions. Pay attention that the curves differ noticeably from each other at all chosen load points.
2. Record the load value in 6000 *MisfireWarn:P(x)* and 6020 *MisfireEcy:P(x)* respectively. Draw the warning characteristic and shutoff characteristic between the two limit characteristics and record the respective values in 6010 *MisfireWarn:nVar(x)* and 6030 *MisfireEcy:nVar(x)*. Enable the functions 4055 *MisfireWarnCurveOn* and/or 4056 *MisfireEcyCurveOn*.

3. Determine the delay times for 55 *MisfireWarnDelay* and 56 *MisfireEcyDelay*. Only when the current value of 2050 *SpeedVariance* has exceeded the warning and/or the shutoff characteristic for at least the respective time indicated the errors 3046 *ErrMisfireWarn* / 3047 *ErrMisfireEcy* are triggered.

When the value of 2050 *SpeedVariance* falls below the load-dependent trigger level by relative 15 % the error 3046 *EErrMisfireWarns* cleared. The emergency shutoff signal 3047 *ErrMisfireEcy* on the other hand can be cleared only by a $\hat{1}$ 3.10 *Reset of control unit*, or by an error clearing through a communication module or switch function.

10.8.1 Single cylinder recognition

Misfire monitoring may optionally be expanded to indicate the cylinder responsible for misfiring. This is possible on condition that misfire monitoring in general is active and a signal from the camshaft is available (with one impulse each crankshaft rotation), on the basis of which the control unit may identify the sequence of cylinders.

In the systems ARCHIMEDES, PRIAMOS and HELENOS the camshaft signal is connected to the input of the second speed pickup. The second speed pickup must be de-activated for redundant speed measuring by setting 4002 *PickUp2On* = 0. The input is configured as camshaft signal reader instead by setting 4005 *CamIndexOn* = 1.

In the system PANDAROS the camshaft signal must be connected to PWM-input 3 (4805 *PUp2_PWMIn3OrDigIn5* = 1). This input too is configured as camshaft signal reader by setting 4005 *CamIndexOn* = 1.

In the system ORION the camshaft signal must be connected to PWM-input 3 (4805 *Pup2_PWMInOrDigIn3* = 1). This input too is configured as camshaft signal reader by setting 4005 *CamIndexOn* = 1.



Since these inputs are not prepared for inductive pickups, in the systems PANDAROS and ORION only a Hall impulse sensor can be used for reading the camshaft signal.

The speed measured at the camshaft is indicated in parameter 2009 *SpeedCamIndex*. Cylinder identification is active only when the camshaft signal is forthcoming and parameter 3003 *ErrCamIndex* registers no error.

The position of the camshaft signal must be communicated to the control unit by entering it in parameter 52 *CamIndexOffset* in degrees crankshaft. In this parameter the distance of the camshaft signal to the top dead center (TDC) of cylinder 1 must be entered.

In order to identify the misfiring cylinder the control unit must know the number of cylinders and their ignition sequence. Starting from parameter 6050 *AngleCylinder1* the TDC angles of the single cylinders must therefore be entered. Unused elements must be

assigned a 0. The control unit automatically recognizes the number of cylinders on basis of the assigned elements. When the parameters for the angles are set, the first data to enter must always be the TDC of cylinder 1 with a crankshaft angle of 0°. The values for the other cylinders are to be entered correspondingly in degrees of crankshaft angle.



Note

These parameters will become active only following a reset.

Example:

A 6 cylinder engine has an ignition sequence of 1-5-3-6-2-4 with an ignition setoff of 120°crank. According to the abovementioned definition, since cylinder 1 has a TDC of 0° the other TDC's will accordingly be equal to:

Cylinder	1	5	3	6	2	4
TDC	0°	120°	240°	360°	480°	600°

These values must now be entered in the cylinder sequence.

<u>Number</u>	<u>Parameter</u>	<u>Value</u>	<u>Unit</u>
6050	AngleCylinder1	0.0	°crank
6051	AngleCylinder2	480.0	°crank
6052	AngleCylinder3	240.0	°crank
6053	AngleCylinder4	600.0	°crank
6054	AngleCylinder5	120.0	°crank
6055	AngleCylinder6	360.0	°crank
6056	AngleCylinder7	0.0	°crank
:	:	:	:
6069	AngleCylinder20	0.0	°crank

For the unused positions of 6056 *AngleCylinder7* to 6069 *AngleCylinder20*, the value of 0° crank must be entered in each case.

The number of cylinder recognized by the control unit is then indicated in parameter 2083 *NumberOfCylinders*.

If a misfiring is now registered by 3046 *ErrMisfireWarn* or 3047 *ErrMisfireEcy* while the engine is running, parameter 2081 *MisfireCylinderNo* will now indicate the cylinder responsible for misfiring. In addition, parameter 2080 *VarianceMaxAngle* will indicate the calculated TDC angle and parameter 2082 *MisfireCylinderAngle* the assigned TDC angle of the cylinder in question.



Note

The precision of recognition depends on the number of teeth on the crankshaft, the quality of the speed signal and also on the number of cylinders. A 12 or 16 cylinder engine with a misfiring cylinder will run much smoother than a 6 or 8 cylinder engine in the same condition. With such bigger engines it is therefore possible that the indicated cylinder will

not correspond to the misfiring one but is the preceding or following one in the ignition sequence.

During commissioning, cylinder misfire identification should be checked carefully, ideally by disabling each single cylinder in turn. Subsequently it must be verified if the indicated cylinder and the calculated TDC angle are correct. If a general displacement between indicated and effective TDC angle of the cylinder is noticed, this may be corrected in parameter 52 *CamIndexOffset*.



Note

*The parameter 52 *CamIndexOffset* may be determined in a simple way by disabling a specific cylinder and then changing the value of parameter 52 *CamIndexOffset* until 2088 *MisfireCylinderAngle* corresponds to the TDC angle of the disabled cylinder. The value obtained in this way must at all costs be checked against those obtained for other disabled cylinders.*

24 single values of cyclic speed variance are determined in order to analyze the misfiring cylinder. When the engine is running, the control unit indicates these values in the parameters ranging from 2051 *VarianceElement1* to 2074 *VarianceElement24*. The 24 elements are filtered through the same filtering constant 51 *SpeedVarFilterConst* as the general cyclic speed variance 2050 *SpeedVariance*. When the engine does not misfire, all indicated values are close to 0. As soon as a cylinder fails, the values shift. The misfiring cylinders is where the values are lowest.

10.9 Alternator charge monitoring

In control units of the ARCHIMEDES type the battery may be monitored in order to see whether the alternator is charging the battery. To this purpose, alternator voltage is to be measured at terminal D+ with 2905 *Alternator* by connecting it to analogue input 6.

If alternator charge monitoring has been activated with 5300 *AlternVoltSupviseOn* = 1, the warning 3040 *ErrAlternatorWarn* is issued when the value falls below 1301 *AlternatorLowValue*. As soon as 1302 *AlternatorHighValue* is exceeded, the warning is automatically cleared.

Monitoring starts after 1300 *AlternatorDelayTime* after each engine start.

10.10 Electronics monitoring

In order to safeguard operational safety, electronic devices carry out autotests. The following table informs about what is monitored and what errors are set in each case. There is a description of the tests carried out only when the control unit is booted. ↑ 27.7 Emergency shutdown errors indicates, which errors lead to an emergency stop or inhibit the engine start, respectively. In ↑ 27.8 Error parameter list each single error is described in detail.

Errors	Reason
--------	--------

Errors	Reason
3075 <i>ErrClearFlash</i>	Error erasing the flash memory (indicated in bootloader)
3076 <i>ErrParamStore</i>	Error saving parameters
3077 <i>ErrProgramTest</i>	Error during permanent check of programme memory
3078 <i>ErrRAMTest</i>	Error during permanent check of RAM memory
3081 <i>Err5V_Ref</i>	Error in voltage reference values
3085 <i>ErrVoltage</i>	Operating voltage too high or too low
3089 <i>ErrWatchdog</i>	Undefined programme flow, internal programming error (indication in bootloader)
3090 <i>ErrData</i>	No parameters available or checksum over parameters wrong (after programme download always active in ARCHIMEDES, ORION and PANDAROS)
3091 <i>ErrLogical</i>	Error in parameter structure (HELENOS and PRIAMOS)
3093 <i>ErrStack</i>	Stack overflow, internal programming error
3094 <i>ErrIntern</i>	Exception, internal programming error

10.10.1 Voltage references

Some control units use voltage reference values for ratiometric measurement of analogue inputs. The values must lie within fixed limits determined by the software and hardware, otherwise an error is output and the respective analogue inputs cannot be corrected.

ARCHIMEDES:	3603 <i>5VRefAnalog/TempIn1</i>	3081 <i>Err5VRefAna/TempIn1</i>
	3604 <i>5VRefAnalog/TempIn2</i>	3082 <i>Err5VRefAna/TempIn2</i>
	3605 <i>5VRefAnalog/TempIn3</i>	3083 <i>Err5VRefAna/TempIn3</i>
	3606 <i>5VRefAnalog/TempIn4</i>	3084 <i>Err5VRefAna/TempIn4</i>
ORION, PANDAROS:	3603 <i>5V_Ref</i>	3081 <i>Err5V_Ref</i>

10.10.2 RAM test

When the application is running, the whole utilized RAM is tested. The address of the currently tested cell is indicated in 3895 *RAMTestAddr*. The current test value is indicated in 3896 *RAMTestPattern*. Whenever a faulty cell is recognized, both these indications stop, error 3078 *ErrRAMTest* is output and the engine is stopped.

10.10.3 Application memory test

When the application is running, application memory is tested. The checksum for the whole application memory is calculated progressively and then compared with the saved checksum. If they don't match, error 3077 *ErrProgramTest* is output and the engine is stopped.

10.10.4 Stack depth test

To execute subprogrammes and interrupt service routines a stack is required. The utilization of this memory is constantly monitored and error 3093 *ErrStack* is output when it runs too low. At the same time, an emergency stop is carried out when the engine is running, since ordinary programme sequence is not guaranteed.

10.10.5 Programme sequence test

While the application is running, it is tested whether the software runs through valid memory ranges. If this is not the case, exception error 3094 *ErrIntern* is output and the engine is stopped. From the values indicated starting from 3095 *ExceptionNumber*, HEINZMANN is able to derive information on the type of error that has occurred.

The value indicated in 3865 *CalculationTime* allows to determine how much computer time the current application requires. The value 3870 *Timer* is a millisecond indicator running end-to-end, used internally for time-dependent functions and influencing the graphical representation of DcDesk 2000.

10.10.6 Monitoring of power supply

Operating voltage 3600 *PowerSupply* is monitored by every control unit. While in ARCHIMEDES, HELENOS and PRIAMOS each crossing of the voltage limits in excess or in defect by the unfiltered operating voltage 3602 *PowerSupplyRaw* is registered immediately in 3085 *ErrVoltage*, ORION and PANDAROS are able to tolerate a drop of battery voltage for a certain time before the error is output.

Normally these two control units carry out a reset when voltage is lower than 9 V. If the function 5600 *LowPowerEnable* is active and the hardware allows it, a low voltage of 8.5 V is tolerated for 20 s and, according to the 12 V battery norm, a voltage below 7 V is tolerated for 1 s. Thereafter the voltage must stay above 9 V for at least three times the duration it had been low before a new occurrence of undervoltage can be tolerated.

If voltage drops for longer than allowed, error 3085 *ErrVoltage* is output.

The function 5600 *LowPowerEnable* can be enabled/disabled at any time but it becomes valid only after a reset of the control unit. 3601 *LowPowerEnabled* shows whether the used control unit hardware is suited for the function.

11 Additional functions

11.1 Engine operating hours counter

Operating hours of the running engine are recorded in 3871 *OperatingHourMeter* and 3872 *OperatingSecondMeter*. An engine is considered running when parameter 3805 *EngineRunning* is set.

The engine operating hours counter is used for \uparrow 27.4 *Error memory*, in order to save each error with the time of its first and last occurrence. The engine operating hours counter can be reset only by means of the special function "Delete operating data" in \uparrow 3.3 *DcDesk 2000* or with the handheld programmer HP 03.



Note

The operating hours counter is available in controls of ARCHIMEDES, ORION and PANDAROS type. It may provided in the system HELENOS on request.

11.2 Jet Assist

The control unit can assist the turbocharger by injecting additional air at specific operating points. This is useful, for instance, in case of load additions. To this purpose, a booster is addressed via a digital output whenever current boost air pressure lies below a curve parameterized in dependence of fuel (\uparrow 20.8 *Digital outputs*). This allows to boost pressure for a (compressor-dependent) presettable maximum duration.

1247 <i>JetAstMaxBoostDiff</i>	max. admissible distance to curve (hysteresis)
1248 <i>JetAstMaxBoostDTime</i>	max. duration for boost signal
3247 <i>JetAstActive</i>	boost signal
3248 <i>JetAstCurrBoostDiff</i>	current distance to curve
5247 <i>JetAssistOn</i>	function enabled
6480 <i>JetAstBoostDiff:f</i>	fuel base points
6490 <i>JetAstBoostDiff:p</i>	boost air pressure values

If current boost air pressure 2904 *BoostPressure* for current fuel is lower than the curve value minus 1247 *JetAstMaxBoostDiff*, 3247 *JetAstActive* is activated until boost air pressure returns above the curve, but at longest for the duration 1248 *JetAstMaxBoostDTime*. Current pressure difference between the curve value and 2904 *BoostPressure* is indicated in 3248 *JetAstCurrBoostDiff*, whenever boost air pressure is below the curve.

11.3 Starting request

Control units of the type ARCHIMEDES are able to start the engine on their own. To this purpose a start request must be transmitted to the control with the switching function 2849 *SwitchStartEngine* while the engine is standing. If this occurs, parameter 3808 *EngineStarter* is set. This parameter must be connected to the starter via one of the digital outputs 5, 6 which are able to drive 12 V (\uparrow 20.8 *Digital outputs* and \uparrow 19.2.7 *Digital outputs*). With 4849 *StartImpulseOrSwitch* it can be decided whether the starter shall be disabled as soon as the function 2849 *SwitchStartEngine* is disabled or if a single impulse to this switching function is sufficient to activate the starter until it is switched off by other conditions.

4849 *StartImpulseOrSwitch* = 0 engine start command continues only as long as 2849 *SwitchStartEngine* remains active

4849 *StartImpulseOrSwitch* = 1 a single switching pulse activates engine start

On reaching speed as set in 256 *StartSpeed2*, the control recognizes that the engine is running. This is also indicated by parameter 3805 *EngineRunning* (also see \uparrow 5 *Starting fuel limitation*). At this moment, parameter 3808 *EngineStarter* is set back and the starter correspondingly de-activated.

In any case, the starter is addressed at most for the duration of 280 *StarterCrankTimeMax*. If the engine does not start within this time, the starter is de-activated. After the waiting time of 281 *StarterInterlockTime* a further starting attempt is undertaken. The maximum number of cranking attempts is set in 282 *StarterCrankAttempts*. Should the engine not have started after the max. number of cranking attempts, error message 3039 *ErrStarter* is output and the starting request is terminated. A repetition of cranking attempts is possible by setting the starting request again with 2849 *SwitchStartEngine*.

12 Vehicle operation

HEINZMANN control units may be used as idle/maximum speed controls in the operative mode vehicle application (\uparrow 7.2 *Vehicle operation*), i.e., it is possible to switch between the operation modes of variable speed control and idle/maximum speed control (e.g., for applications with stationary and driving operation).

12.1 Idle/maximum speed control

The control unit may be operated by standard as an idle/maximum speed control. This mode is selected by the parameters:

<u>Number</u>	<u>Parameter</u>	<u>Value</u>	<u>Unit</u>
1810/3810	<i>OperationMode</i>	1	
<u>Activation:</u>			
4130	<i>IMGovernorOn</i>	1	

This parameter 4130 *IMGovernorOn* (IM = **I**dle/**M**aximum) applies when only idle/maximum speed control is required or when idle/maximum speed operation at fixed intermediary speeds via external switches (fixed speeds or idle speed) is envisaged.

If, however, change-over between operation as an idle/maximum speed control and variable speed control with variable speed setting (e.g., by foot throttle) is desired the switching function 2831 *SwitchIMOrAllSpeed* is to be used:

2831 *SwitchIMOrAllSpeed* = 0 variable speed control

2831 *SwitchIMOrAllSpeed* = 1 idle/maximum speed control.

The control unit will operate in idle/maximum speed control mode only if there is no need for intermediary speeds. The parameter 2141 *IMOrAllSpeedGov* is therefore provided to check on which mode the control is currently operating by:

2141 *IMOrAllSpeedGov* = 0 variable speed control

2141 *IMOrAllSpeedGov* = 1 idle/maximum speed control.

At idle and at maximum speeds the control unit's performance is the same as that of the variable speed control. Between idle speed and absolute maximum speed (maximum speed limit line), the fuel setpoint is determined by the active setpoint adjuster 2900 *Setpoint1Extern* or 2901 *Setpoint2Extern* respectively.

12.1.1 Fuel Setpoint

The fuel setpoint is determined by 2900 *Setpoint1Extern* or 2901 *Setpoint2Extern* respectively, depending on the position of 2827 *SwitchSetpoint2Or1* (PANDAROS and ORION have only one setpoint adjuster).

In addition, there is the option to freeze the fuel setpoint via a switch and to continue operation using the frozen setpoint (not for ORION). This is indicated by the parameter

- 2829 *SwitchFreezeSetp1* = 1 value of setpoint 1 has been frozen
- 2830 *SwitchFreezeSetp2* = 1 value of setpoint 2 has been frozen.

The setpoint coming in when the function is activated will be frozen. As long as the function is active, the current setpoint will be compared with the stored setpoint. If the set value coming from the setpoint adjuster exceeds the frozen value, operation will continue using the current value of the setpoint adjuster; otherwise the frozen value is used. The frozen setpoint, however, will be abandoned only when the switch is opened.

The chosen fuel setpoint is indicated by 2133 *IMFuelSetpExtern*. This value may be used directly as fuel setpoint or else the fuel setpoint is derived from a fuel setpoint and speed dependent map – the $\hat{12.1.2}$ Drive map. In any case, the resulting fuel setpoint for the idle/maximum governor is indicated by parameter 2131 *IMFuelSetp*.

12.1.2 Drive map

The drive map allows to interpret the accelerator pedal position at different speeds so as to achieve optimal injection quantity for the required torque. This function is purely for the comfort of the driver.

The value coming from the setpoint adjuster used for the speed map is indicated by 2133 *IMFuelSetpExtern*. The resulting fuel setpoint is indicated by parameter 2131 *IMFuelSetp*. The drive map is activated by parameter 4132 *IMDriveMapOn*.

The values for the map are stored at the following parameter positions:

- 8100 to 8108 *IMDriveMap:n(x)* speed values for speed map
- 8109 to 8117 *IMDriveMap:Setp(x)* setpoints for drive map
- 8118 to 8198 *IMDriveMap:f(x)* fuel values for speed map

The drive map can be adjusted with up to 9 speed values and setpoints. Intermediary values between adjacent pairs of variates will be interpolated by the control $\hat{3.8}$ *Parameterization of maps*.

Parameterizing Example:

NumberParameter	Value	Unit
8100 <i>IMDriveMap:n(0)</i>	800	rpm
8101 <i>IMDriveMap:n(1)</i>	1000	rpm
8102 <i>IMDriveMap:n(2)</i>	1200	rpm
8103 <i>IMDriveMap:n(3)</i>	1600	rpm
8104 <i>IMDriveMap:n(4)</i>	2000	rpm
8109 <i>IMDriveMap:Setp(0)</i>	10	% (foot throttle)
8110 <i>IMDriveMap:Setp(1)</i>	30	%
8111 <i>IMDriveMap:Setp(2)</i>	50	%
8112 <i>IMDriveMap:Setp(3)</i>	70	%
8113 <i>IMDriveMap:Setp(4)</i>	100	%

8118	<i>IMDriveMap:f(0)</i>	8	% (fuel)
8119	<i>IMDriveMap:f(1)</i>	10	%
8120	<i>IMDriveMap:f(2)</i>	10	%
8121	<i>IMDriveMap:f(3)</i>	8	%
8122	<i>IMDriveMap:f(4)</i>	7	%
8127	<i>IMDriveMap:f(9)</i>	25	%
8128	<i>IMDriveMap:f(10)</i>	28	%
8129	<i>IMDriveMap:f(11)</i>	30	%
8130	<i>IMDriveMap:f(12)</i>	30	%
8131	<i>IMDriveMap:f(13)</i>	28	%
8136	<i>IMDriveMap:f(18)</i>	40	%
8137	<i>IMDriveMap:f(19)</i>	40	%
8138	<i>IMDriveMap:f(20)</i>	40	%
8139	<i>IMDriveMap:f(21)</i>	40	%
8140	<i>IMDriveMap:f(22)</i>	40	%
8145	<i>IMDriveMap:f(27)</i>	60	%
8146	<i>IMDriveMap:f(28)</i>	70	%
8147	<i>IMDriveMap:f(29)</i>	70	%
8148	<i>IMDriveMap:f(30)</i>	70	%
8149	<i>IMDriveMap:f(31)</i>	80	%
8154	<i>IMDriveMap:f(36)</i>	80	%
8155	<i>IMDriveMap:f(37)</i>	90	%
8156	<i>IMDriveMap:f(38)</i>	90	%
8157	<i>IMDriveMap:f(39)</i>	90	%
8158	<i>IMDriveMap:f(40)</i>	90	%

Activation:

4132	<i>IMDriveMapOn</i>	0/1
------	---------------------	-----

12.1.3 Controlling idle and maximum speeds

For the idle/maximum speed control, idle speed is determined by the parameters 10 *SpeedMin1* and 11 *SpeedMin2*, respectively (\uparrow 7.1 *General application*). With low temperatures, this value can be raised by \uparrow 7.6 *Temperature dependent idle speed* (not available in ORION). Likewise, maximum speed is given by the respective parameters 12 *SpeedMax1* and 13 *SpeedMax2*. (PANDAROS and ORION offer only one speed range [10 *SpeedMin*, 12 *SpeedMax*].)




Fig. 34: Idle/maximum speed control

When in idle/maximum speed control mode, the speed control will be on-line all the time using either idle speed or maximum speed as a target speed. Which speed the control unit is operating at can be read from the parameter 2140 *GoverningAtMaxOrIdle*.

2140 *GovernorAtMaxOrIdle* = 0 idle speed control

2140 *GovernorAtMaxOrIdle* = 1 maximum speed control.

Independently of \uparrow 7.8 *Droop* for the variable speed control, a separate droop is available for idle/maximum speed control. Droop for idle speed control is defined by 140 *IMIdleDroop* and for maximum speed limitation by 141 *IMMaximumDroop*. The reference point for zero-load is to be entered via the parameter 142 *IMDroopRefLow* and that for full-load via 143 *IMDroopRefHigh*.

The speed reference point is in each case given by the minimum and maximum speed respectively:

140 <i>IMIdleDroop</i>	Droop for idle speed control
141 <i>IMMaximumDroop</i>	Droop for maximum speed limit
142 <i>IMDroopRefLow</i>	Reference point for zero-load
143 <i>IMDroopRefHigh</i>	Reference point for full-load.

12.1.4 On-load idle speed

When the control is operating in idle/maximum speed control mode, it will in the majority of cases not be desirable to keep idle speed constant. Instead, idle speed will be increased with higher fuel setpoints. This can be achieved through the parameter 150 *IMSpeedIncrease*, which indicates the relative increase of idle speed for 100 % fuel quantity.

Parameterizing Example:

Number	Parameter	Value	Unit
150	<i>IMSpeedIncrease</i>	100	<i>rpm</i>

12.1.5 Fuel ramp

When operating in idle/maximum speed control mode, it may be necessary to delay increase injection quantity, e.g., in order to reduce free acceleration. This can be achieved by activating a fuel ramp.

The rate of the delay can be adjusted for setpoint increase and setpoint decrease independently of one another.

130 *IMRampUp* for upward ramps

131 *IMRampDown* for downward ramps.

The unit for these parameters is increase or decrease speed per second, respectively. Both ramps are enabled by the parameter 4131 *IMFuelRampOn*. If ramping is to be selected for one direction only, the maximum value must be entered for the other direction.

The fuel quantity setpoint as delayed by the ramp can be read from the parameter 2131 *IMFuelSetp*. The parameter 2132 *IMFuelSetpSelect* represents the fuel quantity setpoint the ramp is to arrive at.

Parameterizing Example:

Number	Parameter	Value	Unit
130	<i>IMRampUp</i>	400.0	<i>%/s</i>
131	<i>IMRampDown</i>	700.0	<i>%/s</i>

Activation:

4131 *IMFuelRampOn* 1



Note

This fuel ramp may be used only when the control is operating in idle/maximum speed control mode. For variable speed control mode, a \uparrow 7.7 Speed ramp is provided to achieve smooth speed changes for this mode of operation, too.

13 Locomotive operation

Applications for locomotive operation are possible only with the control units HELENOS and PRIAMOS. For diesel-electric applications the system PEGASOS with integrated HELENOS control unit is particularly suited.

There are many special applications for locomotive operation. Part of them relate to determination of speed setpoints (*↑ 7.3 Locomotive operation*), others to manipulation of generator excitation with diesel-electric applications. Furthermore, forced idle speed as is normally used in locomotive applications on exceeding or dropping below certain sensor values (*↑ 10.5 Forced idle speed in locomotive applications*) can be implemented as well as slide protection functions. Interesting for fuel saving is the reduction of lower idle speed when the machine is standing (*↑ 13.3 Low idle speed*).

If any of the special locomotive functions are to be used the operation mode Locomotive operation must be set to 1810 /3810 *OperationMode = 2*.

13.1 Speed notch switches

Up to four switching functions, from 2819 *SwitchNotch3* to 2822 *SwitchNotch0*, are available to configure the speed notch switches. With these four switches 16 running notches can be determined. For 8 speed notches the switching functions from 2820 *SwitchNotch2* to 2822 *SwitchNotch0* are used.

The states of the speed notch switches can be read from these parameters:

2819 <i>SwitchNotch3</i>	Speed notch switch 3
2820 <i>SwitchNotch2</i>	Speed notch switch 2
2821 <i>SwitchNotch1</i>	Speed notch switch 1
2822 <i>SwitchNotch0</i>	Speed notch switch 0

The four available speed notch switches allow to set exactly the 16 binary values of 0...15. From the three speed notch switches 2820 *SwitchNotch2*..2822 *SwitchNotch0* result the binary values 0..7 (first eight lines of the table). The following table shows how these binary values can be determined.

Binary value	2819 <i>SwitchNotch3</i>	2820 <i>SwitchNotch2</i>	2821 <i>SwitchNotch1</i>	2822 <i>SwitchNotch0</i>
= \sum bit values	Bit value 8	Bit value 4	Bit value 2	Bit value 1
0	0	0	0	0
1	0	0	0	1
2	0	0	1	0
3	0	0	1	1
4	0	1	0	0
5	0	1	0	1
6	0	1	1	0
7	0	1	1	1
8	1	0	0	0
9	1	0	0	1
10	1	0	1	0
11	1	0	1	1
12	1	1	0	0
13	1	1	0	1
14	1	1	1	0
15	1	1	1	1

Table 17: Speed notches from speed notch switches

In locomotive application, the speed notches may either be directly the same as the binary value resulting from the switching functions (see first column of \uparrow *Table 17: Speed notches from speed notch switches*), or it may be necessary to determine the speed notch indirectly from another table via the binary value.

Whether or not direct assignment can be made, will depend on whether it is possible to realize the above binary table with the speed notch switches that are available. Possibly, some of the signals must be inverted before assigning them to the respective speed notch switch (\uparrow *18 Configuration of switching functions*). If this is not feasible - particularly with retrofit applications - there exists an further possibility of determining the speed notches by means of a second table (\uparrow *Table 18: Extended notch table*).

The assignment array consists of 16 components 6880 *LocoNotchAssign(0)* to 6895 *LocoNotchAssign(15)* whose indices are equal to the binary values. In each component the associated speed notch must be entered.

If a specific binary value is intended to lead to an engine stop, instead of the speed notch the value 255 should be entered. This engine stop is equivalent to any other engine stop request for what reason whatsoever (\uparrow 2810 *SwitchEngineStop* or \uparrow 27.7 Emergency shutdown errors). If there is no speed notch associated with a specific binary value 0 will have to be entered. Should one of these combinations occur during operation, then the last value determined will be retained as speed notch value.



*The speed notches are always numbered from 0 to 15. But since in the table 6880 *LocoNotchAssign()* the value 0 means that no speed notch can be assigned, in this specific table (and only here) the speed notches must be entered in the range from 1 to 16.*

The selection of whether the speed notches are to correspond directly to the binary value as derived from the switching functions or whether they are to be determined via another table must be communicated to the control by 5353 *NotchAssignOrBinary*.

5353 *NotchAssignOrBinary* = 0 Speed notch = binary value

5353 *NotchAssignOrBinary* = 1 Speed notch = *LocoNotchAssign*(binary value)

In either case the result is indicated by 3350 *Notch*.

Parameterizing Example:

The speed notches 0..7 result from four switching functions, according to the table below. The combination of 0-0-0-1 (binary value 1) should trigger an engine stop. The other seven binary combinations (3, 4, 5, 9, 11, 12, 13) do not occur or will not change the speed notch.

Notch	2819	2820	2821	2822	Binary value
	<i>SwitchNotch3</i>	<i>SwitchNotch2</i>	<i>SwitchNotch1</i>	<i>SwitchNotch0</i>	
	Bit value 8	Bit value 4	Bit value 2	Bit value 1	= \sum bit values
Engine stop	0	0	0	1	1
0	0	0	0	0	0
1	1	0	0	0	8
2	0	0	1	0	2
3	1	0	1	0	10
4	0	1	1	1	7
5	1	1	1	1	15
6	0	1	1	0	6
7	1	1	1	0	14

Table 18: Extended notch table

Binary value and speed notch derived from the above table now are sorted in order of ascending binary values. Not used binary combinations receive the speed notch value 0. For real speed notches a value increased by 1 is entered, as it is expected for 6880 *LocoNotchAssign()*. For the engine stop request the value 255 must be used.

Binary value	Notch
0	1
1	255
2	3
3	0
4	0
5	0
6	7
7	5

Binary value	Notch
8	2
9	0
10	4
11	0
12	0
13	0
14	8
15	6

The index x of 6880 *LocoNotchAssign(x)* corresponds to the binary value from the first column. The notch value from the second column is entered in the parameters belonging to the binary value.

Number	Parameter	Value	Unit
5350	<i>LocoSetpoint1Mode</i>	0	
5352	<i>NotchAssignOrBinary</i>	1	
6880	<i>LocoNotchAssign(0)</i>	1	
6881	<i>LocoNotchAssign(1)</i>	255	
6882	<i>LocoNotchAssign(2)</i>	3	
6883	<i>LocoNotchAssign(3)</i>	0	
6884	<i>LocoNotchAssign(4)</i>	0	
6885	<i>LocoNotchAssign(5)</i>	0	
6886	<i>LocoNotchAssign(6)</i>	7	
6887	<i>LocoNotchAssign(7)</i>	5	
6888	<i>LocoNotchAssign(8)</i>	2	
6889	<i>LocoNotchAssign(9)</i>	0	
6890	<i>LocoNotchAssign(10)</i>	4	
6891	<i>LocoNotchAssign(11)</i>	0	
6892	<i>LocoNotchAssign(12)</i>	0	
6893	<i>LocoNotchAssign(13)</i>	0	
6894	<i>LocoNotchAssign(14)</i>	8	
6895	<i>LocoNotchAssign(15)</i>	6	

13.2 Generator excitation

In diesel-electric locomotive operation the digital control can influence generator excitation in dependence of current speed and fuel quantity. To this purpose, an excitation signal (correction value) is determined and output via an analogue port.

The excitation signal can be determined either by means of two characteristics and a correction factor or by a closed loop fuel quantity circuit. The first method is called excitation control, the latter excitation governing.

Generally, determination of the excitation signal is enabled with 4600 *Excitation-ControlOn* = 1. Selection of excitation control or excitation governing is made by

4601 *ExcitGovOrControl* = 0 Excitation control

4601 *ExcitGovOrControl* = 1 Excitation governing.

Selection is made during the phase of parameterization. Hence it cannot be modified while the engine is running. This will also explain why certain parameters that are required for both methods have been assigned identical addresses (parameter numbers).

Calculation of an excitation signal can be conducted only when the engine is neither at a standstill nor being stopped – in these cases the value “0” is output. In addition, the switching function 2840 *SwitchExcitationOn* has been provided. It allows to enable or disable the excitation signal by external intervention.

2840 *SwitchExcitationOn* = 1 Excitation signal enabled

2840 *SwitchExcitationOn* = 0 Excitation signal not enabled

If no external switch has been assigned to the associated parameter 840 *FunctExcitationOn* (\uparrow 18 *Configuration of switching functions*), the excitation signal will always be enabled when the engine is running and cannot be affected by external intervention.



Note

In the course of time, parameter names for generator excitation in locomotive operation have been modified to read "Excitation..." instead of "Power...". This does not imply, however, any changes with respect to their meaning.

13.2.1 Excitation control

The excitation signal 2600 *ExcitationSetpoint* is a function of current speed 2000 *Speed*, of current fuel quantity 2350 *FuelQuantity* and of the amplification factor 600 *ExcitCntrlFactor*. This means that for each speed at a specific fuel quantity there is a specific excitation signal value. If there is any difference between actual and programmed fuel quantity, there will be a reaction by varying the excitation signal via a proportional controller.

One triplet of values consists of a speed value, a fuel value and an excitation value, all with the same index. Intermediary values between two adjacent triplets of values will be computed by the control. The characteristics are evaluated based on current speed 2000 *Speed* (\uparrow 3.7 *Parameterization of characteristics*).

For parameterizing the characteristic, there are up to 16 triplets of values available for each. This implies that on using speed notches each speed notch can be assigned its own value. This is not obligatory, though.

The values of the characteristics are stored at the following parameter positions:

6600 to 6615 <i>ExcitControl:n(x)</i> :	speed values for fuel setpoint characteristic and excitation signal characteristic
6620 to 6635 <i>ExcitControl:f(x)</i> :	fuel setpoint characteristic
6640 to 6655 <i>ExcitControlSetp(x)</i> :	excitation signal characteristic.

The control will calculate the correction value with the following formula:

$$\text{Korrekturwert} = (\text{aktuelle Füllung} - \text{Füllungswert (Drehzahl)}) \cdot \frac{\text{Bewertungsfaktor}}{100 \%} + \text{Erregungssignalwert (Drehzahl)}$$

This means that the speed dependent fuel quantity derived from characteristic 6620 *ExcitControl:f(x)* is subtracted from the current fuel quantity 2350 *FuelQuantity* and the difference is multiplied by the weighting factor 600 *ExcitCntrlFactor*. Adding the speed dependent excitation signal value 6640 *ExcitControlSetp(x)* will yield the excitation control correction value 2600 *ExcitationSetpoint*.

Hence when current fuel quantity coincides with the fuel quantity characteristic it is exclusively the excitation signal characteristic that will have an effect.

When current fuel quantity, however, does not coincide with the characteristic it is possible to choose whether the excitation signal is to be increased or decreased by modifying the weighting factor. With a negative weighting factor, a value smaller than the excitation signal value will be output whenever the current injection quantity is above the injection quantity characteristic value (generator excitation), whereas with a positive weighting factor a value larger than the excitation signal value will be output in the same case (generator de-excitation).

13.2.1.1 Fuel quantity offset

The value derived from the fuel quantity characteristic can be modified by 636 *ExcitFuelOffset*. This allows parallel shifting of the fuel quantity characteristic as might be necessary when calibration of one engine is to be transferred to another engine in case the profile of the characteristic is basically identical for both. If no such shifting is required the offset parameter must be set to 0.

13.2.1.2 Excitation ramp

Running up to the calculated excitation signal can be delayed by ramps. The ramp is to be adjusted and activated by means of the following parameters:

610 <i>ExcitCntrlRampUp</i>	upward ramp rate
611 <i>ExcitCntrlRampDown</i>	downward ramp rate
4610 <i>ExcitControlRampOn</i>	activation of the ramps.

13.2.1.3 Determination of excitation characteristics

For capturing the two characteristics, 600 *ExcitCntrlFactor* must be set to 0%. This means that it is exclusively the signal characteristic that will be relevant. Furthermore, it must be ensured that no fuel quantity limitation whatsoever is active, i.e., that all of the fuel quantity limitation functions are disabled (\uparrow 9 *Limiting Functions*).

Then, the speed points for which certain power outputs have been defined should be run up to. At each speed supporting point the excitation signal is to be adjusted manually until the desired power output is obtained. The resulting fuel quantity can then be read from 2350 *FuelQuantity*.



Note

Measuring and indicating current power output will require using an external device.

The most convenient way of defining the speed setpoints as well as of adjusting the excitation signal is by using the PC. To do so, the parameters 4020 *SpeedSetpPCOn* and 4635 *ExcitationSetpPCOn* have to be set to 1. Speed setting is made using the parameter 20 *SpeedSetpPC*, input of the excitation signal is achieved using the parameter 635 *ExcitationSetpPC*.

Speed base points must be entered as x-values in the curve 6600..6615 *ExcitControl:n(x)* einzutragen (\uparrow 3.7 *Parameterization of characteristics*). The determined excitation signal value is entered above the speed supporting point in the characteristic 6640..6655 *ExcitControlSetp(x)*. The fuel quantity 2350 *FuelQuantity* thus established is then to be entered in 6620..6635 *ExcitControl:f(x)* under the same index as the speed value.

Once the characteristics have been evaluated, power control via fuel quantity can be enabled by setting the factor 600 *ExcitCntrlFactor*. The greater this factor is chosen the greater an amplification of the control circuit will result. The values are determined by running up to all speeds on-load; at each point control should be as fast as possible without becoming unstable.

20 <i>SpeedSetpPC</i>	Speed setpoint adjustment via PC
600 <i>ExcitCntrlFactor</i>	Weighting factor
635 <i>ExcitationSetpPC</i>	Adjustment of excitation signal by PC
4020 <i>SpeedSetpPCOn</i>	Activate speed setpoint adjustment via PC
4635 <i>ExcitationSetpPCOn</i>	Activate adjustment of excitation signal via PC
6600..6615 <i>ExcitControl:n(x)</i>	Speed values for the characteristics
6620..6635 <i>ExcitControl:f(x)</i>	Fuel quantity values for the fuel setpoint characteristic
6640..6655 <i>ExcitControlSetp(x)</i>	Excitation signal values for the excitation characteristic

Parameterizing Example:

With diesel-electric locomotive operation, generator excitation is supposed to be controlled in such a way that in steady state operation the diesel engine follows a characteristic within the range of optimum consumption.


If the driving system is operating in accordance with the fuel quantity setpoint characteristic it is the value of the excitation characteristic that will be output. If above the fuel quantity setpoint characteristic, the signal is reduced to a lower value which implies that generator excitation is also reduced until the system is working in accordance with the characteristic again.

Let us suppose, e.g., that with a speed of 1,900 rpm actual actuator travel amounts to 70 %, and that for this speed the value of the fuel quantity setpoint characteristic is 60 %. Now, instead of the excitation characteristic value of 50 % an excitation signal of 37.5 % is to be output in order to reduce actuator travel to 60 %.

Since the weighting factor 600 *ExcitCntrlFactor* has been set to 0%, this characteristic will not take account of load. By entering in the above formula the desired influence of load upon the excitation signal, the weighting factor can be derived from it:

$$37.5 \% = 10 \% \cdot \frac{\text{Factor}}{100 \%} + 50 \%$$

This yields a weighting factor of -125% by which the entire excitation characteristic will be shifted in parallel.


Fig. 35: Excitation control

Number	Parameter	Value	Unit
600	<i>ExcitCntrlFactor</i>	-125	%

Activation:

4600	<i>ExcitationControlOn</i>	1
4601	<i>ExcitGovOrControl</i>	0

13.2.2 Excitation governing

With excitation governing, 2600 *ExcitationSetpoint* constitutes the output signal of a fuel control circuit into which a desired fuel quantity value (reference value) and an actual fuel quantity value will enter. In contrast to excitation control, there exists no adjustable interrelation between speed and excitation signal basing on some characteristic.

The reference value for the excitation control circuit is derived from a single excitation characteristic (\uparrow 3.7 *Parameterization of characteristics*) where in dependence on speed the fuel quantities are stored that corresponds to the required generator output.

6600..6615 *ExcitControl:n(x)* : speed values for the excitation characteristic

6620..6635 *ExcitControl:f(x)* : fuel values for the excitation characteristic

Starting from current speed 2000 *Speed* the characteristic is evaluated, and the fuel quantity setpoint thus determined is indicated by 2602 *ExcitFuelSetpoint*, after it has been acted upon by any offsets, ramps or limitations.

The actual values of the excitation control circuit corresponds to the current, possibly limited fuel quantity setpoint 2350 *FuelQuantity* as derived from the speed control circuit.

The output value of the excitation control circuit is 2600 *ExcitationSetpoint*. This value can in addition be filtered by setting 633 *ExcitationSetpFilter* to a value greater than 1.

13.2.2.1 Fuel quantity offset

The fuel quantity setpoint value derived from the excitation characteristic can be modified by 636 *ExcitFuelOffset*. This will allow parallel shifting of the fuel quantity characteristic as might be necessary when calibration of one engine is to be transferred to another engine in case the profile of the characteristic is basically identical for both. If no such shifting is required the offset parameter must be set to 0.

13.2.2.2 Ramps for fuel quantity setpoint

The fuel quantity setpoint value (\uparrow 13.2.3 *Power limitation*) as derived from the characteristic and possibly limited can be delayed by ramps. The ramp is to be adjusted and activated by means of the following parameters:

640 *ExcitGovFuelRampUp* Upward ramp for fuel quantity setpoint

641 *ExcitGovFuelRampDown* Downward ramp for fuel quantity setpoint

4640 *ExcitGovFuelRampOn* Activation of both ramps

13.2.2.3 Adjustment of PID Parameters

The setpoint value of the fuel quantity 2602 *ExcitFuelSetpoint* and the actual value 2350 *FuelQuantity* enter go into a control circuit whose PID parameters are to be entered in

630 *ExcitGovGain*

631 *ExcitGovStability*

632 *ExcitGovDerivative*

The result is 2600 *ExcitationSetpoint*. While determining the control circuit parameters, all limiting functions should be de-activated.

To accommodate the control circuit to different operating conditions the values of 630 *ExcitGovGain* and 631 *ExcitGovStability* can be corrected in dependence on injection quantity. For unstable working points (e.g., due to non-linear interrelations between actuator travel and injection quantity or between excitation signal and

generator output, or, with two cycle diesel engines, when operating within the turbocharger's range of transition from mechanical to exhaust gas drive) some decrease may be necessary whereas full load may under certain circumstances require an increase. The correction factor is to be entered in the following characteristics (\uparrow 3.7 *Parameterization of characteristics*):

6660 to 6675 *ExcitGovPI:f(x)* injection values for PI correction

6680 to 6695 *ExcitGovPI:Corr(x)* Correction values for P and I

Correction of the PI values is activated by setting 4630 *ExcitGovPICurveOn* = 1. The currently determined correction value is indicated by 2630 *ExcitPI_CorrFactor*.

13.2.2.4 Determination of excitation characteristic

Furthermore, it must be ensured that no fuel quantity limitation whatsoever is active, i.e., that all of the fuel quantity limitation functions are disabled (\uparrow 9 *Limiting Functions* and \uparrow 13.2.3 *Power limitation*).

Then, the speed points for which certain power outputs have been defined should be run up to one after another. At each speed supporting point the excitation signal is to be adjusted manually until the desired power output is obtained. The resulting fuel quantity can then be read from 2350 *FuelQuantity*.



Measuring and indicating current power output will require using an external device.

Note

The most convenient way of defining the speed setpoints as well as of adjusting the excitation signal is by using the PC. To do so, the parameters 4020 *SpeedSetpPCOn* and 4635 *ExcitationSetpPCOn* have to be set to 1. Speed setting is made using the parameter 20 *SpeedSetpPC*, input of the excitation signal is achieved using the parameter 635 *ExcitationSetpPC*.

Speed base points must be entered as x-values in the curve 6600..6615 *ExcitControl:n(x)* einzutragen. The fuel quantity thus established is then to be entered in 6620..6635 *ExcitControl:f(x)* under the same index as the speed value.

20 <i>SpeedSetpPC</i>	Speed setpoint adjustment via PC
635 <i>ExcitationSetpPC</i>	Adjustment of excitation signal by PC
4020 <i>SpeedSetpPCOn</i>	Activate speed setpoint adjustment via PC
4635 <i>ExcitationSetpPCOn</i>	Activate adjustment of excitation signal via PC
6600..6615 <i>ExcitControl:n(x)</i>	Speed values for the excitation characteristic
6620..6635 <i>ExcitControl:f(x)</i>	Fuel quantity values for excitation characteristic.

13.2.3 Power limitation

The excitation signal 2600 *ExcitationSetpoint* that is either determined by excitation control or excitation governing can be limited by various factors.

In the case of excitation control, it is the excitation signal 2600 *ExcitationSetpoint* itself that will be subject to limitation. The currently applied limit is indicated by 2601 *ExcitControlLimit*.

With excitation governing, the excitation signal is indirectly limited by limiting the fuel quantity setpoint for the control circuit.

The parameter 2640 *ExcitLimitMaxActive* is used to indicate whether any limitation is active. The values of 2641 *ExcitFuelLimActive* through 2647 *ExcitSpeedLimActive* offer more detailed information about the causes of limitation. The different causes are described below.

Indication parameter	Used for	Reason	Reference
2640 <i>ExcitLimitMaxActive</i>	One of the following power limitations is active:		
2641 <i>ExcitFuelLimActive</i>	Excitation control and governing	Speed or boost pressure dependent fuel quantity limitation	↑ 9.1 Speed dependent fuel limitation, ↑ 9.2 Boost pressure dependent fuel limitation
2642 <i>ExcitForceLim1Active</i> , 2643 <i>ExcitForceLim2Active</i>	Excitation control and governing	Power limitation selected by switching function	↑ 13.2.3.1 Externally activated power limitation
2644 <i>ExcitSlideLimActive</i>	Excitation control and governing	Power limitation by active slide protection	↑ 13.4 Slide protection
2645 <i>ExcitTempLimActive</i>	Excitation governing	Temperature dependent power reduction	↑ 13.2.3.2 Temperature dependent power reduction
2646 <i>ExcitBoostLimActive</i>	Excitation governing	Boost pressure dependent power limitation	↑ 13.2.3.3 Boost pressure dependent power limitation
2647 <i>ExcitSpeedLimActive</i>	Excitation governing	Speed-dependent power limitation	↑ 13.2.3.4 Speed dependent power limitation

Table 19: Excitation signal limitation

13.2.3.1 Externally activated power limitation

Activation of the switch functions 2823 *SwitchExcitLimit1* or 2824 *SwitchExcitLimit2*, respectively, offers the possibility of limiting the excitation signal to two previously defined maximum values.

When using excitation control, the excitation signal 2600 *ExcitationSetpoint* itself will be limited to 605 *ExcitLimitForced1* or 606 *ExcitLimitForced2*, respectively.

When using excitation governing, however, the fuel quantity setpoint is limited to 637 *ExcitFuelLimForced1* or 638 *ExcitFuelLimForced2* respectively, and the excitation signal is affected via the control circuit.

The parameters 2642 *ExcitForceLim1Active* and 2643 *ExcitForceLim2Active* respectively indicate whether limitation is due to externally activated power limitation.

13.2.3.2 Temperature dependent power reduction

In the event that engine temperature 2907 *CoolantTemp* exceeds the value of 651 *ExcitLimitTempLow* the entire excitation characteristic is lowered in dependence of temperature. The lowering value is linearly interpolated between reduction by 0 % at 651 *ExcitLimitTempLow* and reduction by 650 *ExcitLimitTempDec* at 652 *ExcitLimitTempHigh*. If current temperature exceeds the value of 652 *ExcitLimitTempHigh*, there will be continuous reduction by the value of 650 *ExcitLimitTempDec*.

This function is operative only with excitation governing and is to be activated by the parameter 4650 *ExcitTempLimitOn*. The actual maximum value of the fuel quantity setpoint thus obtained is indicated by 2650 *ExcitFuelLimitTemp*. Whether this value has caused limitation can be seen from 2645 *ExcitTempLimActive*.

On exceeding a coolant temperature limit independent of this function, it is also possible to activate forced idle speed (\uparrow 10.5 *Forced idle speed in locomotive applications*).

13.2.3.3 Boost pressure dependent power limitation

This function is provided to take into account that atmospheric pressure is reduced when operating in high altitudes. By lowering the excitation signal, generator output is reduced and automatically also diesel injection quantity. In diesel-electric operation this function should be preferred to boost pressure dependent fuel quantity limitation (\uparrow 9.2 *Boost pressure dependent fuel limitation*) where injection quantity is reduced without reduction of load. This may lead to speed drops and engine overload.

By means of a boost pressure sensor the current boost pressure 2904 *BoostPressure* is measured and then a characteristic is used to determine the associated maximum fuel quantity. The values of the characteristics are stored at the following parameter positions:

6440 to 6449 *ExcitBoostLimit:p(x)* Boost pressure values for limitation curve

6460 to 6469 *ExcitBoostLimit:f(x)* Fuel quantity values for limitation curve.

For parameterizing the boost pressure dependent limit characteristic, up to 10 pairs of values are available. Each pair of values consists of one boost pressure value and one

fuel quantity value, both with the same index. Intermediary values between adjacent pairs of variates will be interpolated by the control (\uparrow 3.7 *Parameterization of characteristics*).

This function is operative only with excitation governing and is to be activated by the parameter 4655 *ExcitBoostLimitOn*. The actual maximum value of the fuel quantity setpoint thus obtained is indicated by 2655 *ExcitFuelLimitBoost*. The parameter 2646 *ExcitBoostLimActive* will indicate whether there is limitation caused by this value.

13.2.3.4 Speed dependent power limitation

Based on current speed the related maximum excitation signal is determined via a characteristic.

The values of the characteristics are stored at the following parameter positions:

6966 to 6981 *ExcitSpeedLim:n(x)* Speed values for limitation curve

6982 to 6997 *ExcitSpeedLim:E(x)* Excitation values for limitation curve

For parameterizing the speed dependent limit characteristic, there are up to 16 pairs of values available. Each pair of values consists of one speed value and one excitation value, both with the same index. Intermediary values between adjacent pairs of variates will be interpolated by the control (\uparrow 3.7 *Parameterization of characteristics*).

This function is operative only with excitation governing and is to be activated by the parameter 4656 *ExcitSpeedLimitOn*. The resulting actual maximum value for excitation is indicated by 2656 *ExcitationLimitSpeed*. The parameter 2647 *ExcitSpeedLimActive* will indicate whether there exists limitation caused by this value.

13.3 Low idle speed

The function "Low Idle Speed" is offered to save fuel. It allows to set idle speed to a specific level if no excitation signal has been requested for a pre-set minimum time.

The lowest possible idle speed is indicated in 24 *SpeedMinAbsolute*. If after activation of signal 2841 *SwitchLowIdleOn* no excitation signal is triggered for the duration of 242 *SpeedMinAbsDelay* (2600 *ExcitationSetpoint* = 0), the speed setpoint is progressively lowered with ramp value 241 *SpeedMinAbsRampDown* towards 24 *SpeedMinAbsolute*. As soon as the switching function is disabled or the excitation signal is triggered again, the engine returns to the previous operating mode using the normal ramp (\uparrow 7.7 *Speed ramp*).

If pre-set temperatures are exceeded, it is possible to protect the engine by letting it run at forced idle speed (\uparrow 10.5 *Forced idle speed in locomotive applications*). If conditions for low idle speed are given, in this case too the lowest possible idle speed will be used.

13.4 Slide protection

When it detects skidding wheels, the control will continuously reduce the excitation signal until the wheels have a firm grip again. A separate electronic device is required to detect sliding of the wheels and to transmit a specific signal to the control. If modification of the excitation signal is insufficient or impossible the speed setpoint can be modified instead.

13.4.1 Reduction of excitation by digital slide signal

The switch function 2818 *SwitchSlide* is used to inform the control about the currently valid status of slide protection:

2818 <i>SwitchSlide</i> = 0	no slide signal coming in
2818 <i>SwitchSlide</i> = 1	slide signal received.

The same switch can also initiate influencing the speed setpoint (↑ 13.4.3 *Speed reduction by digital slide signal*). When the control recognizes the slide signal for the first time, the current excitation signal 2600 *ExcitationSetpoint* is frozen and reduced by 620 *ExcitSlideDec*. This new excitation signal is held for the time defined by 621 *ExcitSlideDuration*. If there is still a slide signal coming in after that, the excitation signal will be reduced once again. Reduction will be repeated until the slide signals cease to come in, i.e., until the wheels are gripping again.

After that the currently calculated excitation signal is activated again and run up to via the power ramp in case this ramp has been activated.

This digital slide protection function is to be activated by the parameter 4620 *DigSlideExcitCntrlOn*. The parameter 2644 *ExcitSlideLimActive* will indicate whether power limitation is active due to slide protection.




Fig. 36: Slide protection

13.4.2 Reduction of excitation by analogue slide signal

Instead of a digital slide protection signal and a fixed reduction of the excitation value during a predefined period of time (\uparrow 13.4.1 *Reduction of excitation by digital slide signal*) there exists also the possibility of having the reduction value defined by the evaluating electronics directly via a sensor input, viz. 2914 *SlideExcitReduction* (\uparrow 17 *Configuration of sensors*).

Whenever 2914 *SlideExcitReduction* yields a value not equal to zero for the first time, the current excitation signal 2600 *ExcitationSetpoint* will be frozen. Up to the time when 2914 *SlideExcitReduction* returns to zero, its actual value is subtracted from the frozen value. The new excitation signal 2600 *ExcitationSetpoint* will result from the smaller value obtained by the reduction as just described and from the excitation signal value depending on current speed and fuel quantity. This means that the calculations via excitation control/excitation governing will continue but will only be applied if they define an excitation signal value even smaller than the one determined by the reduced value.

This slide protection function can be activated by 4621 *AnaSlideExcitCntrlOn*. Again 2644 *ExcitSlideLimActive* will indicate whether power limitation is active due to slide protection.



Note

*Special care should be taken when determining the reference values at the analogue input for 2914 *SlideExcitReduction* so that a value greater than zero will be measured only if any slide protection measure is supposed to take effect.*

13.4.3 Speed reduction by digital slide signal

The same switch function 2818 *SwitchSlide* that initiates affection of the excitation signal (\uparrow 13.4.1 *Reduction of excitation by digital slide signal*) serves to inform the control about the state of slide protection that is currently active.

2818 <i>SwitchSlide</i> = 0	no slide signal coming in
2818 <i>SwitchSlide</i> = 1	slide signal received.




Fig. 37: Slide protection

Whenever the control recognizes the slide signal, set speed will be reduced by 1350 *DigSlideSpeedDec*. This new speed setpoint is held for the time defined by 1355 *DigSlideDuration*. If after that there is still a slide signal coming in, the set value will be reduced once again. Reduction will be repeated until the slide signals cease to come in,

i.e., until the wheels are gripping again. After that, the previous setpoint is restored and is slowly run up to via the \uparrow 7.7 *Speed ramp* if a speed ramp is being used.

This slide protection function is activated with parameter 5351 *DigSlideSpeedSetpOn*.

13.4.4 Speed reduction by analogue slide signal

Instead of a digital slide protection signal and a fixed reduction of the excitation value for a predefined period of time (\uparrow 13.4.3 *Speed reduction by digital slide signal*) there exists also the possibility of having the reduction value defined by the evaluating electronics directly via a sensor input, viz. 2915 *SlideSpeedReduction* (\uparrow 17 *Configuration* of sensors).

Whenever 2915 *SlideSpeedReduction* yields a value not equal zero for the first time, the current speed setpoint will be frozen. Up to the time when 2915 *SlideSpeedReduction* returns to zero again, its value is subtracted from the frozen value and care is taken that the resulting speed setpoint will never drop below 1356 *AnaSlideSpeedMin*.

This slide protection function can be activated by 5352 *AnaSlideSpedSetpOn*.

Special care should be taken when determining the reference values at the analogue input for 2915 *SlideSpeedReduction* so that a value greater than zero will be measured only if any slide protection measure is supposed to take effect.

14 Generator operation

For parallel generator operation, various devices are required to perform synchronization and real load sharing in isolated parallel operation or real load control when paralleled to the mains. All of these devices will affect the speed setpoint. It is for this reason that a setpoint offset for synchronization and a setpoint offset for load control are added to the setpoint value as determined from the pre-defined setpoint (\uparrow 7.4 *Generator operation*).

If no additional load control device is provided then droop (proportional band) can be used instead though with certain restrictions in case of isolated parallel operation. In mains parallel operation droop can be employed for setting the desired load. In isolated parallel operation droop is made use of to obtain homogeneous load sharing.

To use the specific generator functions the parameter 1810 / 3810 *OperationMode* has to be set to 3.



Note

The following descriptions of synchronizing and power control are valid for automatic operation only. For manual operation and for the conditions of switching over between automatic and manual operation refer to \uparrow 14.4 Automatic or manual operation.

14.1 Synchronization

Synchronization can be performed analogously using the **HEINZMANN** synchronization unit or digitally by presetting synchronization values. Selection is made by the parameter

5210 *SyncAnalogOrDigital* = 0 digital synchronization

5210 *SyncAnalogOrDigital* = 1 synchronization using the synchronization unit

The following switch function serves to inform the control unit that synchronization is enabled:

2834 *SwitchSyncEnable* = 0 synchronization not enabled

2834 *SwitchSyncEnable* = 1 synchronization enabled



Note

If no external switch is assigned to the switching function, the function synchronization will always be active. When assigning digital inputs to the switching functions for enabling synchronization and load control the same input can be assigned inverted which will allow to easily change over between the two operating modes.

The setpoint change resulting from synchronization and load control is indicated by the parameter 2042 *GenSetOffset*.

14.1.1 Digital synchronization

With digital synchronization two switching functions are provided for determining whether the setpoint is to be increased or decreased. The states of the switching functions can be read from the parameters

2825 <i>SwitchSpeedInc</i> = 0	no increase of speed setpoint
2825 <i>SwitchSpeedInc</i> = 1	increase of speed setpoint
2826 <i>SwitchSpeedDec</i> = 0	no decrease of the speed setpoint
2826 <i>SwitchSpeedDec</i> = 1	decrease of the speed setpoint.

There will be no changes of the setpoint unless the two parameters read different values, i.e., if only one of the two functions is active. The scope of the change can be defined by means of the parameter 1210 *DigitalPotSpeedRamp* with speed change per second as a unit. Setpoint changes can be conducted until either maximum or minimum speed is attained. If the signals for changing the setpoint consist of pulses, these pulses must have a duration of at least 20 ms in order to be detected by the control circuit. The control electronics will respond to pulses for changing the setpoint only when the engine is running.

The setpoint change by the digital potentiometer is added as an offset to the value of 2033 *SpeedSetpSelect* as resulting from the preceding setpoint determination after the ramp. This modification of the speed setpoint is executed with the given step size and direction until either maximum (or minimum) speed is attained or the states of both functions are identical (0 or 1). The offset remains in effect even if there is a change-over to some other setpoint value or if an adjustment of the analogue potentiometer occurs. The minimum or maximum speeds, however, can never be exceeded (except for droop). The offset can be read from the parameter 2041 *DigitalPotOffset*. With the engine standing, the accumulated offset will be cleared.


If an offset is applied to the analogue setpoint, minimum or maximum speed will be attained before the potentiometer reaches its end position. When the potentiometer is further turned into its stop position, the offset will be decreased again. In other words, if there has been a digital modification of the setpoint and the potentiometer is then turned on full-scale, the resulting offset will have disappeared.

Parameterizing Example:

Number	Parameter	Value	Unit
1210	<i>DigitalPotSpeedRamp</i>	5	<i>rpmps</i>
1810/3810	<i>OperationMode</i>	3	
5210	<i>SyncAnalogOrDigital</i>	0	

Indication:


2825	<i>SwitchSpeedInc</i>	0/1
2826	<i>SwitchSpeedDec</i>	0/1



If fuel quantity arrives at the high fuel quantity limit(2711 FuelLimitMaxActive = 1) there will be no further increase of speed. This will prevent increasing the set speed when the engine is operating in overload blocking mode (i.e., when the engine is operating at its power range limit and if there is an additional speed drop due to load). Similarly, the speed setpoint cannot be reduced if fuel quantity is at the low fuel quantity limit (2710 FuelLimitMinActive = 1).


14.1.2 Synchronization using the HEINZMANN Synchronizing Unit

With analogue synchronization, the control unit will receive the actual output value of the HEINZMANN synchronization unit SyG 02 as sensor value 2903 SyncInput via an analogue input. This is provided by setting the parameter 5210 SyncAnalogOrDigital to "1".



When the HEINZMANN synchronizing unit is connected to a control of PANDAROS type, analogue input 2 is to use and 5211 SyncInputOrHZM_SyG must be set to 0.

In order to use the switching function 2834 SwitchSyncEnable this function must be active. Likewise, when used, the switching function 2836 SwitchAutoOrManual must have been set to automatic operation (↑ 14.4 Automatic or manual operation).



Prior to adjusting the synchronizing unit, the voltages of the generators should be set to equal values. Besides, reactive load distribution has to be ensured, e.g., by paralleling the generator brushes. If necessary, the generator manufacturers will provide information on this subject.

To adapt the setpoint input to the synchronization unit the following steps must be taken:

NOTICE	Before switching on for the first time, it must be checked whether the voltage across the mains breaker is approximately 0 Volts at all three phases. This is to ensure that there is no phase rotation at the mains breaker. Caution: High voltage!
---------------	---

- With bridges between the terminals 14 and 15 and the terminals 17 and 18 of the synchronization unit the generator set is to be started and voltage to be applied to the synchronization unit. Parameter 1220 SynchronFactor is to be set to 10 %, and then the engine to synchronous speed, e.g., 50 Hz.
- Since the control value from the synchronization unit can completely cover the analogue input range of 0..5 V the reference and error thresholds for the respective

analogue input should be set to the minimum and maximum values (\uparrow 20.2.4 *Error detection for analogue inputs*).

- The signal coming in from the synchronization unit is read out via the parameter 2903 *SyncInput* and then entered in the parameter 1221 *SynchronReference* as a reference value. Reference should be about 50%.
- As soon as frequencies, phase positions and voltages of both generators are equal the relay of the synchronization unit will operate after a delay time that can be adjusted from 0.5 to 5 seconds. When terminals 17 and 18 are bridged the relay for addressing the generator contactor will not switch. This bridge will therefore have to remain connected while adjustments are being made.
- Synchronization is then activated by removing the bridge between terminals 14 and 15. To optimize the dynamic behaviour of synchronization the amplification of the synchronization signal may be modified by means of the parameter 1220 *SynchronFactor* starting with 2%.
- The value range of the amplification factor is defined as follows: Given a signal difference of 10% between 2903 *SyncInput* and 1221 *SynchronReference* and an amplification factor 1220 *SynchronFactor* of 10%, a speed change of +10 rpm will be achieved.
- When synchronization is operating satisfactorily, the bridge between terminals 17 and 18 is to be removed to enable closing of the generator contactor.



Note

For further information on the synchronization unit, please refer to the manual Synchronization Unit SyG 02 no. E 82 002-e.

14.2 Load control

Load control can be performed analogously using the **HEINZMANN** Load Measuring Unit or an external setpoint potentiometer or – on request – with an integrated power governor. Selection is made by the parameters

5233 *PowerGovernorOrLMG* = 1 integrated power governor is used

5233 *PowerGovernorOrLMG* = 0 integrated power governor is not used

5230 *LoadControlOrPot* = 1 HEINZMANN Load Measuring Unit

5230 *LoadControlOrPot* = 0 external potentiometer



Note

*Parameter 5233 *PowerGovernorOrLMG* is available only if the integrated load governor is implemented in the firmware. Otherwise only parameter 5230 *LoadControlOrPot* is valid for the selection.*

The following switch functions normally connected to generator contactor or mains breaker, serve to inform the control unit that load control is enabled:

2835 *SwitchLoadEnable* = 0 load control not enabled

2835 *SwitchLoadEnable* = 1 load control enabled.




If no external switch is assigned to the switching function, the load control function will always be active. When assigning digital inputs to the switching functions for enabling synchronization and load control the same input can be assigned inverted which will allow to easily change over between the two operating modes.

The setpoint change resulting from synchronization and load control is indicated by the parameter 2042 *GenSetOffset*.

14.2.1 Load control using the HEINZMANN Load Measuring Unit

Load control by means of the HEINZMANN Load Measuring Unit LMG 10 is based on evaluation of the output signal that is coming from the Load Measuring Unit and has been connected to one of the control unit's analogue inputs. This signal can be generated also by the generator management system THESEUS (or another load control device). In this case the following statements apply similarly, except that THESEUS has operates in the direction opposite to that of the Load Measuring Unit, therefore the amplification factor must be entered in positive.

To connect the Load Measuring Unit 5233 *PowerGovernorOrLMG* must be set to 0 and 5230 *LoadControlOrPot* must be set to 1.



*When the HEINZMANN Load Measuring Unit LMG 10 is connected to a control of PANDAROS type, analogue input 1 is to use and 5231 *LoadControlOrHZM_LMG* must be set to 0. This parameter must be set to 1 when using the THESEUS or another load control device.*

Besides, when using the switching function 2835 *SwitchLoadEnable* this function must have been activated. Likewise, when used, the switching function 2836 *SwitchAutoOrManual* must have been set to automatic operation (↑ 14.4 *Automatic or manual operation*).



*Droop is deactivated automatically if this operating mode is active and 1230 *LoadControlFactor* is not equal to zero, for droop must not be used in this case.*

To adapt the setpoint input to the Load Measuring Unit the following procedure must be followed:

- The Load Measuring Unit must have been completely connected, the engine must be running, and operating voltage must be applied.

- The generator breaker must be open so that there is no power output from the generator.
- Since the control value from the load measuring unit can completely cover the analogue input range of 0..5 V, the reference and error thresholds for the respective analogue input must be set to the minimum and maximum values (↑ 20.2.4 Error detection for analogue inputs).
- The parameter 1230 *LoadControlFactor* is to be set to 0.
- The signal from the Load Control Unit is read out via the parameter 2902 *LoadControlInput* and entered in the parameter 1231 *LoadControlReference* as a reference value. Reference should be about 30%.
- With the generator on load the setting is conducted at full load. To optimize the dynamic behaviour of the power control, the amplification of the power setpoint signal sent to the governor may be modified by means of the parameter 1230 *LoadControlFactor* starting with -2%.
- The value range of the amplification factor is defined as follows: A signal difference of -10% between 2902 *LoadControlInput* and 1231 *LoadControlReference* and an amplification factor 1230 *LoadControlFactor* of 10% will yield a speed change of +10 rpm.



The working direction of the HEINZMANN Load Control Unit LMG 10 is inverted, i.e., decreasing the control value will increase speed and vice versa. Therefore, the values to be entered for 1230 LoadControlFactor must be negative ones when using the LMG 10.

For more detailed information on the Load Control Unit, please refer to the manual Load Control Unit LMG 10-1 no. E 02 001-e.

In automatic mode or if 5230 LoadControlOrPot = 1 and 2835 SwitchLoadEnable aktiated (or not used), ↑ 7.8 Droop will be automatically de-activated by the control unit as these operating modes do not permit of using droop.

14.2.2 Load control by a preset value

The power output to be produced by the engine in generator operation may also be directly set by a setpoint within the range of 0..100%. This mode requires the parameter 5230 *LoadControlOrPot* to be set to "0". In this case, there is actually no power control but fuel quantity is set according to the given power setpoint assuming output to be linearly depending on fuel quantity.

In pure mains parallel operation, there will be no problem in using droop. Since in this case actual speed must not change when the generator set is coupled to the mains alteration of the setpoint can be used to change fuel quantity and by this engine load.

Droop is required to set a stable load point for the engine, for without droop the engine would slowly tend either to minimum fuel quantity or maximum fuel quantity as resulting from the [↑]9 *Limiting Functions*, because without droop there exists no well-defined relation between speed and fuel quantity. Hence it would be impossible to obtain a stable point.

This is why for this application case a droop of normally 4 % is preset which allows to obtain stable adjustment of load. With droop below 4 %, there exists a certain risk of load variations since no stable load point can be found.

In island parallel operation, droop can be used to achieve that all installations that have been coupled together across the bus bar take over the same percentage of load. This mode of operation, however, has the disadvantage that due to droop load sharing will result in speed changes, i.e., depending on load different speeds will be attained.

If this is not desirable and load distribution at identical speeds is required (so-called isochronous operation), load sharing has to be performed by means of an additional control device, e.g., by employing [↑]14.2.1 *Load control using the HEINZMANN Load Measuring Unit* or by using the [↑]14.3 *Digital generator management THESEUS*.

In isolated parallel operation with droop all sets have been coupled across a bus bar. This means that all sets are working at identical actual speeds. Since a well-defined relation between speed and load is given by droop all sets will produce the same percentage of power output provided droop has been correctly set.

For correct adjustment of droop, the reference speeds 123 *Droop1SpeedRef* and 128 *Droop2SpeedRef* respectively as well as the droops 120 *Droop1* and 125 *Droop2* respectively must be identical for all sets.

The fuel reference value for zero load 121 *Droop1RefLow* and full load 122 *Droop1RefHigh* (126 *Droop2RefLow* and 127 *Droop2RefHigh* respectively) must be determined and parameterized separately for each engine – even if droop refers to an actual power signal ([↑]7.8 *Droop*).

14.2.2.1 Analogue setpoint adjustment

To activate this function, the parameter 5230 *LoadControlOrPot* is to be set to "0". Furthermore, droop must have been activated as it is absolutely necessary for correct operation ([↑]7.8 *Droop*).

Presetting power output is achieved by means of the input for the load setpoint 2902 *LoadControlInput*. Using preset power output the current load is adjusted via the fuel quantity reference values for droop 121 *Droop1RefLow* and 122 *Droop1RefHigh* or respectively 126 *Droop2RefLow* and 127 *Droop2RefHigh* for droop 2. In other words, with 2902 *LoadCtrlInput* set to 0 %, fuel quantity will correspond to 121 *Droop1RefLow*, and similarly with 2902 *LoadCtrlInput* = 100 %, fuel quantity will correspond to 122 *Droop1RefHigh*. Intermediary values will be accordingly interpolated.

Parameterizing Example:

Number	Parameter	Value	Unit
120	<i>Droop1</i>	4	%
121	<i>Droop1RefLow</i>	20	%
122	<i>Droop1RefHigh</i>	80	%
123	<i>Droop1SpeedRef</i>	1500	rpm
2040	<i>DroopOffset</i>	0..60	rpm
2042	<i>GenSetOffset</i>	-60..0	rpm
2902	<i>LoadControlInput</i>	0..100	%
4120	<i>DroopOn</i>	1	
5230	<i>LoadControlOrPot</i>	0	

In this example, the engine is running at rated speed 1500 rpm and 4% droop. The fuel quantity reference value for zero load is 20 % (the control unit reads 20 % fuel quantity for 0 % power output) and the reference value for full load is 80 % (the control unit reads 80 % fuel quantity for 100 % power output). Now, the desired output can be adjusted within the range from 0% to 100% by means of the load setpoint.

Due to droop, there is a speed setpoint offset of 60 rpm at zero load (4% of 1500 rpm) and of 0 rpm at full load, as indicated by the parameter 2040 *DroopOffset*.

The load setpoint generates an opposite offset in order to return in combination with droop to the total setpoint value of 1500 rpm. This means, the 0 % load setpoint will correspond to an offset of -60 rpm and 100% load setpoint to an offset of 0 rpm.




Fig. 38: Load control by Setpoint Adjustment

Given a load setpoint of 2902 *LoadControlInput* = 40%, this will result in calculating a speed offset of -36 rpm. Fuel quantity will now continue to be altered via droop until droop arrives at the fuel quantity of 40 % and with this calculates an offset of +36 rpm which yields a speed setpoint of 1500 rpm - 36 rpm + 36 rpm = 1500 rpm.

So, by load adjustment a speed setpoint offset is formed which corresponds to the droop offset as mirrored with respect to rated speed thus yielding eventually a total offset of 0 rpm.

14.2.2.2 Digital setpoint adjustment

If synchronization and load control are performed exclusively via digital potentiometers it is recommended to configure load control for power adjustment by setpoint definition with 5230 *LoadControlOrPot* = 0 but to leave the load setpoint 2902 *LoadControlInput* unassigned by setting 902 *AssignIn_LoadCtrlInp* = 0 (\uparrow 17 *Configuration* of sensors). Due to this, the load setpoint will always yield 2902 *LoadControlInput* = 0 % which will result in an exactly opposite droop offset at zero load. This will cause the engine to run exactly at rated speed after start-up. Afterwards, synchronization can be performed via the digital potentiometer and load accordingly controlled.

This will, however, presuppose droop to have been accurately parameterized. Since in this case neither the switch 2836 *SwitchAutoOrManual* will be needed nor activation by 2834 *SwitchSyncEnable* and 2835 *SwitchLoadEnable* required, they must not have been configured.

14.2.3 Integrated power governor

If both a setpoint and an actual power signal are available, the control unit can take over load control if the integrated power governor has been implemented in the firmware by request. In this case the internal, higher-ranking power governor calculates a speed setpoint offset for the speed governor or, for mains operation, even the fuel setpoint for the engine, bypassing the speed control circuit.

To activate the integrated power governor 5233 *PowerGovernorOrLMG* must be set to 1. Parameter 5230 *LoadControlOrPot* has no meaning.

The power setpoint is transmitted in 2919 *PowerSetpoint*. For testing and commissioning, instead of this value a pre-set PC value 1243 *PowerSetpointPC* may be used if 5243 *PowerSetpPCOn* is set to 1. This function cannot be saved, i.e. after a reset of the control device the external value 2919 *PowerSetpoint* will be active again.

If required, the setpoint can be approached by ramp, with 1241 *PowerSetpRampUp* denoting increasing adjustment speed and 1242 *PowerSetpRampDown* decreasing adjustment speed. Both ramp directions are activated together with 5241 *PowerSetpRampOn*. If ramping is to be in one direction only, the other parameter must be set to its maximum value.

The resulting effective power setpoint is indicated in 3233 *PowerSetpEffective*. In addition, measured power 2918 *MeasuredPower* is indicated in relation to rated power 1232 *RatedPower* in 3232 *RelativePower*.

Power control is effective only when the engine is running (3830 *Phase* > 4), when the values for measured power and power setpoint are available without errors (3023 *ErrMeasuredPower* = 0 and 3024 *ErrPowerSetpoint* = 0), when there is no engine stop request (3802 *EngineStopRequest* = 0) and the breaker is closed (2835 *SwitchLoadEnable* = 1).

3234 *GovernorPowerOrSpeed* = 1 indicates whether the power governor is active or not. Otherwise only speed is controlled. The error situation arising when power control fails while the contactor is closed, because measured power or power setpoint register a sensor error should be provided for by always parameterizing the droop mode ↑ 7.8 *Droop*.

Settings for the power control circuit are made in:

1233 <i>PowerGovGain</i>	proportional factor of power governor
1234 <i>PowerGovStability</i>	integral factor of power governor
1235 <i>PowerGovDerivative</i>	derivative factor of power governor

The P-factor and I-factor can be subjected to power-dependent variation by activating a characteristic with 5235 *PIDCurvePowerOn* = 1.

6300 <i>PIDCrvPowGov:P</i>	power supporting points
6310 <i>PIDCrvPowGov:Corr</i>	correction factors
3235 <i>PowerPIDCorrFactor</i>	current correction factor for P and I

5234 *FuelOrSpeedOffsMode* allows to decide if power governor output acts as modification of the speed setpoint or directly on fuel quantity. Fuel offset is used in mains operation and speed setpoint offset in island operation. If a system is to work in both operational modes the modification of the speed setpoint must be parameterized.

5234 <i>FuelOrSpeedOffsMode</i> = 0	speed setpoint offset
5234 <i>FuelOrSpeedOffsMode</i> = 1	fuel offset
2042 <i>GenSetOffset</i>	current speed setpoint offset
2111 <i>FuelGenSetOffset</i>	current fuel offset

If fuel offset is enabled, 2835 *SwitchLoadEnable* should be connected with the mains breaker, if speed setpoint offset is used it should be connected with the generator contactor. When the integrated power governor works with fuel offset in mains operation, this is indicated by 3200 *GenCtrlMainsOrIsland* = 1.

The results of power control can be monitored for deviations if in 1239 *MaxPowerDifference* a maximum admissible deviation for the duration of 1240 *MaxPowerDiffMaxTime* is set and the function has been enabled with 5239

SupvisePowerDiffOn. Deviations from the set values are indicated in 3048 *ErrPowerDifference*.

14.2.3.1 Reduced power caused by knocking

The switch function 2818 *SwitchKnock* is used to inform the control about the presence of knocking.

2818 *SwitchKnock* = 0 no knocking

2818 *SwitchKnock* = 1 engine is knocking

When the power governor recognizes the knock signal for the first time, the current power setpoint 3233 *PowerSetpEffective* is frozen and reduced by 1245 *KnockPowerReduction*. This new power setpoint is maintained for the duration of 1246 *KnockDuration*. If after that there is still a knock signal coming in, the power setpoint will be reduced further. The reduction continues until the knock signal ends.

After that the currently pre-set power setpoint is activated again and run up to via the power ramp if this ramp has been activated.

This engine protection function – which is implemented in the firmware only on request – is enabled by means of the parameter 5245 *KnockControlOn*. 3245 *KnockPowerRedActive* shows whether a power reduction is active.

14.3 Digital generator management THESEUS

THESEUS Digital Generator Management is an accessory device for generator operation that is capable of executing all synchronization and power control functions. This **HEINZMANN** device has been designed for optimum cooperation with **HEINZMANN** control units. The preferred type of connection is via the CAN bus. [↑] 23 *Bus Protocols* offers a description of how to configure the CAN bus system for this purpose. But it is also possible to connect the THESEUS output to the control unit using an analogue input. This value is used in the same way as for the Load Control Unit and is described in [↑] 14.2.1 *Load control using the HEINZMANN Load Measuring Unit*.

For operation with THESEUS, droop will be de-activated automatically, yet for the eventuality of a change-over to manual operation ([↑] 14.4 *Automatic or manual operation*) droop should always be parameterized. Any further adjustment for synchronization and load control will be performed on the part of THESEUS.

Operation using THESEUS offers the possibility of disabling synchronization and load control in case of failure or of changing over to manual operation by means of a digital potentiometer. For this purpose, the switching function

2836 *SwitchAutoOrManual* = 0 manual operation by digital potentiometer

2836 *SwitchAutoOrManual* = 1 automatic operation

is available. If this switching function is not parameterized, no external change-over to manual operation will be possible. When THESEUS has been switched over to manual

operation, the control unit will be switched over to manual operation as well. There will also be manual operation in case CAN communication with THESEUS is no longer available. Operation mode can be checked by the parameter 3201 *GenCtrlAutoOrManual*.

In manual operation, the control signals received from THESEUS unit will not be evaluated, and it is only the switch inputs for the digital potentiometer that will be active. The inputs and parameters used in this case are the same as for [↑ 14.1.1 Digital synchronization](#). In case manual operation is also to be used for load control, this will in addition require to activate droop. On switching over to manual operation, the current offset values will be taken over for the digital potentiometer to avoid speed and load jumps. When switching back to automatic operation this will not always be possible since the offset values of the digital potentiometer are cleared and the signals from THESEUS have to be used (see also [↑ 14.4 Automatic or manual operation](#)).



For further information about the adjustment and operation of THESEUS, please refer to the manual Basic Information THESEUS, ord. no. DG 01 015-e.

14.4 Automatic or manual operation

Generator operation offers the additional option to disable synchronization and load control in case of failure and to switch over to manual operation using a digital potentiometer. For this purpose, the switching function

2836 *SwitchAutoOrManual* = 0 manual operation by digital potentiometer
 2836 *SwitchAutoOrManual* = 1 automatic operation

is available. If the switching function has not been parameterized ([↑ 18 Configuration of switching functions](#)) the system always runs in automatic mode.

In manual operation, the control signals received via the analogue inputs or from the THESEUS unit ([↑ 14.3 Digital generator management THESEUS](#)) will not be taken into account, and it is only the switch inputs for the digital potentiometer that will be active. The inputs and parameters used in this case are the same as for [↑ 14.1.1 Digital synchronization](#). The switch functions 2834 *SwitchSyncEnable* and 2835 *SwitchLoadEnable* for enabling synchronization and power control, however, will be ignored.

In case manual operation is also to be used for load control, this will in addition require to activate droop. This is achieved by assigning the same digital input which is used to change over to manual operation to the switch 812 *FunctDroop2Or1* ([↑ 18 Configuration of switching functions](#)) for changing over between droop 1 and droop 2.

On switching over to manual operation, the current offset values will be taken over for the digital potentiometer to avoid speed and load jumps. When switching back to automatic operation this will not always be possible since when using, e.g., the synchronization and load measuring devices the offset values of the digital potentiometer will be cleared and the input signals used.

Whether the control unit is operating in automatic or manual mode can be read from the parameter 3201 *GenCtrlAutoOrManual*.



If the engine is started by manual operation it will run by set speed plus droop. On switching over to automatic operation droop will be deactivated thus clearing also the offset resulting from droop. The engine will then be running at pre-set speed. When returning to manual operation droop will be activated, but in such a way as to retain the currently set speed, and on switching back again to automatic operation the set speed will no longer undergo alteration. This is motivated by the wish to avoid load jumps when switching over under load after attaining a stabilized state. In automatic operation, the set will be running in isochronous mode, i.e., there will be no speed change across load. Therefore, this speed must be sustained on switching over to manual operation, as in manual operation the actual set speed can be altered by droop and by this possibly cause a speed or load jump when switching back to automatic operation. By using the ↑7.7 Speed ramp any such speed jump and hence load jump can be retarded by a ramp.

Parameterizing Example:

Synchronization is to be enabled with switch input 4 opened and load is to be enabled with switch input 4 closed. Switch input 5 serves for changing between automatic and manual operation. In addition, droop of 4 % is to be provided for manual operation..

Number	Parameter	Value	Unit
120	<i>Droop1</i>	4	%
125	<i>Droop2</i>	0	%
812	<i>FunctDroop2Or1</i>	5	
834	<i>FunctSyncEnable</i>	-4	
835	<i>FunctLoadEnable</i>	4	
836	<i>FunctAutoOrManual</i>	5	
4120	<i>DroopOn</i>	1	

Indication when synchronizing in manual mode:

2812	<i>SwitchDroop2Or1</i>	0
2834	<i>SwitchSyncEnable</i>	1
2835	<i>SwitchLoadEnable</i>	0
2836	<i>SwitchAutoOrManual</i>	0
3201	<i>GenCtrlAutoOrManual</i>	0

Indication when load controlling in automatic mode:

2812	<i>SwitchDroop2Or1</i>	1
2834	<i>SwitchSyncEnable</i>	0
2835	<i>SwitchLoadEnable</i>	1
2836	<i>SwitchAutoOrManual</i>	1
3201	<i>GenCtrlAutoOrManual</i>	1

14.5 PANDAROS variants

The control unit PANDAROS is available both with freely configurable firmware and in variants with fixed functionality. This section describes the generator variants and how they relate to the abovementioned functionality for generators. The integrated power governor is not implemented in these variants with fixed functionality.

14.5.1 DC 6-01: Standard Generator

The standard generator variant is a simple solution fitted for example for island single or mains parallel operation.

<i>Digital input</i>	<i>Pin</i>	<i>Designation</i>	<i>Configuration</i>
3	7	SpA	fixed 2825 <i>SwitchSpeedInc</i>
4	9	SpD	fixed 2826 <i>SwitchSpeedDec</i>
5	11	Stp	1: fixed 2810 <i>SwitchEngineStop</i> 0: fixed 2815 <i>SwitchSpeedFix</i>

<i>Digital output</i>	<i>Pin</i>	<i>Designation</i>	<i>Configuration</i>
Error output	10	Err	fixed 3801 <i>CommonAlarm</i>

The assignment of digital inputs to switching functions is fixed and cannot be configured separately. The polarity of the engine shutdown input on the other hand may be set with 4811 *StopOpenOrClose*. After having changed the polarity the parameters must be saved and the control unit must be restarted (\uparrow 3.10 *Reset of control unit*). The changed polarity will be valid for 2815 *SwitchSpeedFix* too.

5230 *LoadControlOrPot* is fixedly set to “0” (\uparrow 14.2 *Load control*).

When the engine stop input is disabled, speed setpoint is automatically set to fixed speed 17 *SpeedFix*. This can be changed additively with the aid of the buttons 2825 *SwitchSpeedInc* and 2826 *SwitchSpeedDec* (\uparrow 14.2.2.2 *Digital setpoint adjustment*).

For mains parallel operation droop 120 *Droop* must be adjusted and enabled with 4120 *DroopOn* = 1. In island single operation it is possible to use droop or isochronous mode.

14.5.2 DC 6-03: Extended Generator 1

With the variant Extended Generator 1 it is possible to signal to the device after synchronization with the buttons 2825 *SwitchSpeedInc* and 2826 *SwitchSpeedDec* (\uparrow 14.1.1 *Digital synchronization*) via 2835 *SwitchLoadEnable* that the generator contactor is closed. This enables input 2902 *LoadControlInput*, which is used for load sharing in island parallel operation with the aid of the HEINZMANN load control unit LMG 10 (or another control device) (\uparrow 14.2.1 *Load control using the HEINZMANN Load Measuring Unit*).

<i>Analogue input</i>	<i>Pin</i>	<i>Designation</i>	<i>Configuration</i>
1	2	P1	fixed 2902 <i>LoadControlInput</i> , 0..5 V

<i>Digital input</i>	<i>Pin</i>	<i>Designation</i>	<i>Configuration</i>
2	1	P2	fixed 2835 <i>SwitchLoadEnable</i>
3	7	SpA	fixed 2825 <i>SwitchSpeedInc</i>
4	9	SpD	fixed 2826 <i>SwitchSpeedDec</i>
5	11	Stp	fixed 2810 <i>SwitchEngineStop</i>

<i>Digital output</i>	<i>Pin</i>	<i>Designation</i>	<i>Configuration</i>
Error output	10	Err	fixed 3801 <i>CommonAlarm</i>

The assignment of inputs and outputs is fixed and cannot be configured separately.

5210 *SyncAnalogOrDigital* is stably set to 0 (\uparrow 14.1.1 *Digital synchronization*).

5230 *LoadControlOrPot* is stably set to 1 (\uparrow 14.2.1 *Load control using the HEINZMANN Load Measuring Unit*).

When the HEINZMANN load control unit LMG 10 is connected, 5231 *LoadControlOrHZM_LMG* must be set to 0, otherwise to 1.

After changing this value or the polarity of the engine stop input with 4811 *StopOpenOrClose* the parameters must be saved and the control unit must be restarted (\uparrow 3.10 *Reset of control unit*).

14.5.3 DC 6-04: Extended Generator 2

The variant Extended Generator 2 allows to modify the speed setpoint with 2900 *SetpointExtern* over the engine's whole speed range. For synchronizing and load control 2815 *SwitchSpeedFix* is used to switch to fixed speed 17 *SpeedFix*. At the same time, 2834 *SwitchSyncEnable* and 2835 *SwitchLoadEnable* are enabled.

For operation with variable speed setpoint, droop 120 *Droop* may be adjusted and enabled (4120 *DroopOn* = 1). During load control in fixed speed operating mode, droop will be automatically disabled (isochronous operating mode).

For synchronization the HEINZMANN synchronizing unit SyG 02 (or a similar device) is used, connected to 2903 *SyncInput*.

For load sharing the HEINZMANN load control unit LMG 10 (or a similar device) is used, connected to 2902 *LoadControlInput*.

5210 *SyncAnalogOrDigital* and 5230 *LoadControlOrPot* are both set stably to 1 (↑ 14.1.2 *Synchronization using the HEINZMANN Synchronizing Unit* and ↑ 14.2.1 *Load control using the HEINZMANN Load Measuring Unit*).

<i>Analogue input</i>	<i>Pin</i>	<i>Designation</i>	<i>Configuration</i>
1	2	P1	fixed 2902 <i>LoadControlInput</i> , 0..5 V
2	1	P2	fixed 2903 <i>SyncInput</i> , 0..5V
3	7	SpA	fixed 2900 <i>SetpointExtern</i>

<i>Digital input</i>	<i>Pin</i>	<i>Designation</i>	<i>Configuration</i>
4	9	SpD	fixed 2815 <i>SwitchSpeedFix</i> fixed 2834 <i>SwitchSyncEnable</i> fixed 2835 <i>SwitchLoadEnable</i>
5	11	Stp	fixed 2810 <i>SwitchEngineStop</i>

<i>Digital output</i>	<i>Pin</i>	<i>Designation</i>	<i>Configuration</i>
Error output	10	Err	fixed 3801 <i>CommonAlarm</i>

The assignation of inputs and outputs is fixed and cannot be configured separately.

When the HEINZMANN synchronizing unit SyG 02 is connected, 5211 *SyncInputOrHZM_SyG* must be set to 0, otherwise to 1.

When the HEINZMANN load control unit LMG 10 is connected, 5231 *LoadControlOrHZM_LMG* must be set to 0, otherwise to 1.

After having changed these values or the polarity of the engine stop input with 4811 *StopOpenOrClose*, the parameters must be saved and the control unit must be restarted (↑ 3.10 *Reset of control unit*).

14.5.4 DC 6-14: Extended Generator 3

The variant Extended Generator 3 has been developed specifically for operation in conjunction with generator management THESEUS (↑ 14.3 *Digital generator management THESEUS*). Both devices are connected via the HEINZMANN-CAN bus.

This variant allows to change between automatic and manual operation (↑ 14.4 *Automatic or manual operation*).

In automatic operation synchronization and load sharing are carried out by THESEUS. In doing so, the engine runs at fixed speed 17 *SpeedFix*.

In manual operation, speed is set by the potentiometer 2900 *SetpointExtern*. Synchronizing and load sharing are carried out using the Up/Down keys.

<i>Analogue input</i>	<i>Pin</i>	<i>Designation</i>	<i>Configuration</i>
3	7	SpA	fixed 2900 <i>SetpointExtern</i>

<i>Digital input</i>	<i>Pin</i>	<i>Designation</i>	<i>Configuration</i>
1	2	P1	fixed 2825 <i>SwitchSpeedInc</i>
2	1	P2	fixed 2826 <i>SwitchSpeedDec</i>
4	9	SpD	1: fixed 2815 <i>SwitchSpeedFix</i> 1: fixed 2836 <i>SwitchAutoOrManual</i> 0: fixed 2836 <i>SwitchAutoOrManual</i>
5	11	Stp	fixed 2810 <i>SwitchEngineStop</i>

<i>Digital output</i>	<i>Pin</i>	<i>Designation</i>	<i>Configuration</i>
Error output	10	Err	fixed 3801 <i>CommonAlarm</i>

For mains parallel operation droop 120 *Droop* must always be adjusted and enabled with 4120 *DroopOn* = 1. It will be taken into account only in manual operation.

After having changed the polarity of the engine stop input with 4811 *StopOpenOrClose* the parameters must be saved and the control unit must be restarted (↑ 3.10 *Reset of control unit*)

15 Marine operation

15.1 Master/slave operation

For ships equipped with two engines on one shaft the function twin-engine operation, respectively, master/slave or father/son operation is available.

The switch function 2841 *SwitchMasterOrSlave* tells both control devices which engine is master and which is slave. It is convenient to use a single switch and connect it to both control devices. In one device the digital input is assigned the respective value in positive, in the other with negative sign (\uparrow 18 *Configuration of switching functions*). In this way, both get the same information, but in inverted form.

The switch functions 2843 *SwitchClutch*, 2842 *SwitchLoadTransfer* and, if required, 2844 *SwitchAsymLoadEnable* must be connected to both control devices, for the selection master/slave is dynamic. The effective elaboration in the control device depends on the assigned engine type.

The two control units are connected with the HZM-CAN bus. The bus transmits the fuel setpoint for the slave. Besides, the two control units continually exchange information about the operative state of the engines. This allow a quick reaction when errors require both engines to go in droop (\uparrow 7.8 *Droop*).

Parameter 3250 *TwinEnginePhase* shows the different phases of engaging, load pick-up and disengaging.

- 0: engine runs by itself, not engaged, has not reached engagement speed yet
- 1: engagement speed reached, engine waits for engagement
 master stays in this phase
 slave proceeds to phase 2 after engagement
- 2: engaged slave, ramp running after clutch is closed
- 3: engaged slave, load pick-up active
- 4: engaged slave, load pick-up deactivated, ramp to minimum load
- 5: engaged slave, disengagement load reached, engine waits for disengagement

As soon as engagement speed range between 1255 *LowerSpeedClutchIn* and 1256 *UpperSpeedClutchIn* is reached, the value of 3251 *CloseClutchPossible* switches from 0 to 1 and engaging becomes possible.

If the value changes from 1 to 0, disengaging is possible because the slave engine has reached the disengagement load 1252 *SlaveLoadForDeClutch*.

If parameter number 3251 is assigned to a digital output and therefore to a lamp, the lamp is off when the engine starts and lights up when engagement speed is reached; it stays on as long as load pick-up is required and goes out when load pick-up is over and disengaging load has been reached (\uparrow 20.8 *Digital outputs*).

The engagement request by switch function 2843 *SwitchClutch* = 1 is accepted by the control unit only if 3251 *CloseClutchPossible* has been enabled from 0 to 1 – or differently put, when 3250 *TwinEnginePhase* = 1.

After engaging, the slave runs up to load 1252 *SlaveLoadForDeClutch*, until load pick-up is requested by 2842 *SwitchLoadTransfer* = 1. From then on, the slave runs along the ramps 1253 *SlaveLoadRampUp* or 1254 *SlaveLoadRampDown* to the position pre-set by the master.

2842 *SwitchLoadTransfer* = 0 ends the load pick-up. The slave goes automatically to disengagement load 1252 *SlaveLoadForDeClutch* and signals it with 3251 *CloseClutchPossible* = 0.

The disengagement request operated by switch function 2843 *SwitchClutch* = 0 is accepted by the slave engine only if the disengagement load has been reached and 3251 *CloseClutchPossible* has been disabled from 1 to 0 – or differently put, when 3250 *TwinEnginePhase* = 5.

3252 *PositionerOrGovernor* indicates whether the respective control unit is the active speed governor or the slave in positioning mode.

3252 *PositionerOrGovernor* = 0 Speed governor

3252 *PositionerOrGovernor* = 1 Slave in positioning mode

The transmission of the setpoint from master to slave is in form of load value. To this purpose it is necessary to define the respective actuator positioning values for zero-load and full-load on both control units.

1250 *FuelAtZeroLoad* Actuator position at zero-load

1251 *FuelAtFullLoad* Actuator position at full-load

The resulting own load setpoint is indicated in 3253 *MyLoadSetpoint*, the load setpoint of the other engine in 3254 *OtherLoadSetpoint*. The slave derives its own fuel setpoint from the received load setpoint and the two own actuator positions and indicates it in 3255 *SlaveFuelSetpoint*.

The fuel setpoint can be limited both in master and slave. This is indicated by the following parameters:

2711 *FuelLimitMaxActive* fuel for this engine is limited

2721 *AsymmLoadLimitActive* slave limit for asymmetric load is active

3256 *Slave&MasterLimited* fuel for both engines is being limited

While fuel limitation in the master, i.e. in the speed governor, may be either speed-dependent or boost pressure dependent, in the slave it is determined exclusively by the asymmetric load value received as sensor value 2917 *AsymmetricLoad*. If the asymmetric load value is connected by cable, 2722 *FuelLimitAsymmLoad* is set to 2917 *AsymmetricLoad*, otherwise this value is equal to 100%, i.e. no limitation is active. In this

case the limitation in the master applies to the slave too, for both are working with the same load setpoint.

When the asymmetric load value is connected, the switching function 2844 *SwitchAsymLoadEnable* allows to determine whether 2917 *AsymmetricLoad* is to be observed or not.

For the CAN connection between the two control units set following parameters.

400 <i>CanStartTimeOutDelay</i>	delay after switching on the control until messages are expected from the other engine
401 <i>CanMyNodeNumber</i>	node number of this engine
402 <i>CanDCNodeNumber</i>	node number of the other engine
4400 <i>CanCommDCOn</i>	enabling of CAN communication

The node numbers of the two control devices must be parameterized crosswise.

2405 *CanOnline* indicates whether the CAN connection is established. If one of the CAN errors 3070 *ErrCanBus* or 3071 *ErrCanComm* is indicated, meaning that the connection is disturbed, 3048 *ErrTwinEngine* is output and both engines go into single operation with droop (\uparrow 7.8 *Droop*).

The droop parameters for this error situation are:

129 <i>TwinEcyDroop</i>	droop
130 <i>TwinEcyDroopRefLow</i>	actuator values for zero-load
131 <i>TwinEcyDroopRefHigh</i>	actuator values for full-load
132 <i>TwinEcyDroopSpeedRef</i>	rated speed

These droop parameters are used whenever errors occur in twin-engine systems. They do not depend on droop being generally enabled and on how the droop values are set in parameters 120 ff and 125 ff. The parameters 129 *TwinEcyDroop* and 132 *TwinEcyDroopSpeedRef* must be identical in both control units.

The function twin-engine system is enabled by setting 5251 *TwinEngineEnable* = 1.

15.2 Multiple engine set with directional information

The throttle lever with directional setting (\uparrow 7.5.1 *Setpoint adjuster with directional information*) can be adjusted in order to operate two engines. The lever itself is then present twice on the unit, in order to allow separate addressing of each engine.



Note

In the following section "Throttle lever" will refer to the whole device and "Lever" to the setpoint adjuster only.

A COMMAND button on the throttle lever (or separate from it) allows to request that both engines receive setpoint and directional information from the same lever. For an engine set

composed of three or four engines, a second throttle lever has to be used accordingly. By enabling the SYNCHRO button on one of the two throttle levers (or separate from them), all engines can be driven from a single one of the four levers.

15.2.1 CAN communication

The coupling of the engines is achieved by a CAN bus connection between the **HEINZMANN** control units. For this purpose the same parameters have to be set in all control units.

- 400 *CanStartTimeOutDelay* delay after switching on the control until messages are expected from the other engines
- 401 *CanMyNodeNumber* node number of this engine
- 397 *PartnerDCNodeNumber* node number of the other engine on same throttle lever
- 398 *ThirdDCNodeNumber* node number of the third engine
- 399 *FourthDCNodeNumber* node number of the fourth engine
- 4400 *CanCommDCOn* enabling of CAN communication

Engine node numbers must be determined first and then be entered crosswise in the four parameters for each control unit, e.g., in the following way:

Throttle lever	1		2	
Parameter	Engine 1	Engine 2	Engine 3	Engine 4
401 <i>CanMyNodeNumber</i>	1	2	3	4
397 <i>PartnerDCNodeNumber</i>	2	1	4	3
398 <i>ThirdDCNodeNumber</i>	3	3	1	1
399 <i>FourthDCNodeNumber</i>	4	4	2	2

Table 20: HZM-CAN: Node numbers in multiple engine set

If only two or three engines are used, zeros must be entered in 398 *ThirdDCNodeNumber* and/or 399 *FourthDCNodeNumber*.

The current states of the other engines are indicated by the following parameters:

- 3260 *CanSetp2Setpoint* through 3266 *CanSetp2PositionIII*
- 3270 *CanSetp3Setpoint* through 3276 *CanSetp3PositionIII*
- 3280 *CanSetp4Setpoint* through 3286 *CanSetp4PositionIII*.

These values have the same meaning as the parameters

- 3250 *LeverSetpoint* through 3256 *SetpointPositionIII*,

that indicate the values of the primary engine (\uparrow 7.5.1 *Setpoint adjuster with directional information*). CanSetp2 is always the value of node 397 *PartnerDCNodeNumber*, CanSetp3 the value of node 398 *ThirdDCNodeNumber* and CanSetp4 of node 399 *FourthDCNodeNumber*.

15.2.2 Common setpoint adjustment

Each engine is equipped with its own **HEINZMANN** control unit. The commutation Local \leftrightarrow Remote must be connected to all control units. In every control unit the respective lever with directional information must be calibrated as described in chapter \uparrow 7.5.1.1 *Calibration of lever positions*. The engagement is achieved as described in \uparrow 7.5.1.2 *Clutch* or \uparrow 7.5.1.3 *Clutch disabling*.

COMMAND and SYNCHRO buttons of a throttle lever (or an external device) can be connected in parallel to both engine controlling units as 2842 *SwitchCommand* or 2843 *SwitchSynchro*. For the SYNCHRO button this is recommended especially when the four engines do not run together all the time.

However, for the function discussed here it is sufficient if the switches are connected to the one control unit that is entrusted with the common setpoint adjustment and transmission. Both are push-buttons, i.e., non-locking switches.



Note

Enabling and disabling of a common setpoint adjustment can be done only when all levers are in neutral position.

The command 2842 *SwitchCommand* enables common setpoint adjustment with the partner engine from the same throttle lever. This is indicated by 3257 *SetpointCommandActiv* = 1 and 3267 *CanSetp2CommandActiv* = 1. When 2842 *SwitchCommand* is enabled at the other throttle lever, this is indicated by 3277 *CanSetp3CommandActiv* = 1 and 3287 *CanSetp4CommandActiv* = 1.

In the same way, this applies to 2843 *SwitchSynchro*, which allows to take over setpoint adjustment for all engines from one of the two throttle levers. The enabled state of the function is indicated by a "1" in 3258 *SetpointSynchroActiv* and 3268 *CanSetp2SynchroActiv* or by a "1" in 3278 *CanSetp3SynchroActiv* and 3288 *CanSetp4SynchroActiv*.

After the respectively applying function is enabled, setpoint adjustment can be taken over by one of the two levers on the same throttle lever on which the button has been pressed. This is always the first lever shifted away from the neutral position. From which node the common setpoint adjustment is being effected at any given time is indicated with a "1" in 3259 *SetpointActive*, 3269 *CanSetp2Active*, 3279 *CanSetp3Active* or 3289 *CanSetp4Active*. In case of separated setpoint adjustment all four values are equal to "0". The resulting setpoint for two or all engines is taken from 3290 *CommonLeverSetpoint*.

Common setpoint adjustment for two engines is disabled by pressing again the same COMMAND button that had been used to enable the function, on condition both levers are in neutral position.

Common setpoint adjustment for all engines is disabled by pressing again the same SYNCHRO button that had been used to enable the function, on condition all levers are in neutral position.



Note

If the currently active setpoint adjuster receives an engine stop request, the common setpoint determination is automatically suspended and each of the two or four setpoint adjusters becomes active separately again.

15.2.3 LED indicators

On the throttle lever, or separate from it, two lamps can be addressed. The respective output parameters are stored in 3291 *CommandLED* and 3292 *SynchroLED*.

3291 *CommandLED* is active when the COMMAND button on its own throttle lever has been pressed, thereby enabling setpoint adjustment in common with the partner engine.

3292 *SynchroLED* is active when one of the SYNCHRO buttons on the two throttle levers has been pressed, thereby enabling common setpoint adjustment for all engines.

16 Speed control for dual fuel engines (ARTEMIS)

The basic systems DC 1, DC 2, DC 6 and XIOS are conceived not only for control of diesel and gas engines but also for use in dual fuel engines.

The DC 1-04 and XIOS control units can each directly operate up to three actuators – the diesel actuator and one or two gas throttle valves. The DC 1-03, DC 2 and DC 6 systems control only the diesel actuator with their own hardware and transmit the gas setpoint either through an analogue output to an external gas adjuster or are connected to a periphery module via the HEINZMANN CAN bus (\uparrow 23.1 CAN protocol HZM-CAN) that receives the gas setpoint and controls the throttle valve or MEGASOL valves. In addition, the periphery module provides additional inputs and outputs for sensors, switching functions and indicators.

ARTEMIS is the overall system consisting of the control unit, periphery module and actuators/throttle valves or valves.

The control unit is responsible for all tasks necessary to ensure dual fuel operation and for clean switching from diesel to gas and back. Various conditions that have to be met for dual fuel operation can be enabled, for example that the load must be in a certain range, that the exhaust temperature must not be too high, or that there must be a minimum gas pressure.

For dual fuel operation, either a separate speed control loop is enabled to determine the gas setpoint or the gas quantity to be supplied is determined from a diesel reduction control loop.

One of the most important requirements for safe dual fuel operation and protection of the engine against overload is the presence of a power or power-equivalent signal. In contrast to a diesel engine, where the power and (diesel) injection quantity are normally in proportion to each other, this is no longer the case in dual fuel operation. A diesel engine governor can therefore work with the diesel fuel quantity of diesel as a power-equivalent signal, but a dual fuel control unit cannot (at least not in dual fuel operation).

Therefore, in generator applications the power measured by the HEINZMANN LMG power measuring unit (or other external units) 2918 *MeasuredPower* or the relative power supplied by the HEINZMANN THESEUS generator management system 3232 *RelativePower* is required.

In diesel / electric locomotive applications, the traction power calculated from the traction current and voltage 3231 *TractionPower* is used for functions relating to power.

In control units for marine drives, the pure diesel power is determined on the test bench and used in speed and fuel quantity dependent characteristic maps, while the gas power is calculated online by the HEINZMANN ELEKTRA gas metering unit (FlowControl).

16.1 Gas speed control

Integrated diesel and gas speed governors can be used in dual fuel applications with fixed speed. This variation can only be used in generator applications – and primarily in mains parallel systems. The safety functions are based on power.

Once the conditions for dual fuel operation are met, the switch to gas is performed. To do this, the gas is positioned increasingly high using a ramp until the diesel speed governor, which responds to the gas power supplied by reducing the diesel quantity, only calculates the minimum permitted diesel fuel quantity, known as the ignition oil quantity, previously specified. At that point, the speed control is switched from diesel to gas, which means that the output value of the speed governor is a gas fuel quantity value from now on. Meanwhile, the diesel is positioned at the ignition oil quantity.




Fig. 39: Gas speed control

If the conditions for dual fuel operation are no longer met, the diesel speed governor is enabled again and the gas is returned to 0% either immediately or via a ramp.

16.2 Diesel reduction control

The diesel reduction control function is always used when dual fuel engines are to be used in applications with a variable speed or in generator sets if a very fast response to changes of load is important. To date, locomotive, generator and marine drive applications have been realised.

In this dual fuel variation, the diesel quantity always remains the actuating variable for the speed governor. The gas quantity is calculated by a second, subordinate control loop, known as the diesel reduction governor. The same algorithm is also used in separate dual fuel gas positioners that are connected to an external diesel speed governor.




Fig. 40: Diesel reduction control

There are two variations of diesel reduction control. Either the setpoint and actual diesel fuel quantity or the setpoint and actual diesel power are fed into the control loop. In the first case, we refer to diesel fuel quantity control and in the second case to diesel power control. However, this explicitly does not involve engine power control; in both cases it involves reduction of the diesel proportion of the total power.

Diesel fuel quantity control can always be used if the diesel fuel quantity is proportional to the diesel power at a particular speed. For example, if this is not the case for engines with PT pump, diesel power control is to be used. This relates exclusively to the setpoint and actual value for the control loop, otherwise both functions are absolutely identical.

16.2.1 Diesel reduction by diesel fuel quantity control

The diesel fuel quantity setpoint 12060 *DieselRedGovSetp* is taken from a speed or load dependent characteristic and corresponds to the permitted minimum diesel quantity, so it is never less than the ignition oil quantity. The output value from the higher level speed governor is used as the actual diesel fuel quantity for the diesel reduction governor, i.e. the diesel fuel quantity setpoint 2350 *FuelQuantity*. The actuating variable

for the control loop is the gas quantity that is required to achieve the specified diesel fuel quantity.

To avoid interfering with the higher level speed governor, the diesel fuel quantity setpoint is supplied to the diesel reduction governor with a delay using a ramp function.

Every change of speed or load is compensated by the higher priority and faster speed governor and the diesel reduction governor is then subordinate with the gas addition.

16.2.1.1 Applications for locomotive operation

In diesel/electric locomotive operation, the diesel fuel quantity setpoint is determined depending on the traction power. The calculated traction power is also the most important value for protecting the engine against overload in dual fuel operation.

The traction power is determined from the traction current and the traction voltage, which must be available as measured values.

On the test bench, the diesel fuel quantity is determined relative to the electrical diesel power over the entire speed range and is saved as a characteristic. During operation, it can be used to determine the current diesel power at any time and to calculate the maximum possible proportion of the gas power.

In this case, both actuators on throttle valves and HEINZMANN solenoid valves (MEGASOL) can be used for the gas positioning.

16.2.1.2 Generator applications

In generator operation, the electrical proportion of the engine power is measured. This is the most important value for protecting the engine against overload in dual fuel operation.

On the test bench, the diesel fuel quantity is determined relative to the electrical diesel power at the nominal speed and is saved as a characteristic. During operation, it can be used to determine the current diesel power at any time and to calculate the maximum possible proportion of the gas power.

In this case, both actuators on throttle valves and HEINZMANN solenoid valves (MEGASOL) can be used for the gas positioning.

16.2.1.3 Maritime applications

In Marine operation, the gas positioning is performed by the HEINZMANN ELEKTRA unit (publication “ELEKTRA FLOW Control”, order no. DF 14 001-d).

ELEKTRA calculates the gas power from the gas flow. Together with the speed-dependent and fuel quantity dependent diesel power calculated on the test bench, the target gas quantity for the specified gas power can be calculated and the engine can

thus be protected against overloading. The application is performed on the test bench with the engine manufacturer.

16.2.2 Diesel reduction by diesel power control

In engines with a PT pump, as the diesel power does not have a linear correlation with the actuating variable, the reduction governor cannot operate based on the set and actual diesel fuel quantity. Instead, the set and actual diesel power are fed into the control loop.

The diesel power setpoint 12060 *DieselRedGovSetp* is taken from a load dependent characteristic and corresponds to the permitted minimum diesel quantity, so it is never less than the ignition oil quantity. The associated diesel quantity must be sufficient to ignite the gas. The actual diesel power 12050 *DieselPower* is taken from a speed and fuel pressure dependent map. The actuating variable for the control loop is the gas quantity that is required to achieve the specified diesel power.

To avoid interfering with the higher level speed governor, the diesel power setpoint is supplied to the diesel reduction governor with a delay using a ramp function.

Every change of speed or load is compensated by the higher priority and faster speed governor and the diesel reduction governor is then subordinate.

16.3 Determining the ignition oil quantity

To ensure safe dual fuel operation, it is essential that the current diesel quantity is sufficient to burn the gas. The ignition oil quantity must therefore be defined.



Notice

The term "ignition oil quantity" implies that it always relates to diesel fuel quantity. This is the case, but with one exception. For diesel reduction by diesel power control, it is a diesel power value, ↑ 16.2.2 Diesel reduction by diesel power control, but this must of course correspond to a minimum permitted diesel quantity.

The ignition oil quantity that must always be met is specified as a fixed value for the entire speed and power range in 10055 *PilotDslAbsMinimum*. This value applies without exception as the absolute minimum; an ignition oil quantity calculated in another way is always (!) limited with this value as the lower threshold.

The minimum ignition oil quantity can also be stipulated depending on speed in the 16780 *PilotDslAbsMin:n(x)* and 16790 *PilotDslAbsMin:Dsl(x)* curve. This curve is enabled with 14055 *PilotAbsMinCurveOn* = 1, otherwise the parameter 10055 *PilotDslAbsMinimum* is used. These curve values are also limited internally with 10055 *PilotDslAbsMinimum* in the event of incorrect configuration.

These parameters for the absolute minimum ignition oil quantity are stipulated in Level 6 and are normally specified by the engine manufacturer. For safety reasons, they should not be enabled for changes by end customers.

Parameters

10055 <i>PilotDslAbsMinimum</i>	Absolute minimum ignition oil quantity
12055 <i>PilotDslAbsMinimum</i>	Current minimum ignition oil quantity
14055 <i>PilotAbsMinCurveOn</i>	Enable / disable speed-dependent absolute minimum ignition oil quantity
16780 <i>PilotDslAbsMin:n(x)</i>	Speed grid points for absolute minimum ignition oil quantity
16790 <i>PilotDslAbsMin:Dsl(x)</i>	Values for the absolute minimum ignition oil quantity

The ignition oil quantity should normally be set higher than the absolute minimum. To do this, either the parameter 10060 *PilotDieselSetpoint* or the result of the power-dependent characteristic for 16300 *PilotDiesel:P(x)* and 16310 *PilotDiesel:Dsl(x)* is used. This curve is enabled with 14060 *PilotDslPowerCurvOn*.

These parameters are available at Level 4 and can therefore be influenced by end customers. The ignition oil quantity valid at a specific time is indicated in 12060 *PilotDieselPresent*. It is never less than 10055 *PilotDslAbsMinimum*.

In applications with a gas speed governor, the parameter 14062 *PilotDslCurrLessOn* is a special case. It must be set if a mechanical stop on the engine specifies the minimum position for the ignition oil quantity. Without this parameter, the diesel actuator would continuously press against the stop and be permanently overloaded or overheat when the diesel is positioned to the ignition oil quantity in gas control mode. With the parameter enabled, the diesel actuator is disconnected and the gas speed governor is enabled. This is the case when switching from diesel to gas if the diesel fuel quantity has reached the ignition oil quantity. The value of 10055 *PilotDslAbsMinimum* must be adapted to the mechanical stop.

Parameters

10055 <i>PilotDslAbsMinimum</i>	Absolute minimum ignition oil quantity
10060 <i>PilotDieselSetpoint</i>	Ignition oil quantity parameter if 14060 <i>PilotFuelPowerCurvOn</i> = 0
12060 <i>PilotDieselPresent</i>	Current ignition oil quantity, never less than 10055 <i>PilotDslAbsMinimum</i>
14060 <i>PilotDslPowerCurvOn</i>	Enable / disable power-dependent ignition oil quantity
14062 <i>PilotDslCurrLessOn</i>	Enable / disable deactivation of the actuator power supply when the gas speed governor is enabled

16300 <i>PilotDiesel:P(x)</i>	Power grid points for ignition oil quantity
16310 <i>PilotDiesel:Dsl(x)</i>	Ignition oil quantity setpoints

16.4 Determining the power proportions

Monitoring the total engine power from the diesel and gas proportions is one of the most important tools for avoiding engine overloads in dual fuel operation. Power or power-equivalent measurement and calculation values are therefore needed in all dual fuel variants, for use for limitation.

In a pure diesel engine, the injection quantity and the power are normally equivalent at a speed. It is therefore often sufficient here to use the speed-dependent fuel quantity limitation instead of real power limitation. This is different in a dual fuel engine as, the gas quantity is no longer equivalent to the power output due to various external influences such as gas pressure, gas temperature and changing gas quality.

16.4.1 Applications for locomotive operation

In diesel / electric locomotives, the measured values for traction current 2919 *TractionCurrent* and traction voltage 2918 *TractionVoltage* can be used to calculate the traction power 3231 *TractionPower*.

$$3231 \text{ TractionPower [kW]} = 2918 \text{ TractionVoltage [V]} \times 2919 \text{ TractionCurrent [A]} / 1000$$

Multiplying the maximum current and voltage sensor values gives a maximum power value, which is well above the actual range of the generator. For this reason,

$$1232 \text{ TractionPowerHigh}$$

should contain the actual maximum power value. This maximum value applies to all traction power parameters. The relative power 3232 *RelativTractionPower* is specified as a percentage of this value.

The locomotive manufacturer specifies the required traction power for each speed notch and thus for fixed values, and these also have to be observed with a dual fuel engine. These values are entered in the 16050 *MaxPower:n* and 16060 *MaxPower:P* characteristic, enabling the maximum total electric power required 12048 *PowerMax* to be determined at any time.

During commissioning, the pure diesel traction power is entered in a speed and fuel quantity dependent map or, for engines with a PT pump, in a speed and diesel pressure dependent map, 16800 *DieselPower:n(x)*, 16810 *DieselPower:f(y) / DieselPower:p(y)* and 16835 *DieselPower:P(z)*. In dual fuel operation, the diesel proportion taken from the map 12050 *DieselPower* is subtracted from the current traction power, thus giving the current gas proportion 12051 *GasPower*.

Parameters

1232 <i>TractionPowerHigh</i>	Definition of the actual maximum traction power of the locomotive
2918 <i>TractionVoltage</i>	Current traction voltage
2919 <i>TractionCurrent</i>	Current traction current
3231 <i>TractionPower</i>	Current traction power
3232 <i>RelativTractionPower</i>	Traction power relative to 1232 <i>TractionPowerHigh</i>
12048 <i>PowerMax</i>	Current maximum traction power
12049 <i>DieselPowerMap</i>	Diesel power from speed and fuel quantity dependent map
12050 <i>DieselPower</i>	Current diesel power
12051 <i>GasPower</i>	Current gas power
12053 <i>RelativeDieselPower</i>	Current diesel power relative to 1232 <i>TractionPowerHigh</i>
14050 <i>DieselPowerCurveOn</i>	Enable / disable diesel power map
16050 <i>MaxPower:n(x)</i>	Speed grid points for max. traction power
16060 <i>MaxPower:P(x)</i>	Maximum traction power values
16800 <i>DieselPower:n(x)</i>	Speed grip points for diesel power
16810 <i>DieselPower:f(y)</i>	Diesel fuel quantity grid points for diesel power
16810 <i>DieselPower:p(y)</i>	Diesel pressure grid points for diesel power (engines with PT pump)
16835 <i>DieselPower:P(z)</i>	Diesel power

16.4.2 Generator applications

In generator sets, the actual power 2918 *MeasuredPower* must be transmitted to the control unit. The relationship between actual power and diesel fuel quantity is determined on the test bench in pure diesel operation and the relevant power is entered in a fuel quantity dependent characteristic for 16050 *DieselPower:f* and 16065 *DieselPower:P*. This curve is enabled with 14050 *DieselPowerCurveOn*.

In dual fuel operation, the diesel power taken from the characteristic, 12050 *DieselPower*, is subtracted from the total power 2918 *MeasuredPower* and the rest is the gas power, 12051 *GasPower*.

Parameters

1232 <i>RatedPower</i>	Nominal power
2918 <i>MeasuredPower</i>	Current power
3232 <i>RelativePower</i>	Power relative to nominal power
12050 <i>DieselPower</i>	Current diesel power
12051 <i>GasPower</i>	Current gas power
14050 <i>DieselPowerCurveOn</i>	Enable / disable diesel power characteristic
16050 <i>DieselPower:f(x)</i>	Diesel fuel quantity grid points for diesel power
16065 <i>DieselPower:P(x)</i>	Diesel power

16.4.3 Maritime applications

In ships, there are ship generators, which are included in this brochure in the generator application section, and drive motors.

For dual fuel operation in drive motors, the lack of power measurement means that it is necessary to calculate the engine power online. The required maps for the maximum permitted engine power and the diesel proportion of the power are prepared using a test bench with integrated power measurement. This is mostly only possible in conjunction with the engine manufacturer. Dual fuel operation on marine drive motors is not possible without these values. There is therefore no separate on/off switch for these maps. In other words, they are essential and are therefore always active.

The speed-dependent maximum engine power resulting from the propeller curve must be saved in 16130 *DFSpeedLimit:P(x)*. The speed grid points correspond to those for speed-dependent diesel fuel quantity limitation 6700 *SpeedLimit:n(x)*. In other words, in pure diesel operation the maximum engine power is determined using the envelope curve and in dual fuel operation using the power values specified here. During operation, the current maximum engine power is indicated in 12052 *DF:EnginePowerLimit*.

The speed and fuel quantity dependent diesel power is then determined on the test bench by running up to the speed / power levels of the propeller curve. The speed grid points are entered in 16800 *DieselPower:n(x)*. The diesel fuel quantity is taken from 2350 *DieselFuelQuantity* and saved in 16810 *DieselPower:f(y)* while the associated diesel power values have to be entered in 16835 *DieselPower:P(z)*. The resulting current diesel power value appears in 12050 *DieselPower*.



Due to the different fuel quantity values at the speed and power levels, a conversion using an Excel sheet may be necessary to enter the power values at the same fuel quantity grid points.

Parameters

3231 <i>EnginePower</i>	Current engine power
12050 <i>DieselPower</i>	Current diesel power
12051 <i>GasPower</i>	Current gas power
12052 <i>DF:EnginePowerLimit</i>	Maximum permitted total engine power
16800 <i>DieselPower:n(x)</i>	Speed grid points for diesel power map
16810 <i>DieselPower:f(y)</i>	Diesel fuel quantity grid points for diesel power map
16835 <i>DieselPower:P(z)</i>	Diesel power values

16.4.3.1 Diesel power for power take-offs

The minimum ignition oil quantity 12055 *PilotDslAbsMinimum* may be below the electrical zero power limit if power take-offs are consuming part of the total mechanical engine power. In dual fuel operation it is possible that this diesel power proportion will also be substituted with gas, thus increasing the conversion rate.

The mechanical diesel power proportion under the electrical zero-fuel limit is saved in the characteristic for 16490 *DieselNegPow:f(x)* and 16500 *DieselNegPow:P(x)* depending on the fuel quantity. Of course, the diesel fuel quantity 2350 *DieselFuelQuantity* is below the values of 16810 *DieselPower:f(y)*, which determine the electrical diesel power. The current mechanical diesel power value is indicated in 12049 *NegDieselPower*.

NOTICE	<p>For safety reasons, this characteristic may only be created by the engine manufacturer, who can also specify a low ignition oil quantity such that gas combustion is guaranteed at all times. Otherwise, the ignition oil quantity must be above the electrical zero-fuel limit and 0 should be entered as the power values for this characteristic. Fehler! Textmarke nicht definiert.</p>
---------------	---

Parameters

12049 <i>NegDieselPower</i>	Mechanical diesel power under the electrical zero-fuel limit
12055 <i>PilotDslAbsMinimum</i>	Current minimum ignition oil quantity
16490 <i>DieselNegPow:f(x)</i>	Fuel quantity grid points
16500 <i>DieselNegPow:P(x)</i>	Power values

16.5 Configuring the gas output

Depending on the application, the calculated gas setpoint value can either be output at an actuator to thus control a throttle valve, or at a solenoid valve control unit, which uses it to determine the actuation period for MEGASOL valves.

When using the DC 1-04 or XIOS as a dual fuel control unit, the gas actuator can be connected to its own hardware, otherwise the HZM-CAN bus is used to connect a periphery module whose actuator or valves are used for the gas output.

In marine drives, the ELEKTRA Flow-Control is used, which transmits the gas power setpoint. The ELEKTRA is an HZM-CAN add-on module.

The customer-specific firmware specifies the general application and only the relevant variation from those listed below is provided.

16.5.1 Own actuator (DC 1-04)

One or two throttle valves are required depending on the mechanical mounting of the gas section (e.g. on the V-type engine). The DC 1-04 control unit can control up to three actuators, one for the diesel and one or two for the gas. However, if the StG 180 is required for the diesel fuel quantity, only one free amplifier is available for the gas. In any case, the firmware always specifies the maximum possible number of gas actuators.

The gas setpoint 12023 *GasFuelQuantity* is either transmitted directly to 12021 *GasActSetpoint* or it can be routed through the fuel quantity dependent actuator characteristic 16210 *GasFToActSetp:f(x)* / 16225 *GasFToActSet:Pos(x)*. The curve is enabled with 14021 *GasFuelToActPosCrvOn*.

If 14090 *GasActuatorOn* is enabled, 12021 *GasActSetpoint* is always output to amplifier 2. If 14091 *GasDoubleActuatorOn* is also enabled, the same value is also transmitted to amplifier 3.

The values of 14090 *GasActuatorOn* and 14091 *GasDoubleActuatorOn* are only considered during initialisation after a control unit reset. 12092 *ActuatGasPositioner* and 12093 *ActuatGasPositioner2* indicate whether one or two (or no) assignment to actuators was detected for the gas output.

For configuration of the actuators themselves, see [↑ 24 Actuator trigger with position feedback](#).

Parameters

12021 <i>GasActSetpoint</i>	Gas actuator setpoint
12023 <i>GasFuelQuantity</i>	Gas setpoint
12092 <i>ActuatGasPositioner</i>	Amplifier 2 is used
12093 <i>ActuatGasPositioner2</i>	Amplifier 3 is used

14021 <i>GasFuelToActPosCrvOn</i>	Enable / disable fuel quantity dependent actuator characteristic
14090 <i>GasActuatorOn</i>	Enable / disable output to amplifier 2
14091 <i>GasDoubleActuatorOn</i>	Enable / disable output to amplifier 3
16210 <i>GasFToActSetp:f(x)</i>	Fuel quantity grid points for the actuator characteristic
16225 <i>GasFToActSet:Pos(x)</i>	Positions of the actuator characteristic

16.5.2 Own actuator (XIOS)

One or two throttle valves are required depending on the mechanical mounting of the gas section (e.g. on the V-type engine). The XIOS control unit can control up to three actuators – one for the diesel and one or two for the gas, or two for the diesel and one for the gas. Additional periphery modules may have to be used for other combinations. In any case, the firmware always specifies the maximum possible number of gas actuators.

The diesel and gas setpoints are assigned to actuators by the assignment to actuator outputs. These values are only taken into account after a control unit reset. 12092 *ActuatGasPositioner* and 12093 *ActuatGasPositioner2* indicate whether one or two (or even no) assignment to actuators was detected for the gas output.

If only one gas actuator is controlled, it must be assigned the parameter 12023 *GasFuelQuantity*. If two gas actuators are used, they must be assigned 12026 *GasFuelQuantityBank1* and 12027 *GasFuelQuantityBank2* even if the two values are identical. 12021 *GasActSetpoint(0)* or 12022 *GasActSetpoint(1)* must not be assigned as these values are only generated by the above assignment.

For configuration of the actuators themselves, see [↑ 24 Actuator trigger with position feedback](#).

Parameters

12021 <i>GasActSetpoint</i>	Gas actuator setpoint (1 throttle valve)
12021 <i>GasActSetpoint(0)</i>	Gas actuator setpoints
12022 <i>GasActSetpoint(1)</i>	(2 throttle valves)
12023 <i>GasFuelQuantity</i>	Gas setpoint for one throttle valve
12026 <i>GasFuelQuantityBank1</i>	Gas setpoints for two throttle valves
12027 <i>GasFuelQuantityBank2</i>	
12092 <i>ActuatGasPositioner</i>	First throttle valve is used
12093 <i>ActuatGasPositioner2</i>	Second throttle valve is used

16.5.3 HZM-CAN periphery module: Actuator or solenoid valves

If the gas value is to be transferred to an HZM-CAN periphery module, the assignment is carried out as described in [↑ 20 Configuring the control's inputs and outputs](#).

The configuration values are only taken into account after a control unit reset. 12094 *CanGasPositioner* and 12096 *CanGasPositioner2* indicate whether one or two (or no) periphery modules are used for the gas output. For assignment to periphery modules with electronic fuel injection, 12095 *EFIGasPositioner* and 12097 *EFIGasPositioner2* are also set to 1. For assignment to periphery modules with actuators, these parameters either do not exist at all or they indicate a value of 0.

For configuration of the periphery module communication, see [↑ 23.1 CAN protocol HZM-CAN](#).

Parameters

12094 <i>CanGasPositioner</i>	HZM-CAN periphery module for gas value output
12095 <i>EFIGasPositioner</i>	HZM-CAN periphery module for gas value output to: 0: Throttle valve 1: MEGASOL solenoid valves
12096 <i>CanGasPositioner2</i>	Second HZM-CAN periphery module for gas value output
12097 <i>EFIGasPositioner2</i>	Second HZM-CAN periphery module for gas value output to: 0: Throttle valve 1: MEGASOL solenoid valves

During operation, when using an MVC periphery module, 2200 (previously 2305) *PEGasQuantity* indicates which fuel quantity value the module is currently using. The value is 0 if the MVC is not synchronised. When using a periphery module with an actuator, 2200 (previously 2305) *PEActPos* shows the current back measurement of the actuator position (corresponds to 2300 *ActPos* in the periphery module) and 2210 (previously 2320) *PEActuatorOn* indicates whether the actuator is enabled (corresponds to 5910 *ActuatorOn* in the periphery module).

16.5.4 HZM-CAN add-on module: ELEKTRA Flow-Control

In maritime applications, the HEINZMANN ELEKTRA unit is connected to the dual fuel control unit via the HZM-CAN bus to determine the gas quantity necessary at the required gas power and for output to an actuator. In terms of the HZM-CAN bus system, ELEKTRA is known as an add-on module (AC). ELEKTRA Flow-Control has the AC module type 1.

Up to five add-on modules can normally be connected to a control unit. Their node numbers are saved in the parameters starting from 430 *CanACNodeNumber* and their type in the parameters starting from 435 *CanACNodeType*. Therefore, during initialisation after a control unit reset, these two fields are searched for the first add-on module with a node number not equal to 0 and AC module type 1. If a matching element is found, this is indicated by 12091 *CanGasFlowControl*.

To transfer the setpoint 12023 *GasPowerSetpoint* to the ELEKTRA Flow-Control, the enable parameter associated with the AC module 4375 *AC1SetpointOn...4395 AC5SetpointOn* must also be set, where the number AC1...AC5 must correspond to the Index+1 of 430 *CanACNodeNumber*.

For configuration of the add-on module communication, see [↑ 23.1 CAN protocol HZM-CAN](#). The functioning of the ELEKTRA is described in the “ELEKTRA Flow Control” manual, order no. DF 14 001-e.

Parameters

430 <i>CanACNodeNumber</i>	Node numbers of up to 5 AC modules
435 <i>CanACNodeType</i>	Node type of up to 5 AC modules
4375 <i>ACxSetpointOn</i>	Enable / disable setpoint transmission
12023 <i>GasPowerSetpoint</i>	Gas power setpoint
12091 <i>CanGasFlowControl</i>	ELEKTRA Flow-Control is enabled

16.5.5 Analogue or PWM output of gas setpoint

If a gas actuator is not available on its own hardware and the HZM-CAN bus cannot be used, it is also possible to output the gas setpoint using an analogue or PWM output on the dual fuel control unit.

For assignment of the gas setpoint 12021 *GasActSetpoint* or 12023 *GasFuelQuantity* to this kind of output, see [↑ 20 Configuring the control's inputs and outputs](#). Evaluation is only carried out in the initialisation phase after a control unit reset and the result of this check is indicated in 12091 *ADPWMGasPositioner*.

Parameters

12021 <i>GasActSetpoint</i>	Gas actuator setpoint
12023 <i>GasFuelQuantity</i>	Gas fuel quantity setpoint
12091 <i>ADPWMGasPositioner</i>	The gas setpoint is output using an analogue or PWM output

16.6 Enabling and disabling dual fuel operation

For the engine to run in dual fuel operation, this must generally be enabled first with 14000 *DualFuelOn* = 1.

The engine generally starts in diesel mode and only switches to dual fuel operation when all of the required conditions are met. An important and essential condition is enabling or disabling using the switching function 2837 *SwitchGasOrDiesel*. The switch back to diesel operation is normally performed by disabling this switch. The switching function 2838 *SwitchFastToDiesel* enables dual fuel operation to be terminated more quickly – but still in a controlled way – while 2849 *SwitchEmergencyStop* (XIOS: 2873 *SwitchEmergencyStop*) shuts it down immediately with no conditions.

In generator operation with a gas speed governor, diesel control mode is indicated by 12030 *DieselGovernorActive* = 1 and gas control mode by 12031 *GasGovernorActive* = 1.

On control units with diesel reduction control, the diesel speed governor is always enabled and therefore does not need to be signalled separately. However, 12031 *GasActive* = 1 indicates whether gas is currently enabled.

12034 *GasConsumptionActive* indicates whether gas is actually being consumed in dual fuel operating mode. This is always the case if a gas quantity $\diamond > 0$ is calculated; i.e. the throttle valve or MEGASOL valves are open.

16.6.1 Conditions for enabling dual fuel operating mode

A wide range of different conditions for dual fuel operation can be checked – depending on the engine type, the available sensors and the required safety measures. The control unit is only able to switch to this operating mode if all the active checks return positive results. Accordingly, dual fuel mode is terminated immediately if at least one of the conditions ceases to be met.

In generator operation with gas speed control, an external device can also be used to check whether dual fuel operation is permitted. In this case, only a few safety-related tests are performed in the speed governor and otherwise the decision is made exclusively using the switching function 2837 *SwitchGasOrDiesel*, which is controlled by the external device. This type of check is known as monitoring mode and is enabled using 14098 *GasSupviseOrCntlMode* = 1. However, if the dual fuel control unit is intended to carry out all control itself, 14098 *GasSupviseOrCntlMode* = 0 should be set.

The diesel reduction governor is always enabled if the conditions for dual fuel operation are met and it is disabled again as soon as this is not the case. Thus, the operating mode is changed continuously depending on the condition – but always in such a way that as much gas as possible is supplied. Separate enabling of this function is not necessary.

The following table lists all the check types and notes the application for which the relevant test is relevant.

In gas speed governor mode “(Control)” indicates which tests play a role exclusively in the control mode, i.e. when 14098 *GasSupviseOrCntlMode* = 0. All other tests are also performed in monitoring mode.

Test	Gas speed governor	Diesel reduction governor		
		Gen	Loc	Marine
<i>Reference</i>	Gen	Gen	Loc	Marine
Gas request active	X	X	X	X
	2837 <i>SwitchGasOrDiesel</i> = 1			
No fast switch back request	X	X	X	X
	2838 <i>SwitchFastToDiesel</i> = 0			
No external gas alarm	X	X	X	X
↑ 16.7.15 <i>External gas alarm</i>	2847/2871 <i>SwitchExternGasAlarm</i> = 0			
No fatal error	X	X	X	X
↑ 27.7 <i>Emergency shutdown errors</i>	3800 <i>EmergencyAlarm</i> = 0			
Engine running	X	X	X	X
↑ 5 <i>Starting fuel limitation</i>	3830 <i>Phase</i> between 4 and 7 3805 <i>EngineRunning</i> = 1			
No gas termination error	X	X	X	X
↑ 16.6.2 <i>Conditions for terminating dual fuel operating mode</i>	12032 <i>PromptReturnToDiesel</i> = 0			
No gas output device error	X	X	X	X
↑ 16.7.16 <i>Monitoring the gas output device</i>	13001 <i>ErrGasPositioner</i> = 0 13032 <i>ErrDualFuelStatus.0</i> = 0 (XIOS)			
No error in ARIADNE knock monitoring device	X	X	X	X
↑ 16.7.14 <i>Engine</i>	13009 <i>ErrKnockControlOff</i> = 0 13032 <i>ErrDualFuelStatus.1</i> = 0 (XIOS)			
MEGASOL control unit is synchronised	X	X	X	X
↑ 16.7.16.4 <i>MEGASOL valves on HZM-CAN periphery module</i>	13022 <i>ErrEFIGasPosDiff</i> = 0 13031 <i>ErrGasConditions.12</i> = 0 (XIOS)			
No misfires	X	X	-	-
↑ 10.8 <i>Misfire monitoring in generator operation</i>	3046 <i>ErrMisfireWarn</i> = 0 3047 <i>ErrMisfireEcy</i> = 0 3047 <i>ErrMisfireDetection</i> = 0 (XIOS)			

Test	Gas speed governor	Diesel reduction governor		
		Gen	Loc	Marine
<i>Reference</i>	Gen	Gen	Loc	Marine
Gas section monitoring OK	(Control)	X	X	X
↑16.7.1 Gas section test	12082 <i>GasTrainReady</i> = 1			
Power in permissible range	(Control)	X	X	X
↑16.7.2 Monitoring the power	13013 <i>ErrPowerRangeForGas</i> = 0 13031 <i>ErrGasConditions.2</i> = 0 (XIOS)	12013 <i>PowerInRangeForGas</i> = 1		
Exhaust temperature not too high	(Control)	X	X	X
↑16.7.3 Monitoring the exhaust temperature	13019 <i>ErrExhTRangeForGas</i> = 0 13031 <i>ErrGasConditions.8</i> = 0 (XIOS)	12017 <i>ExhTInRangeForGas</i> = 1		
Exhaust temperature difference (max-min) not too high	(Control)	X	X	X
↑16.7.3 Monitoring the exhaust temperature	13020 <i>ErrExhTDRangeForGas</i> = 0 13031 <i>ErrGasConditions.8</i> = 0 (XIOS)	12018 <i>ExhTDInRangeForGas</i> = 1		
Coolant temperature OK	(Control)	X	X	X
↑16.7.4 Coolant temperature monitoring	13018 <i>ErrCoolTRangeForGas</i> = 0 13031 <i>ErrGasConditions.6</i> = 0 (XIOS)	12019 <i>CoolTInRangeForGas</i> = 1		
Charge air temperature OK	(Control)	X	X	X
↑16.7.5 Charge air temperature monitoring	13021 <i>ErrChAirTRangeForGas</i> = 0 13031 <i>ErrGasConditions.7</i> = 0 (XIOS)	12002 <i>ChAirTInRangeForGas</i> = 1		
Oil pressure OK	(Control)	X	X	X
↑16.7.7 Oil pressure monitoring	13016 <i>ErrOilPRangeForGas</i> = 0 13031 <i>ErrGasConditions.5</i> = 0 (XIOS)	12015 <i>OilPrInRangeForGas</i> = 1		

Test	Gas speed governor	Diesel reduction governor		
		Gen	Loc	Marine
<i>Reference</i>	Gen	Gen	Loc	Marine
Boost pressure OK	(Control)	X	X	X
↑ 16.7.8 Boost pressure monitoring	13015 <i>ErrBoostRangeForGas</i> = 0 13031 <i>ErrGasConditions.4</i> = 0 (XIOS)	12016 <i>BoostInRangeForGas</i> = 1		
Gas pressure OK	(Control)	X	X	X
↑ 16.7.9 Gas rail pressure monitoring	13017 <i>ErrGasPrRangeForGas</i> = 0 13030 <i>ErrGasRailStatus.7</i> = 0 (XIOS)	12005 <i>GasPrInRangeForGas</i> = 1		
Gas pressure switch active (if assigned)	(Control)	X	X	X
↑ 16.7.10 External gas pressure monitoring	2845/2870 <i>SwitchGasPressReady</i> = 1			
Speed OK	(Control)	X	X	X
↑ 16.7.11 Speed monitoring	13012 <i>ErrSpeedRangeForGas</i> = 0 13031 <i>ErrGasConditions.1</i> = 0 (XIOS)	12010 <i>SpeedInRangeForGas</i> = 1		
Diesel fuel quantity OK	(Control)	X	X	X
↑ 16.7.12 Ignition oil quantity monitoring	13014 <i>ErrFuelRangeForGas</i> = 0 13031 <i>ErrGasConditions.13</i> = 0 (XIOS)	12012 <i>DieselInRangeForGas</i> = 1		
Excitation governor on traction power	-	-	X	-
↑ 13.2.1 Excitation control	2605 <i>ExcitGovTrPowOrFuel</i> = 1			
ELEKTRA is enabled	-	-	-	X
↑ 16.7.16.5 ELEKTRA FlowControl (HZM-CAN add-on module)	12006 <i>GasPosNotActive</i> = 0			

Tab. 21: Conditions for enabling dual fuel operating mode

16.6.2 Conditions for terminating dual fuel operating mode

If at least one of the following conditions is met in dual fuel operating mode, this operating state is terminated. Depending on the specified safety level, the return is either performed using a ramp or dual fuel mode has to be terminated immediately.

The following table lists the situations that lead to termination of dual fuel mode. In gas speed governor mode “(Control)” indicates which tests play a role exclusively in the control mode, i.e. when 14098 *GasSupviseOrCntlMode* = 0. All other tests are also performed in monitoring mode. (↑ 16.6.1 Conditions for enabling dual fuel operating mode).

In the gas speed governor, “Norm” indicates normal termination using the gas ramp, “Fast” indicates use of a separate, faster ramp and “Prompt” indicates immediate, non-ramped termination (↑ 16.8.3 *Switching ramp from gas to diesel operation*).

In the diesel reduction governor, “Fast” or “Prompt” indicates whether dual fuel mode has to be terminated using a fast ramp or immediately. By contrast, “Norm” means termination using the normal diesel ramp (↑ 16.9.3 *Diesel setpoint ramp*).

In case of error, the fast shutdown is signalled using 12032 *PromptReturnToDiesel* = 1. The gas is immediately switched to 0 % and the diesel takes over abruptly. In this case, the cause of the error is indicated by an error marker. It is not possible to enable dual fuel operation again until the cause has been remedied and an edge change from 0 → 1 is detected in the switching function 2837 *SwitchGasOrDiesel*.

Test	Gas speed governor		Diesel reduction governor		
	Gen		Gen	Loc	Marine
<i>Reference</i>					
Gas request ends	Norm		Norm	Norm	Norm
	2837 <i>SwitchGasOrDiesel</i> = 0				
Fast switch back to diesel requested	Fast		Fast	Fast	Fast
	2838 <i>SwitchFastToDiesel</i> = 1				
Fatal error	Prompt		Prompt	Prompt	Prompt
↑ 27.7 <i>Emergency shutdown errors</i>	3800 <i>EmergencyAlarm</i> = 1 2849 <i>SwitchEmergencyStop</i> = 1				
External gas alarm	Fast		Prompt	Prompt	Prompt
↑ 16.7.15 <i>External gas alarm</i>	2847/2871 <i>SwitchExternGasAlarm</i> = 1 13024 <i>ErrExternGasAlarm</i> = 1 13030 <i>ErrGasRailStatus.6</i> =1 (XIOS)				
Breaker opens	Prompt		Fast	-	-
↑ 9.4 <i>Zero fuel delivery characteristic</i>	2846 <i>SwitchGenBreaker</i> 1 → 0				

Test	Gas speed governor	Diesel reduction governor		
	Gen	Gen	Loc	Marine
<i>Reference</i>				
Gas pressure switch inactive	Prompt (Control)	Fast	Fast	Fast
↑ 16.7.10 External gas pressure monitoring	2845/2870 <i>SwitchGasPressReady</i> = 0			
Gas pressure too high	Prompt	Fast	Fast	Fast
↑ 16.7.9 Gas rail pressure monitoring	13017 <i>ErrGasPrRangeForGas</i> = 1 13030 <i>ErrGasRailStatus.7</i> = 1 (XIOS)	12005 <i>GasPrInRangeForGas</i> = 0 2925/2942 <i>GasDiffPressure</i> > 10006 <i>GasModeGasRPressMax</i>		
Gas pressure switch “not ready”	Prompt	-	-	-
↑ 16.7.1 Gas section test	2848/2872 <i>SwitchExternGasReady</i> = 0			
Diesel fuel quantity < ignition oil quantity	Prompt	Fast	Fast	Fast
↑ 16.7.12 Ignition oil quantity monitoring	13023 <i>ErrBelowPilotFuel</i> = 1 13031 <i>ErrGasConditions.13</i> = 1 (XIOS)	12011 <i>DieselBelowPilotFuel</i> = 1		
Heavy knocking	Prompt	Prompt	Prompt	Prompt
↑ 16.7.14 Engine	13007 <i>ErrHeavyKnocking</i> =1 13031 <i>ErrGasConditions.11</i> =1 (XIOS)			
Error in ARIADNE knock monitoring device	Prompt	Prompt	Prompt	Prompt
↑ 16.7.14 Engine	13009 <i>ErrKnockControlOff</i> = 1 13032 <i>ErrDualFuelStatus.1</i> = 1 (XIOS)			
Gas actuator error	Prompt	Fast	Fast	Fast
↑ 16.7.16 Monitoring the gas output device	13001 <i>ErrGasPositioner</i> = 1 (13032 <i>ErrDualFuelStatus.0</i> =1 (XIOS) 13025 <i>ErrGasPosFatal</i> = 0 13032 <i>ErrDualFuelStatus.15</i> =0 (XIOS)			
MEGASOL control unit is not synchronised (setpoint <> 0, actual value = 0)	Prompt	Prompt	Prompt	Prompt
↑ 16.7.16.4 MEGASOL valves on HZM-CAN periphery module	13022 <i>ErrEFIGasPosDiff</i> = 1 13031 <i>ErrGasConditions.12</i> = 1 (XIOS)			

Test	Gas speed governor	Diesel reduction governor		
	Gen	Gen	Loc	Marine
<i>Reference</i>				
Misfire	Prompt	Fast	-	-
↑27.8.1.4 Misfire monitoring (generator)	3047 <i>ErrMisfireEcy</i> = 1 3047 <i>ErrMisfireDetection.6</i> = 1 (XIOS)			
Engine stop request in dual fuel mode	Fast	Fast	Fast	Fast
↑16.12 <i>Residual gas combustion</i>	12068 <i>EngStopRequWithGas</i> = 1			
Gas governor at lower limit for a maximum time	Norm	-	-	-
↑16.7.13 <i>Gas quantity monitoring</i>	Diesel at ignition oil quantity cannot be reduced, risk of passing the limit			
Power not in permissible range	-	Fast	Fast	Fast
↑16.7.2 <i>Monitoring the power</i>		12013 <i>PowerInRangeForGas</i> = 0		
Power too high	Prompt	-	-	-
↑16.7.2 <i>Monitoring the power</i>	13013 <i>ErrPowerRangeForGas</i> = 1 13031 <i>ErrGasConditions.2</i> = 1 (XIOS)			
Power too low	Norm (Control)	-	-	-
↑16.7.2 <i>Monitoring the power</i>	13013 <i>ErrPowerRangeForGas</i> = 1 13031 <i>ErrGasConditions.2</i> = 1 (XIOS)			
Max. exhaust temperature too high	Norm (Control)	Fast	Fast	Fast
↑16.7.3 <i>Monitoring the exhaust temperature</i>	13019 <i>ErrExhTRangeForGas</i> = 1 13031 <i>ErrGasConditions.8</i> = 1 (XIOS)			12017 <i>ExhTInRangeForGas</i> = 0
Exhaust temperature difference	Norm (Control)	Fast	Fast	Fast

Test	Gas speed governor	Diesel reduction governor		
	Gen	Gen	Loc	Marine
(max-min) too high				
↑16.7.3.2 One exhaust temperature sensor per cylinder or per throttle valve	13020 <i>ErrExhTDRangeForGas</i> = 1 13031 <i>ErrGasConditions.9</i> = 1 (XIOS)	12018 <i>ExhTDInRangeForGas</i> = 0		
Coolant temperature not OK	Norm (Control)	Fast	Fast	Fast
↑16.7.4 Coolant temperature monitoring	13018 <i>ErrCoolTRangeForGas</i> = 1 13031 <i>ErrGasConditions.6</i> = 1 (XIOS)	12019 <i>CoolTInRangeForGas</i> = 0		
Charge air temperature not OK	Norm (Control)	Fast	Fast	Fast
↑16.7.5 Charge air temperature monitoring	13021 <i>ErrChAirTRangeForGas</i> = 1 13031 <i>ErrGasConditions.7</i> = 1 (XIOS)	12002 <i>ChAirTInRangeForGas</i> = 0		
Oil pressure not OK	Norm (Control)	Fast	Fast	Fast
↑16.7.7 Oil pressure monitoring	13016 <i>ErrOilPrRangeForGas</i> = 1 13031 <i>ErrGasConditions.5</i> = 1 (XIOS)	12015 <i>OilPrInRangeForGas</i> = 0		
Boost pressure not OK	Norm (Control)	Fast	Fast	Fast
↑16.7.8 Boost pressure monitoring	13015 <i>ErrBoostRangeForGas</i> = 1 13031 <i>ErrGasConditions.4</i> = 1 (XIOS)	12016 <i>BoostInRangeForGas</i> = 0		
Speed not OK	Norm (Control)	Fast	Fast	Fast
↑16.7.11 Speed monitoring	13012 <i>ErrSpeedRangeForGas</i> = 1 13031 <i>ErrGasConditions.1</i> = 1	12010 <i>SpeedInRangeForGas</i> = 0		

Test	Gas speed governor	Diesel reduction governor		
	Gen	Gen	Loc	Marine
<i>Reference</i>	(XIOS)			
Light knocking and max. offset reached	Norm (Control)	Fast	Fast	Fast
↑ 16.7.14 Engine	13011 <i>ErrLightKnocking</i> = 1 13031 <i>ErrGasConditions.10</i> = 1 (XIOS)	12014 <i>LightKnocking</i> = 1		
Gas above a minimum value but diesel setpoint/actual variation still too high over time	-	Prompt	Prompt	Prompt
↑ 16.7.12.2 Diesel reduction governor		Diesel speed governor not responding to addition of gas, main gas valve closed? 13027 <i>ErrGasNoPower</i> = 1 13031 <i>ErrGasRailStatus.9</i> = 1 (XIOS)		
Excitation governor on diesel fuel quantity	-	-	Prompt	-
↑ 13.2.2 Excitation governing		2605 <i>ExcitGovTrPowOrFuel</i> = 0		
ELEKTRA is not active	-	-	-	Fast
↑ 16.7.16.5 ELEKTRA FlowControl (HZM-CAN add-on module)		12006 <i>GasPosNotActive</i> = 1		

Tab. 22: Conditions for terminating dual fuel operating mode

16.6.2.1 Gas speed control

In generator operation with gas speed control, once enabled dual fuel operation must be terminated if at least one of the conditions is not met. Depending on the cause, there is normally a ramped return to diesel, or dual fuel mode has to be terminated immediately.

However, whether there is an automatic switch back to dual fuel operation if the conditions are met again after normal termination of dual fuel operation is determined by the parameter 14001 *GasAutomaticModeOn*. If it is set to 1, there is always an automatic switch to dual fuel mode if the conditions are met again. If it is set to 0, the switch has to be requested manually, in this case always by an edge change from 0 → 1 in 2837 *SwitchGasOrDiesel*.

In case of error, the fast shutdown is signalled using $12032 \text{ PromptReturnToDiesel} = 1$. The gas is immediately set to 0 % and the diesel takes over abruptly. The cause of the error is indicated by an error marker. Regardless of the parameter $14001 \text{ GasAutomaticModeOn}$ a return to gas is only possible after remedying the cause and an edge change from $0 \rightarrow 1$ in $2837 \text{ SwitchGasOrDiesel}$.

16.6.2.2 Diesel reduction control

In the diesel reduction governor, the gas supply is interrupted if either slightly changing conditions are no longer met or if such a serious error has occurred that its cause can only be remedied by a service callout.

In the first case $12033 \text{ FastReturnToDiesel} = 1$ is set. The gas is reduced to 0 % and the diesel takes over gradually. When the conditions are met again, there is a switch back to gas.

The second case is indicated by $12032 \text{ PromptReturnToDiesel} = 1$. The gas is immediately switched to 0 % and the diesel takes over abruptly. In this case, the cause of the error is indicated by an error marker. It is not possible to enable dual fuel operation again until the cause has been remedied and an edge change from $0 \rightarrow 1$ is detected in the switching function $2837 \text{ SwitchGasOrDiesel}$.

16.7 Monitoring functions

This section sets out all the monitoring functions, which either have to be observed to switch to dual fuel mode or which have a negative output that leads to dual fuel mode having to be terminated. The response to the monitoring is listed in detail in a table in [↑ 16.6 Enabling and disabling dual fuel operation](#).

16.7.1 Gas section test

The gas section is normally monitored by the manufacturer's electronics. In this case, the HEINZMANN control unit only outputs the signal that monitoring should start and expects the response that everything is OK within a certain time.

Based on explicit customer requests, however, gas section monitoring can also be performed internally in the HEINZMANN control unit. As this is not certified, the customer accepts complete responsibility for the gas section.

The monitoring does not start until dual fuel operation is requested using the switching function $2837 \text{ SwitchGasOrDiesel}$ and all other conditions are met. As one of the potentially enabled conditions, the gas pressure can of course only be checked once the gas section test has been successfully completed.

In applications with a gas speed governor, the monitoring always starts when there is to be a switch from pure diesel operation to dual fuel operation.

However, in applications with a diesel reduction governor this is only necessary when switching to gas for the first time after starting the engine or after dual fuel operation has had to be aborted due to an error and is to restart. Under normal circumstances, the gas proportion changes constantly and can also fall to 0. For safety reasons, the valves are closed in this situation. However, repeat monitoring is not necessary; it would take too much time and would be detrimental to the overall gas/diesel ratio.

Monitoring is enabled with 14080 *CheckGasValveReady*.



Notice

The parameter 14080 CheckGasValveReady must always be set in delivered applications; it is only permitted to dispense with it for tests on test benches.

At the start of gas section monitoring 12081 *GasValveCheckActive* = 1 is set. This parameter must be assigned to a binary output, which is connected to the associated input to the external electronics.

Within 10080 *GasValveCheckDelay* seconds, it is expected that the switching function 2848 *SwitchExternGasReady* (XIOS: 2872 *SwitchExternGasReady*) will be enabled, which in turn is actuated by the gas section electronics.

Successful completion of the gas section test is indicated by 12082 *GasTrainReady* and the gas valves are opened, 12035 *GasValvesOpen* = 1. To do this, 12035 must be assigned to a binary output that is connected to the valves.

In the event of a failed gas section test, 13010 *ErrGasTrain* = 1 or 13030 *ErrGasRailStatus.0* = 1 on the XIOS is set and dual fuel operation is not possible.

If the duration of the test in the external electronics is not known, for setting purposes 10080 *GasValveCheckDelay* can be set to a high value and the actual time required can be observed with 12080 *GasValveCheckDelay* and 12082 *GasTrainReady*. Meaningful adjustment of the parameter is then possible.

Parameters

2848 <i>SwitchExternGasReady</i>	Response from external electronics
2872 <i>SwitchExternGasReady</i> (XIOS)	
10080 <i>GasValveCheckDelay</i>	Time in which 2848/2972 <i>SwitchExternGasReady</i> has to be enabled
12035 <i>GasValvesOpen</i>	1: Gas valves open
12080 <i>GasValveCheckDelay</i>	Currently elapsing time
12081 <i>GasValveCheckActive</i>	Start signal for external electronics
12082 <i>GasTrainReady</i>	1: Gas section OK
13010 <i>ErrGasTrain</i>	1: Gas section not OK
13030 <i>ErrGasRailStatus.0</i> (XIOS)	

16.7.2 Monitoring the power

For dual fuel operation, the total power must be between 10013 *GasModePowerMin* and 10014 *GasModePowerMax* if this function has been enabled with 14013 *CheckPowerInRange*.

Parameters

10013 <i>GasModePowerMin</i>	Minimum power for dual fuel operation
10014 <i>GasModePowerMax</i>	Maximum power for dual fuel operation
10015 <i>GasModePowerHyst</i>	Hysteresis
14013 <i>CheckPowerInRange</i>	Enable / disable monitoring

16.7.2.1 Gas speed governor

If gas is requested in diesel operation when the function is enabled or if the engine is already running in dual fuel operation and the power is not (or is no longer) in the permissible range, the error 13013 *ErrPowerRangeForGas* (or 13031 *ErrGasConditions.2* for XIOS) is reported.

Parameters

3232 <i>RelativePower</i>	Current power in generator operation
13013 <i>ErrPowerRangeForGas</i>	Power not in permissible range
13031 <i>ErrGasConditions.2 (XIOS)</i>	

16.7.2.2 Diesel reduction governor

Different power values are monitored depending on the application. If the power is not in the permissible range, either there is no switch to dual fuel mode or the mode is terminated. However, in each case this is viewed as a normal operating condition and no error is reported.

If the power is in the range or if the monitoring function is not enabled at all, this is signalled with 12013 *PowerInRangeForGas* = 1. This indication is cancelled if monitoring is enabled and the power is 10015 *GasModePowerHyst* below 10013 *GasModePowerMin* or above 10014 *GasModePowerMax* or if the power signal has failed.



Notice

*If both 14013 *CheckPowerInRange* and 14110 *MaxGasPosGovernorOn* are actuated in generator or locomotive operation, then 10014 *GasModePowerMax* must be greater than 10062 *GasPowerLimitMaxAbs*. Up to 10062 *GasPowerLimitMaxAbs* the gas falling is reduced but at 10014 *GasModePowerMax* the gas is switched off.*

Parameters

12013 *PowerInRangeForGas*

Power in permissible range

16.7.2.2.1 Applications for locomotive operation

In diesel/electric locomotive operation, the traction power is used to determine the required and permissible gas quantity and to protect the engine against overload. The traction power is determined from the traction current and the traction voltage, which must be available as measured values.

Parameters

 3231 *TractionPower*

Power in locomotive operation

16.7.2.2.2 Generator applications

The engine power is available in generator operation. The fuel quantity dependent diesel power is determined on the test bench and saved in a characteristic. During operation at nominal speed, the current diesel power can thus be determined at any time and the maximum possible gas power can be calculated.

Parameters

 3232 *RelativePower*

Power in generator operation

16.7.2.2.3 Maritime applications

In Marine operation, gas positioning is performed by the HEINZMANN ELEKTRA device. ELEKTRA calculates the gas power from the gas flow. Together with the speed-dependent and fuel quantity dependent diesel power established on the test bench, the target gas quantity for the specified gas power can be calculated and the engine can thus be protected against overloading.

Parameters

 3231 *EnginePower*

Engine power in marine operation

16.7.3 Monitoring the exhaust temperature

When monitoring the exhaust temperature, we differentiate whether a single measured value is available for the entire engine or whether an exhaust temperature sensor is attached to each cylinder.

16.7.3.1 One exhaust temperature for the entire engine

For dual fuel operation, the exhaust temperature 2911 *ExhaustTemp* must be below 10017 *GasModeExhTempMax* if this function has been enabled with 14017 *CheckExhTempInRange*.

Parameters

 2911 *ExhaustTemp*

Current exhaust temperature

10017 <i>GasModeExhTempMax</i>	Maximum temperature for dual fuel operation
10018 <i>GasModeExhTempHyst</i>	Hysteresis
14017 <i>CheckExhTempInRange</i>	Enable / disable monitoring

16.7.3.1.1 Gas speed governor

If gas is requested in diesel operation when the function is enabled or if the engine is already running in dual fuel operation and the exhaust temperature is not (or is no longer) below the maximum value, the error 13019 *ErrExhTRangeForGas* (or 13031 *ErrGasConditions.8* on XIOS) is signalled.

Parameters

13019 <i>ErrExhTRangeForGas</i>	1 = Exhaust temperature not in permissible range
13031 <i>ErrGasConditions.8</i> (XIOS)	

16.7.3.1.2 Diesel reduction governor

If the exhaust temperature is below the limit or if the monitoring function is not enabled at all, this is signalled with 12017 *ExhTInRangeForGas* = 1. This indication is cancelled if the exhaust temperature is 10018 *GasModeExhTempHyst* above 10017 *GasModeExhTempMax* when the function is enabled.

If the exhaust temperature is not in the permissible range, either there is no switch to dual fuel mode or the mode is terminated. However, in each case this is viewed as a normal operating condition and no error is reported.

Parameters

12017 <i>ExhTInRangeForGas</i>	1 = Exhaust temperature in permissible range
--------------------------------	--

16.7.3.2 One exhaust temperature sensor per cylinder or per throttle valve

The minimum, maximum and average values are determined from all exhaust temperatures on an ongoing basis: 2911 *ExhaustTempMin*, 2913 *ExhaustTempMax* and 2912 *ExhaustTempAverage* (or 12572 *ExhaustTempMin*, 12573 *ExhaustTempMax* and 12570 *ExhaustTempAverage* on XIOS).

To switch to dual fuel operation, the maximum exhaust temperature must be below 10017 *GasModeExhTempMax* and the difference between the minimum and maximum exhaust temperature must be less than 10019 *GasModeExhTempDiff* in diesel operation and less than 10027 *GasModeGasExhTnpDiff* in dual fuel operation if monitoring has been enabled with 14017 *CheckExhTempInRange*.

Every time there is a switch between diesel and dual fuel operation and vice versa, there is a monitoring delay 10028 *GasModeExhTempDelay* before the permissible difference – which then changes – is taken into account.

Parameters

2911/12572 <i>ExhaustTempMin</i>	Current minimum exhaust temperature
2912/12570 <i>ExhaustTempAverage</i>	Current average value of all exhaust temperatures
2913/12573 <i>ExhaustTempMax</i>	Current maximum exhaust temperature
10017 <i>GasModeExhTempMax</i>	Maximum temperature for dual fuel operation
10018 <i>GasModeExhTempHyst</i>	Hysteresis
10019 <i>GasModeExhTempDiff</i>	Maximum permissible difference between 2911 <i>ExhaustTempMin</i> and 2913 <i>ExhaustTempMax</i> in diesel operation
10027 <i>GasModeGasExhTmDiff</i>	Maximum permissible difference between 2911 <i>ExhaustTempMin</i> and 2913 <i>ExhaustTempMax</i> in dual fuel operation
10028 <i>GasModeExhTempDelay</i>	Monitoring delay after switching to gas or diesel operation
14017 <i>CheckExhTempInRange</i>	Enable / disable monitoring

16.7.3.2.1 Gas speed governor

If the exhaust temperature is 10018 *GasModeExhTempHyst* above 10017 *GasModeExhTempMax* when the function is enabled or if the difference is greater than 10019 *GasModeExhTempDiff* in diesel operation or greater than 10027 *GasModeGasExhTmDiff* in dual fuel operation, the error 13019 *ErrExhTRangeForGas* (or 13031 *ErrGasConditions.8* for XIOS) or 13020 *ErrExhTDRangeForGas* (or 13031 *ErrGasConditions.9* for XIOS) is signalled.

Parameters

13019 <i>ErrExhTRangeForGas</i>	1 = Exhaust temperature too high
13031 <i>ErrGasConditions.8</i> (XIOS)	
13020 <i>ErrExhTDRangeForGas</i>	1 = Exhaust temperature difference too high
13031 <i>ErrGasConditions.9</i> (XIOS)	

16.7.3.2.2 Diesel reduction governor

If both the maximum exhaust temperature and the difference are below the relevant limit or if monitoring is not enabled at all, this is signalled with 12017 *ExhTInRangeForGas* = 1 and 12018 *ExhTDInRangeForGas* = 1. This indication is cancelled if the exhaust temperature is 10018 *GasModeExhTempHyst* above 10017 *GasModeExhTempMax* or the difference is greater than 10019 *GasModeExhTempDiff* or 10027 *GasModeGasExhTmpDiff* when the function is enabled.

If the exhaust temperatures are not in the permissible range, either there is no switch to dual fuel mode or the mode is terminated. However, in each case this is viewed as a normal operating condition and no error is reported.

Parameters

12017 <i>ExhTInRangeForGas</i>	1 = Exhaust temperature in permissible range
12018 <i>ExhTDInRangeForGas</i>	1 = Exhaust temperature difference in permissible range

16.7.4 Coolant temperature monitoring

For dual fuel operation the coolant temperature 2907 *CoolantTemp* must be between 10020 *GasModeCoolTempMin* and 10021 *GasModeCoolTempMax* if this function has been enabled with 14020 *CheckCoolTempInRange*.

Parameters

2907 <i>CoolantTemp</i>	Current coolant temperature
10020 <i>GasModeCoolTempMin</i>	Minimum temperature for dual fuel operation
10021 <i>GasModeCoolTempMax</i>	Maximum temperature for dual fuel operation
10022 <i>GasModeCoolTempHyst</i>	Hysteresis
14020 <i>CheckCoolTempInRange</i>	Enable / disable monitoring

16.7.4.1 Gas speed governor

If gas is requested in diesel operation when the function is enabled or if the engine is already running in dual fuel operation and the coolant temperature is not (or is no longer) in the permissible range, the error 13018 *ErrCoolTRangeForGas* (or 13031 *ErrGasConditions.6* for XIOS) is reported.

Parameters

13018 <i>ErrCoolTRangeForGas</i>	Coolant temperature not in permissible
13031 <i>ErrGasConditions.6</i> (XIOS)	range

16.7.4.2 Diesel reduction governor

If the coolant temperature is in the range or if the monitoring function is not enabled at all, this is signalled with 12019 *CoolTInRangeForGas* = 1. This indication is cancelled if the coolant temperature is 10022 *GasModeCoolTempHyst* below 10020 *GasModeCoolTempMin* or above 10021 *GasModeCoolTempMax* when monitoring is enabled.

If the coolant temperature is not in the permissible range, either there is no switch to dual fuel mode or the mode is terminated. However, in each case this is viewed as a normal operating condition and no error is reported.

Parameters

12019 <i>CoolTInRangeForGas</i>	Coolant temperature in permissible range
---------------------------------	--

16.7.5 Charge air temperature monitoring

For dual fuel operation the charge air temperature 2908 *ChargeAirTemp* must be between 10002 *GasModeChAirTempMin* and 10003 *GasModeChAirTempMax* if this function has been enabled with 14002 *CheckChAirTmpInRange*.

Parameters

2908 <i>ChargeAirTemp</i>	Current charge air temperature
10002 <i>GasModeChAirTempMin</i>	Minimum temperature for dual fuel operation
10003 <i>GasModeChAirTempMax</i>	Maximum temperature for dual fuel operation
10004 <i>GasModeChAirTempHyst</i>	Hysteresis
14002 <i>CheckChAirTmpInRange</i>	Enable / disable monitoring

16.7.5.1 Gas speed governor

If gas is requested in diesel operation when the function is enabled or if the engine is already running in dual fuel operation and the charge air temperature is not (or is no longer) in the permissible range, the error 13021 *ErrChAirTRangeForGas* (or 13031 *ErrGasConditions.7* for XIOS) is reported.

Parameters

13021 <i>ErrChAirTRangeForGas</i>	Charge air temperature not in permissible
13031 <i>ErrGasConditions.7</i> (XIOS)	range

16.7.5.2 Diesel reduction governor

If the charge air temperature is in the range or if the monitoring function is not enabled at all, this is signalled with 12002 *ChAirTInRangeForGas* = 1. This indication is cancelled if the charge air temperature is 10004 *GasModeChAirTempHyst* below 10002 *GasModeChAirTempMin* or above 10003 *GasModeChAirTempMax* when monitoring is enabled.

If the charge air temperature is not in the permissible range, either there is no switch to dual fuel mode or the mode is terminated. However, in each case this is viewed as a normal operating condition and no error is reported.

Parameters

12002 <i>ChAirTInRangeForGas</i>	Charge air temperature in permissible range
----------------------------------	---

16.7.6 Gas temperature monitoring

For dual fuel operation the gas temperature 2910 *GasTemp* (XIOS: 2926 *GasTemp*) must be between 10023 *GasModeGasTempMin* and 10024 *GasModeGasTempMax* if this function has been enabled with 14022 *CheckGasTempInRange*.

Parameters

2910 <i>GasTemp</i> (Others)	Current gas temperature
2926 <i>GasTemp</i> (XIOS)	
10023 <i>GasModeGasTempMin</i>	Minimum temperature for dual fuel operation
10024 <i>GasModeGasTempMax</i>	Maximum temperature for dual fuel operation
10025 <i>GasModeGasTempHyst</i>	Hysteresis
14022 <i>CheckGasTempInRange</i>	Enable / disable monitoring

16.7.6.1 Gas speed governor

If gas is requested in diesel operation when the function is enabled or if the engine is already running in dual fuel operation and the gas temperature is not (or is no longer) in the permissible range, the error 1301826 *ErGasTRangeForGas* (or 13030 *ErrGasRailStatus.8* for XIOS) is reported.

Parameters

13026 <i>ErGasTRangeForGas</i>	Gas temperature not in permissible
13030 <i>ErrGasRailStatus.8</i> (XIOS)	range

16.7.6.2 Diesel reduction governor

If the gas temperature is in the range or if the monitoring function is not enabled at all, this is signalled with 12004 *GasTInRangeForGas* = 1. This indication is cancelled if the gas temperature is 10025 *GasModeGasTempHyst* below 10023 *GasModeGasTempMin* or above 10024 *GasModeGasTempMax* when monitoring is enabled.

If the gas temperature is not in the permissible range, either there is no switch to dual fuel mode or the mode is terminated. However, in each case this is viewed as a normal operating condition and no error is reported.

Parameters

12004 *GasTInRangeForGas* Gas temperature in permissible range

16.7.7 Oil pressure monitoring

For dual fuel operation the oil pressure 2905 *OilPressure* must be above the warning curve if this function has been enabled with 14015 *CheckOilPressInRange* (↑ 10.6 *Speed dependent oil pressure monitoring*).

Of course, the oil pressure must be sufficient for diesel operation, but this is to be monitored separately.

Parameters

2905 *OilPressure* Current oil pressure

3030 *ErrOilPressWarn* Oil pressure is below warning curve

3010 *ErrOilPressure.bExceedLimit1*(XIOS)

14015 *CheckOilPressInRange* Enable / disable monitoring

16.7.7.1 Gas speed governor

If gas is requested in diesel operation when the function is enabled or if the engine is already running in dual fuel operation and the oil pressure is not (or is no longer) in the permissible range, the error 13016 *ErrOilPrRangeForGas* (or 13031 *ErrGasConditions.5* for XIOS) is reported.

Parameters

13016 *ErrOilPrRangeForGas* Oil pressure not in permissible range

13031 *ErrGasConditions.5* (XIOS)

16.7.7.2 Diesel reduction governor

If the oil pressure is above the warning curve or if the monitoring function is not enabled at all, this is signalled with 12015 *OilPrInRangeForGas* = 1. This indication

is cancelled if the oil pressure falls below the warning curve 3030 *ErrOilPressWarn* (or 3010 *ErrOilPressure.bExceedLimit1* for XIOS) when monitoring is enabled.

If the oil pressure is not in the permissible range, either there is no switch to dual fuel mode or the mode is terminated. However, in each case this is viewed as a normal operating condition and no error is reported.

Parameters

12015 <i>OilPrInRangeForGas</i>	Oil pressure in permissible range
---------------------------------	-----------------------------------

16.7.8 Boost pressure monitoring

For dual fuel operation the boost pressure 2904 *BoostPressure* must be above the power-dependent characteristic if this function has been enabled with 14016 *CheckBoostPrInRange*.

In generator and Marine operation, the characteristic is created based on the relative power 3232 *RelativePower* and in locomotive applications based on the traction power 3231 *TractionPower*.

Parameters

2904 <i>BoostPressure</i>	Current boost pressure
16100 <i>GasModeBoostPr:P(x)</i>	Power values from characteristic
16115 <i>GasModeBoostPr:p(x)</i>	Boost pressure values from characteristic
10016 <i>GasModeBoostHyst</i>	Hysteresis
14016 <i>CheckBoostPrInRange</i>	Enable / disable monitoring

16.7.8.1 Gas speed governor

If gas is requested in diesel operation when the function is enabled or if the engine is already running in dual fuel operation and the boost pressure is not (or is no longer) in the permissible range, the error 13015 *ErrBoostRangeForGas* (or 13031 *ErrGasConditions.4* for XIOS) is reported.

Parameters

13015 <i>ErrBoostRangeForGas</i>	Boost pressure not in permissible range
13031 <i>ErrGasConditions.4</i> (XIOS)	

16.7.8.2 Diesel reduction governor

If the boost pressure is in the range or if the monitoring function is not enabled at all, this is signalled with 12016 *BoostInRangeForGas* = 1. This indication is cancelled if the boost pressure is 10016 *GasModeBoostHyst* below the power-dependent characteristic or if the power signal has failed when monitoring is enabled.

If the boost pressure is not in the permissible range, either there is no switch to dual fuel mode or the mode is terminated. However, in each case this is viewed as a normal operating condition and no error is reported.

Parameters

12016 *BoostInRangeForGas* Boost pressure in permissible range

16.7.9 Gas rail pressure monitoring

The gas rail pressure 2921 *GasRailPressure* (XIOS: 2928 *GasRailPressure*) is monitored for dual fuel operation. It is calculated relative to the boost pressure on the charged engine and the result is provided in 2925 *GasDiffPressure* (XIOS: 2942 *GasDiffPressure*). On a non-charged engine 2925 *GasDiffPressure* and 2921 *GasRailPressure* are identical (XIOS: 2942 *GasDiffPressure* and 2928 *GasRailPressure*).

For dual fuel operation 2925 *GasDiffPressure* (XIOS: 2942 *GasDiffPressure*) must be between 10005 *GasModeGasRPressMin* and 10006 *GasModeGasRPressMax* if this function has been enabled with 14005 *CheckGasRPrInRange*.

Parameters

2921 <i>GasRailPressure</i>	Gas pressure
2928 <i>GasRailPressure</i> (XIOS)	
2925 <i>GasDiffPressure</i>	Relative gas pressure
2942 <i>GasDiffPressure</i> (XIOS)	(gas rail pressure minus boost pressure)
10005 <i>GasModeGasRPressMin</i>	Minimum relative gas pressure for dual fuel operation
10006 <i>GasModeGasRPressMax</i>	Maximum relative gas pressure for dual fuel operation
10007 <i>GasModeGasRPressHyst</i>	Hysteresis
10008 <i>GasModeGasAtLimitMax</i>	Max. time for which the relative gas pressure
	can be outside the error limits
14005 <i>CheckGasRPrInRange</i>	Enable / disable monitoring

16.7.9.1 Gas speed governor

The error 13017 *ErrGasPrRangeForGas* (or 13030 *ErrGasRailStatus.7* for XIOS) is reported if the relative gas pressure is more than 10007 *GasModeGasRPressHyst* below 10005 *GasModeGasRPressMin* or above 10006 *GasModeGasRPressMax* for the time period 10008 *GasModeGasAtLimitMax* when monitoring is enabled.

Parameters

13017 <i>ErrGasPrRangeForGas</i>	Relative gas pressure not in
13030 <i>ErrGasRailStatus.7</i> (XIOS)	permissible range

16.7.9.2 Diesel reduction governor

If the relative gas pressure is in the range or if the monitoring function is not enabled at all, this is signalled with 12005 *GasPrInRangeForGas* = 1. This indication is cancelled if the relative gas pressure is more than 10007 *GasModeGasRPressHyst* below 10005 *GasModeGasRPressMin* or above 10006 *GasModeGasRPressMax* for the duration 10008 *GasModeGasAtLimitMax* when monitoring is enabled.

If the relative gas pressure is not in the permissible range, either there is no switch to dual fuel mode or the mode is terminated. However, in each case this is viewed as a normal operating condition and no error is reported.

Parameters

12005 <i>GasPrInRangeForGas</i>	1: Relative gas pressure in permissible range
---------------------------------	---

16.7.10 External gas pressure monitoring

If an external monitoring device checks the gas pressure, the result must be transferred to the control unit with the switching function 2845 *SwitchGasPressReady* (XIOS: 2870 *SwitchGasPressReady*). If this function becomes inactive 13008 *ErrGasPressTooLow* or 13030 *ErrGasRailStatus.5* (XIOS) is triggered and there is no switch to gas operation or dual fuel mode is terminated.

Parameters

2845 <i>SwitchGasPressReady</i>	Gas pressure switch state
2870 <i>SwitchGasPressReady</i> (XIOS)	
13008 <i>ErrGasPressTooLow</i>	Gas pressure switch is inactive when
13030 <i>ErrGasRailStatus.5</i> (XIOS)	dual fuel operation is requested

16.7.11 Speed monitoring

For dual fuel operation the speed 2000 *Speed* must be between 10010 *GasModeSpeedMin* and 10011 *GasModeSpeedMax* if this function has been enabled with 14010 *CheckSpeedInRange*.

Parameters

2000 <i>Speed</i>	Current speed
10010 <i>GasModeSpeedMin</i>	Minimum speed for dual fuel operation
10011 <i>GasModeSpeedMax</i>	Maximum speed for dual fuel operation

10012 <i>GasModeSpeedHyst</i>	Hysteresis
14010 <i>CheckSpeedInRange</i>	Enable / disable monitoring

16.7.11.1 Gas speed governor

If gas is requested in diesel operation when the function is enabled or if the engine is already running in dual fuel operation and the speed is not (or is no longer) in the permissible range, the error 13012 *ErrSpeedRangeForGas* (or 13031 *ErrGasConditions.1* for XIOS) is reported.

Parameters

13012 <i>ErrSpeedRangeForGas</i>	Speed not in permissible range
13031 <i>ErrGasConditions.1</i> (XIOS)	

16.7.11.2 Diesel reduction governor

If the speed is in the range or if the function is not enabled at all, this is signalled with 12010 *SpeedInRangeForGas* = 1. This indication is cancelled if the speed is 10012 *GasModeSpeedHyst* below 10010 *GasModeSpeedMin* or above 10011 *GasModeSpeedMax* when the function is enabled.

If the speed is not in the permissible range, either there is no switch to dual fuel mode or the mode is terminated. However, in each case this is viewed as a normal operating condition and no error is reported.

Parameters

12010 <i>SpeedInRangeForGas</i>	Speed in permissible range
---------------------------------	----------------------------

16.7.12 Ignition oil quantity monitoring

To ensure safe dual fuel operation, it is essential that the current diesel quantity is sufficient to combust the gas. The ignition oil quantity must therefore be monitored on an ongoing basis.

16.7.12.1 Gas speed governor

In pure diesel operation, a check is made for whether the current diesel quantity 2350 *DieselFuelQuantity* is above the ignition oil quantity 12060 *PilotFuelPresent* + 10061 *PilotFuelHysteresis*. If this is the case, or if the associated monitoring function 14012 *CheckDieslAbovePilot* is not enabled at all, this condition – as one of several – is met. Otherwise, there is no switch to dual fuel operation and the error message 13014 *ErrFuelRangeForGas* or 13031 *ErrGasConditions.3* (XIOS) is indicated despite the request.

The enabled dual fuel operation must be terminated if 2350 *DieselFuelQuantity* falls below 12060 *PilotFuelPresent* – 10061 *PilotFuelHysteresis*. Monitoring in dual fuel

operation is always carried out, regardless of whether 14012 *CheckDieslAbovePilot* is enabled or not. In case of error 13023 *ErrBelowPilotFuel* or 13031 *ErrGasConditions.13* (XIOS) is indicated.

Parameters

10061 <i>PilotFuelHysteresis</i>	Hysteresis
12060 <i>PilotFuelPresent</i>	Current ignition oil quantity, never less than 10055 <i>PilotDslAbsMinimum</i>
12061 <i>DieselAtPilotFuel</i>	Diesel fuel quantity has reached ignition oil quantity
13014 <i>ErrFuelRangeForGas</i>	Diesel fuel quantity in diesel operation not in
13031 <i>ErrGasConditions.3</i> (XIOS)	permissible range for gas
13023 <i>ErrBelowPilotFuel</i>	Diesel fuel quantity in dual fuel operation
13031 <i>ErrGasConditions.13</i> (XIOS)	below ignition oil quantity
14012 <i>CheckDieslAbovePilot</i>	Enable / disable check in diesel operation

16.7.12.2 Diesel reduction governor

In applications with diesel reduction governor, dual fuel operation is terminated without errors if the diesel fuel quantity 2350 *DieselFuelQuantity* falls 10061 *DieselHysteresis* below the current setpoint 12060 *DieselRedGovSetp* and it is re-enabled when the conditions are met again. The diesel fuel quantity must be 10061 *DieselHysteresis* above 12060 *DieselRedGovSetp*.

If the current diesel fuel quantity in dual fuel operation actually falls below the ignition oil quantity 12055 *PilotDslAbsMinimum* – 10061 *DieselHysteresis*, this is indicated by the message 12011 *DieselBelowPilotFuel*. This message is only cancelled if the current diesel fuel quantity is above 12055 *PilotDslAbsMinimum* + 10061 *DieselHysteresis*.

To stop the diesel, which is currently being ramped up, from being reduced again immediately, connection of the gas is delayed by 10094 *GasStartDelay* after the diesel has reached the setpoint 12060 *DieselRedGovSetp*.

If dual fuel operation is active, a check is made of whether the actual diesel value is actually falling towards the setpoint when gas is added. This is an indirect test of whether the main gas valve is open. The check is of whether, with addition of gas greater than 10040 *DieselDiffGasMin*, the difference between the diesel actual value and setpoint remains greater than 10041 *DieselDiffMax* over the time period 10042 *DieselDiffDelay*. In this case dual fuel operation is immediately terminated with the error 13027 *ErrGasNoPower* or 13031 *ErrGasRailStatus.9* (XIOS).

Parameters

10040 <i>DieselDiffGasMin</i>	Minimum gas value for valve test
10041 <i>DieselDiffMax</i>	Difference between diesel actual value and setpoint for valve test
10042 <i>DieselDiffDelay</i>	Valve testing time
10061 <i>DieselHysteresis</i>	Hysteresis
10094 <i>GasStartDelay</i>	Delay time for gas addition after diesel ignition oil quantity is reached again
12011 <i>DieselBelowPilotFuel</i>	Diesel is below current ignition oil quantity
12012 <i>DieselInRangeForGas</i>	In diesel operation, diesel is in permissible range for dual fuel operation
12060 <i>DieselRedGovSetp</i>	Current diesel setpoint
13027 <i>ErrGasNoPower</i>	Gas does not produce any power
proportion, diesel	
13031 <i>ErrGasRailStatus.9</i> (XIOS)	not responding, main gas valve open?

16.7.13 Gas quantity monitoring

16.7.13.1 Gas speed governor

If no power is requested from the engine in standard gas operation, it must be ensured that the total of the current gas and diesel power proportions does not lead to the engine overspeeding. This is particularly necessary because the ignition oil quantity generates a certain power proportion. Therefore if the calculated gas fuel quantity over the time period *10069 GasMinToDieselDelay* is less than *10065 GasDecrAtDieselStart* the gas must be switched off with a return to diesel.

Note that *10065 GasDecrAtDieselStart* is also used in [↑]16.8.3 *Switching ramp from gas to diesel operation* and [↑]16.8.4.1 *Gas at the power limit*.

Parameters

<i>10065 GasDecrAtDieselStart</i>	Lower limit for dual fuel operation at zero fuel
<i>10069 GasMinToDieselDelay</i>	Maximum permissible time at the lower limit

16.7.14 Engine knocking monitoring

For knock monitoring, the HEINZMANN ARIADNE device is connected to the dual fuel control unit via the HZM-CAN bus. In terms of the HZM-CAN bus system, ARIADNE is known as an add-on module (AC).

Up to five add-on modules can normally be connected to a control unit. Their node numbers are saved in the parameters starting from 430 *CanACNodeNumber* and their type in the parameters starting from 435 *CanACNodeType*. ARIADNE has type 0 (not specified).

It is essential to use 10056 *KnockModulACIndex* to notify the dual fuel control unit which index (0...4) is assigned to the ARIADNE starting at 430 *CanACNodeNumber*/435 *CanACNodeType*. This parameter is only evaluated after a reset. For the messages about light or heavy knocking to be evaluated, the control unit must evaluate the ARIADNE error messages. To do this 4430 *ReceiveACErrorOn* must be enabled. Whether the control unit has accepted the configuration is indicated with 12090 *AriadneKnockControl* = 1.

In order to evaluate the knocking 14014 *CheckKnocking* must be enabled.

In the dual fuel control unit, light knocking is indicated in 13011 *ErrLightKnocking* (gas speed governor and diesel reduction governor) or 12014 *LightKnocking* (diesel reduction governor) and heavy knocking in 13007 *ErrHeavyKnocking*. If the CAN connection to the ARIADNE is lost, this is noted in 13009 *ErrKnockControlOff*.

The reaction to light knocking is described in the two following subchapters. In the event of heavy knocking or failure of the monitoring by ARIADNE, the gas is shut down immediately.

The ARIADNE also reports fatal errors in its own control unit, e.g. pickup or overspeed errors or if the synchronisation is lost. In these cases, knocking cannot be monitored and therefore the dual fuel control unit should also shut down the gas immediately here. This function is enabled with 14057 *GasOff@AriadneFatal*.

Parameters

430 <i>CanACNodeNumber</i>	Node numbers of up to 5 AC modules
435 <i>CanACNodeType</i>	Node type of up to 5 AC modules
10056 <i>KnockModulACIndex</i>	Index for ARIADNE in 430 <i>CanACNode-number</i> /435 <i>CanACNodeType</i>

12090 <i>AriadneKnockControl</i>	ARIADNE configuration accepted
13007 <i>ErrHeavyKnocking</i>	Heavy knocking
13009 <i>ErrKnockControlOff</i>	Connection to ARIADNE has failed
14014 <i>CheckKnocking</i>	Enable / disable knock monitoring
14057 <i>GasOff@AriadneFatal</i>	Switch off gas if ARIADNE reports a fatal error

16.7.14.1 Gas speed governor

With light knocking, in the gas speed governor the current ignition oil quantity and thus the diesel proportion is gradually increased by 10057 *KnockPilotDslOffset*. This automatically results in calculation of a smaller gas quantity. If the light knocking persists, the next increase is carried out 10059 *KnockPilotDOffsDelay* seconds later. The increases indicated as a total in 12059 *DieselKnockOffset* continue up to a maximum of 10058 *KnockPilotDslOffsMax* after which the gas is switched off with the error message 13011 *ErrLightKnocking* or 13031 *ErrGasConditions.13* (XIOS).

If the knocking is remedied by increasing the ignition oil quantity, this new ignition oil value is retained until an external or internal request leads to a return to diesel operation. The next dual fuel operation starts again with the originally configured ignition oil quantity.

Parameters

10057 <i>KnockPilotDslOffset</i>	Offset for the ignition oil quantity
10058 <i>KnockPilotDslOffsMax</i>	Max. permissible offset total
10059 <i>KnockPilotDOffsDelay</i>	Waiting time between two increases
12059 <i>DieselKnockOffset</i>	Current offset total
13011 <i>ErrLightKnocking</i>	Max. offset for light knocking reached
13031 <i>ErrGasConditions.13</i> (XIOS)	

16.7.14.2 Diesel reduction governor

With light knocking 12014 *LightKnocking* in the diesel reduction governor the current diesel setpoint is gradually increased by 10057 *KnockDslSetpOffset*. This automatically results in calculation of a smaller gas quantity. If the light knocking persists, the next increase is carried out 10059 *KnockDslSetOffsDelay* seconds later. The increases indicated as a total in 12059 *DieselKnockOffset* continue up to a maximum of 10058 *KnockDslSetpOffsMax* after which the gas is switched off.

As this operating mode involves continuous switching between pure diesel and dual fuel operation, the offset for the diesel setpoint is increased with light knocking and lowered again when there is no knocking. The increase is made at intervals of 10059

KnockDslSetOffsDelay, for as long as knocking persists. Lowering of the offset is half as fast at intervals of 2×10059 *KnockDslSetOffsDelay*, as long as no knocking is detected. This automatically results in the necessary offset to prevent knocking.

Parameters

10057 <i>KnockDslSetpOffset</i>	Offset on diesel setpoint
10058 <i>KnockDslSetpOffsMax</i>	Max. permissible offset total
10059 <i>KnockDslSetOffsDelay</i>	Waiting time between two increases, double between two reductions
12014 <i>LightKnocking</i>	Light knocking
12059 <i>DieselKnockOffset</i>	Current offset total
13011 <i>ErrLightKnocking</i>	Max. offset for light knocking reached
13031 <i>ErrGasConditions.13</i> (XIOS)	

16.7.15 External gas alarm monitoring

If an external monitoring device triggers a gas alarm, this must be transferred to the control unit using the switching function 2847 *SwitchExternGasAlarm* (2871 *SwitchExternGasAlarm* on XIOS). When this function is enabled, 13024 *ErrExternGasAlarm* or 13030 *ErrGasRailStatus.6* on the XIOS is triggered and the gas is immediately switched off.

Parameters

2847 <i>SwitchExternGasAlarm</i>	Gas alarm switch state
2871 <i>SwitchExternGasAlarm</i> (XIOS)	
13024 <i>ErrExternGasAlarm</i>	Gas alarm switch active
13030 <i>ErrGasRailStatus.6</i> (XIOS)	

16.7.16 Monitoring the gas output device

Ongoing checks must be made for whether the gas output on the actuator or valves is operational. Otherwise, there is no switch to dual fuel mode or the mode is terminated immediately. If one of the following errors occurs, dual fuel operation is not possible.

16.7.16.1 Own actuator (DC 1-04)

Parameters

3051 <i>ErrFeedback2</i>	Only if 12092 <i>ActuatGasPositioner</i> = 1
3052 <i>ErrFeedback3</i>	Only if 12093 <i>ActuatGasPositioner2</i> = 1

16.7.16.2 Own actuator (XIOS)

A check is made for whether the actuators to which the gas value 12023 *GasFuelQuantity* or, with two throttle valves, 12022 *GasFuelQuantity(0)* or 12023 *GasFuelQuantity(1)* has been assigned have an error.

Parameters

3050 <i>ErrActuator1</i>	Error on actuator 1
3051 <i>ErrActuator2</i>	Error on actuator 2
3051 <i>ErrActuator3</i>	Error on actuator 3

16.7.16.3 Actuator on HZM-CAN periphery module

A check is made whether the CAN connection to the periphery module has been established and that the periphery module is not reporting any actuator or other fatal errors.

Parameters

3070 <i>ErrCanBus</i>	CAN bus error
3071 <i>ErrCanComm</i>	CAN communication error (timeout)
12020 <i>GasActPos</i>	Actuator position in periphery module
13001 <i>ErrGasPositioner</i>	Gas positioner error
13025 <i>ErrGasPosFatal</i>	Fatal error on gas positioner
13032 <i>ErrDualFuelStatus.0</i> (XIOS)	

16.7.16.4 MEGASOL valves on HZM-CAN periphery modules

A check is made whether the CAN connection to the periphery module has been established and that the periphery module is not reporting any fatal errors. Whether the periphery module is actually outputting the gas value to the MEGASOL valves is also monitored. 13022 *ErrEFIGasPosDiff* is set if this is not possible due to a lack of synchronisation. In this case, instead of the received setpoint the periphery module always returns the value 0 %. This received value is compared with the send value in the master and the error is output after 1 s.

Parameters

3070 <i>ErrCanBus</i>	CAN bus error
3071 <i>ErrCanComm</i>	CAN communication error (timeout)
12020 <i>GasFuelActual</i>	Return value from periphery module, = 0 % if not synchronised
13022 <i>ErrEFIGasPosDiff</i>	Error if 12020 <i>GasFuelActual</i> over 1 s = 0%, although 12023 <i>GasFuelQuantity</i> > 0

16.7.16.5 ELEKTRA FlowControl (HZM-CAN add-on module)

Parameters

3070 <i>ErrCanBus</i>	CAN bus error
3071 <i>ErrCanComm</i>	CAN communication error (timeout)
12006 <i>GasPosNotActive</i>	Gas positioner is not active

16.7.16.6 Gas output via analogue output

When the gas value is output to an analogue or PWM output to actuate an external device ([↑]20 *Configuring the control's inputs and outputs*) this device is expected to return the current throttle valve position. This value can be received using an analogue or PWM input and is indicated in the sensor value 2916 *GasPosition* (XIOS: 2927 *GasPosition*) ([↑]17 *Configuration of sensors*). If the setpoint and actual gas position differ from one another by more than 5 % over a second, 13001 *ErrGasPositioner* is set.

Furthermore, it is expected that 2839 *SwitchGasPosState* will be active for as long as the external positioner is not reporting an error. If 2839 *SwitchGasPosState* = 0, 13001 *ErrGasPositioner* is also set.

Both monitoring functions are only taken into account if the relevant input is configured.

Parameters

2839 <i>SwitchGasPosState</i>	Switching function that is assigned the status of the gas positioner
2916 <i>GasPosition</i>	Current gas position via analogue input
2927 <i>GasPosition</i> (XIOS)	
13001 <i>ErrGasPositioner</i>	Gas positioner error

16.7.17 Compressed status indication

Parameters

12084 *GasConditionStatHigh*

Bit	Meaning
8000	Switching function of ext. gas alarm is active
4000	Ariadne reporting heavy knocking
2000	Ariadne reporting light knocking
1000	Gas section OK
0800	Relative gas pressure can be calculated
0400	Load in range for dual fuel operation
0200	Diesel below true ignition oil quantity in the case of gas usage
0100	Diesel in range for gas
0080	Speed in range for dual fuel operation
0040	Oil pressure in range for dual fuel operation
0020	Gas pressure in range for dual fuel operation
0010	Boost pressure in range for dual fuel operation
0008	Charge air temperature in range for dual fuel operation
0004	Coolant temperature in range for dual fuel operation
0002	Exhaust temperature difference in range for dual fuel operation
0001	Exhaust temperature in range for dual fuel operation

12085 *GasConditionStateLow*

Bit	Meaning
8000	Elektra reports error to switch off gas but recovers
4000	Gas positioner: Setpoint specified by PC
2000	-
1000	Gas temperature in range for dual fuel operation
0800	Gas does not produce any power; main valve closed?

12086 *DualFuelStateHigh*

Bit	Meaning
8000	Continue ramp after interruption
4000	Gas is held (at limit or load jump)
2000	Gas at lower limit
1000	Error conditions for immediate reset
0800	Error conditions for reset using fast ramp

0400	Diesel rises while gas is held
0200	Gas lowered after it has been fixed (because diesel is lagging below)
0100	Reaction to downwards load jump in dual fuel operation
0080	Reaction to upwards load jump in dual fuel operation
0040	Gas is involved – as governor or positioner
0020	Initialise filter buffer due to diesel<-->gas switch
0010	Residual gas combustion after return to diesel running
0008	Switch to gas is active (mixed operation)
0004	Switch to diesel is active (mixed operation)
0002	Switch to gas requested
0001	Switch to diesel requested

12087 DualFuelState1Low

Bit	Meaning
8000	Gas at limit active
4000	Diesel controller active
2000	Gas governor active
1000	Gas is being consumed (throttle valve open), only for display
0800	Diesel at the ignition oil quantity
0400	Engine stop request in dual fuel operation
0200	Monitoring of the gas section has been triggered
0100	Open (1) or close (0) gas valve 1 – upstream pressure → pressure chamber
0080	Open (1) or close (0) gas valve 2 – pressure chamber → rail
0040	
0020	Temperature compensation is possible
0010	Everything in green range apart from gas pressure, switch to gas can start
0008	Error conditions for immediate reset but work can continue
0004	Upwards setpoint ramp enabled/disabled
0002	Downwards setpoint ramp enabled/disabled
0001	Check gas setpoint at 0 % to close valves

13030 *ErrGasRailStatus* (XIOS)

Bit	Meaning
0200	Gas does not produce any power
0100	Gas temperature is not in the range for dual fuel operation
0080	Gas pressure is not in the range for dual fuel operation
0040	The gas alarm external switch is active
0001	Gas section not OK

 13031 *ErrGasConditions* (XIOS)

Bit	Meaning
2000	Diesel fuel quantity is below ignition oil quantity
1000	MEGASOL gas positioner not synchronised
0800	Ariadne reporting heavy knocking
0400	Ariadne reporting light knocking
0200	Exhaust temperature difference is not in the range for dual fuel operation
0100	Exhaust temperature is not in the range for dual fuel operation
0080	Charge air temperature is not in the range for dual fuel operation
0040	Coolant temperature is not in the range for dual fuel operation
0020	Oil pressure is not in the range for dual fuel operation
0010	Boost pressure is not in the range for dual fuel operation
0008	Diesel fuel quantity is not in the range for dual fuel operation
0004	Power is not in the range for dual fuel operation
0002	Speed is not in the range for dual fuel operation
0001	Conditions for gas incorrect

 13032 *ErrDualFuelStatus* (XIOS)

Bit	Meaning
0004	Emergency stop command via external input
0002	Ariadne is not responsive
0001	Gas positioner is not responsive

16.8 Gas speed control loop

If the conditions for dual fuel operation are met in diesel mode ([↑ 16.6.1 Conditions for enabling dual fuel operating mode](#)) and the request for dual fuel operation is enabled ([↑ 16.6 Enabling and disabling dual fuel operation](#)), the switch starts.

The switch from diesel to dual fuel operation and vice versa is always performed with an active diesel speed governor and gas positioning. The gas value is gradually changed using

ramps and the diesel speed governor reacts to this by recalculating the diesel proportion. The I-ratio of the diesel speed control loop is assigned the offset 10033 *ConversionStability* during the change (\uparrow 8.1 *Adjustment of PID parameters*).

Ramping from diesel to dual-fuel mode is ended when the diesel proportion has reached the ignition oil quantity. At the same moment, the speed governor is switched to dual fuel operation, i.e. the diesel is positioned to the ignition oil quantity and the actuating variable is then the gas proportion.




Fig. 41: Gas speed control

If the conditions for dual fuel operation are no longer met in dual fuel mode (\uparrow 16.6.2 *Conditions for terminating dual fuel operating mode*), it is normally terminated using a ramp. In exceptional situations, a faster ramp can be used instead or immediate termination of dual fuel mode can be enabled. In any case, the diesel speed governor is enabled immediately and the gas is then only positioned. Mixed operation is ended when the gas proportion has fallen to 0%.

Active diesel control operation is indicated with 12030 *DieselGovernorActive* = 1 (including while the gas is ramped) and active gas control operation is indicated with 12031 *GasGovernorActive* = 1. 12034 *GasConsumptionActive* indicates whether gas is actually being consumed in dual fuel operating mode. This is always the case if a gas quantity $\langle \rangle$ 0 is calculated; i.e. the throttle valve or MEGASOL valves are open.

16.8.1 Setting the PID parameters

Different PID settings naturally apply in dual fuel operation than in diesel operation. Otherwise the gas speed governor functions in exactly the same way as the diesel speed governor, see (\uparrow 8.1 *Adjustment of PID parameters*). As in the diesel speed governor, PID corrections are possible for static and/or dynamic operation.

For static operation see \uparrow 8.5 *Correction of PID parameters for static operation*, for the PID curves see \uparrow 8.2 *PID map*.

As only one of the PID curves specified below should be enabled, the parameters for the correction values 16030 *GasPIDCurve:Corr(x)* only appear once. If multiple values are enabled, 14030 *GasPIDCurvePowerOn* therefore applies before 14031 *GasPIDCurveSpeedOn* before 14032 *GasPIDCurveGasFuelOn*, otherwise the PID values are not corrected.

The gas value resulting from the control loop is indicated in 12025 *GasFuelSetpUnlimited*. It may then be limited with 12062 *GasFuelLimitMax*, the resulting value appears in 12024 *GasFuelQuantUncorr* (\uparrow 16.10.1 Gas speed governor) and finally it can be corrected with the gas pressure and/or gas temperature (\uparrow 16.11 Gas fuel quantity correction). The actual result to be output is provided in 12023 *GasFuelQuantity*.



Notice

If the firmware does not contain any sensors for gas pressure and gas temperature, there is no parameter 12024 GasFuelQuantUncorr and the result of the limitation appears immediately in 12023 GasFuelQuantity.

Parameters

10030 <i>GasGain</i>	P-ratio of gas PID control loop
10031 <i>GasStability</i>	I-ratio of the gas PID control loop
10032 <i>GasDerivative</i>	D-ratio of the gas PID control loop
10033 <i>ConversionStability</i>	Additional I-ratio for the diesel PID control loop during switch from diesel to gas or from gas to diesel
10034 <i>GasSpeedDT1</i>	Speed DT1 proportion, gas PID control loop
10035 <i>GasPowerDT1</i>	Power DT1 proportion, gas PID control loop
10036 <i>GasStaticCorrFactor</i>	Static correction factor
10037 <i>GasStaticCorrRange</i>	Static correction range

14035 <i>GasStaticCorrOn</i>	Enable / disable static correction
12023 <i>GasFuelQuantity</i>	Resulting effective gas value after correction with gas pressure/temperature
12024 <i>GasFuelQuantUncorr</i>	Current gas value after limitation with 12062 <i>GasFuelLimitMax</i>
12025 <i>GasFuelSetpUnlimited</i>	Current gas value calculated by gas speed governor or ramped during switch
12030 <i>DieselGovernorActive</i>	Diesel speed governor is active
12031 <i>GasGovernorActive</i>	Gas speed governor is active
12034 <i>GasConsumptionActive</i>	Indicates that the throttle valve or MEGASOL valves are open
14030 <i>GasPIDCurvePowerOn</i>	Enable / disable power-dependent correction of P and I-ratio
16020 <i>GasPIDCurve:P(x)</i>	Power grid points, PI correction
14031 <i>GasPIDCurveSpeedOn</i>	Enable / disable speed-dependent correction of P and I-ratio
16000 <i>GasPIDCurve:n(x)</i>	Speed grid points, PI correction
14032 <i>GasPIDCurveGasFuelOn</i>	Enable / disable gas fuel quantity dependent correction of P and I-ratio
16010 <i>GasPIDCurve:Gasf(x)</i>	Gas fuel quantity grid points, PI correction
16030 <i>GasPIDCurve:Corr(x)</i>	PI correction values

16.8.2 Switching ramps from diesel to dual fuel operation

Switching from diesel, to dual fuel operation is always carried out using a ramp. The ramp speeds must therefore be set but they do not have to be separately enabled. The gas value is gradually increased and the diesel speed governor, which is still active, reacts to this by reducing the diesel proportion. Ramping is ended when the diesel proportion has reached the ignition oil quantity (\uparrow 16.7.12 *Ignition oil quantity monitoring*). At the same moment, the speed governor is switched to dual fuel operation, i.e. the actuating variable is now the gas proportion and the diesel, is positioned at the ignition oil quantity.

The ramp can begin quickly and stop slowly like an e-curve if 10051 *DieselToGasRampHigh* is greater than 10050 *DieselToGasRampLow*. Otherwise, the ramp function is carried out with the lower, i.e. slower, of the two values.

Parameters

10033 <i>ConversionStability</i>	Additional I-ratio for the diesel PID control loop during switch from diesel to gas or from gas to diesel
10050 <i>DieselToGasRampLow</i>	Slow gas ramp for a gentle phase-in to gas control operation
10051 <i>DieselToGasRampHigh</i>	Faster gas ramp for start of switching

16.8.3 Switching ramp from gas to diesel operation

Switching from gas to diesel operation is normally carried out using a ramp, unless it has to be switched off immediately for safety reasons (\uparrow 16.6.2 *Conditions for terminating dual fuel operating mode*).

The diesel speed governor is enabled and the gas value is simultaneously reduced by 10065 *GasDecrAtDieselStart*. Due to the resulting abrupt reduction in the gas power proportion, the diesel speed governor takes over control immediately.

The gas value is then gradually reduced from the current value. The diesel speed governor reacts to this by increasing the diesel proportion. Ramping is ended when the gas proportion has reached 0%.

The ramp can begin quickly and stop slowly like an e-curve if 10053 *GasToDieselRampHigh* is greater than 10052 *GasToDieselRampLow*. Otherwise, the ramp function is carried out with the lower, i.e. slower, of the two values.

If a fast ramp is requested using the switching function 2838 *SwitchFastToDiesel* or an external engine stop request is enabled during dual fuel operation with 3802 *EngineStopRequest* = 1 or the external gas alarm 2847 *SwitchExternGasAlarm* (XIOS: 2871 *SwitchExternGasAlarm*) is active the fast ramp 10054 *FastGasToDieselRamp* is used instead.

Parameters

10033 <i>ConversionStability</i>	Additional I-ratio for the diesel PID control loop during switch from diesel to gas or from gas to diesel
10052 <i>GasToDieselRampLow</i>	Slow gas ramp for gentle phase-out of the gas supply
10053 <i>GasToDieselRampHigh</i>	Faster gas ramp for start of switching

10054 *FastGasToDieselRamp*

General fast gas ramp

10065 *GasDecrAtDieselStart*

Gas reduction value at start of ramp

16.8.4 Diesel support in gas control operation

When the gas speed governor is active – 12031 *GasGovernorActive* = 1 – and either the gas reaches the power limit or a fast response to load additions or load shedding is needed, diesel can intervene to provide support.

16.8.4.1 Gas at the power limit

The gas is at the power limit if the value determined from the speed governor 12025 *GasFuelSetpUnlimited* exceeds the maximum permissible value 12062 *GasFuelLimitMax* and has to be limited. This is indicated by 2711 *FuelLimitMaxActive* = 1 (\uparrow 16.10.1 Gas speed governor). The resulting gas value actually used is provided in 12023 *GasFuelQuantity*.

If the calculated gas value has to be limited for over 10067 *GasFuelLimitMaxTime* seconds, 12063 *GasAtUpperLimit* is set. If 14076 *GasLimitReactionOn* is then enabled, support from diesel begins.

The current gas value is reduced to double the value of 10065 *GasDecrAtDieselStart* and held at this position. At the same time, the gas speed governor is disabled and the diesel speed governor is enabled.




Fig. 42: Diesel support in gas control operation

The gas power proportion is therefore slightly reduced and the diesel can cover the rest of the high load request. When the load request ends, the diesel speed governor will automatically lower the diesel proportion. When it reaches the ignition oil quantity again, there is a switch back to gas control operation. Of course, the prerequisite is that the conditions for dual fuel operation are met.

This enables the conversion rate to be kept high while still achieving the full engine power.

Parameters

2711 <i>FuelLimitMaxActive</i>	Indicator that the gas value is being limited
10065 <i>GasDecrAtDieselStart</i>	Reduction value at start of diesel support (subtracted 2x)
10067 <i>GasFuelLimitMaxTime</i>	Maximum time for gas at the power limit before diesel support is enabled
12023 <i>GasFuelQuantity</i>	Resulting gas value
12024 <i>GasFuelQuantUncorr</i>	Current gas value after limitation with 12062 <i>GasFuelLimitMax</i>
12025 <i>GasFuelSetpUnlimited</i>	Current gas value calculated by the gas speed governor
12030 <i>DieselGovernorActive</i>	Diesel speed governor is active
12031 <i>GasGovernorActive</i>	Gas speed governor is active
12062 <i>GasFuelLimitMax</i>	Maximum permissible gas quantity
12063 <i>GasAtUpperLimit</i>	Indication that gas was at the power limit for a specified time
12064 <i>DieselSupportActive</i>	Indication that diesel is supporting operation
14076 <i>GasLimitReactionOn</i>	Enable / disable diesel support

16.8.4.2 Load addition

On a dual fuel engine, when compensating for load additions in generator operation (\uparrow 8.6 *Load jump regulation in generator systems (DTI factor)*) it is essential to take into account whether the gas speed governor is currently active. It is possible to configure that the diesel speed governor intervenes to provide support for major load additions.

A major load jump in dual fuel operation is detected when 2029 *LoadGradientDTI* is greater than 10075 *GasPowGradThreshold*. If the load measuring unit only detects a load jump with a delay, it is possible to react to a significant speed undershoot

instead if $2028 \text{ SpeedGradientDTI} < -10076 \text{ GasLoadingSpeedGrThr}$. The decision is made in pure diesel operation and either $4029 \text{ LoadGradientDTIOn}$ or $4028 \text{ SpeedGradientDTIOn}$ is selected accordingly. Regardless of how the load addition is detected, $12075 \text{ GasLoadingActive} = 1$ is set as an indicator.

If diesel support is now requested with $14077 \text{ GasLoadingReactOn} = 1$, the gas speed governor is disabled, the gas is held at the current position and the diesel speed governor is enabled and compensates for the load jump. This situation is indicated by $12076 \text{ GasLoadingReactionOn} = 1$.

When the load addition has been compensated (\uparrow 8.6 *Load jump regulation in generator systems* (DTI factor)), a check is made of whether it is possible to switch immediately back to dual fuel operation. If the conditions are met, it is executed. If the conditions are not met at this time, the engine remains in the diesel speed governor. At this point it is crucial whether automatic mode was enabled with $14001 \text{ GasAutomaticModeOn} = 1$ (\uparrow 16.6.2.1 *Gas speed control*). In this case, the return to gas occurs at the latest when the conditions are met again. Otherwise, an edge change $0 \rightarrow 1$ on the gas switch $2837 \text{ SwitchGasOrDiesel}$ is necessary.

Parameters

$12075 \text{ GasLoadingActive}$	Indicator of major load addition in gas control operation
$12076 \text{ GasLoadingReactionOn}$	Indication that diesel is supporting
$14077 \text{ GasLoadingReactOn}$	Enable / disable diesel support

16.8.4.3 Load shedding

On a dual fuel engine, when compensating for load shedding in generator operation (\uparrow 8.6 *Load jump regulation in generator systems* (DTI factor)) it is essential to take into account whether the gas speed governor is currently active. It is possible to configure that if there is major load shedding the diesel speed governor can control freely in order to go below the ignition oil quantity, which is otherwise held.

Major load shedding in dual fuel operation is detected when $2029 \text{ LoadGradientDTI}$ is less than $10075 \text{ GasPowGradThreshold}$. If the load measuring unit only detects a load jump with a delay, it is possible to react to a significant speed overshoot instead if $2028 \text{ SpeedGradientDTI} > -10078 \text{ GasLoadingSpeedGrThr}$. The decision is made in pure diesel operation and either $4029 \text{ LoadGradientDTIOn}$ or $4028 \text{ SpeedGradientDTIOn}$ is enabled. Regardless of how the load shedding is detected, $12077 \text{ GasLoadRejectActive} = 1$ is set as an indicator.

If diesel support is now requested with $14078 \text{ GasLoadRejectReactOn} = 1$, the gas speed governor is disabled, the gas is immediately set to 0% and the diesel speed governor is enabled. It compensates for the load shedding, in particular ensuring that

the diesel proportion can quickly fall below the ignition oil quantity. This situation is indicated by 12078 *GasLoadRejReactionOn* = 1.

When the load shedding has been compensated (\uparrow 8.6 *Load jump regulation in generator systems* (DT1 factor), a check is made of whether it is possible to switch immediately back to dual fuel operation. If the conditions are met, it is executed. If the conditions are not met at this time, the engine remains in the diesel speed governor. At this point it is crucial whether automatic mode was enabled with 14001 *GasAutomaticModeOn* = 1 (\uparrow 16.6.2.1 *Gas speed control*). In this case, the return to gas occurs at the latest when the conditions for this are met again. Otherwise, an edge change 0 \rightarrow 1 on the gas switch 2837 *SwitchGasOrDiesel* is necessary.

Parameters

12077 <i>GasLoadRejectActive</i>	Indication of major load shedding in gas control operation
12078 <i>GasLoadRejReactionOn</i>	Indication that diesel is supporting
14078 <i>GasLoadRejectReactOn</i>	Enable / disable diesel support

16.8.5 Integrated power governor

If the integrated power governor is used \uparrow 16.1 *Gas speed control*, it should be expected that different PID parameters are required in dual fuel operation than in diesel operation.

Parameters

10070 <i>GasPowGovGain</i>	P-ratio of integrated power governor in dual fuel operation
10071 <i>GasPowGovStability</i>	I-ratio of integrated power governor in dual fuel operation
10072 <i>GasPowGovDerivative</i>	D-ratio of integrated power governor in dual fuel operation

Power-dependent correction is also possible for these parameters. The associated characteristic is enabled with 14070 *GasPowGovPIDCurveOn*.

Parameters

6300 <i>PIDCrVPowGov:P(x)</i>	Power grid points for PI correction of the integrated power governor in diesel and dual fuel operation
16040 <i>GasPICrvPGov:Corr(x)</i>	Correction values for PI correction of the integrated power governor in dual fuel operation

16.9 Diesel reduction control loop

The diesel reduction governor is always active if the conditions for gas are met. One of the most important conditions is that the diesel quantity calculated by the speed governor 2350 *DieselFuelQuantity* or, for engines with PT pump, the calculated diesel power 12050 *DieselPower* is above the ignition oil quantity necessary for ignition of the gas.

A required diesel setpoint 12060 *DieselRedGovSetp* and the current diesel fuel quantity 2350 *DieselFuelQuantity* or, for engines with PT pump, the calculated diesel power 12050 *DieselPower* are fed into the control loop. The result of the control loop is a gas fuel quantity 12023 *GasFuelQuantity*. Adding the gas automatically increases the speed and the speed governor responds to this by reducing the diesel quantity. As a result of the interrelationships between the two control loops, gas is added until the diesel value reaches the desired low setpoint. In static operation, this diesel value is held and thus ensures the maximum possible conversion rate.




Fig. 43: Diesel reduction control

Because the diesel speed governor can control freely, it reacts quickly to every change in speed or load with no influence from the gas. The diesel reduction governor follows more slowly – but always taking into account the safety conditions that determine whether gas can actually be added. Thus, if the calculated diesel quantity after load shedding is below the current setpoint or even below the ignition oil quantity, the gas is immediately switched off.

However, due to the dynamics of the diesel speed governor it is possible that the diesel reduction governor setpoint 12060 *DieselRedGovSetp* is not reached for a long time and

the actual diesel value 2350 *DieselFuelQuantity* or, for engines with PT pump, the actual diesel power 12050 *DieselPower* remains higher than the setpoint. The diesel reduction governor would respond to this by continuously increasing the gas value 12023 *GasFuelQuantity* in order to reduce the diesel proportion. This can lead to overloading of the engine. Therefore, it is hugely important that the gas quantity calculated in the diesel reduction governor is limited in such a way that this kind of overload is prevented or at least its duration is limited.

NOTICE	<p>HEINZMANN does not accept any responsibility for damage due to engine overload, as suitable software functions are available to prevent this. The actual use of these functions is the responsibility of the operator.</p> <p>Particular attention should therefore be paid to chapters: ↑16.4 <i>Determining the power proportions</i> and ↑16.10 <i>Gas limitation!</i></p>
---------------	---

16.9.1 Determining the diesel setpoint

The value to which the diesel quantity is to be adjusted in dual fuel operation is determined on the test bench. It is possible to gradually specify the gas directly by bypassing the diesel reduction governor using 10029 *GasSetpointPC*. To do this 14030 *GasSetpointPCOn* must be enabled. This function cannot be saved and thus is always inactive after a control unit reset. Gas is added until the diesel either reaches the ignition oil quantity limit or engine disturbances or even knocking is detected before this. In the two cases mentioned, the gas value must be reduced again until the engine is running smoothly. The resulting diesel value is the minimum possible target value.

During commissioning on the test bench, this target value can be determined for each load stage and then either a load-independent fixed value can be assigned to the parameter 10060 *DieselSetpoint* or a characteristic can be drawn up.

The power-dependent characteristic exists in generator sets for this purpose, and in locomotive applications there is an equivalent traction power dependent curve 16300 *DieselSetpGas:P(x)* and 16310 *DieselSetpGas:Dsl(x)*.

In marine drives, the characteristic is speed-dependent to match the propeller curve, 16300 *DieselSetpGas:n(x)* and 16310 *DieselSetpGas:Dsl(x)*.

This curve is used when 14060 *DieselSetpGasCurveOn* is enabled, otherwise the fixed parameter 10060 *DieselSetpoint* is applicable. The currently valid setpoint is indicated in 12060 *DieselRedGovSetp*.

Parameters

10029 <i>GasSetpointPC</i>	Gas specified by PC
10060 <i>DieselSetpoint</i>	Fixed diesel setpoint

12060 <i>DieselRedGovSetp</i>	Current diesel setpoint
14030 <i>GasSetpointPCOn</i>	Enable / disable gas specification by PC (cannot be saved)
14060 <i>DieselSetpGasCurveOn</i>	Enable / disable power or speed- dependent setpoint characteristic
16300 <i>DieselSetpGas:P(x)</i>	Power grid points (generator, locomotive)
16300 <i>DieselSetpGas:n(x)</i>	Speed grid points (marine drive)
16310 <i>DieselSetpGas:Dsl(x)</i>	Diesel setpoints


Notice

Between 12060 DieselRedGovSetp and 10055 PilotDslAbsMinimum a fixed hysteresis of 2 % is included. Therefore, the setpoint can never be lower than 10055 PilotDslAbsMinimum + 2 %. This is intended to prevent dual fuel operation from being constantly switched on and off when the actual diesel value moves too close to the absolute minimum.

16.9.2 Setting the PID parameters

Determination of the diesel setpoint is followed by tests involving load changes in order to derive the PID control parameters. As in the speed governor, the PID values can be adapted to dynamic processes and can undergo a reduction in static operation using the StaticCorrection function ([↑8.5 Correction of PID parameters for static operation](#)).

The diesel reduction governor is designed to supply as much gas as possible as quickly as possible, but without interfering with the diesel speed governor to such an extent that it rises rapidly. For this reason, the PID parameters selected for the diesel reduction governor should be lower than those for the speed governor so that it reacts more slowly and the speed control loop retains the higher priority.

The output value of the control loop can never be greater than the limiting value 12062 *GasFuelLimitMax* determined separately. The result of the limitation is indicated in 12024 *GasFuelQuantUncorr* if a gas temperature and/or gas pressure correction of the value can still be carried out. In any case, the resulting effective gas value is available in 12023 *GasFuelQuantity*. This is output to either an actuator with throttle valve or to electronic fuel injection with MEGASOL valves ([↑16.5 Configuring the gas output](#)).

Parameters

10030 <i>DieselRedGain</i>	PID governor P-ratio
10031 <i>DieselRedStability</i>	PID governor I-ratio
10032 <i>DieselRedDerivative</i>	PID governor D-ratio
10035 <i>DslRedStatCorrFactor</i>	Correction value for the PID parameters

10036 <i>DslRedStatCorrRange</i>	Static range around the setpoint
14035 <i>DieselRedStatCorrOn</i>	Enable / disable static correction
2350 <i>DieselFuelQuantity</i> or	Current actual diesel fuel quantity value (speed control loop output)
12050 <i>DieselPower</i>	Current actual diesel power value in engines with PT pump
12060 <i>DieselRedGovSetp</i>	Current diesel setpoint
12083 <i>GasReleased</i>	Indication that dual fuel mode is active
12062 <i>GasFuelLimitMax</i>	Current limiting value
12023 <i>GasFuelQuantity</i>	Resulting effective gas value
12024 <i>GasFuelQuantUncorr</i>	Current gas value before gas temperature/gas pressure correction

16.9.3 Diesel setpoint ramp

To avoid unnecessarily interfering with the speed governor, changes in the diesel setpoint are not made abruptly but with a ramp so that the resulting gas quantity builds up slowly. This is especially important as dual fuel operation depends on many conditions and can be continuously switched on or off. Therefore it changes constantly – regardless of whether the fixed or power-dependent setpoint is used for 12060 *DieselRedGovSetp*.

When activating dual fuel mode, the setpoint should always move away from the current actual value with a ramp. For this reason the diesel setpoint 12060 *DieselPosGovSetp* corresponds to the actual value 2350 *DieselFuelQuantity* or, on engines with PT pump, 12050 *DieselPower*, as long as dual fuel mode is switched off and it corresponds to the (ramped) target value when dual fuel mode is enabled.

The setpoint can be changed upwards and downwards at different speeds, with an increasing diesel setpoint meaning that less gas is to be added, i.e. a faster reaction is required, than when more gas is to be calculated for a falling diesel setpoint. The upwards ramp 10051 *DieselSetpRampUp* should therefore be faster than the downwards ramp 10052 *DieselSetpRampDown*.

The conditions for terminating dual fuel operation are specified in [↑] 16.6.2 *Conditions for terminating dual fuel operating mode*. There are normal termination (Norm) and fast termination (Fast) using a ramp, and unramped immediate termination (Prompt).

To terminate dual fuel operation with a ramp, the diesel setpoint is always changed upwards, i.e. it moves towards a higher actual diesel value. For normal termination, 10051 *DieselSetpRampUp* is applicable. For fast termination the ramp 10050

FastDieselSetpRampUp is used instead. As a result, there is a faster reduction of the gas proportion but not an immediate shutdown. Each ramped termination of dual fuel mode is indicated by 12039 *RampToDieselActive*.

For immediate termination the gas supply must be stopped immediately. The diesel speed governor will experience a slight interruption depending on how high the gas proportion was at this time. However, this is unavoidable on safety grounds.

All ramps are enabled collectively with 14051 *DieselSetpRampOn*.

The upwards diesel setpoint ramp is internally disabled when the resulting gas value has reached 0 %. 12060 *DieselRedGovSetp* is then set to the actual value 2350 *DieselFuelQuantity* or, on engines with PT pump, 12050 *DieselPower*.

In parallel, the downwards diesel setpoint ramp is internally disabled when the gas reaches the permissible maximum value (↑ 16.10.2 Diesel reduction governor).

Parameters

10050 <i>FastDieselSetpRampUp</i>	Fast upwards diesel setpoint ramp to terminate dual fuel operation
10051 <i>DieselSetpRampUp</i>	Normal upwards diesel setpoint ramp
10052 <i>DieselSetpRampUp</i>	Normal downwards diesel setpoint ramp
14051 <i>DieselSetpRampOn</i>	Enable / disable diesel setpoint ramp

16.10 Gas limitation

Limitation of the current gas proportion is one of the most important functions in dual fuel operation to protect the engine against overloading. There are several options available for this, which can also be enabled all together. The smallest value is then selected from all the limiting values.

16.10.1 Gas speed governor

There is a maximum permissible value for gas fuel quantity limitation, 10063 *GasFuelLimitMaxAbs*, but the value may be lower than this for different speed and/or power dependent functions or with an external setpoint. The resulting limiting value is provided in 12062 *GasFuelLimitMax*. If the gas speed governor is active, 12031 *GasGovernorActive* = 1, and the gas fuel quantity value calculated in it is limited, this is indicated with 2711 *FuelLimitMaxActive* = 1.

The gas value calculated by the gas speed governor 12025 *GasFuelSetpUnlimited* can therefore be limited with 12062 *GasFuelLimitMax*. The result is provided in 12024 *GasFuelQuantUncorr*. After any correction with gas pressure and/or gas temperature, the actual gas value used is provided in 12023 *GasFuelQuantity*.

Parameters

10063 <i>GasFuelLimitMaxAbs</i>	Absolute maximum gas fuel quantity value
2711 <i>FuelLimitMaxActive</i>	Gas fuel quantity is currently being limited
12023 <i>GasFuelQuantity</i>	Resulting effective gas value after correction with gas pressure/temperature
12024 <i>GasFuelQuantUncorr</i>	Current gas value after limitation with 12062 <i>GasFuelLimitMax</i>
12025 <i>GasFuelSetpUnlimited</i>	Current gas value calculated by gas speed governor or ramped during switch
12031 <i>GasGovernorActive</i>	1 = Gas speed governor is active
12062 <i>GasFuelLimitMax</i>	Current maximum permissible gas fuel quantity value


Notice

*If the firmware does not contain any sensors for gas pressure and gas temperature, there is no parameter 12024 *GasFuelQuantUncorr* and the result of the limitation appears immediately in 12023 *GasFuelQuantity*.*

16.10.1.1 Speed-dependent gas fuel quantity limitation

Speed-dependent gas fuel quantity limitation is only effective if the gas speed governor is active, 12031 *GasGovernorActive* = 1. It uses a characteristic to determine the maximum gas fuel quantity value associated with the current speed 2000 *Speed*. This can still be reduced depending on various temperatures.

As the diesel speed governor and gas speed governor are only active in alternation, the same parameters are used for the limitation indication. The speed grid points for the limitation characteristic are also identical; only the limiting values themselves are different in diesel mode than they are in gas mode.

Speed-dependent gas fuel quantity limitation must be enabled with 14023 *GasFuelLimitSpeedOn* = 1.

For the temperature dependent reductions, see ↑ 16.10.4 Temperature dependent reduction. The overall result is provided in 2703 *FuelLimitSpeed*.

If the current gas fuel quantity limitation actually results from this speed-dependent function, 2713 *SpeedLimitActive* is set.

Parameters

2000 <i>Speed</i>	Current speed
2703 <i>FuelLimitSpeed</i>	Speed-dependent gas fuel quantity limitation

2713 <i>SpeedLimitActive</i>	Indicates that the current gas fuel quantity limitation is speed-dependent
12031 <i>GasGovernorActive</i>	1 = Gas speed governor is active
14023 <i>GasFuelLimitSpeedOn</i>	1 = Enable / disable speed-dependent gas fuel quantity limitation
6700 <i>SpeedLimit:n(x)</i>	Speed grid points
16140 <i>GasSpeedLimit:f(x)</i>	Gas fuel quantity values

16.10.1.2 Power-dependent gas fuel quantity limitation

Power-dependent gas fuel quantity limitation uses a characteristic to determine the maximum gas fuel quantity value associated with the current power 2918 *MeasuredPower*. To do this, the function must have been enabled with 14027 *GasFuelLimitPowerOn* = 1. It is only effective if the gas speed governor is active, 12031 *GasGovernorActive* = 1.

The value determined can be reduced further depending on various temperature values, see [↑ 16.10.4 Temperature dependent reduction](#). The overall result is provided in 12064 *GasFuelLimitPower*.

If the current gas fuel quantity limitation actually results from this function, 2716 *PowerLimitActive* (XIOS: 2728 *PowerLimitActive*) is set.

Parameters

2716 <i>PowerLimitActive</i> XIOS: 2728 <i>PowerLimitActive</i>	Indication that the current gas fuel quantity limitation is power-dependent
2918 <i>MeasuredPower</i>	Current power
12031 <i>GasGovernorActive</i>	1 = Gas speed governor is active
12064 <i>GasFuelLimitPower</i> limitation	Power-dependent gas fuel quantity
14027 <i>GasFuelLimitPowerOn</i>	1 = Enable / disable power-dependent gas fuel quantity limitation
16150 <i>GasPowerLimit:P(x)</i>	Power grid points
16180 <i>GasPowerLimit:f(x)</i>	Gas fuel quantity values

16.10.1.3 Externally enabled gas fuel quantity limitation

This gas fuel quantity limitation is enabled using the switching function 2813 *SwitchForcedLimit*. It is only effective if the gas speed governor is active, 12031 *GasGovernorActive* = 1. The resulting maximum gas fuel quantity value is a fixed

setting in 10066 *GasFuelLimitForced*. If the current gas fuel quantity limitation actually results from this function, 2715 *ForcedLimitActive* is set.

Parameters

10066 <i>GasFuelLimitForced</i>	Gas fuel quantity limitation
2715 <i>ForcedLimitActive</i>	Indication that the current gas fuel quantity limitation is externally specified
2813 <i>SwitchForcedLimit</i>	1 = Enable / disable external limitation
12031 <i>GasGovernorActive</i>	1 = Gas speed governor is active

16.10.2 Diesel reduction governor (maritime application)

For gas power limitation there is a maximum permissible value 10062 *GasPowerLimitMaxAbs*, but the value can be below this depending on the speed. The lowest limiting value is used and is indicated in 12062 *GasPowerLimitMax*.

The maximum permissible gas power at a particular speed is determined by the current value of the propeller curve 12052 *DF:EnginePowerLimit* minus the current diesel power proportion 12050 *DieselPower* (\uparrow 16.4.3 Maritime applications). This value is indicated in 12063 *GasPowerLimitSpeed*. If it is actually being used for limitation, this is indicated by 12065 *GasSpeedLimitActive* = 1.

If the diesel fuel quantity during operation is below the electrical zero load limit, i.e. if 12050 *DieselPower* = 0 kW, then 12063 *GasPowerLimitSpeed* is set to the value of 12049 *NegDieselPower*, which corresponds to the remaining mechanical engine power necessary to supply power take-offs.

NOTICE	For safety reasons, the characteristic for determination of 12049 <i>Neg Diesel Power</i> may only be created by the engine manufacturer, who can also specify a low ignition oil quantity such that gas combustion is guaranteed at all times. Otherwise, the ignition oil quantity must be above the electrical zero-fuel limit and 0 should be entered as the power values for this characteristic.
---------------	--

The gas value calculated by the diesel reduction governor is constantly limited with 12062 *GasPowerLimitMax*. The result is provided in 12024 *GasPowerUncorr*. After any correction with gas pressure and/or gas temperature the actual gas value used is provided in 12023 *GasPowerSetpoint*. This value is sent to the HEINZMANN ELEKTRA Flow Control gas control unit as the setpoint power for the gas.

Parameters

10062 <i>GasPowerLimitMaxAbs</i>	Absolute maximum gas power value
12023 <i>GasPowerSetpoint</i>	Resulting effective gas power after correction with gas pressure/temperature
12024 <i>GasPowerUncorr</i>	Current gas value after limitation with 12062 <i>GasFuelLimitMax</i>
12062 <i>GasPowerLimitMax</i>	Current maximum permissible gas power value
12063 <i>GasPowerLimitSpeed</i>	Speed-dependent gas power limitation
12065 <i>GasSpeedLimitActive</i>	1 = Current limitation using speed
6700 <i>SpeedLimit:n(x)</i>	Speed grid points
16130 <i>DFSpeedLimit:P(x)</i>	Gas power limits



Notice

*If the firmware does not contain any sensors for gas pressure and gas temperature, there is no parameter 12024 *GasPowerUncorr* and the result of the limitation appears immediately in 12023 *GasPowerSetpoint*.*

16.10.3 Diesel reduction governor (generator and locomotive application)

As the power must be available in these applications, in each case power-dependent limitation $\hat{\uparrow}$ 16.10.3.2 *Power-dependent gas fuel quantity limitation* should be selected. Additional speed-dependent fuel quantity limitation still makes at least some sense in locomotives $\hat{\uparrow}$ 16.10.3.1 *Speed-dependent gas fuel quantity limitation*.

For gas fuel quantity limitation, there is a maximum permissible value 10063 *GasFuelLimitMaxAbs*. However, different functions can specify lower values. The lowest limiting value is used and is indicated in 12062 *GasFuelLimitMax*. It is used continuously for gas fuel quantity limitation.

The gas value calculated by the diesel reduction governor is constantly limited with 12062 *GasFuelLimitMax*. The result is provided in 12024 *GasFuelQuantUncorr*. After any correction with gas pressure and/or gas temperature the actual gas value used is provided in 12023 *GasFuelQuantity*.

Parameters

10063 <i>GasFuelLimitMaxAbs</i>	Absolute maximum gas fuel quantity value
12023 <i>GasFuelQuantity</i>	Resulting effective gas value after correction with gas pressure/temperature
12024 <i>GasFuelQuantUncorr</i>	Current gas value after limitation with 12062 <i>GasFuelLimitMax</i>

12062 *GasFuelLimitMax*

 Current maximum permissible
gas fuel quantity value

Notice

If the firmware does not contain any sensors for gas pressure and gas temperature, there is no parameter 12024 GasFuelQuantUncorr and the result of the limitation appears immediately in 12023 GasFuelQuantity.

16.10.3.1 Speed-dependent gas fuel quantity limitation

Speed-dependent gas fuel quantity limitation uses a characteristic to determine the maximum gas fuel quantity value associated with the current speed 2000 *Speed*. This can still be reduced depending on various temperatures.

For the temperature dependent reductions, see ↑ 16.10.4 Temperature dependent reduction. The overall result is provided in 12063 *GasFuelLimitSpeed*.

Speed-dependent gas fuel quantity limitation must be enabled with 14023 *GasFuelLimitSpeedOn* = 1.

If 12063 *GasFuelLimitSpeed* is actually being used for limitation, 12065 *GasSpeedLimitActive* is set.

Parameters

2000 <i>Speed</i>	Current speed
12063 <i>GasFuelLimitSpeed</i> limitation	Speed-dependent gas fuel quantity
12065 <i>GasSpeedLimitActive</i>	1 = Indication of current gas fuel quantity limitation using speed
14023 <i>GasFuelLimitSpeedOn</i>	Enable / disable speed-dependent gas fuel quantity limitation
16130 <i>GasSpeedLimit:n(x)</i>	Speed grid points
16140 <i>GasSpeedLimit:f(x)</i>	Gas fuel quantity values

16.10.3.2 Power-dependent gas fuel quantity limitation

For power-dependent limitation, either a limiting governor or a power-dependent gas fuel quantity value can be used. The first choice is to enable the limiting governor. This determines the maximum permissible gas fuel quantity in a control loop from the distance between the current power and the nominal power (or between the current and maximum traction power in locomotives). The governing and the exclusive reference to the total power means that the relationship between gas fuel quantity and gas power no longer plays a role, while the gas fuel quantity values in a limitation characteristic actually only apply under the same ambient conditions as at the time of configuration (gas quality, gas pressure, gas temperature etc.).

In generator sets, power-dependent limitation is based on 2918 *MeasuredPower*, and in locomotive applications is carried out using 3231 *TractionPower*.

If neither of the two limitation functions listed below is active, the value of 10063 *GasFuelLimitMaxAbs* is returned.

The result of the power-dependent limitation can then be reduced further depending on different temperature values, \uparrow 16.10.4 *Temperature dependent* reduction. The overall result appears in 12064 *GasFuelLimitPower*.

16.10.3.2.1 Power limiting governor

If the engine power is below the nominal power 1232 *RatedPower* or the speed-dependent maximum traction power 12048 *PowerMax* (\uparrow 16.4.1 *Applications* for locomotive operation) and it was not previously above it, there is currently no power-dependent gas limitation.

However, if the engine power rises above the nominal or maximum traction power, the gas is gradually reduced starting from the current value 12023 *GasFuelQuantity*; thus the limiting value for gas 12064 *GasFuelLimitPower* is not fixed in the configuration, it is determined from the current power and gas values. At the same time, the diesel fuel quantity is limited with the value that was recorded when the engine or traction power exceeded the limit. This value is indicated in 2706 *(Diesel)FuelLimPower* (XIOS: 2727 *FuelLimPower*). Both limiting values remain active until the measured power falls below the limit minus hysteresis 10015 *GasModePowerHyst*.

The gas limiting value is determined with governing. The actual and nominal power in generator operation or the actual and maximum traction power in locomotive operation are fed into the control loop.

If power measurement fails, the limitation function passes over to the characteristic, provided it is enabled, \uparrow 16.10.3.2.2 *Power-dependent limitation* characteristic. Otherwise the fixed limiting value 10063 *GasFuelLimitMaxAbs* is used.



Notice

If monitoring of the power range for dual fuel operation is enabled \uparrow 16.7.2 Monitoring the power, failure of the power sensor switches off the gas. This function has a higher priority than the limiting governor and limitation characteristic.

Parameters

1232 <i>RatedPower</i>	Maximum power in generator operation
12048 <i>PowerMax</i>	Maximum power in locomotive operation

2918 <i>MeasuredPower</i>	Current power in generator operation
3231 <i>TractionPower</i>	Current power in locomotive operation
10015 <i>GasModePowerHyst</i>	Hysteresis on the power limit
10063 <i>GasFuelLimitMaxAbs</i>	Absolute maximum permissible gas fuel quantity in dual fuel operation
2706 (<i>Diesel</i>) <i>FuelLimPower</i> XIOS: 2727 <i>FuelLimPower</i>	Current power-dependent diesel limitation
2716 <i>PowerLimitActive</i> XIOS: 2728 <i>PowerLimitActive</i>	1 = Current diesel limitation using Power
12064 <i>GasFuelLimitPower</i>	Gas limiting value (after reduction)
12066 <i>GasPowerLimitActive</i>	1 = Current gas limitation using power
10110 <i>MaxGasPosGain</i>	PID gas limiting governor P-ratio
10111 <i>MaxGasPosStability</i>	PID gas limiting governor I-ratio
10112 <i>MaxGasPosDerivative</i>	PID gas limiting governor D-ratio
14110 <i>MaxGasPosGovernorOn</i>	Enable / disable gas limiting governor


Notice

If both 14013 *CheckPowerInRange* and 14110 *MaxGasPosGovernorOn* are enabled (↑ 16.7.2 *Monitoring the power*), then 10014 *GasModePowerMax* must specify a higher value than 1232 *RatedPower*/12048 *PowerMax*. Above these power values, the gas fuel quantity is reduced, but above 10014 *GasModePowerMax* the gas is switched off immediately.

16.10.3.2.2 Power-dependent limitation characteristic

If the limiting governor 14110 *MaxGasPosGovernorOn* is not enabled or the actual power signal has failed, the limiting value must be taken from the power-dependent gas limitation curve 16150 *GasPowerLimit:P(x)* and 16180 *GasPowerLimit:f(x)* if this is enabled with 14027 *GasFuelLimitPowerOn* = 1.

The current maximum permissible gas power value is provided in 12052 *GasPowerMax*. It is determined from the difference between the maximum permissible engine or traction power (1232 *RatedPower* or 12048 *PowerMax*) and the current diesel proportion 12050 *DieselPower*. 12052 *GasPowerMax* is used to derive the associated maximum gas fuel quantity value from the characteristic. It can then also be reduced depending on the temperature. The result is provided in 12064 *GasFuelLimitPower*. Whether it is actually being used to limit the gas fuel quantity can be seen from the indication 12066 *GasPowerLimitActive*.

If 14027 *GasFuelLimitPowerOn* is not enabled, 12064 *GasFuelLimitPower* is assigned the value of 10063 *GasFuelLimitMaxAbs*.



Notice

If monitoring of the power range for dual fuel operation is enabled ↑ 16.7.2 Monitoring the power, failure of the power sensor switches off the gas. This function has a higher priority than the limiting governor and limitation characteristic.

Parameters

1232 <i>RatedPower</i>	Maximum power in generator operation
12048 <i>PowerMax</i>	Maximum power in locomotive operation
2918 <i>MeasuredPower</i>	Current power in generator operation
3231 <i>TractionPower</i>	Current power in locomotive operation
10063 <i>GasFuelLimitMaxAbs</i>	Absolute maximum permissible fuel quantity in dual fuel operation
12050 <i>DieselPower</i>	Current diesel power
12052 <i>GasPowerMax</i>	Current maximum permissible gas power
12064 <i>GasFuelLimitPower</i>	Gas fuel quantity limiting value (after reduction)
12066 <i>GasPowerLimitActive</i>	1 = Current limitation using power
14027 <i>GasFuelLimitPowerOn</i>	1 = Enable / disable gas limitation curve
16150 <i>GasPowerLimit:P(x)</i>	Power grid points
16180 <i>GasPowerLimit:f(x)</i>	Fuel quantity limiting values

16.10.3.3 Externally enabled gas fuel quantity limitation

Parameters

2813 <i>SwitchForcedLimit</i>	Switching function to enable / disable 10066 <i>GasFuelLimitForced</i>
10066 <i>GasFuelLimitForced</i>	Fixed limiting value
12067 <i>GasForcedLimitActive</i>	1 = Current externally requested limitation

16.10.4 Temperature dependent reduction

Speed and power-dependent gas fuel quantity limitation in generator and locomotive operation can be reduced both in the gas speed governor and in the diesel reduction governor depending on the charge air, exhaust and/or coolant temperature.

Each reduction function has its own on/off switch. The temperature dependent reductions take effect exactly as described in ↑ 9.5 *Reduction of the full-load*

characteristic with XIOS, except that in dual fuel operation different parameters are used.



Notice

Note that the reduction parameters including enabling / disabling the function can be used for both speed-dependent and power-dependent gas fuel quantity limitation.

16.10.4.1 Charge air temperature dependent reduction

The speed-dependent and power-dependent gas fuel quantity limitation can be reduced simultaneously depending on the current charge air temperature 2908 *ChargeAirTemp*.

In all control units except for XIOS, a reduction of 10100 *GasReductChAirTmpDec* is made if 2908 *ChargeAirTemp* is above 692 *SpPowLimChAirTmpHigh*.

At temperatures between 691 *SpPowLimChAirTempLow* and 692 *SpPowLimChAirTmpHigh* the reduction value is determined by linear interpolation between 0 % and 10100 *GasReductChAirTmpDec*. At charge air temperatures below 691 *SpPowLimChAirTempLow* there is no reduction.

On the XIOS, charge air temperature grid points starting at 7120 *ChAirTempReduce:T(x)* are available for calculating the reduction value, and these apply for both diesel and dual fuel operation (\uparrow 9.5.1.2 Charge air temperature dependent reduction). However, the corresponding factors for the percentage reduction are stored separately for dual fuel operation starting from 16680 *GasLChAirTmpRed:F(x)*.

The reduction function must be enabled with 14100 *GasReductChAirTmpOn*.

Parameters

2908 <i>ChargeAirTemp</i>	Current charge air temperature
14100 <i>GasReductChAirTmpOn</i>	1 = Enable / disable reduction
Not XIOS:	
691 <i>SpPowLimChAirTempLow</i>	Lower temperature without reduction
692 <i>SpPowLimChAirTmpHigh</i>	Upper temperature with max. reduction
10100 <i>GasReductChAirTmpDec</i>	Maximum reduction in dual fuel operation
XIOS:	
7120 <i>ChAirTempReduce:T(x)</i>	Charge air temperature values for reduction
16680 <i>GasLChAirTmpRed:F(x)</i>	Percentage reduction in dual fuel operation



Notice

On V engines with one charge air temperature sensor per bank (2908 *ChargeAirTempLB* and 2920 *ChargeAirTempRB*) the higher value from the two sensors is used for reduction.

16.10.4.2 Exhaust temperature dependent reduction

The speed-dependent and power-dependent gas fuel quantity limitation can be reduced simultaneously depending on the current exhaust temperature. If only one exhaust temperature sensor is fitted on the engine, this is done using the value 2911 *ExhaustTemp*. With multiple exhaust temperature sensors, the current highest temperature 2913 *ExhaustTempMax* is used for reduction instead.

In all control units except XIOS, a reduction of 10103 *GasReductExhTempDec* is made if the exhaust temperature is above 697 *SpPowLimExhTempHigh*.

At temperatures between 696 *SpPowLimExhTempLow* and 697 *SpPowLimExhTempHigh* the reduction value is determined by linear interpolation between 0 % and 10103 *GasReductExhTempDec*. At exhaust temperatures below 696 *SpPowLimExhTempLow* there is no reduction.

On the XIOS, exhaust temperature grid points starting at 7160 *ExhTempReduce:T(x)* are available for calculating the reduction value, and these apply for both diesel and dual fuel operation (↑ 9.5.1.4 Exhaust-dependent reduction). However, the corresponding factors for the percentage reduction for dual fuel operation are stored in 16700 *GasLimExhTmpRed:F(x)*.

The reduction function must be enabled with 14103 *GasReductExhTempOn*.

Parameters

2911 <i>ExhaustTemp</i>	Current exhaust temperature (one sensor)
2913 <i>ExhaustTempMax</i>	Maximum exhaust temperature
12573 <i>ExhaustTempMax</i> (XIOS)	(multiple sensors)
14103 <i>GasReductExhTempOn</i>	1 = Enable / disable reduction
Not XIOS:	
696 <i>SpPowLimExhTempLow</i>	Lower temperature without reduction
697 <i>SpPowLimExhTempHigh</i>	Upper temperature with max. reduction
10103 <i>GasReductExhTempDec</i>	Maximum reduction in dual fuel operation
XIOS:	
7160 <i>ExhTempReduce:T(x)</i>	Exhaust temperature values for reduction
16700 <i>GasLimExhTmpRed:F(x)</i>	Percentage reduction in dual fuel operation

16.10.4.3 Coolant temperature dependent reduction

The speed-dependent and power-dependent gas fuel quantity limitation can be reduced simultaneously depending on the current coolant temperature 2907 *CoolantTemp*.

In all control units except for XIOS, a reduction of 10106 *GasReductCoolTempDec* is made if 2907 *CoolantTemp* is above 703 *SpPowLimCoolTempHigh*.

At temperatures between 702 *SpPowLimCoolTempLow* and 703 *SpPowLimCoolTempHigh* the reduction value is determined by linear interpolation between 0 % and 10106 *GasReductCoolTempDec*. At coolant temperatures below 702 *SpPowLimCoolTempLow* there is no reduction.

On the XIOS, coolant temperature grid points starting at 7100 *CoolTempReduce:T(x)* are available for calculating the reduction value, and these apply for both diesel and dual fuel operation (↑ 9.5.1.1 Coolant temperature dependent reduction). However, the corresponding factors for the percentage reduction are stored separately for dual fuel operation starting from 16670 *GasLimColTmpRed:F(x)*.

The reduction must be enabled with 14106 *GasReductCoolTempOn*.

Parameters

2907 <i>CoolantTemp</i>	Current coolant temperature
14106 <i>GasReductCoolTempOn</i>	1 = Enable / disable reduction
Not XIOS:	
702 <i>SpPowLimCoolTempLow</i>	Lower temperature without reduction
703 <i>SpPowLimCoolTempHigh</i>	Upper temperature with max. reduction
10106 <i>GasReductCoolTempDec</i>	Maximum reduction in dual fuel operation
XIOS:	
7100 <i>CoolTempReduce:T(x)</i>	Coolant temperature values for reduction
16670 <i>GasLimColTmpRed:F(x)</i>	Percentage reduction in dual fuel operation

16.11 Gas fuel quantity correction

If the gas pressure 2921 *GasRailPressure* (XIOS: 2928 *GasRailPressure*) and/or the gas temperature 2910 *GasTemp* (XIOS: 2926 *GasTemp*) are measured on the engine, these values can be used to correct the gas quantity. There are two curves for doing this, in which factors are stored depending on gas temperature or relative gas pressure to correct the calculated and, where applicable, limited gas value 12024 *GasFuelQuantUncorr* before it is output as 12023 *GasFuelQuantity*.

On the charged engine, the gas pressure is calculated relative to the boost pressure and the result is provided in 2925 *GasDiffPressure* (XIOS: 2942 *GasDiffPressure*). On a non-charged engine 2925 *GasDiffPressure* and 2921 *GasRailPressure* (XIOS: 2942 and 2928) are identical. In any case, the function uses 2925/2942 *GasDiffPressure*.

Parameters

12023 <i>GasFuelQuantity</i>	Resulting effective gas value after correction with gas pressure/temperature
12024 <i>GasFuelQuantUncorr</i>	Current gas value after limitation with 12062 <i>GasFuelLimitMax</i>
12025 <i>GasFuelSetpUnlimited</i>	Current gas value calculated by gas speed governor or ramped during switch
2910 <i>GasTemp</i> (Others)	Current gas temperature
2926 <i>GasTemp</i> (XIOS)	
14028 <i>GasTempFactorOn</i>	Enable / disable gas temperature dependent correction
16450 <i>GasTempFactor:T(x)</i>	Gas temperature grid points
16460 <i>GasTempFactor:F(x)</i>	Correction factors
2904 <i>BoostPressure</i>	Boost pressure
2921 <i>GasRailPressure</i>	Gas pressure
2928 <i>GasRailPressure</i> (XIOS)	
2925 <i>GasDiffPressure</i>	Gas differential pressure
2942 <i>GasDiffPressure</i> (XIOS)	
14029 <i>GasPressFactorOn</i>	Enable / disable gas pressure dependent correction
16470 <i>GasPressFactor:p(x)</i>	Gas pressure grid points
16480 <i>GasPressFactor:F(x)</i>	Correction factors



*If the firmware does not contain any sensors for gas pressure and gas temperature, there is no parameter 12024 *GasFuelQuantUncorr* and the result of the limitation with 12062 *GasFuelLimitMax* appears immediately in 12023 *GasFuelQuantity*.*

16.12 Residual gas combustion

After switching off dual fuel operation and closing the gas valves, for safety reasons it is essential to ensure that any residual gas remaining in the pipe is combusted.

In the gas speed governor every gas switch-off is “final”, i.e. the electrically operated valves are closed and the gas section is monitored again before any further gas request. Residual gas combustion should therefore take place each time dual fuel operation is terminated – whether this is because the gas request was cancelled, because the conditions

for dual fuel operation are no longer met, or because an engine stop was requested during dual fuel operation.

By contrast, in the diesel reduction governor there is continuous switching between diesel and dual fuel operation. The electrically operated values 12035 *GasValvesOpen* must be closed if a gas value of 0% is calculated, because the throttle valve is not impermeable, but a repeated time-consuming gas section test would have an extremely negative impact on the conversion rate. Therefore, in contrast to the gas speed governor in this case residual gas combustion is performed exclusively after an engine stop request and when the gas request is disabled using the switching functions 2837 *SwitchGasOrDiesel* = 0 and 2838 *SwitchFastToDiesel* = 1, but not if the gas is temporarily switched off due to other conditions.

In any case, the prerequisite for residual gas combustion is that the current diesel fuel quantity at least corresponds to the ignition oil quantity.

16.12.1 Engine stop request

If there is a fatal error 3800 *EmergencyAlarm*, the engine is always stopped immediately (\uparrow 27.7 *Emergency shutdown errors*). The gas is abruptly positioned to 0 % and the gas valves are closed, 12035 *GasValvesOpen* = 0. However, residual gas remains in the supply pipe and in this case has to be removed in another way, for example using a valve into the open air, which is switched using 3800 *EmergencyAlarm*.

For a normal engine stop request 2810 *SwitchEngineStop* when dual fuel operation is active, on the other hand, this operating mode is terminated first, i.e. there is a switch back to diesel. This is always done using the fast ramp (\uparrow 16.8.3 *Switching ramp from gas to diesel operation* and \uparrow 16.9.3 *Diesel setpoint ramp*). This situation is indicated with 12068 *EngStopRequWithGas*.

When the gas is switched off and the valves are closed – 12035 *GasValvesOpen* = 0 – combustion of the residual gas in the pipe begins.

Therefore, the stop request is delayed until the gas has reached 0 %, the valves have been closed and then the residual gas combustion has also been completed. This takes different times depending on the current gas value.

16.12.2 Gas speed governor

For residual gas combustion, it is important that the diesel is running at least at the ignition oil quantity 12061 *DieselAtPilotFuel* = 0, otherwise the residual gas combustion has to be terminated.

After closing the gas supply valves. 12035 *GasValvesOpen* = 0, the gas value is ramped to 10091 *DslModeGasFuelBurn* to open the actuator or the MEGASOL valves. Residual gas combustion is normally terminated either when the rail pressure 2921 *GasRailPressure* falls below 10090 *DslModeGasRPressMax* or, at the latest, when the

time 10092 *GasBurnTimeMax* has elapsed. 12069 *RemainGasBurning* indicates that residual gas combustion is in progress.

Parameters

10090 <i>DslModeGasRPressMax</i>	Max. permissible remaining relative gas pressure in rail
10091 <i>DslModeGasFuelBurn</i>	Forced gas opening
10092 <i>GasBurnTimeMax</i>	Max. time for residual gas combustion
12068 <i>EngStopRequWithGas</i>	Engine stop request in dual fuel operation
12069 <i>RemainGasBurning</i>	Residual gas combustion in progress

16.12.3 Diesel reduction governor

The gas is reduced to 0 % if it is not already there. The gas supply valves are closed, 12035 *GasValvesOpen* = 0, and the time 10092 *GasBurnTimeMax* begins to elapse. During this time, the throttle valve or the MEGASOL valves are opened to the value 10091 *DslModeGasFuelBurn* so that the residual gas in the pipe can be combusted. The prerequisite is that the diesel fuel quantity 2350 *DieselFuelQuantity* or – on engines with PT pump – the actual diesel power 12050 *DieselPower* is still above the ignition oil quantity 12055 *PilotDslAbsMinimum*. After 10092 *GasBurnTimeMax* has elapsed, the engine stop – if requested – is performed, i.e. both the gas and the diesel fuel quantity are reduced to 0 %. 12069 *RemainGasBurning* indicates that residual gas combustion is in progress.

Parameters

10091 <i>DslModeGasFuelBurn</i>	Forced gas opening
10092 <i>GasBurnTimeMax</i>	Max. time for residual gas combustion
12068 <i>EngStopRequWithGas</i>	Engine stop request in dual fuel operation
12069 <i>RemainGasBurning</i>	Residual gas combustion in progress

17 Configuration of sensors

In the HEINZMANN control units, a strict distinction is made between hardware and communication inputs on one side and sensors on the other. This means that the engine or application control is determined by the current values read by sensors, but where those sensors take their values from is configured separately.

Normally, they will be influenced by analogue or PWM inputs but in specific applications they can also be assigned their values via Modbus or CAN protocols.

For this reason, it must first be defined which type should be assigned to variable ports (*↑ 19.1.1 Variable Ports*), then the inputs must be configured. Only then – if no configuration error is reported – can the sensors be configured and the source from which they receive their current status be specified. If communication modules are used for transmitting sensor values, they must also be configured beforehand.

Once the entire configuration is complete and a reset has been carried out, there must be no configuration error reported, otherwise the configuration must be checked again.

17.1 Overview of all sensors

Sensors are needed to measure set values, pressures, temperatures, etc., and to execute functions depending on these quantities. The following table gives an overview of implemented sensors, although not all of them are usually found in every application or firmware:

Parameter	Meaning	Usage
2900 <i>Setpoint1Extern</i>	Setpoint adjuster 1	Setpoint for speed governor
2901 <i>Setpoint2Extern</i>	Setpoint adjuster 2	2. Setpoint for speed governor
2902 <i>LoadControlInput</i>	Input value from load control unit	Generator operation: Power control
2903 <i>SyncInput</i>	Input value from synchronization unit	Generator operation: Synchronization
2904 <i>BoostPressure</i>	Boost pressure	Boost-pressure dependent fill limit dual fuel: Boost pressure monitoring
2905 <i>OilPressure</i>	Oil pressure	Oil pressure monitoring
2906 <i>AmbientPressure</i>	Ambient pressure	Calculation of relative boost pressure, reduction of speed-dependent filling limitation
2907 <i>CoolantTemp</i>	Coolant temperature	Coolant temperature warning, temperature-dependent idle speed and start filling, PID correction, reduction of the speed-dependent or power-dependent fill limit, locomotive operation: forced idle speed

Parameter	Meaning	Usage
2908 <i>ChargeAirTemp</i>	Charge air temperature	Charge air temperature warning, reduction of the speed-dependent or power-dependent fill limit
2909 <i>OilTemp</i>	Oil temperature	Oil temperature warning, locomotive operation: forced idle speed
2910 <i>FuelTemp</i>	Fuel temperature	Reduction of the speed-dependent filling limitation
2910 <i>GasTemp</i> (XIOS see 2926)	Gas temperature	Dual fuel: Gas filling correction, gas temperature monitoring
2911 <i>ExhaustTemp</i> see 12900 <i>ExhaustTempCylx</i> , if exhaust temperature measurement per cylinder	Exhaust temperature	Exhaust temperature warning, reduction of the speed-dependent or power-dependent fill limit, gas limit on the dual-fuel engine
2914 <i>SlideExcitReduction</i>	Reduction value of excitation signal	Locomotive operation: Slide protection
2915 <i>SlideSpeedReduction</i>	Reduction value for the setpoint speed	Locomotive operation: Slide protection
2915 <i>AlternatorVoltage</i> (XIOS see 2936)	Alternator voltage	Vehicle operation: Alternator monitoring
2916 <i>CoolantPressure</i>	Coolant pressure	Locomotive operation: Coolant pressure monitoring, forced idle speed
2916 <i>GasPosition</i> (XIOS see 2927)	Position of external gas throttle valve	Monitoring actuator difference
2917 <i>AsymmetricLoad</i>	Asymmetric load	Nautical applications: Offset on slave filling setpoint in twin-engine systems (master/slave)
2918 <i>MeasuredPower</i>	Actual power If the breaker on the control unit is wired, 2918 <i>MeasuredPower</i> = 0 if 2846 <i>SwitchGenBreaker</i> is inactive.	Generator operation: Misfire monitoring, speed governor DT1 factor load-dependent P-level, actual value for integrated power governor
2918 <i>TractionVoltage</i>	Traction voltage	Locomotive operation: Calculation of the traction power
2919 <i>PowerSetpoint</i>	Power setpoint	Generator operation: Setpoint for integrated power governors
2919 <i>TractionCurrent</i>	Traction current	
2920 <i>TurboOilTemp</i>	Turbocharger oil	Turbocharger oil temperature monitoring

Parameter	Meaning	Usage
	temperature	
2921 <i>FuelPressure</i>	Fuel pressure	Fuel pressure monitoring
2921 <i>GasRailPressure</i> (XIOS see 2928)	Gas rail pressure	Dual fuel: Gas rail pressure monitoring
2922 <i>OilLevel</i>	Oil level	Oil level monitoring
2923 <i>FuelLimitExtern</i>	Filling limitation from external source	Filling limitation
2924 <i>TransmissionOilPress</i>	Transmission oil pressure	Transmission oil pressure monitoring
2925 <i>AirMass</i>	Air mass sensor	
2926 <i>GasTemp</i> (not XIOS, see 2910)	Gas temperature	Dual fuel: Gas filling correction, gas temperature monitoring
2927 <i>GasPosition</i> (not XIOS see 2916)	Position of external gas throttle valve	Dual fuel: Actuator difference monitoring of external gas positioners
2928 <i>GasRailPressure</i> (not XIOS see 2921)	Gas rail pressure	Dual fuel: Gas rail pressure monitoring
2931 <i>BoostPressure2</i>	2. Boost pressure sensor	Boost-pressure dependent fill limit dual fuel: Boost pressure monitoring
2932 <i>Lambda1</i>	Lambda 1	Exhaust recycling
2933 <i>Lambda2</i>	Lambda 2	Exhaust recycling
2934 <i>NOx</i>	Nitrogens	Exhaust recycling
2935 <i>O2</i>	Oxygen	Exhaust recycling
2936 <i>AlternatorVoltage</i> (DC5 see 2915)	Alternator voltage	Vehicle operation: Alternator monitoring
12900 <i>ExhaustTempCylx</i>	Exhaust temperature per cylinder	Exhaust temperature warning, reduction of the speed-dependent fill limit, gas limit on the dual-fuel engine

Table 23: Sensors



Note

The 2918 *MeasuredPower* value is set to 0 % / 0 kW automatically by the control unit if the switching function 2846 *SwichGenBreaker* is assigned and has the current value "0". In this case, it is assumed that the breaker is open and the power can therefore not be measured.

The following sensor values can be derived from the received values outlined below:

Parameter	Meaning	Usage
2925 <i>GasDiffPressure</i> (XIOS see 2942)	Relative gas pressure, if a boost pressure sensor is present	Dual-fuel engines
2940 <i>BoostPressRelative</i>	Relative boost pressure, if a boost pressure and ambient pressure sensor are present	Boost pressure dependent fill limitation
2941 <i>AbsoluteAltitude</i>	Height above sea level if an ambient pressure sensor is present	Display
2942 <i>GasDiffPressure</i> (not XIOS see 2925)	Relative gas pressure, if a boost pressure sensor is present	Dual-fuel engines
2943 <i>LambdaCalculated</i>	Lambda if, instead of a lambda sensor, the Smart NO _x and O ₂ sensor are connected via SAE J1939 CAN protocol	Exhaust recycling
3231 <i>TractionPower</i>	Traction power, if 2918 <i>TractionVoltage</i> and 2919 <i>TractionCurrent</i> are present, 1232 <i>TractionPowerHigh</i> should also be considered as an applicable limit value for the traction power	Locomotive operation
12570 <i>ExhaustTempAverage</i> 12572 <i>ExhaustTempMin</i> 12573 <i>ExhaustTempMax</i>	average minimum maximum exhaust temperature of all cylinders	Exhaust temperature warning, reduction of the speed-dependent fill limit, gas limit on the dual-fuel engine (all with 12573 <i>ExhaustTempMax</i>)

Table 24: Derived sensors

17.2 Configuration of sensors

Sensors and setpoint adjusters deliver either an analogue signal (current or voltage) or a PWM or frequency signal. This signal may also be measured at a different point and sent to the control unit via communication modules, [↑]22 *Bus-Protokolle*. The firmware decides which options are available, as CAN protocols are usually only implemented on request.

The sensors available from HEINZMANN are described in detail in the manuals of the basic systems as well as in the brochure "Product overview sensors no. E 99 001-e".

The selection of the sensor as an analogue, PWM, frequency or "communication" sensor takes place via the parameters from 4900 *ChanTyp...* or 14900 *ChanTyp...* One of the following values must be entered there depending on the application:

ChanTyp	Sensor source
0	Analogue signal (current or voltage) on own hardware
1	PWM signal on own hardware
2	HZM-CAN periphery module
3	Customer-defined CAN protocol
4	CANopen protocol (speed governor control unit is CANopen slave)
5	DeviceNet CAN protocol (speed governor control unit is slave)
6	Modbus protocol
7	SAE J1939 CAN protocol
8	HZM-CAN customer module
9	HZM-CAN second control unit of same type (double system)
10	WAGO module protocol (speed governor control unit is CANopen master)
13	ICENI module protocol (speed governor control unit is CANopen master)
14	HZM-CAN ALL
15	Frequency signal on own hardware (only XIOS)
16	HZM-CAN add-on module

Table 25: Sensor sources

When assigning a HZM-CAN periphery module, it is important to note whether just one or multiple periphery modules can be connected to the control unit. With multiple periphery modules, the module in question must also be entered in the parameters for the sensor. For this, the index of the module is assigned in the field 404 *CanPENodeNumber()* to the sensor from 4950 *PEIx...* or 14950 *PEIx...*



Note

When configuring the system with DcDesk 2000, only the options implemented in the relevant firmware are available for selection in the sensor window.

Parametrization example:

The signal for setpoint adjuster 1 is received from an analogue potentiometer, and setpoint adjuster 2 works with a PWM signal. The boost pressure is received from a periphery module via the HZM-CAN bus: It is connected to the second of three periphery modules.

Number	Parameter	Value	Unit
404	CanPENodeNumber(0)	1	
405	CanPENodeNumber(1)	2	
406	CanPENodeNumber(2)	3	
4900	ChanTypSetp1Ext	0	
4901	ChanTypSetp2Ext	1	
4904	ChanTypBoostPress	2	
4954	PEIxBoostPress	1	

17.3 Assigning the inputs to the sensors and setpoint adjusters

The assignment of inputs to sensors and setpoint adjusters is made by entering the corresponding channel numbers of the analogue, PWM or frequency input channels or the channel number of the communication module in the assignment parameters from 900 *AssignIn...* or 10900 *AssignIn...*. The channel numbers run from 1 to the maximum number for the control unit or communication module. The port number is entered on the XIOS.



It should be noted that only a few fixed defined sensors can be received via equally fixed defined telegrams via the CAN protocols SAE J1939 and HZM-CAN ALL (↑ 23.2 Configuration of sensors). In this case, the assignment to the sensor in 4900 ChanTyp... is only possible with the value 1 (= yes), not with a counter variable. The relevant receipt telegram must also be activated for this.

For the assignment of hardware inputs, it must first be defined which type should be assigned to variable ports (↑ 19.1.1 *Variable Ports*), then the inputs must be configured. Only then can the sensors be configured and the source from which they receive their current value be specified. If communication modules are used for receiving sensors, they must also be configured beforehand.



If the HEINZMANN load measuring unit LMG 10 is connected to 2902 LoadCtrlInput or the HEINZMANN synchronising unit SyG 02 is connected to 2903, the hardware of the 0...5 V analogue input in control units type DC 1 and DC 2 must first be adapted in the HEINZMANN production line.

Control units of type DC 6 and DC 11 enable the adjustment to be carried out via the configuration parameters 5231 LoadControlOrHZM_LMG or 5211 SyncInputOrHZM_SyG, with analogue input 1 used for the load control unit and analogue input 2 for the synchronising unit.

Entering the number 0 in the assignment parameter signifies that the respective sensor has neither been connected nor activated. Consequently, the input will not be subject to monitoring. Therefore, the assignment parameters of any sensors not needed should be set to zero. The sensor value during operation will then constantly be equal to the minimum value.



Double assignments will not be intercepted. But the HEINZMANN communication program DcDesk 2000 reports such multiple configurations in its sensor window.

Parametrization example XIOS:

Setpoint adjuster 1 should be connected to port 1 (voltage input), setpoint adjuster 2 to port 89 (PWM input) and the boost pressure sensor to the HZM-CAN periphery module input 3. For the other sensors remaining unused, the value zero must be entered.

Number	Parameter	Value	Unit
900	AssignIn_Setp1Ext	1	
901	AssignIn_Setp2Ext	89	
904	AssignIn_BoostPress	3	
4900	ChanTypSetp1Ext	0	
4901	ChanTypSetp2Ext	1	
4904	ChanTypBoostPress	2	

Parametrization example other control unit:

Setpoint adjuster 1 should be connected to analogue input 1, setpoint adjuster 2 to PWM input 1 and the boost pressure sensor to the HZM-CAN periphery module input 3. For the other sensors remaining unused, the value zero must be entered.

Number	Parameter	Value	Unit
900	AssignIn_Setp1Ext	1	
901	AssignIn_Setp2Ext	1	
904	AssignIn_BoostPress	3	
4900	ChanTypSetp1Ext	0	
4901	ChanTypSetp2Ext	1	
4904	ChanTypBoostPress	2	

17.4 Measuring ranges of sensors

In HEINZMANN control units, all sensor parameters and all relating values are provided with the maximum possible value range. Thus, temperature sensors can be utilized for a range from -100 to +1,000 °C. Boost pressure and coolant pressure sensors cover a maximum range from 0 to 5 bar, and oil pressure sensors work with a maximum range from 0 to 10 (resp. 20) bar. Indication for sensors without physical measurement ranges (setpoint adjuster) is by per cent.

Since there are pressure sensors with different measurement ranges, the control unit must be informed of the particular value ranges which may differ from the maximum possible physical value range. These ranges are defined as the physical values corresponding to minimum and maximum input values such as 0.5 to 4.5 Volts or 4 to 20 mA for analogue inputs or 10 % to 90 % for PWM inputs.

Sensor	Minimum measured value	Maximum measured value
Air mass sensor	966 <i>AirMassSensorLow</i>	967 <i>AirMassSensorHigh</i>
Nitrogens	968 <i>NOxSensorLow</i>	969 <i>NOxSensorHigh</i>
Oxygen	970 <i>O2SensorLow</i>	971 <i>O2SensorHigh</i>
Lambda sensor 1	972 <i>Lambda1SensorLow</i>	973 <i>Lambda1SensorHigh</i>
Lambda sensor 2	974 <i>Lambda2SensorLow</i>	975 <i>Lambda21SensorHigh</i>
Boost pressure sensor 2	976 <i>BoostPress2SensLow</i>	977 <i>BoostPress2SensHigh</i>
Coolant pressure	978 <i>CoolPressSensorLow</i>	979 <i>CoolPressSensorHigh</i>
Oil pressure	980 <i>OilPressSensorLow</i>	981 <i>OilPressSensorHigh</i>
Boost pressure	982 <i>BoostPressSensorLow</i>	983 <i>BoostPressSensorHigh</i>
Ambient pressure	984 <i>AmbPressSensorLow</i>	985 <i>AmbPressSensorHigh</i>
Coolant temperature	986 <i>CoolTempSensorLow</i>	987 <i>CoolTempSensorHigh</i>
Charge air temperature	988 <i>ChAirTempSensorLow</i>	989 <i>ChAirTempSensorHigh</i>
Gas temperature (dual fuel)	990 <i>GasTempSensorLow</i>	991 <i>GasTempSensorHigh</i>
Reduction value setpoint speed (locomotives)	fixed, 0	991 <i>SpeedRedSensorHigh</i>
Traction voltage (locomotives)	fixed, 0	992 <i>TractVoltSensorHigh</i>
Traction current (locomotives)	fixed, 0	993 <i>TractCurrSensorHigh</i>
Traction power calculated from the traction current and traction voltage (locomotives)	fixed, 0	1232 <i>TractionPowerHigh</i>
Actual power (generator) ↑ 23.5 Configuration of power sensors	992 <i>MeasPowerSensorLow</i>	993 <i>MeasPowerSensorHigh</i>
Power setpoint ↑ 23.5 Configuration of power sensors	994 <i>PowerSetpSensorLow</i>	995 <i>PowerSetpSensorHigh</i>
Nominal output reference value for 3232 <i>RelativePower</i>	-	1232 <i>RatedPower</i>
Fuel pressure	996 <i>FuelPressSensorLow</i>	997 <i>FuelPressSensorHigh</i>
Gas rail pressure (dual fuel)	996 <i>GasRailPrSensorLow</i>	997 <i>GasRailPrSensorHigh</i>
Transmission oil pressure	998 <i>TrOilPressSensorLow</i>	999 <i>TrOilPressSensorHigh</i>

Table 26: Sensor measurement ranges



The reference values of the corresponding analogue inputs may not be used to determine the physical value range. They are only responsible for the definition of 4 and 20 mA or 0 and 5 V (or 0.5 and 4.5 V). The physical value range is defined exclusively via the sensor reference values.

Temperature sensors usually have a non-linear behaviour, which is why linearisation curves are specified for different temperature sensors at the factory. There is no need to specify the physical measurement range for these sensors. It is different if the linearisation takes place in the sensor. In this case, reference values must also be specified for temperature sensors.

Parametrization example:

A boost pressure sensor has a measurement range from 0.5 to 3.5 bar.

Number	Parameter	Value	Unit
982	<i>BoostPressSensorLow</i>	0.5	bar
983	<i>BoostPressSensorHigh</i>	3.5	bar

17.5 Configuration of power sensors

Some additional information is required for the correct parametrisation of power sensors and derived values.

17.5.1 Load measurement

If the generator breaker or mains breaker is wired to the control unit, 2918 *MeasuredPower* = 0 if 2846 *SwitchGenBreaker* is inactive, or, in other words, if the breaker is open.

17.5.2 Value ranges

All measured power values have the value range [0, x] kW or [0, 100] %, which is fixed in the firmware. Kilowatt values are only possible in customer firmware, where the engine/generator power range is known. In the HEINZMANN basic software 00.x.xx, the values are shown in percent to be independent from a specific power range.

The following parameters therefore all have the same value range [0, x] kW or [0, 100] %, within which operation can take place:

2918 <i>MeasuredPower</i>	Power actual value
2919 <i>PowerSetpoint</i>	Power setpoint
1232 <i>RatedPower</i>	Rated power
992 <i>MeasPowerSensorLow</i>	Minimum value of the rated power sensor
993 <i>MeasPowerSensorHigh</i>	Maximum value of the rated power sensor

994 <i>PowerSetpSensorLow</i>	Minimum value of the setpoint power sensor
995 <i>PowerSetpSensorHigh</i>	Maximum value of the setpoint power sensor



The reference values of the corresponding analogue inputs may not be used to define the power range. They are only responsible for the definition of 4 and 20 mA or 0 and 5 V (or 0.5 and 4.5 V). The corresponding power range is defined exclusively via the sensor reference values.

The measured actual power value (and the power setpoint) are also displayed relative to the rated power.



*The integrated power governor currently does not permit any overload (the setpoint is limited to *RatedPower*). If necessary, the firmware can be adapted on request. In this case, 995 *PowerSetpSensorHigh* must be selected larger as required, but never larger than the value range of the measured value sensor.*

Power-related parameters and curves always refer to the relative power. All these parameters have the value range [0, 200] %. Examples include:

3232 <i>RelativePower</i>	Relative actual power value
3231 <i>RelativePowerSetp</i>	Relative power setpoint
6000 <i>MisfireWarn:P(x)</i>	Power-dependent misfire monitoring
6350 <i>PIDMap:P(x)</i>	Speed-dependent and power-dependent PID map

The internal calculation of the power-dependent P-level (4121 *DroopPowerOrFuel* = 1) also takes place with the relative power.

17.5.3 Configuration example with kilowatt entry

The value range specified by the firmware for power values is [0, 4000] kW. The engine/generator used works in the power range up to 2000 kW, the setpoint potentiometer (a voltage sensor here) should therefore be able to give values between 0 and 2000 kW. The connected power sensor (a current sensor here) can measure up to 3000 kW.

Value range firmware:	[0, 4000] kW
Engine/generator:	[0, 2000] kW
	→ 1232 <i>RatedPower</i> = 2000 kW
Measured value sensor:	[4, 20] mA = [0, 3000] kW

- 992 *MeasPowerSensorLow* = 0 kW
- 993 *MeasPowerSensorHigh* = 3000 kW

Setpoint potentiometer: [0, 5] V = [0, 2000] kW

- 994 *PowerSetpSensorLow* = 0 kW
- 995 *PowerSetpSensorHigh* = 2000 kW
- full adjustment range of the potentiometer up to the rated power

17.5.4 Configuration example with percent entry

If the power is shown in percent rather than kW in the software, then, in contrast to the configuration described above, the measurement range of the power sensor is used and defined as [0, 100] %. 1232 *RatedPower* and 2919 *PowerSetpoint* are adapted accordingly.

The engine used works in the power range up to 2000 kW, the setpoint potentiometer (a voltage sensor here) should therefore be able to give values between 0 and 2000 kW. The power sensor used (a current sensor here) can measure up to 2500 kW.

Value range firmware: [0, 100] %

Measured value sensor: [4, 20] mA = [0, 2500] kW = [0, 100] %

- 992 *MeasPowerSensorLow* = 0 %
- 993 *MeasPowerSensorHigh* = 100 %

Engine/generator: [0, 2000] kW

- 1232 *RatedPower* = 2000 kW * 100 % / 2500 kW
= 80 %

Setpoint potentiometer: [0, 5] V = [0, 2000] kW = [0, 80] %

- 994 *PowerSetpSensorLow* = 0 %
- 995 *PowerSetpSensorHigh* = 80 %
- full adjustment range of the potentiometer up to the rated power

17.6 Influence on reaction to sensor errors

Setpoint adjusters and sensors on analogue or PWM inputs are monitored for compliance with the valid measurement range. If the values stray outside of this range in either direction, a sensor error is detected. If a sensor is received via a communication module, it is faulty if the bus fails completely, or if only the corresponding transmission telegram fails, or the opposite side is not transmitting the sign of life as agreed.

For any detected error, the respective response to this error can be modified by appropriate configuration which will allow to adjust the control's behaviour to the specific application and mode of operation in case of failure.

For setpoint adjusters and sensors, the parameters from 1000 *Subst...* can be used to define substitute values with which the control unit can continue working in the event of a failure in the relevant sensor. However, there is also the possibility of reverting to the last valid value before the setpoint adjuster or sensor failure occurred rather than maintaining operation by resorting to a substitute value. The parameters from 5000 *SubstOrLast...* are used to decide by which value the control unit is to continue operation in the event of a failure in the setpoint adjuster or the sensor. If the relevant parameter is set to "1", the defined substitute value is used; if it is set to "0", the last valid value is used. This troubleshooting measure helps to maintain more reliable emergency operation for the system.

The table below lists both the parameters where the substitute values are stored and the associated parameters for selecting operation by substitute value or by the last valid value.

Substitute value	Selection of substitute value	Substitute value for
1000 <i>SubstSetp1Ext</i>	5000 <i>Setp1ExtSubstOrLast</i>	Target value 1
1001 <i>SubstSetp2Ext</i>	5001 <i>Setp2ExtSubstOrLast</i>	Target value 2
1002 <i>SubstLoadCtrlInput</i>	5002 <i>LoadCtrInSubstOrLast</i>	Value from load control unit
1003 <i>SubstSyncInput</i>	5003 <i>SyncInputSubstOrLast</i>	Synchronisation
1004 <i>SubstBoostPressure</i>	5004 <i>BoostPresSubstOrLast</i>	Boost pressure
1005 <i>SubstOilPressure</i>	5005 <i>OilPressSubstOrLast</i>	Oil pressure
1006 <i>SubstAmbientPressure</i>	5006 <i>AmbPressSubstOrLast</i>	Ambient pressure
1007 <i>SubstCoolantTemp</i>	5007 <i>CoolTempSubstOrLast</i>	Coolant temperature
1008 <i>SubstChargeAirTemp</i>	5008 <i>ChAirTempSubstOrLast</i>	Charge air temperature
1009 <i>SubstOilTemp</i>	5009 <i>OilTempSubstOrLast</i>	Oil temperature
1010 <i>SubstFuelTemp</i>	5010 <i>FuelTempSubstOrLast</i>	Fuel temperature
1011 <i>SubstExhaustTemp</i>	5011 <i>ExhstTempSubstOrLast</i>	Exhaust temperature
fixed 0 %	5014 <i>ExcitRedSubstOrLast</i>	Slide protection signal
fixed 0 rpm	5015 <i>SpeedRedSubstOrLast</i>	Slide protection signal
1015 <i>SubstAlternator</i>	5015 <i>AlternatrSubstOrLast</i>	Alternator
1016 <i>SubstCoolPressure</i>	5016 <i>CoolPressSubstOrLast</i>	Coolant pressure
1017 <i>SubstAsymmetricLoad</i>	5017 <i>AsymmLoadSubstOrLast</i>	Asymmetric load
1018 <i>SubstMeasuredPower</i>	5018 <i>MeasPowerSubstOrLast</i>	Measured power
1018 <i>SubstTractionVoltage</i>	5018 <i>TractVoltSubstOrLast</i>	Traction voltage
1019 <i>SubstPowerSetpoint</i>	5019 <i>PowerSetpSubstOrLast</i>	Power setpoint
1019 <i>SubstTractionCurrent</i>	5019 <i>TractCurrSubstOrLast</i>	Traction current
1020 <i>SubstTurboOilTemp</i>	5020 <i>TuOilTempSubstOrLast</i>	Turbocharger oil

Substitute value	Selection of substitute value	Substitute value for
		temperature
1021 <i>SubstFuelPressure</i>	5021 <i>FuelPressSubstOrLast</i>	Fuel pressure
1022 <i>SubstOilLevel</i>	5022 <i>OilLevelSubstOrLast</i>	Oil level
1023 <i>SubstFuelLimitExtern</i>	5023 <i>FuelLimExSubstOrLast</i>	External filling limitation
1024 <i>SubstTransmOilPress</i>	5024 <i>TransOilPSubstOrLast</i>	Transmission oil pressure
1025 <i>SubstAirMass</i>	5025 <i>AirMassSubstOrLast</i>	Air mass
1026 <i>SubstGasTemp</i>	5026 <i>GasTempSubstOrLast</i>	Gas temperature
1027 <i>SubstGasPosition</i>	5027 <i>GasPosSubstOrLast</i>	External gas actuator position
1028 <i>SubstGasRailPressure</i>	5028 <i>GasRailPrSubstOrLast</i>	Gas rail pressure
1029 <i>SubstGasVCheckPress</i>	5029 <i>GasVChPrSubstOrLast</i>	Gas valve check pressure
1031 <i>SubstBoostPressure2</i>	5031 <i>BoostPr2SubstOrLast</i>	Boost pressure 2
1032 <i>SubstLambda1</i>	5032 <i>Lambda1SubstOrLast</i>	Lambda 1
1033 <i>SubstLambda2</i>	5033 <i>Lambda2SubstOrLast</i>	Lambda 2
1034 <i>SubstNOx</i>	5034 <i>NoxSubstOrLast</i>	Nitrogens
1035 <i>SubstO2</i>	5035 <i>O2SubstOrLast</i>	Oxygen
1036 <i>SubstAlternatorVolt</i>	5036 <i>AlterVoltSubstOrLast</i>	Alternator voltage
11000 <i>SubstExhaustTempCylx</i>	15000 <i>ExTmpCyl1SubstOrLast</i>	Exhaust temperature per cylinder

Table 27: Sensor substitution in case of error



Note

If the speed adjustment by setpoint 1 (normally bridge, 4-20 mA) fails during nautical applications, the digital potentiometer is activated automatically to enable adjustment of the speed in emergency operation. In this case, it is always the last valid speed setpoint that is used as an initial value for the digital potentiometer.

If the parameter 5252 *NoDigPotAtSetp1Err* exists, this automatic function can be deactivated with 5252 *NoDigPotAtSetp1Err* = 1. In this case, operation continues with either the last valid value or the substitute value of setpoint 1 1000 *SubstSetp1Ext*.

For the setpoint and sensor inputs, the parameters from 5040 *HoldOrReset...* can also be used to decide how the control unit should react if the error disappears by itself (e.g. loose wiring contact or a missing CAN telegram returns). If the corresponding parameter is set to "1" the error will be treated as having resolved itself. In this case, the control unit does not react when the measured sensor value returns to the valid range. If the parameter is set to "0", the error is reset and the system continues working with the signal coming from the sensor (or telegram).

Parameter	Reaction to error at
5040 <i>Setp1ExtHoldOrReset</i>	Target value 1
5041 <i>Setp2ExtHoldOrReset</i>	Target value 2
5042 <i>LoadCtrInHoldOrReset</i>	Value from load control unit
5043 <i>SyncInputHoldOrReset</i>	Synchronisation
5044 <i>BoostPressHoldOrReset</i>	Boost pressure
5045 <i>OilPressHoldOrReset</i>	Oil pressure
5046 <i>AmbPressHoldOrReset</i>	Ambient pressure
5047 <i>CoolTempHoldOrReset</i>	Coolant temperature
5048 <i>ChAirTempHoldOrReset</i>	Charge air temperature
5049 <i>OilTempHoldOrReset</i>	Oil temperature
5050 <i>FuelTempHoldOrReset</i>	Fuel temperature
5051 <i>ExhstTempHoldOrReset</i>	Exhaust temperature
5054 <i>ExcitRedHoldOrReset</i>	Slide protection signal
5055 <i>SpeedRedHoldOrReset</i>	Slide protection signal
5055 <i>AlternatrHoldOrReset</i>	Alternator
5056 <i>CoolPressHoldOrReset</i>	Coolant pressure
5057 <i>AsymmLoadHoldOrReset</i>	Asymmetric load
5058 <i>MeasPowerHoldOrReset</i>	Measured power
5059 <i>PowerSetpHoldOrReset</i>	Power setpoint
5060 <i>TuOilTempHoldOrReset</i>	Turbocharger oil temperature
5061 <i>FuelPressHoldOrReset</i>	Fuel pressure
5062 <i>OilLevelHoldOrReset</i>	Oil level
5063 <i>FuelLimExHoldOrReset</i>	External filling limitation
5064 <i>TransOilPHoldOrReset</i>	Transmission oil pressure
5065 <i>AirMassHoldOrReset</i>	Air mass
5066 <i>GasTempHoldOrReset</i>	Gas temperature
5067 <i>GasPosHoldOrReset</i>	External gas actuator position
5068 <i>GasRailPrHoldOrReset</i>	Gas rail pressure
5069 <i>GasVChPrHoldOrReset</i>	Gas valve check pressure
5071 <i>BoostPr2HoldOrReset</i>	Boost pressure 2
5072 <i>Lambda1HoldOrReset</i>	Lambda 1
5073 <i>Lambda2HoldOrReset</i>	Lambda 2
5074 <i>NoxHoldOrReset</i>	Nitrogens
5075 <i>O2HoldOrReset</i>	Oxygen
5076 <i>AlterVoltHoldOrReset</i>	Alternator voltage
15040 <i>ExTmpCyl1HoldOrReset</i>	Exhaust temperature per cylinder

Table 28: Sensor error with latching

18 Configuration of switching functions

In HEINZMANN control units, a strict distinction is made between external switches and internal switching functions. This means that engine or application control is determined by the current values read by switching functions but where those switching functions take their values from is configured separately.

Normally, they will be influenced by binary inputs but in specific applications they can also be assigned their values via analogue inputs, Modbus or CAN protocols.

For this reason, it must first be defined which type should be assigned to variable ports (\uparrow *Variable Ports*), then the inputs must be configured. Only then can the switching functions be configured and the source from which they receive their current status be specified. If communication modules are used for receiving switch values, they must also be configured beforehand (\uparrow *22 Bus-Protokolle*).

Once the entire configuration is complete and a reset has been carried out, there must be no configuration error reported, otherwise the configuration must be checked.

For each switching function there are up to five parameters defining the external source and the current value. The last three digits of the parameter numbers are always identical for a specific switching function and, of course, the parameter name also matches the function.

Parameter	Meaning
810 <i>Funct...</i>	Assignment of a binary input on the own hardware or assignment of an analogue input on the own hardware or assignment of a binary input on a HZM-CAN periphery module (latter only in old control units or older firmware)
2810 <i>Switch...</i>	Display of the current value of the switching function that the firmware is working with
20810 <i>Comm...</i>	Assignment of the input number of a communication module (in XIOS and in newer control units or newer firmware, this also includes the HZM-CAN periphery modules)
24810 <i>ChanTyp...</i>	Assignment of the communication module type
24910 <i>PEIx...</i>	Assignment of the HZM-CAN periphery module if several PE modules are released

Table 29: Switching function parameters

18.1 Complete overview of all switching functions

Switching functions may be defined as on-off switches or as selector switches. The name of a switching function will indicate the meaning. The names of selector switches always include the operator *Or*, where the expression preceding "*Or*" will be valid when the value

of the switching function is "1" and where the expression following "Or" will be valid when the switching function has the value "0". In the case of on/off switches, the name is equivalent to the condition On. State "1" will always define On and the state "0" Off.

For each of the switching functions there exists a parameter to indicate whether the function is active.

The following table gives an overview of the existing switch functions. Explanations of the individual functions and switch priorities will be found in the corresponding chapters of the function descriptions.



Note

The firmware of the control units is prepared on an application-specific basis. Depending on the application therefore only a part of the listed switching functions is required and indicated.

Switch function	Meaning	Application
2810 <i>SwitchEngineStop</i>	1 = Engine stop	
2811 <i>SwitchIdleSpeed</i>	1 = Idle speed active	
2812 <i>SwitchDroop2Or1</i>	0 = P droop 1 active 1 = P droop 2 active	
2813 <i>SwitchForcedLimit</i>	1 = Fixed fuel limitation active	
2814 <i>SwitchSpeedRange2Or1</i>	0 = Speed range 1 active 1 = Speed range 2 active	
2815 <i>SwitchSpeedFix1</i>	1 = Fixed speed 1 active	
2816 <i>SwitchSpeedFix2</i>	1 = Fixed speed 2 active	
2817 <i>SwitchSpeedLimit2Or1</i>	0 = Speed-depend. Fill limit 1 active 1 = Speed-depend. Fill limit 2 active	
2818 <i>SwitchSlide</i>	1 = Slide signal coming in	Locomotive
2818 <i>SwitchKnock</i>	1 = Knock signal coming in	Generator
2819 <i>SwitchNotch3</i>	1 = Speed notch switch 3	Locomotive
2820 <i>SwitchNotch2</i>	1 = Speed notch switch 2	Locomotive
2821 <i>SwitchNotch1</i>	1 = Speed notch switch 1	Locomotive
2821 <i>SwitchBackwards</i>	1 = Backwards	Marine
2822 <i>SwitchNotch0</i>	1 = Speed notch switch 0	Locomotive
2822 <i>SwitchForwards</i>	1 = Forwards	Marine
2823 <i>SwitchExcitLimit1</i>	1 = Excitation signal limit 1 active	Locomotive
2824 <i>SwitchExcitLimit2</i>	1 = Excitation signal limit 2 active	Locomotive
2825 <i>SwitchSpeedInc</i>	1 = Speed increase	
2826 <i>SwitchSpeedDec</i>	1 = Speed decrease	
2827 <i>SwitchSetpoint2Or1</i>	0 = Setpoint adjuster 1 active 1 = Setpoint adjuster 2 active	

Switch function	Meaning	Application
2828 <i>SwitchErrorReset</i>	0→1 = Clear current error (only with edge change)	
2829 <i>SwitchFreezeSetp1</i>	1 = Freeze setpoint 1	Vehicle
2830 <i>SwitchFreezeSetp2</i>	1 = Freeze setpoint 2	Vehicle
2831 <i>SwitchIMOrAllSpeed</i>	0 = Variable speed control 1 = Idle/Maximum speed control	Vehicle and locomotive
2833 <i>SwitchForcedStart</i>	1 = Forced opening of actuator	
2834 <i>SwitchSyncEnable</i>	1 = Synchronizing enabled	Generator
2835 <i>SwitchLoadEnable</i>	1 = Load control enabled	Generator
2836 <i>SwitchAutoOrManual</i>	0 = Manual mode 1 = Automatic mode	Generator
2837 <i>SwitchGasOrDiesel</i>	0 = Diesel request 1 = Gas request	Dual fuel
2838 <i>SwitchFastToDiesel</i>	1 = Fast reset to diesel	Dual fuel
2839 <i>SwitchGasPositioner</i>	1 = External gas positioner OK	Dual fuel
2840 <i>SwitchExcitationOn</i>	1 = Excitation signal enabled	Locomotive
2840 <i>SwitchPitchOn</i>	1 = Pitch control on	Marine
2841 <i>SwitchLowIdleOn</i>	1 = Low idle speed requested	Locomotive
2841 <i>SwitchMasterOrSlave</i>	0 = Slave 1 = Master in twin-engine applications	Marine
2842 <i>SwitchPID2Or1</i>	0 = PID set 1 1 = PID set 2	Generator
2842 <i>SwitchLoadTransfer</i>	1 = Load pick-up requested in twin-engine applications	Marine
2842 <i>SwitchCommand</i>	1 = Command button enabled in multiple engine applications	Marine
2843 <i>SwitchClutch</i>	1 = Clutch closed in twin-engine applications	Marine
2843 <i>SwitchSynchro</i>	1 = Synchro button enabled in multiple engine applications	Marine
2844 <i>SwitchAsymLoadEnable</i>	1 = Asymmetric load input enabled in twin-engine setups	Marine
2844 <i>SwitchEngineRelease</i>	1 = Engine release	
2845 <i>SwitchAutoAdjust</i>	0→1 = Automatic actuator adjustment (once at edge change)	
2845 <i>SwitchGasPressReady</i>	1 = Gas pressure switch (not XIOS)	Dual fuel
2846 <i>SwitchGenBreaker</i>	1 = Breaker closed	Generator
2847 <i>SwitchAlternator</i>	1 = Alternator signal	Vehicle
2847 <i>SwitchExternGasAlarm</i>	1 = External gas alarm (not XIOS)	Dual fuel

Switch function	Meaning	Application
2848 <i>SwitchExternGasReady</i>	1 = External gas section ready (not XIOS)	Dual fuel
2849 <i>SwitchStartEngine</i>	1 = Starter switch enabled	Vehicle
2849 <i>SwitchEmergencyStop</i>	1 = Emergency stop request (not XIOS)	Dual fuel
2870 <i>SwitchGasPressReady</i>	1 = Gas pressure switch (XIOS)	Dual fuel
2871 <i>SwitchExternGasAlarm</i>	1 = External gas alarm (XIOS)	Dual fuel
2872 <i>SwitchExternGasReady</i>	1 = External gas section ready (XIOS)	Dual fuel
2873 <i>SwitchEmergencyStop</i>	1 = Emergency stop request (XIOS)	Dual fuel

Table 30: Switch functions

18.1.1 Engine start request

For the engine start switch 2849 *SwitchStartEngine* parameter 4849 *StartImpulseOrSwitch* can be used to specify whether the engine start shall remain active as long as the switch itself remains active or whether a single switching pulse shall be sufficient to activate the engine start.

4849 *StartImpulseOrSwitch* = 0 engine start command continues only as long as 2849 *SwitchStartEngine* remains active

4849 *StartImpulseOrSwitch* = 1 the engine start is activated via a single switching pulse

In the second case, the command is terminated only when starting speed 256 *StartSpeed2* is exceeded or another condition interrupts the starting procedure.

18.1.2 Engine stop request

There are different ways of requesting an engine stop externally depending on the unit and application. All of these sources are equal, although the emergency stop request also results in the unconditional immediate stop of a dual-fuel engine, while the other stop requests end the dual fuel operation correctly first before the diesel operation is stopped. For details of other emergency stop situations see referring chapter.

2810 <i>SwitchEngineStop</i>	directly wired or received via a communication module
2844 <i>SwitchEngineRelease</i> = 0	no start release
2849 <i>SwitchEmergencyStop</i> (not XIOS) 2873 <i>SwitchEmergencyStop</i> (XIOS)	emergency stop request (wired directly!)
3790 <i>IgnitionOn</i> = 0	terminal 15 inactive (XIOS from revision 7)
5353 <i>NotchAssignOrBinary</i> = 1 and 6880 <i>LocoNotchAssign(x)</i> = 255	stop request via speed levels in locomotive applications

For all engine stop requests, 4810 *StopImpulseOrSwitch* can be used to specify whether they shall remain active as long as the input itself remains active or whether a single switching pulse shall be sufficient to activate the engine stop. In this second case, the engine stop request will end only when the engine has completely stopped, i.e. when speed 0 is recognized.

4810 *StopImpulseOrSwitch* = 0 engine stop is active only as long as the stop command is coming in

4810 *StopImpulseOrSwitch* = 1 one-off impulse keeps the engine stop request active until the engine stops

In specific situations it might be necessary to uphold the engine stop request even longer, for example when the engine turns backwards after a very quick stop. In such a case, the electronic control recognizes new impulses from the pick-up and erroneously interprets them as engine start. In extreme cases this can lead to a pick-up error. In order to avoid this situation, the engine stop request can be prolonged by the duration of 809 *EngineStopExtraTime* after speed 0 is recognized.

The parameter 3802 *EngineStopRequest* serves to indicate that the engine is being stopped by an internal or external engine stop request. The external engine stop requests are described above. For an internal engine stop, the stop command is determined by the control unit itself (e.g. in the event of overspeed). The parameter 3803 *EngineStopped* is provided to indicate that the engine has stopped.



*For safety reasons, HEINZMANN recommends direct connection of the engine stop switch 2810 *SwitchEngineStop* and/or 2849 *SwitchEmergencyStop* (XIOS: 2873 *SwitchEmergencyStop*), regardless of whether it is also received via a communication module.*

18.2 Assignment of hardware inputs

18.2.1 Assignment of binary inputs

A binary input can be assigned to a switching function by entering the number of the input in the corresponding assignment parameter of the function from 810 *Funct...*

These assignment parameters are parallel to the indication parameters for switching functions that start from 2810 *Switch...*

The numbers of binary inputs always run from 1 to the maximum number maxDI of the particular control unit. If the number of assignable inputs from parameter 810 *Funct...* exceeds the maximum possible number of binary inputs on the control unit, the first maxDI inputs are the binary inputs. An explanation for the surplus inputs can be found in [↑ 24.2.2 Assignment of other inputs](#).

For XIOS, it is important to remember that there is no automatic assignment of ports to binary or other input types. Each of the 117 ports can be assigned here, providing they are only configured as binary inputs.

An assignment of 0 means that the switching function is not being used by a binary input. Such a switching function will always have the value 0, except when it is received via a communication module (↑ 24.3 *Assignment of communication modules*).

The switching functions via binary inputs can be configured as high-active, i.e., active with the switch closed, or low-active, i.e. active with the switch open. High-active switching functions are assigned positive binary input numbers, low-active ones with negative binary input numbers.

One single binary input may simultaneously activate or change several functions. In this case, the functions involved will have to be assigned the same input number, possibly with the activity inverted (negative sign).

If a switching function is required that is permanently active (e.g. when the engine is running exclusively with active fixed speed 2815 *SpeedFix1*), in generator operation, any unused (not connected) binary input may be utilized to activate this function by assigning the negative number of this input to the switching function. For a selector switch, the meaning to the left of "Or" can be set with negative assignment and the meaning to the right of "Or" with positive assignment of an unused binary input.



A switch impulse must be at least 20 ms long to be detected by the control electronics. Any switching function will remain active only for the time the switch input is active (with the exception of ↑ 24.1.1 Engine start and ↑ 24.1.2 Engine stop).

Parametrization example:

Closing the switch of input no. 1 should stop the engine. When the switch is open on input 2, you want the engine to run at fixed speed 1. By closing the switch on input 2 you want to disable fixed speed 1 and at the same time enable the fixed fuel limitation.

Number	Parameter	Value	Unit
810	<i>FunctEngineStop</i>	1	
813	<i>FuncForcedLimit</i>	2	
815	<i>FunctSpeedFix1</i>	-2	

Indication:	Switch open	Switch closed
2810 <i>SwitchEngineStop</i>	0	1
2813 <i>SwitchForcedLimit</i>	0	1
2815 <i>SwitchSpeedFix1</i>	1	0

18.2.2 Assignment of other inputs

If the number of assignable inputs from parameter 810 *Funct...* exceeds the maximum possible number of binary inputs maxDI on the control unit, the possible sources for switching functions were expanded for this firmware. The binary inputs on the own hardware are always the first 1...maxDI assignment options ([↑ 24.2.1 Assignment of binary inputs](#)).

Due to the development history, there are two different versions for the assignment of other inputs via this route:

- Assignment of binary inputs on the HEINZMANN-CAN periphery modules

If the firmware generally allows HZM-CAN periphery module connection (parameter 4402 *CanCommPEOn* is available), this can be the binary inputs on these modules. For this variant, it is important that there is no switching function parameter from 20810 *Comm...* or, if there is, that it only has a positive value range. Further information is available under [↑ 24.2.2.1 Assignment of binary inputs of the HZM-CAN periphery modules](#).

- Assignment of analogue inputs on the own hardware

If the firmware does not support the connection of HZM-CAN periphery modules (parameter 4402 *CanCommPEOn* does not exist) or there are no switching function parameters from 20810 *Comm...*, or if there are, the value range has a sign, the surplus inputs from parameter 810 *Funct...* are the analogue inputs on the own hardware [↑ 24.2.2.2 Assignment of analogue inputs](#). The binary inputs of any connected HZM-CAN periphery modules are treated like other communication modules in this case, [↑ 24.3 Assignment of communication modules](#).

If the number of assignable inputs from parameter 810 *Funct...* corresponds exactly to the maximum possible number of binary inputs of the control unit and HZM-CAN periphery modules can be connected (parameter 4402 *CanCommPEOn* exists), their binary inputs are treated like those of other communication modules, [↑ 24.3 Assignment of communication modules](#).



Info

All variants for the assignment of inputs to switching functions are detected automatically in a special window of DcDesk 2000 and can be configured easily there without having to take into account the criteria outlined above.

18.2.2.1 Assignment of binary inputs of the HZM-CAN periphery modules

With their binary inputs, the periphery modules connected via the HZM-CAN protocol ([↑ Basic information HEINZMANN-CAN, publication no. DG 13 002-d](#)) are classed as an extension of the binary inputs on the own hardware. They are therefore added together in older systems or firmware variants.

To make the configuration in newer systems easier, the periphery modules are treated like other communication modules here ([↑] 24.3 *Assignment of communication modules*). This means that the binary inputs of the periphery modules are now no longer an extension of the hardware binary inputs, but are treated separately – as has always been the case for sensors connected to periphery modules. In addition to the clearer configuration, it is therefore also possible to receive a switching function via the main module, as well as via a periphery module, which can sometimes be necessary for safety reasons (e.g. the engine stop request).

The parameters from 20810 *Comm...* indicate whether a system uses the old or new configuration method. If there is no parameter there or, if one does exist, it only has a positive value range, then it is an older system, where the binary inputs of the periphery modules are added to those of the main module ([↑] 24.2.2.1.1 *Assignment in older systems*).

If parameters from 20810 *Comm...* exist and have a signed value range, then it is a new system ([↑] 24.3 *Assignment of communication modules*).

As newer systems, the control units DC 8, DC 11, DC 12 and XIOS only offer the new variant. On all older systems, downwards compatibility means that it is not possible to change the HEINZMANN basic software or existing customer software variants. New customer-specific firmware solutions may use the new variant, however.

18.2.2.1.1 Assignment in older systems

If the system includes at least one periphery module, the total number of binary inputs in the control unit increases by the number of binary inputs on all periphery modules, whereby the sequence of the periphery module types from 407 *CanPENodeType* determines the number of the input. The total number of binary inputs is limited to 32, however.

If, for example, with

407 *CanPENodeType*(0) = 1 type 1 (PE 6-07 with max. 5 binary inputs)

408 *CanPENodeType*(1) = 0 type 0 (PE 2 with max. 8 binary inputs)

two periphery modules are connected to a control unit of the type DC 2, the resulting number of available binary inputs is 21 with numbers from 1 to 8 on the own hardware, numbers 9 to 13 on the PE 6-07 periphery module and numbers 14 to 21 on the PE 2 periphery module. Here, it does not matter whether all possible ports have actually been configured as binary inputs, the maximum number is always used.

18.2.2.2 Assignment of analogue inputs

It is always advisable to use analogue inputs for switching functions if either the number of binary inputs is not sufficient, but free analogue inputs are available, or the input has to be monitored. This is the case in maritime applications, for example.

In this case, the value range of the assignment parameters to switching functions from parameter 810 *Funct...* is larger than the equivalent for the number of maxDI binary inputs of the control unit. The switches 1 .. maxDI are the binary inputs, the switches maxDI+1 to maxDI+maxAI are the current/voltage inputs of the control unit.

The XIOS is an exception here, as no automatic assignment of ports to binary or analogue inputs takes place. Each of the 117 ports can be assigned here, providing they are only configured as current or voltage inputs.

During the assignment to switching functions, the two reference values of the analogue inputs are used to determine the switching thresholds for the binary value 0 or 1 (with hysteresis).

Assuming that analogue input 1 is assigned to a switching function. If the current value of the switching function is 0, the switch to 1 takes place if the unfiltered analogue value 3511 *AnalogIn1_Value* exceeds the limit 1511 *AnalogIn1_RefHigh*. If the value of the switching function is 1, the return to 0 takes place if the unfiltered value 3511 *AnalogIn1_Value* falls below the limit 1510 *AnalogIn1_RefLow*.

For the XIOS, the same applies with the values 32021 *P001_(1.1)_AI_Value*, 30020 *P001_(1.1)_IO_RefLow* and 30021 *P001_(1.1)_IO_RefHigh* (if port 1 is configured as an analogue input and has been assigned a switching function).

18.2.2.2.1 Monitoring for cable breakage

On request, the firmware provides parameters for selected switching functions, which can be used to activate the monitoring for cable breaks and display errors. It should be noted that this monitoring requires a pull-up resistor on the analogue input.

For example, it may be necessary to monitor the engine stop input 2810 *SwitchEngineStop*. In this case, the parameters 4809 *SwitchEngStopBWDOn* (BWD = Broken Wire Detection) and 23810 *ErrSwEngineStop* would be made available. The exact parameters can be found in the relevant firmware description.

The monitoring of the analogue inputs takes place as described in [↑] 20.2.1.5 *Fehlererkennung bei den analogen Eingängen*.

18.3 Assignment of communication modules

A switching function can also receive its current value via communication modules, e.g. from a CAN protocol like CANopen (↑ 22.4 *CAN-Protokoll CANopen*) or a serial protocol like Modbus (↑ 22.8 *Seriell-Protokoll Modbus*). In newer control units or firmware versions, the HZM-CAN periphery module is also integrated in this way.

The communication module type is specified per switching function in 24810 *ChanTyp*.... These assignment parameters are parallel to the assignment parameters of binary inputs from 810 *Funct*... and the display parameters of the switching functions from 2810 *Switch*....

ChanTyp	Switching function source
0	No receipt via a communication module
2	HZM-CAN periphery module
3	Customer-defined CAN protocol
4	CANopen protocol (speed governor control unit is CANopen slave)
5	DeviceNet CAN protocol (speed governor control unit is slave)
6	Modbus protocol
7	SAE J1939 CAN protocol
8	HZM-CAN customer module
9	HZM-CAN second control unit of same type (double system)
10	WAGO module protocol (speed governor control unit is CANopen master)
13	ICENI module protocol (speed governor control unit is CANopen master)
15	HZM-CAN add-on module

Table 31: Communication modules as switching function sources (channel type)

For the receipt from HZM-CAN periphery modules, the number of the binary input on this module must be entered in the assignment parameters from 20810 *Comm*.... All values are always transferred, i.e. according to the maximum number of binary inputs, even if a specific port has a different configuration. In this case, the transferred value is always 0.

Which switching function is received by which bit of other communication modules is determined by the manufacturer of the sending module and must be agreed with him. The switching functions received from the communication module are then simply numbered from 1 onwards:

Telegram byte 0, bit 0 to bit 7 → switching function 1..8

Telegram byte 1, bit 0 to bit 7 → switching function 9..16

Telegram byte 2, bit 0 to bit 7 → switching function 17..23 etc.

The relevant number is entered in the assignment parameters from 20810 *Comm...* These assignment parameters are parallel to the assignment parameters of binary inputs from 810 *Funct...* and the display parameters of the switching functions from 2810 *Switch...*



*It should be noted that only a few fixed defined switching functions can be received via equally fixed defined telegrams via the CAN protocol SAE J1939. In this case, the assignment to the switching function in 20810 *Comm...* is only possible with the value 1 (= yes), not with a counter variable.*

If the parameters from 20810 *Comm...* are signed, the switching functions via communication modules can also be high-active, i.e. active when 1 is received, or low-active, i.e. active when a 0 is received. High-active switching functions are assigned positive communication input numbers, low-active ones with negative communication input numbers.

Assignment of 0 to 20810 *Comm...* means that the respective switching function is not received via a communication module (but possibly via another input [↑]24.2 *Assignment of hardware inputs*). For communication purposes, such a switching function will always have the value 0.



In old systems, if the connection to the communication module is interrupted, all "binary inputs" of the relevant receipt telegram are set to 0 (positive assignment parameters only). In newer systems (assignment parameters signed), the most recent state is retained.

18.4 Value of a switch function

In the case of on/off switches, the name is equivalent to the condition On. Status "1" of the switching function always defines On while status 0 denotes Off. In the case of selector switches, the names of which always contain the text "Or", the part to the left of "Or" is active when the switching function has the value "1", while the part to the right of the "Or" is active when it has the value "0".

If no communication module is integrated in the current firmware, the value of the switch function is dictated solely by the hardware input (binary or analogue). The parameters from 20810 *Comm...*, 24810 *ChanTyp...* and 24910 *PEIx...* do not exist.

However, if a communication module is to be taken into account, every switching function can be received either via the hardware input, the communication module or both.

1. Receipt via digital input only

The parameter 20810 *Comm...* must be set to 0.

If 810 *Funct...* = 0, then the switching function always has the value 0, otherwise it has the current value of the hardware input (with inverted activity if the input number is negative).

2. Receipt via communication module only

The parameter 810 *Funct...* must be set to 0 and 24810 *ChanTyp...* ≥ 2 .

If 20810 *Comm...* = 0, the switching function always has the value 0, or otherwise the current value from the receipt telegram.

In older systems, only high-active receipt is possible via a communication module, i.e. the assignment parameters on 20810 *Comm...* can only be entered in positive state. If the connection to the communication module is interrupted on systems like this, the values of the receipt telegram are set to 0 automatically.

In newer systems, these parameters can be entered signed as for the parameters from 810 *Funct...* and can therefore also be low-active. If the connection to the communication module is interrupted in these systems, the switching functions retain their most recent value.

3. Receipt via hardware input and communication module

The parameter 810 *Funct...* is not equal to 0, 20810 *Comm...* is not equal to 0 and 24810 *ChanTyp...* ≥ 2 .

The current value of the hardware input (poss. inverted) and that of the communication module (poss. inverted) are linked via OR. Therefore, the switch function is only 0 when both sources specify the value 0, and is only 1 when at least one source specifies the value 1.



*For safety reasons, it is advisable to always connect the engine stop request 2810 *SwitchEngineStop* directly, regardless of a possible additional transmission via a communication module (20810 *CommEngineStop*). HEINZMANN also advises never to connect selector switches that switch between two functions (with "Or" in their parameter name) with two signal paths.*

19 Inputs and outputs

The following sections describe the inputs and outputs of the various types of control unit.



Note

HEINZMANN control units may be connected to HEINZMANN I/O modules via a CAN bus to increase the number of inputs and outputs.

All adjustments for inputs and outputs can be carried out comfortably using \uparrow 3.3 DcDesk 2000, where there are specific windows for all the important aspects, considerably simplifying the process of parameter setting.

19.1 General

19.1.1 Selectable inputs and outputs

In all basic control systems the direction and/or signification of certain connections are freely configurable. This affects the number of available analogue, PWM and digital inputs and outputs. The parameter setting required to define these properties are described in the respective sections *Selectable inputs and outputs*.

The effectively available number of inputs and outputs must be taken into account during the configuration of sensors (\uparrow 17 *Configuration of sensors*), the configuration of switching functions (\uparrow 18 *Configuration of switching functions*) and the configuration of analogue, PWM and digital outputs (\uparrow 20 *Configuring the control's inputs and outputs*).

The maximum possible number of ports for a specific connection type is numbered serially. Even when the number of available inputs and outputs varies due to a change of configuration, the serial number assigned to a connection stays the same, regardless of possible gaps in the numbering.



Note

*The assignments of the channels cannot be altered during operation. It will therefore be necessary to save the data (\uparrow 3.2 *Saving data*) and restart the control unit with a \uparrow 3.10 *Reset of control unit after configuration*. The value ranges of analogue inputs and outputs then must be adapted again to the newly chosen electric unit.*

19.1.2 Pickup inputs

While the input for pickup1 has fixed and unchangeable functionality in all control units, for the input of pickup2 the same holds true only in control devices ARCHIMEDES, HELENOS, PRIAMOS and PRIAMOS III. In ORION and PANDAROS the input for pickup2 must be configured specifically for this function since the port-pin may also be used as digital or PWM input.

19.1.3 Analogue inputs

The different types of control unit are equipped with different numbers and types of analogue inputs. The possible variants are described in the following sections. Sensors receive values from analogue inputs \uparrow 17 *Configuration of sensors*.

On request it is also possible to implement switching functions via analogue inputs. In this case, a lower switching threshold, below which the switching function has the value "0", must be entered in parameter 976 *SensorSwitchLow*.

When the upper switching threshold 977 *SensorSwitchHigh* is exceeded, the switching function assumes the value "1".

19.1.4 PWM inputs

The various control units have a certain number of inputs that can be configured as PWM inputs. Sensors receive PWM input values, the configuration of sensors is described in \uparrow 17 *Configuration of sensors*.

19.1.5 Digital inputs

The digital inputs are used as on/off or toggle switches for switching functions \uparrow 18 *Configuration of switching functions*. The switching functions can be configured to be high-active, i.e., active with the switch closed, or low-active, i.e., active with the switch opened.

For each of the switching functions, there exists a parameter to indicate whether the function is active. Regardless of whether the respective switching function is high-active or low-active, the state "1" will always signify that the function is active, and "0" that it is inactive, regardless of the hardware design of the respective switch (high side/low side).



Note

Since the input signals are being debounced by the control circuit it is necessary that they be applied for at least 20 ms to be detected. In general, any switching function will be active only for the time the switch input is active.

19.1.6 Analogue outputs

The control units have several analogue outputs that may be utilized for indicating speed or injection quantity or as setpoint outputs to other units \uparrow 20.5 *Analogue outputs*.

19.1.7 PWM outputs

HEINZMANN control units are equipped with ports that can be used as PWM outputs to control power end stages or for signal transmission \uparrow 20.6 *PWM outputs*.

19.1.8 Digital outputs

The control units are equipped with several digital outputs that may be used to address optical or acoustic signalling devices, according to their capacity range, or to transmit signals to other devices \uparrow 20.8 *Digital outputs*.

19.2 ARCHIMEDES (DC 5)

19.2.1 Selectable inputs/outputs

The basic system ARCHIMEDES is equipped with six configurable ports: a PWM or digital input, two frequency or digital outputs, a PWM or digital output, a current or voltage input and a current or voltage output.

The speed measured at both pickup inputs can be configured to be transmitted to the two frequency outputs, where it is ready for use by other users.

“F” means the vehicle plug, “M” the engine plug.

Connection name	Plug pin	Configuration parameters	Configuration
ID1	F11	4800 <i>PWMIn1OrDigitalIn1</i>	0 = digital input 1 1 = PWM input 1
IA5	F2	5550 <i>AnalogIn5_Type</i>	1 = 0..5 V input 2 = 4.. 20 mA input
OD8	F26	4801 <i>FreqOut1OrDigOut8</i>	0 = digital output 8 1 = frequency output 1
OD9	M26	4802 <i>FreqOut2OrDigital</i>	0 = output 1 = frequency output 2
		4803 <i>PWMOut2OrDigOut9</i>	if output: 0 = digital output 9 1 = PWM output 2
OD10	F13	4804 <i>PWMOut1OrDigOut10</i>	0 = digital output 10 1 = PWM output 1
OA1	F3	5640 <i>AnalogOut_Type</i>	3 = 0..5 V output 4 = 4..20 mA output

Table 32: ARCHIMEDES: Variable connections

19.2.2 Analogue inputs

HEINZMANN control units of the ARCHIMEDES series are equipped with ten analogue inputs.

Input 5 may be configured on site for current or voltage \uparrow 19.2.1 *Selectable inputs/outputs*. Input 6 is conceived primarily for monitoring of battery voltage. The analogue inputs 7 to 10 are used as temperature inputs.

“F” means the vehicle plug, “M” the engine plug.

Input	Designation	Plug pin	Range
Analogue input 1	IA1	M3	fixed 0..5 V
Analogue input 2	IA2	M31	fixed 0..5 V
Analogue input 3	IA3	M37	fixed 0..5 V
Analogue input 4	IA4	F4	fixed 0..5 V
Analogue input 5	IA5	F2	0..5 V or 4..20 mA
Analogue input 6	IA6	M20	fixed 0..37.2 V
Analogue input 7 Temperature input 1 *	IT1	M9	PT 2000
Analogue input 8 Temperature input 2 *	IT2	M15	PT 2000
Analogue input 9 Temperature input 3 *	IT3	M25	PT 2000
Analogue input 10 Temperature input 4 *	IT4	F9	PT 2000

* Microcontroller resolution is 1/1024, with a precision of ± 3 digits.

One digit corresponds to approx. 22 Ω .

PT100: 3.8 Ω deviation for 10°C \rightarrow excluded

PT1000: 38 Ω deviation 10°C \rightarrow may be used, but not precise

NI 1000: approx. 50 Ω deviation for 10°C \rightarrow may be used, but not precise

Table 33: ARCHIMEDES: Analogue inputs

19.2.3 PWM input

The ARCHIMEDES series features an input on the vehicle plug that can be used as PWM input \uparrow 19.2.1 *Selectable inputs/outputs*.

Input	Designation	Plug pin	Maximum frequency
PWM input *	ID1	F11	500 Hz

* digital input also possible

Table 34: ARCHIMEDES: PWM input

19.2.4 Digital inputs

The series ARCHIMEDES features eight digital inputs, one of which may be configured as PWM input \uparrow 19.2.1 *Selectable inputs/outputs*.

“F” means the vehicle plug, “M” the engine plug.

Input	Designation	Plug pin
Digital input 1*	ID1	F11
Digital input 2	ID2	F18
Digital input 3	ID3	F22
Digital input 4	ID4	F21
Digital input 5	ID5	F17
Digital input 6	ID6	F10
Digital input 7	ID7	F16
Digital input 8	ID8	M16

*configurable as PWM input

Table 35: ARCHIMEDES: Digital inputs

19.2.5 Analogue output

HEINZMANN control units of the ARCHIMEDES series are equipped with one current output on the vehicle plug.

Output	Designation	Plug pin	Type	Range
Analogue output	OA1	F3	current	4..20 mA

Table 36: ARCHIMEDES: Analogue output

19.2.6 PWM outputs

The series ARCHIMEDES features two PWM outputs that may be also be configured as digital outputs, [↑]19.2.1 Selectable inputs/outputs.

“F” means the vehicle plug, “M” the engine plug.

Input	Designation	Plug pin	Frequency range	Type	Power (max.)
PWM output 1*	OD10	F13	50..500 Hz	low side	1.3 A
PWM output 2*	OD9	M26	50..500 Hz	low side	0.43 A at 85 °C

* also configurable as digital output

Table 37: ARCHIMEDES: PWM outputs

19.2.7 Digital outputs

HEINZMANN control units of the ARCHIMEDES series are equipped with ten freely configurable digital outputs and one error output, [↑]19.2.1 *Selectable inputs/outputs*. “F” means the vehicle plug, “M” the engine plug.

Input	Designation	Plug pin	Type	Power (max.)
Digital output 1	OD1	M12	high side	$I_{nom} = 2.5 \text{ A}$
Digital output 2	OD2	F23	high side	$I_{nom} = 2.5 \text{ A}$
Digital output 3	OD3	M17	high side	$I_{nom} = 2.5 \text{ A}$
Digital output 4	OD4	F19	high side	$I_{nom} = 2.5 \text{ A}$
Digital output 5	OD5	M28	high side	$I_{nom} = 12 \text{ A}$
Digital output 6	OD6	M34	high side	$I_{nom} = 12 \text{ A}$
Digital output 7	OD7	F20	low side	$I_{nom} = 0.43 \text{ A}$ @ 85 °C $I_{max} = 1.2 \text{ A}$
Digital output 8*	OD8	F26	low side	$I_{nom} = 0.43 \text{ A}$ @ 85 °C
Digital output 9 ⁺	OD9	M26	low side	$I_{nom} = 0.43 \text{ A}$ @ 85 °C
Digital output 10 [#]	OD10	F13	low side	$I_{nom} = 1.3 \text{ A}$
Error output	ODE	F7	low side	$I_{nom} = 0.43 \text{ A}$ @ 85 °C $I_{max} = 1.2 \text{ A}$

* also configurable as frequency output pickup 1

* also configurable as frequency output pickup 2 or PWM output 2

also configurable as PWM output 1

Table 38: ARCHIMEDES: Digital outputs

The parameters starting from 3611 *DigitalOut1:Feedback* indicate the output signal fed back for each digital output. The parameters starting from 3631 *DigitalOut1:ErrType* give detailed information in case of error:

Bit	Meaning
0	short against Ubatt
1	short against GND
2	OpenLoad or short against Ubatt
3	OpenLoad or short against GND

19.3 HELENOS (DC 2-01)

19.3.1 Selectable inputs/outputs

The HELENOS digital control is equipped with 4 channels that can be individually configured as PWM or digital inputs or outputs and an additional channel that can be used as a PWM output or digital output. The following parameters determine the direction and type of the ports:

Connection name	Plug pin terminal	Configuration parameters	Configuration
IO 0	K3 / 30	4800 <i>DigChannel1OutOrIn</i>	0 = input 1 = output
		4801 <i>DigChannel1PWMOrDIO</i>	if input: 0 = digital input 5 1 = PWM input 1
			if output: 0 = digital output 1 1 = PWM output 1
IO 1	J3 / 31	4802 <i>DigChannel2OutOrIn</i>	0 = input 1 = output
		4803 <i>DigChannel2PWMOrDIO</i>	if input: 0 = digital input 6 1 = PWM input 2
			if output: 0 = digital output 2 1 = PWM output 2
IO 2	T3 / 32	4804 <i>DigChannel3OutOrIn</i>	0 = input 1 = output
		4805 <i>DigChannel3PWMOrDIO</i>	if input: 0 = digital input 7 1 = PWM input 3
			if output: 0 = digital output 3 1 = PWM output 3
IO 3	H3 / 33	4806 <i>DigChannel4OutOrIn</i>	0 = input 1 = output
		4807 <i>DigChannel4PWMOrDIO</i>	if input: 0 = digital input 8 1 = PWM input 4
			if output: 0 = digital output 4 1 = PWM output 4
AN OUT 0	V3 / 25	4809 <i>DigChannel5PWMOrDO</i>	0 = digital output 5

Connection name	Plug pin terminal	Configuration parameters	Configuration
			1 = PWM output 5

Table 39: HELENOS: Variable connections

Parameterizing Example:

The first channel is to be used as a switch input and the second as a switch output. The third digital input shall be configured as a PWM input and the fourth as a PWM output.

Number	Parameter	Value	Unit
4800	<i>DigChannel1OutOrIn</i>	0	
4801	<i>DigChannel1PWMOrDIO</i>	0	
4802	<i>DigChannel2OutOrIn</i>	1	
4803	<i>DigChannel2PWMOrDIO</i>	0	
4804	<i>DigChannel3OutOrIn</i>	0	
4805	<i>DigChannel3PWMOrDIO</i>	1	
4806	<i>DigChannel4OutOrIn</i>	1	
4807	<i>DigChannel4PWMOrDIO</i>	1	

19.3.2 Analogue inputs

The **HEINZMANN** control units of the HELENOS series are equipped with 6 analogue inputs whose hardware must be adapted to the desired requirements.

Four inputs may be factory-configured individually as current inputs with 4..20 mA or as voltage inputs with 0..5 V for universal use as setpoint and pressure inputs.

The analogue inputs 5 to 6 are used as temperature inputs. They too must be prepared in the factory for the respective temperature sensor type.

In the table below the standard configurations are in bold print.

Input	Designation	Plug pin / terminal	Range
Analogue input 1	ANIN 0	R2 / 16	fixed 0.5 V or 0..22.7 mA
Analogue input 2	ANIN 1	S2 / 17	fixed 0.5 V or 0..22.7 mA
Analogue input 3	ANIN 2	P1 / 4	fixed 0.5 V or 4..20 mA
Analogue input 4	ANIN 3	L1 / 6	fixed 0.5 V or 4..20 mA
Analogue input 5 Temperature input 1	THIN 0	S1 / 13	fixed PT 1000 or PT 200 or NTC
Analogue input 6 Temperature input 2	THIN 1	U1 / 14	fixed NTC or PT 1000 or PT 200

Table 40: HELENOS: Analogue inputs

19.3.3 PWM inputs

The HEINZMANN control units of the HELENOS series are equipped with four inputs configurable as PWM inputs, [↑]19.3.1 Selectable inputs/outputs.

Input	Designation	Plug pin / terminal	Maximum frequency
PWM input 1 *	IO 0	K3 / 30	1000 Hz
PWM input 2 *	IO 1	J3 / 31	1000 Hz
PWM input 3 *	IO 2	T3 / 32	1000 Hz
PWM input 4 *	IO 3	H3 / 33	1000 Hz

* configurable as PWM output, digital input, digital output

Table 41: HELENOS: PWM inputs

19.3.4 Digital inputs

The **HEINZMANN** control units of the HELENOS series feature four digital inputs. Four further ports may be configured individually as digital inputs, [↑]19.3.1 *Selectable inputs/outputs*.

Input	Designation	Plug pin / terminal
Digital input 1	DIGI IN 0	B3 / 26
Digital input 2	DIGI IN 1	C3 / 27
Digital input 3	DIGI IN 2	P3 / 28
Digital input 4	DIGI IN 3	D3 / 29
Digital input 5*	IO 0	K3 / 30
Digital input 6*	IO 1	J3 / 31
Digital input 7*	IO 2	T3 / 32
Digital input 8*	IO 3	H3 / 33

*configurable as digital output, PWM input, PWM output

Table 42: HELENOS: Digital inputs

19.3.5 Analogue outputs

The **HEINZMANN** control units of the HELENOS series feature four analogue outputs, two of which are implemented as current outputs and two as voltage outputs.

Output	Designation	Plug pin / terminal	Type	Range
Analogue output 1	CURR0	K2 / 21	current	4..20 mA
Analogue output 2	CURR1	J2 / 22	current	4..20 mA
Analogue output 3	VOLT0	B2 / 19	voltage	0..5 V/0..10 V
Analogue output 4	VOLT1	C2 / 20	voltage	0..5 V/0..10 V

Table 43: HELENOS: Analogue outputs

The selection of the voltage range for analogue outputs 3 and 4 is made with 5651 *VoltOut1Range10VOr5V* and 5656 *VoltOut2Range10VOr5V*. Value “1” selects 10V, value “0” selects 5V.

19.3.6 PWM outputs

The **HEINZMANN** control units of the HELENOS series are equipped with five ports that can be configured individually as PWM outputs, \uparrow 19.3.1 *Selectable inputs/outputs*.

Input	Designation	Plug pin / terminal	Frequency range	Type	Power (max.)
PWM output 1 [*]	IO 0	K3 / 30	128...4000 Hz	low side	(bus driver)
PWM output 2 [*]	IO 1	J3 / 31	128...4000 Hz	low side	(bus driver)
PWM output 3 [*]	IO 2	T3 / 32	128...4000 Hz	low side	(bus driver)
PWM output 4 [*]	IO 3	H3 / 33	128...4000 Hz	low side	(bus driver)
PWM output 5 ⁺	AN OUT 0	V3 / 25	128...4000 Hz	low side	3 A

^{*} configurable as PWM input, digital input, digital output

⁺ also configurable as digital output

Table 44: HELENOS: PWM outputs

For the outputs 1..4 **HEINZMANN** offers the relay interface RIF 01, which on the HELENOS side ensures that the strict specification of the bus drivers is observed and on the output side admits a maximum current of 3 A at 24 V. Ordering Number: 620-00-041-00.

19.3.7 Digital outputs

The **HEINZMANN** control units of the HELENOS series feature a maximum of five freely configurable digital outputs, \uparrow 19.3.1 *Selectable inputs/outputs*.

Input	Designation	Plug pin / terminal	Type	Power (max.)
Digital output 1 [*]	IO 0	K3 / 30	low side	(bus driver)
Digital output 2 [*]	IO 1	J3 / 31	low side	(bus driver)
Digital output 3 [*]	IO 2	T3 / 32	low side	(bus driver)
Digital output 4 [*]	IO 3	H3 / 33	low side	(bus driver)
Digital input 5 ⁺	ANOUT 0	V3 / 25	low side	3 A

^{*} configurable as digital input, PWM input, PWM output

⁺ also configurable as PWM output

Table 45: HELENOS: Digital outputs

For the outputs 1..4 **HEINZMANN** offers the relay interface RIF 01, which on the HELENOS side ensures that the strict specification of the bus drivers is observed and on the output side admits a maximum current of 3 A at 24 V. Ordering Number: 620-00-041-00.

19.3.8 Fixed alarm outputs

The control units of the HELENOS series provide dedicated outputs that have been pre-configured for error-indication and overspeed.

The overspeed output is provided as a relay output to enable a separate overspeed protection to be activated by this output. For a description of how to adjust overspeed, chapter [↑]6.4 *Overspeed monitoring* offers a description of adjustment of overspeed and of the control unit's response to overspeeding. It should be noted that the output is triggered for each error intended to lead to an engine stop ([↑]27.7 *Emergency shutdown errors*), not just when overspeed is detected. The engine stop is achieved – independently from the existence of a separate overspeed protection device – by the control unit itself, that forcefully pulls the actuator in “0” position. A separate overspeed protection is important for all situations in which the actuator can no longer be moved and is therefore indispensable.

As to its meaning, the output “Control unit operative” is identical with the overspeed output and serves to indicate that no fatal error such as overspeed has occurred and that the governor is able to control engine speed.

The common alarm output is activated when the control has detected at least one error or sent out a warning. The output may be used for a visual or audible signal. The common alarm output 3825 *LED_CommonAlarm* is described in detail in the chapter [↑]27 *Error Handling* which will also deal with the possible error causes.

The common alarm as well as the overspeed output may be more heavily loaded than the other governor outputs. The following table shows the pin assignments of the alarm outputs.

Output	Plug pin / terminal	Type	Power (max.)
Overspeed	X1 / 10	high side	3 A
Control ready	A2 / 23	high side	3 A
Common alarm	L2 / 24	high side	3 A

Table 46: HELENOS: Fixed alarm outputs

19.4 ORION (DC 9)

19.4.1 Selectable inputs

The basic system ORION is equipped with two configurable inputs, that may function as digital input, current or voltage input. A further input may be used as digital, PWM or frequency input.

Connection name	Terminal	Configuration parameters	Configuration
Tmp	4	4806 <i>AnalogIn2OrDigIn4</i>	0 = digital input 4 1 = analogue input 2 always 0..5 V
SpA	5	4804 <i>AnalogInOrDigitalIn1</i>	0 = digital input 1 1 = analogue input 1
		5510 <i>AnalogIn1_Type</i>	if analogue input: 1 = 0..5 V 2 = 4..20 mA
Stp	11	4805 <i>PUp2_PWMInOrDigIn3</i>	0 = digital input 3 1 = pickup2/PWM
		4002 <i>PickUp2On</i>	if pickup2/PWM: 0 = PWM input 1 1 = pickup2 input

Table 47: ORION: Variable connections

Parameterizing Example:

The variable input on pin 5 is to be configured for a 4..20 mA sensor.

Number	Parameter	Value	Unit
4804	<i>AnalogInOrDigitalIn1</i>	1	
5510	<i>AnalogIn1_Type</i>	2	

19.4.2 Pickup 2 input

HEINZMANN control devices of the ORION series feature an input that may be configured as input for pickup2, \uparrow 19.4.1 Selectable input.

Input	Designation	Terminal
Pickup 2*	Stp	11

* configurable as digital input or PWM input

Table 48: ORION:Input for pickup 2

While the input for pickup 1 may be used with a Hall or inductive sensor, for pickup 2 only Hall sensor or terminal W are allowed.

19.4.3 Analogue inputs

The digital control of the ORION series are equipped with 2 analogue inputs. One of them can be configured for current or voltage by setting the adequate parameters, \uparrow 19.4.1 Selectable input.

Input	Designation	Terminal	Range
Analogue input 1*	SpA	7	0..5 V or 4..20 mA
Analogue input 2	Tmp	4	fixed 0..5 V

* configurable as digital input or PWM input

Table 49: ORION: Analogue inputs

19.4.4 PWM input

ORION systems feature a configurable PWM input \uparrow 19.4.1 Selectable input.

Input	Designation	Terminal	Max. frequency
PWM input*	Stp	11	500 Hz

* configurable as digital input or input for pickup 2

Table 50: ORION:PWM input

19.4.5 Digital inputs

The **HEINZMANN** control units of the ORION series are equipped with four digital inputs, one of which can be configured as analogue input, \uparrow 19.4.1 *Selectable input*.

Input	Designation	Terminal
Digital input 1 *	SpA	7
Digital input 2	SpD	9
Digital input 3 *	Stp	11
Digital input 4 ⁺	Tmp	4

* configurable as input for pickup 2 or PWM input 1

⁺ configurable as analogue input

Table 51: ORION: Digital inputs

19.4.6 Digital outputs

The **HEINZMANN** control units of the ORION series feature one freely configurable digital output that is normally assigned to error-indication.

Input	Designation	Terminal	Type	Power (max.)
Digital output / error output	Err	10	low side	0.3 A

Table 52: ORION: Digital outputs

It should be noted that the error output is commuted by the bootloader during the control unit's start-up (\uparrow 27.5 *Bootloader*).



Note

The ORION series has neither analogue nor PWM outputs.

19.5 PANDAROS (DC 6)

19.5.1 Selectable inputs/outputs

The basic system PANDAROS is equipped with four selectable ports. Two of these so-called multifunctional ports can function as input or output, digital, PWM or analogue. A further port can be used as digital or analogue input and the last as digital, PWM or pickup 2 input.

Connection name	Terminal	Configuration parameters	Configuration
P1	2	4800 <i>Port1Type</i>	0 = analogue 1 1 = PWM 1 2 = digital 1
		4801 <i>Port1OutOrIn</i>	0 = input 1 1 = output 1 if analogue output: 4..20 mA
		5510 <i>AnalogIn1_Type</i>	if analogue input: 1 = 0..5 V 2 = 4..20 mA 3 = 0..10 V
P2	1	4802 <i>Port2Type</i>	0 = analogue 2 1 = PWM 2 2 = digital 2
		4803 <i>Port2OutOrIn</i>	0 = input 2 1 = output 1 if analogue output: 4..20 mA
		5520 <i>AnalogIn2_Type</i>	if analogue input: 1 = 0..5 V 2 = 4..20 mA 3 = 0..10 V
SpA	7	4804 <i>AnaIn3OrDigIn3</i>	0 = digital input 3 1 = analogue input 3
		5530 <i>AnalogIn3_Type</i>	if analogue input: 1 = 0..5 V 2 = 4..20 mA
Stp	11	4805 <i>PUp2_PWMIn3OrDigIn5</i>	0 = digital input 5 1 = pickup 2 or PWM input
		4002 <i>PickUp2On</i>	if pickup2/PWM input: 0 = PWM input 3 1 = pickup 2 input

Table 53: PANDAROS: Variable connections

Parameterizing Example:

Multifunctional port 1 is used as current input 1 and multifunctional port 2 as digital output 2. The third channel is to be used as digital input 3.

Number	Parameter	Value	Unit
4800	Port1Type	0	
4801	Port1OutOrIn	0	
5510	AnalogIn1_Type	2	
4802	Port2Type	2	
4803	Port2OutOrIn	1	
4804	AnaIn3OrDigIn3	0	

19.5.2 Pickup 2 input

HEINZMANN control devices of the PANDAROS series feature an input that may be configured as input for pickup2, ↑ 19.5.1 *Selectable inputs/outputs*.

Input	Designation	Terminal
Pickup 2*	Stp	11

* configurable as digital input or PWM input

Table 54: PANDAROS: Input for pickup2

While the input for pickup 1 may be used with a Hall or inductive sensor, for pickup 2 only Hall sensor or terminal W are allowed.

19.5.3 Analogue inputs

The series PANDAROS is equipped with a maximum of four analogue inputs. Three inputs be configured for current or voltage by setting the respective parameters, ↑ 19.5.1 *Selectable inputs/outputs*. Analogue input 4 is an universal temperature input.

Input	Designation	Terminal	Range
Analogue input 1*	P1	2	0..5 V or 4..20 mA or 0..10 V
Analogue input 2*	P2	1	0..5 V or 4..20 mA or 0..10 V
Analogue input 3 ⁺	SpA	7	0..5 V or 4..20 mA
Analogue input 4 Temperature input	Tmp	4	both as PT 1000 and NTC

* configurable as analogue output, digital input/output, PWM input/output

⁺configurable as digital input

Table 55: PANDAROS: Analogue inputs

19.5.4 PWM inputs

The **HEINZMANN** control units of the series PANDAROS are equipped with three inputs that may be configured as PWM inputs, \uparrow 19.5.1 *Selectable inputs/outputs*.

Input	Designation	Terminal	Maximum frequency
PWM input 1 [*]	P1	2	500 Hz
PWM input 2 [*]	P2	1	500 Hz
PWM input 3 ⁺	Stp	11	500 Hz

^{*} configurable as digital output, PWM input/output, analogue input/output

⁺ configurable as digital input or input for pickup 2

Table 56: PANDAROS: PWM inputs

19.5.5 Digital inputs

The **HEINZMANN** control units of the PANDAROS series feature a maximum of five digital inputs, \uparrow 19.5.1 *Selectable inputs/outputs*.

Input	Designation	Terminal
Digital input 1 [*]	P1	2
Digital input 2 [*]	P2	1
Digital input 3 ⁺	SpA	7
Digital input 4	SpD	9
Digital input 5 [#]	Stp	11

^{*} configurable as digital output, PWM input/output, analogue input/output

⁺ configurable as analogue input

[#] configurable as PWM input or input for pickup 2

Table 57: PANDAROS: Digital inputs

19.5.6 Analogue outputs

The **HEINZMANN** control units of the series PANDAROS are equipped with two ports that may be configured individually as current outputs, \uparrow 19.5.1 *Selectable inputs/outputs*.

Output	Designation	Terminal	Type	Range
Analogue output 1 [*]	P1	2	current	4..20 mA
Analogue output 2 [*]	P2	1	current	4..20 mA

^{*} configurable as digital output, PWM input/output, analogue input/output

Table 58: PANDAROS: Analogue outputs

19.5.7 PWM outputs

The **HEINZMANN** control units of the series PANDAROS are equipped with two ports that may be configured as PWM outputs, *↑19.5.1 Selectable inputs/outputs*.

Input	Designation	Terminal	Frequency range	Type	Power (max.)
PWM output 1*	P1	2	50...500 Hz	low side	0.3 A
PWM output 2*	P2	1	50...500 Hz	low side	0.3 A

*configurable as PWM input, digital input/output, analogue input/output

Table 59: PANDAROS: PWM outputs

19.5.8 Digital outputs

The **HEINZMANN** control units of the PANDAROS series feature a maximum of two freely configurable digital outputs. The required parameter settings for the assignment are described in chapter *↑19.5.1 Selectable inputs/outputs*.

Input	Designation	Terminal	Type	Power (max.)
Digital output 1*	P1	2	low side	0.3 A
Digital output 2*	P2	1	low side	0.3 A
Error output	Err	10	low side	0.3 A

*configurable as digital input, PWM input/output, analogue input/output

Table 60: PANDAROS: Digital outputs

19.6 PRIAMOS (DC 1-03)

19.6.1 Selectable inputs/outputs

The basic system PRIAMOS is equipped with two channels that can be utilized as PWM inputs or digital inputs and three channels that can be utilized as PWM outputs or digital outputs. The following parameters serve to define the signal type of the channels.

Plug pin	Configuration Parameter	Configuration
E3	4801 <i>PWMIn1OrDigitalIn11</i>	0 = digital input 11 1 = PWM input 1
G4	4802 <i>PWMIn2OrDigitalIn12</i>	0 = digital input 12 1 = PWM input 2
S1	4803 <i>PWMOut1OrDigitalOut1</i>	0 = digital output 1 1 = PWM output 1
X1	4804 <i>PWMOut2OrDigitalOut2</i>	0 = digital output 2 1 = PWM output 2
A4	4805 <i>PWMOut3OrDigitalOut3</i>	0 = digital output 3 1 = PWM output 3

Table 61: PRIAMOS: Variable connections

Parameterizing Example:

The first channel is to be used as a PWM input and the second as a digital output 12. The third and fourth channels shall both be configured as digital outputs.

Number	Parameter	Value	Unit
4801	<i>PWMInOrDigitalIn11</i>	1	
4802	<i>PWMIn2OrDigitalIn12</i>	0	
4803	<i>PWMOut1OrDigitalOut1</i>	0	
4805	<i>PWMOut2OrDigitalOut2</i>	0	

19.6.2 Analogue inputs

The **HEINZMANN** control units of the PRIAMOS series are equipped with seven analogue inputs whose hardware must be adapted to the desired requirements. Five inputs may be factory-configured individually as current inputs with 4..20 mA or as voltage inputs with 0..5 V for universal use as setpoint and pressure inputs. The analogue inputs 6 to 7 are used as temperature inputs.

In the table below the standard configurations are in bold print.

Input	Designation	Plug pin	Range
Analogue input 1	ADC1	A3	fixed 0..5 V or 4..20 mA
Analogue input 2	ADC2	L3	fixed 0..5 V or 4..20 mA
Analogue input 3	ADC3	C3	fixed 0..5 V or 4..20 mA
Analogue input 4	ADC4	T1	fixed 0..5 V or 4..20 mA
Analogue input 5	ADC5	R1	fixed 0..5 V or 4..20 mA
Analogue input 5 Temperature input 1	ADC6 / TEMP1	J1	fixed NTC
Analogue input 6 Temperature input 2	ADC7 / TEMP2	L1	fixed Ni 1000

Table 62: PRIAMOS: Analogue inputs

19.6.3 PWM inputs

The series PRIAMOS features two inputs, that may be configured as PWM inputs, ↑
19.6.1 Selectable inputs/outputs.

Input	Plug pin	Maximum frequency
PWM input 1 *	E3	1000 Hz
PWM input 2 *	G4	1000 Hz

* digital input also possible

Table 63: PRIAMOS: PWM inputs

19.6.4 Digital inputs

The **HEINZMANN** controls of the PRIAMOS series are equipped with a maximum of twelve digital inputs, ↑ 19.6.1 *Selectable inputs/outputs*.

Input	Plug pin
Digital input 1	T2
Digital input 2	V2
Digital input 3	P2
Digital input 4	H2
Digital input 5	S2
Digital input 6	R2
Digital input 7	D2
Digital input 8	G2
Digital input 9	F2
Digital input 10	E2
Digital input 11*	E3
Digital input 12*	G4

*configurable as PWM input

Table 64: PRIAMOS: Digital inputs

19.6.5 Analogue outputs

The **HEINZMANN** control units of the PRIAMOS series feature two outputs, which can be implemented either as current or as voltage output.

Output	Plug pin	Type	Range
Analogue output 1	J3	Current	4..20 mA
	K3	Voltage	0..5 V
Analogue output 2	G3	Current	4..20 mA
	S3	Voltage	0..5 V

Table 65: PRIAMOS: Analogue outputs

19.6.6 PWM outputs

The **HEINZMANN** control units of the PRIAMOS series are equipped with three configurable outputs that can be utilized as PWM outputs, \uparrow 19.6.1 *Selectable inputs/outputs*.

Input	Plug pin	Frequency range	Type	Power (max.)
PWM output 1*	S1	128...4000 Hz	low side	1 A
PWM output 2*	X1	128...4000 Hz	low side	1 A
PWM output 3*	A4	128...4000 Hz	low side	1 A

* digital input also possible

Table 66: PRIAMOS: PWM outputs

19.6.7 Digital outputs

The **HEINZMANN** controls of the PRIAMOS series are equipped with a maximum of three digital outputs. The required parameter settings for the assignment are described in chapter \uparrow 19.6.1 *Selectable inputs/outputs*.

Output	Plug pin	Type	Power (max.)
Digital output 1*	S1	low side	1 A
Digital output 2*	X1	low side	1 A
Digital output 3*	A4	low side	1 A

* also configurable as PWM output

Table 67: PRIAMOS: Digital outputs

19.6.8 Fixed alarm outputs

The control units of the PRIAMOS series provide three dedicated outputs that have been pre-configured for error-indication and overspeed.

The overspeed output is provided as a relay output to enable a separate overspeed protection to be activated by this output. For a description of how to adjust overspeed, chapter \uparrow 6.4 *Overspeed monitoring* offers a description of adjustment of overspeed and of the control unit's response to overspeeding. It should be noted that the output is triggered for each error intended to lead to an engine stop (\uparrow 27.7 *Emergency shutdown errors*), not just when overspeed is detected. The engine stop is achieved – independently from the existence of a separate overspeed protection device – by the control unit itself, that forcefully pulls the actuator in “0” position. A separate overspeed protection is important for all situations in which the actuator can no longer be moved and is therefore indispensable.

As to its meaning, the output “Control unit operative” is identical with the overspeed output and serves to indicate that no fatal error such as overspeed has occurred and that the governor is able to control engine speed.

The common alarm output is activated when the control has detected at least one error or sent out a warning. The output may be used for a visual or audible signal. The common alarm output 3826 *LED_CommonAlarm* is described in detail in the chapter [↑ 27 Error Handling](#) which will also deal with the possible error causes.

The common alarm as well as the overspeed output may be more heavily loaded than the other governor outputs. The following table shows the pin assignments of the alarm outputs.

E1 and C2 are the same output physical. They can supply the nominal current only once (combined power).

Output	Plug pin	Type	Power (max.)
Overspeed	E1	high side	3 A
Control ready	C2	high side	3 A
Common alarm	B2	low side	1 A

Table 68: PRIAMOS: Fixed alarm outputs



Note

When initializing the digital contro DC 11, the common alarm output is activated for about 500 ms.

19.7 PRIAMOS III (DC 1-04)

19.7.1 Selectable inputs/outputs

The basic system PRIAMOS III is equipped with one port that can be utilized as a PWM input or digital input and three channels that can be utilized as PWM outputs or digital outputs. The following parameters serve to define the signal type of the channels.

Plug pin	Configuration parameters	Configuration
E3	4801 <i>PWMIn1OrDigitalIn11</i>	0 = digital input 11 1 = PWM input 1
S1	4803 <i>PWMOut1OrDigitalOut1</i>	0 = digital output 1 1 = PWM output 1
X1	4804 <i>PWMOut2OrDigitalOut2</i>	0 = digital output 2 1 = PWM output 2
A4	4805 <i>PWMOut3OrDigitalOut3</i>	0 = digital output 3 1 = PWM output 3

Table 69: PRIAMOS III: Variable connections

Parameterizing Example:

The first channel is to be used as a digital input 11 and the second as a digital output 1.

Number	Parameter	Value	Unit
4801	<i>PWMIn1OrDigitalIn11</i>	0	
4803	<i>PWMOut1OrDigitalOut1</i>	0	

19.7.2 Analogue inputs

The HEINZMANN control units of the PRIAMOS III series are equipped with ten analogue inputs whose hardware must be adapted to the desired requirements.

The inputs 1..8 may be factory-configured individually as current inputs with 4..20 mA or as voltage inputs with 0..5 V for universal use as setpoint and pressure inputs.

The analogue inputs 9 to 10 are used as temperature inputs.

In the table below the standard configurations are in bold print.

Input	Designation	Plug pin	Range
Analogue input 1	ADC1	A3	fixed 0.5 V or 4..20 mA
Analogue input 2	ADC2	L3	fixed 0.5 V or 4..20 mA
Analogue input 3	ADC3	C3	fixed 0.5 V or 4..20 mA
Analogue input 4	ADC4	T1	fixed 0.5 V or 4..20 mA
Analogue input 5	ADC5	R1	fixed 0.5 V or 4..20 mA
Analogue input 6	ADC6	T5	fixed 0.5 V or 4..20 mA
Analogue input 7	ADC7	X5	fixed 0.5 V or 4..20 mA
Analogue input 8	ADC8	Y5	fixed 0.5 V or 4..20 mA
Analogue input 9 Temperature input 1	ADC9 / TEMP1	J1	fixed NTC
Analogue input 10 Temperature input 2	ADC10 / TEMP2	L1	fixed Ni 1000

Table 70: PRIAMOS III : Analogue inputs

19.7.3 PWM input

PRIAMOS III has one input that can be configured as PWM input, [↑] 19.7.1 *Selectable inputs/outputs*.

Input	Plug pin	Maximum frequency
PWM input *	E3	1000 Hz

* digital input also possible

Table 71: PRIAMOS III: PWM input

19.7.4 Digital inputs

HEINZMANN control units of the PRIAMOS III series feature 10 digital inputs. Another port may be configured as a further digital input if required, [↑ 19.7.1 Selectable inputs/outputs](#).

Input	Plug pin
Digital input 1	T2
Digital input 2	V2
Digital input 3	P2
Digital input 4	H2
Digital input 5	S2
Digital input 6	R2
Digital input 7	D2
Digital input 8	G2
Digital input 9	F2
Digital input 10	E2
Digital input 11*	E3

*configurable as PWM input

Table 72: PRIAMOS III : Digital inputs

19.7.5 Analogue outputs

The **HEINZMANN** control units of the PRIAMOS III series feature two outputs, which can be implemented either as current or as voltage output.

Output	Plug pin	Type	Range
Analogue output 1	J3	Current	4..20 mA
	K3	Voltage	0..5 V
Analogue output 2	G3	Current	4..20 mA
	S3	Voltage	0..5 V

Table 73: PRIAMOS III : Analogue outputs

19.7.6 PWM outputs

The **HEINZMANN** control units of the PRIAMOS III series are equipped with three configurable outputs that can be utilized as PWM outputs, [↑ 19.7.1 Selectable inputs/outputs](#).

Input	Plug pin	Frequency range	Type	Power (max.)
PWM output 1 [*]	S1	128...4000 Hz	low side	1 A
PWM output 2 [*]	X1	128...4000 Hz	low side	1 A
PWM output 3 [*]	A4	128...4000 Hz	low side	1 A

^{*}digital output also possible

Table 74: PRIAMOS III: PWM outputs

19.7.7 Digital outputs

The **HEINZMANN** controls of the PRIAMOS series are equipped with a maximum of three digital outputs. The required parameter settings for the assignment are described in chapter [↑]19.7.1 *Selectable inputs/outputs*.

Output	Plug pin	Type	Power (max.)
Digital output 1 [*]	S1	low side	1 A
Digital output 2 [*]	X1	low side	1 A
Digital output 3 [*]	A4	low side	1 A

^{*}also configurable as PWM output

Table 75: PRIAMOS III: Digital outputs

19.7.8 Fixed alarm outputs

The control units of the PRIAMOS III series provide dedicated outputs pre-configured for error-indication and overspeed.

The overspeed output is provided as a relay output to enable a separate overspeed protection to be activated by this output. For a description of how to adjust overspeed, chapter [↑]6.4 *Overspeed monitoring* offers a description of adjustment of overspeed and of the control unit's response to overspeeding. It should be noted that the output is triggered for each error intended to lead to an engine stop ([↑]27.7 *Emergency shutdown errors*), not just when overspeed is detected. The engine stop is achieved – independently from the existence of a separate overspeed protection device – by the control unit itself, that forcefully pulls the actuator in “0” position. A separate overspeed protection is important for all situations in which the actuator can no longer be moved and is therefore indispensable.

As to its meaning, the output “Control unit operative” is identical with the overspeed output and serves to indicate that no fatal error such as overspeed has occurred and that the governor is able to control engine speed.

The common alarm output is activated when the control has detected at least one error or sent out a warning. The output may be used for a visual or audible signal. The

common alarm output 3826 *LED_CommonAlarm* is described in detail in the chapter [↑ 27 Error Handling](#) which will also deal with the possible error causes.

The common alarm as well as the overspeed output may be more heavily loaded than the other governor outputs. The following table shows the pin assignments of the alarm outputs.

Output	Plug pin	Type	Power (max.)
Overspeed	E1	high side	3 A
Control ready	C2	high side	3 A
Common alarm	B2	low side	1 A

Table 76: PRIAMOS III: Fixed alarm outputs



Note

When initializing the digital control, the common alarm output is activated for about 500 ms

19.8 XIOS

All ports on the universally configurable control unit, type XIOS, must be configured with regard to their meaning and direction.

The XIOS consists of a main board, known as the C module, an extender board, known as the D module, and eleven slots for so-called A modules. Five of these slots are located on the main board (C module) and six are on the extender board (D module). Both the C and D module have the option of using inputs and outputs directly. The A modules are available for I/O extension.

The inputs/outputs of the A modules are referred to as "channel" if they are looked at in isolation, but inputs/outputs with reference to the slots or connector pins are referred to as "port". The XIOS can operate 117 ports in the maximum expansion stage.

Due to the wide range of options offered by the XIOS with the plug-on modules, it is not advisable to divide the ports according to analogue, PWM and binary inputs or outputs from the outset as is the case in other control units. Instead, every port must be configured, specifying whether something is connected to it and, if yes, what.

The ports are numbered according to the following table and each A module slot is always assigned eight ports (of which max. 6 are used by the A7 module, however).



Note

The configuration of the XIOS system described below can be achieved very easily and conveniently using a special window in DcDesk 2000.

19.8.1 Module types

Module type	Ports	Usage options
A Expander module	01 – 08, slot C1	Analogue input Temperature input Binary input Actuator feedback (only SL1, SL2 and SL5) Analogue output Binary output PWM output Actuator control (only SL1, SL2 and SL5)
	09 – 16, slot C2	
	17 – 24, slot C3	
	25 – 32, slot C4	
	33 – 40, slot C5	
	41 – 48, slot D1	
	49 – 56, slot D2	
	57 – 64, slot D3	
	65 – 72, slot D4	
	73 – 80, slot D5	
	81 – 88, slot D6	
C Main board	01 – 40	5 slots for A modules, C1 – C5, s.a.
	89	Binary input, pull down Speed input (Hall sensor) Frequency input (Hall sensor) PWM input
	90	Binary input, pull down Speed input (Hall sensor) Frequency input (Hall sensor)
	91 – 92	Binary output, low side, 4 A
	93 – 103	Analogue input, 0...5 V Binary input, pull down
D Expander board	41 – 88	6 slots for A modules, D1 – D6, s.a.
	104	Binary input, pull down Speed input (inductive sensor) Frequency input (inductive sensor)
	105	Binary input, pull down Speed input (inductive sensor) Frequency input (inductive sensor)
	106 – 107	Binary input, pull down
	108 – 109	Binary output, low side, 4 A
	110 – 117	Analogue input, 0...10 V Binary input, pull down

Table 77: XIOS – module types

19.8.2 A module versions

In the following three tables, the different A modules are listed sorted according to input and output modules.

Module	Meaning	Type	Config.	Channels
A1	Thermocouple -10..+75 mV	K	5	2
		J	6	
		N	7	
		R	8	
		T	9	
		B	10	
		E	11	
Both channels are galvanically isolated. A non-galvanically isolated terminal for the thermal compensation of the two channels via sensor PT1000 is present on the same slot (this means that the C module analogue input on the connector is no longer available).				
A3	Voltage	0...5 V	1	4
		0...5 V, pull-up	38	
		0...10 V	2	
		0...36 V	3	
	Current	0...31.24 mA	4	
	Temperature	0.05...60 kΩ	12...21	
	Binary	Pull-up	23	
All four channels are applied to one signal ground and connected internally with "-BAT". Sensor supply, standard equipment 5 V, 40 mA <u>Equipment versions</u> 1. Sensor supply 12 V or +VBAT_p 2. Second sensor supply (the C module analogue input on the connector is no longer present)				
A4	Voltage	0...5 V	1	2
		0...10 V	2	
		0...36 V	3	
	Current	0...31,24 mA	4	
	Temperature	0.05...60 kΩ	12...21	
	Binary	Pull down	22	
		Pull-up	23	
Both channels are galvanically isolated				

Module	Meaning	Type	Config.	Channels
	Sensor supply 5 V, 40 mA equipment version: Second sensor supply 5 V, 40 mA (the C module analogue input on the connector is no longer present)			
A7	Binary	Pull down	22	6
	All 6 channels are applied to one signal ground and connected internally with "-BAT". The C module analogue input is no longer present.			

Table 78: XIOS - input A modules

Module	Meaning	Type	Config.	Channels
A2	Voltage	0...5 V	29	4
	Current	0...24 mA	30	
	Binary, 1.2 A	high-side	31	
		low-side	32	
	PWM, 100 mA	high-side	33	
		low-side	34	
		half bridge	35	
All 4 channels are applied to one signal ground and connected internally with "-BAT".				
A5	Voltage only channel 1 and 3	0...5 V	29	2
	Current only channel 1 and 3	0...22.2 mA	30	
	Binary, 400 mA only channel 2 and 4	low side	32	2
	Galvanically isolated islands Isolated island A with channel 1 and 2 Isolated island B with channel 3 and 4			
A6	Voltage	0...5 V	29	2
	Current	0...24 mA	30	
	Both channels are galvanically isolated. Output current and output voltage are measured.			
A8	Binary, 4 A	high-side	31	2
		low-side	32	
	PWM, 3 A,	high-side	33	

Module	Meaning	Type	Config.	Channels
	126...300 Hz	low-side	34	
Both channels are connected internally with "-BAT" and "+BAT" and have safety functions, measurement of the output current for diagnosis. A8 can only be connected on the slots SL1, SL2 and SL5.				

Table 79: XIOS - output A modules

Module	Meaning	Type	Config.	Channels
A9	Actuator, 2 kHz (4 A static, 11 A brief)	H-bridge	36	1
	Current- controlled proportional valve 0.1...2 A, +/- 1%, T=10 ms	H-bridge	39	
	Feedback	ElySION	37	1
		Analogue, 0...5 V, pull- up	38	
The control channel is connected internally with "-BAT" and "+BAT", has safety functions and measurement of the output current for diagnostic purposes and current control in the proportional valve. When the analogue feedback is used, the C module analogue input on the connector is no longer available. A9 can only be connected on the slots SL1, SL2 and SL5.				

Table 80: XIOS – actuator module A9

19.8.3 Maximum number of inputs and outputs

Because each of the 117 ports on the XIOS has different uses, there are an endless number of combination options for input and output types. The two tables below provide a brief overview of the theoretical maximum values if the device were to be equipped with just one single type.

Input type		A	C	D	C+D	Maximum
Voltage	0...5 V	44	11	-	11	55
	0...10 V	44	-	8	8	54
	0...36 V	44	-	-	-	44

Current	0...31.24 mA	44	-	-	-	44
Temperature	Thermocouple	22	-	-	-	22
	Resistance	44	-	-	-	44
PWM		-	1	-	1	1
Binary		66	13	12	25	91
Pickup	Hall sensor	-	2	-	4	4
	Inductive sensor	-	-	2		

Table 81: XIOS – maximum number of inputs

Output type		A	C	D	C+D	Maximum
Analogue		44	-	-	-	44
PWM		44	-	-	-	44
Binary		44	2	2	4	48

Table 82: XIOS – maximum number of outputs

Actuator		A9	C	D	C+D	Maximum
Amplifier Actuator HEINZMANN	4Q	3	-	-	-	3
Feedback Actuator HEINZMANN	Analogue	3	-	-	-	
	ElySION	3	-	-	-	
Current-controlled proportional valve		3				

Table 83: XIOS – maximum number of actuators

The table also shows what can be achieved with the C module or the C plus D module alone, without considering the options afforded by the A modules.

The possible alternatives available for each port must be taken into account for a real application.

19.8.4 Minimum configuration for speed governors and positioners

The main board (C module) alone has two Hall sensor speed inputs, up to eleven voltage inputs and thirteen binary inputs and up to two binary outputs, but no temperature measurement and no actuator control or feedback. This means that, if no external actuator or electronic fuel injection with connection via the CAN bus are to be used, at least one A9 module is required.

The main board with an A9 module on slot C1 is therefore the minimum configuration for a speed governor with Hall sensor pickup and an actuator with analogue or Elyson feedback.

The same configuration level is also the minimum configuration for a positioner with external setpoint selection for an actuator.

This means that, for a positioner with three actuators, three analogue inputs on the mainboard are required for the external setpoint selection and three A9 modules for the control and feedback of the actuators.

19.8.5 Pin assignment

The following table lists the pin assignment on the eleven slots of the C module depending on which A module is connected. Input modules are shown in blue, output modules are shown in green. A9 is a bi-directional actuator module.

Pin	no A module	A1	A2	A3	A4	A5	A6	A7	A8	A9
									only on SL1, SL, SL5	
		2x TC in.	4x AO	4x AI	2x is. AI	2x is. AO+DO	2x is. AO	6x DI	2x Power-DO	1x StG-IO
on GND	2x isol. island	on GND	on GND	2x isol. island	2x isol. island	2x isol. island	on GND	on GND	on GND	
1	AIx	- (PT1000)	AIx	AIx or suppl. 2 (n.b.)	Ch2 suppl. (+5 V)	Ch2 suppl. (+5 V)	Ch2 suppl. (+5 V)	Ch6	AIx	FB Analogue
2	-	GND	GND	GND	Ch2 GND	Ch2 GND	Ch2 GND	GND	Ch2	-out
3	-	Ch2 signal -	Ch4 signal	Ch4 signal	-	Ch2 signal DO	-	Ch5	-	Elyson FB_L
4	-	Ch2 signal +	Ch3 signal	Ch3 signal	Ch2 signal	Ch2 signal AO	Ch2 signal	Ch4	-	Elyson FB_H
5	-	Ch1 signal +	Ch2 signal	Ch2 signal	-	Ch1 signal DO	-	Ch3	-	-
6	-	Ch1 signal -	Ch1 signal	Ch1 signal	Ch1 signal	Ch1 signal AO	Ch1 signal	Ch2	-	GND
7	-	GND	GND	GND	Ch1 GND	Ch1 GND	Ch1 GND	GND	Ch1	+out
8	-	-	-	Suppl.1 (+5 V)	Ch1 suppl. (+5 V)	Ch1 suppl. (+5 V)	Ch1 suppl. (+5 V)	Ch1	-	Suppl. (+8 V)

Table 84: XIOS - pin assignment A modules on slots

19.8.6 Port configuration

All 117 ports on the XIOS must be configured with regard to meaning and direction [↑]19.12.1 Module types. Depending on the add-on board used on a slot, it is possible that not all ports that are assigned to this slot are used (or can be used). The port numbering always remains the same, however. An A module uses the slot ports from the first specified through to the total number of channels of the module (exception: A5).

The meanings of the configuration values for each individual port are listed separately for inputs and outputs in the following two tables. The corresponding configuration parameters are available from 24000 *P001_(C1.1)_Config*.

Unused ports and ports that are not present – including on unused slots – must be given the configuration value 0.

Config.	Channel type	Module	Section
0	Port is not used	-	
1	Analogue input, 0...5 V	A3, A4 C	
2	Analogue input, 0...10 V	A3, A4 D	
3	Analogue input, 0...36 V	A3, A4	
4	Analogue input, 0...31.24 mA	A3, A4	
5	Thermocouple input, type K	A1	
6	Thermocouple input, type J		
7	Thermocouple input, type N		
8	Thermocouple input, type R		
9	Thermocouple input, type B		
10	Thermocouple input, type T		
11	Thermocouple input, type E	A3, A4	
12	Temperature input, PT100		
13	Temperature input, PT200		
14	Temperature input, PT1000		
15	Temperature input, Ni1000		
16	Temperature input, NTC 0...60 kΩ		
17	Temperature input, 0...5 kΩ		
18	Temperature input, 0...5 kΩ		
19	Temperature input, 0...5 kΩ		
20	Temperature input, 0...60 kΩ		
21	Temperature input, 0...60 kΩ		

Config.	Channel type	Module	Section
22	Binary input	A4, C, D	
23	Binary input with internal pull-up	A3, A4	
24	PWM input	C	
25	Speed input, reaction to falling edge	C, D	
26	Speed input, reaction to rising edge	C, D	
27	Frequency input, reaction to falling edge	C, D	
28	Frequency input, reaction to rising edge	C, D	
37	ElySION actuator feedback	A9	↑ 19.12.6.9.2 Feedback
38	Analogue actuator feedback, with internal pull-up		

Table 85: XIOS - input channel types

Config.	Channel type	Module	Section
29	Analogue output, 0...5 V	A2, A6	
	Analogue output, 0...5 V only channel 1 and 3 can be used	A5	
30	Analogue output, 0...22.2 mA only channel 1 and 3 can be used	A5	
	Analogue output, 0...24 mA	A2, A6	
31	Binary output, high side	A2, A8	
32	Binary output, low side A5 only channel 2 and 4 can be used	A2, A5, A8	
33	PWM output, high side	A2, A8	
34	PWM output, low side	A2, A8	
35	PWM output, half bridge	A2	
36	Actuator control	A9	

Table 86: XIOS - output channel types



Note

Once the port configuration has been defined, the parameters must be saved and a reset carried out so that the corresponding parameters and measured

values are shown in the correct physical unit (↑ 3.2 Saving data and ↑ 3.10 Reset of control unit).

The configuration is checked during the control unit initialization during booting or after each reset. The parameters from 22000 *P001_(1.1)_Function* show which function is correctly assigned to the relevant port.

The configuration is only successful if all 117 parameters from 22000 *P001_(1.1)_Function* are identical with those from 24000 *P001_(1.1)_Config*. Incorrectly parametrised ports receive the value 0 in the *Function* and a configuration error is shown in 3000 *ConfigurationError*. The relevant channel is not operated.



Warning

HEINZMANN recommends carrying out the configuration while the drive is not yet wired. This is to prevent sensors which are already (or still) connected from being damaged by any reconfiguration of inputs to outputs or vice versa.

19.8.6.1 Analogue inputs

The modules C, D, A3 and A4 are available for analogue inputs. The A modules can be connected to any slot. This means that all ports 1 to 84, 93 to 103 and 110 to 117 can be used. The parameter for port 1 is shown as an example:

Parameter	Meaning
24000 <i>P001_(C1.1)_Config</i>	Selection of the sensor type 1: 0...5 V 2: 0...10 V 3: 0...36 V 4: 0...31,24 mA

Table 87: XIOS – port configuration analogue inputs

Module A4 has a maximum of two galvanically isolated analogue inputs. Therefore, only the first two ports of the respective slot can be used here – the other six ports must be configured with 0.



Note

The analogue input of the C module (port 93...103) is no longer available on the slot when a number of A modules are used ↑ 19.12.2 A module versions.

Parametrization example:

Module A4 is used with a voltage and a current input on slot C2. The two inputs of the module are therefore on ports 9 and 10. The remaining ports of the slot must be set with 0.

Number	Parameter	Value	Unit
24008	<i>P009_(C2.1)_Config</i>	1	
24009	<i>P010_(C2.2)_Config</i>	4	
24010	<i>P011_(C2.3)_Config</i>	0	
24011	<i>P012_(C2.4)_Config</i>	0	
24012	<i>P013_(C2.5)_Config</i>	0	
24013	<i>P014_(C2.6)_Config</i>	0	
24014	<i>P015_(C2.7)_Config</i>	0	
24015	<i>P016_(C2.8)_Config</i>	0	

19.8.6.2 Temperature inputs

Thermocouples and resistance sensors up to a measurement range of 60 kΩ can be connected on the XIOS.

A1 modules must be used for thermocouples, A3 or A4 modules are used for other temperatures sensors. The A modules can be connected to any position, which means that, in principle, all ports 1 to 84 can be used. The parameter for port 1 is shown as an example:

Parameter	Meaning
24000 <i>P001_(C1.1)_Config</i>	5..21: Selection of the temperature sensor type

Table 88: XIOS – port configuration temperature inputs

A maximum of 2 temperature sensors can be connected to A1 and A4 modules. Therefore, only the first two ports of the respective slot can be assigned in this case – the following six ports must be configured with 0.

The corresponding analogue input of the C module is no longer available on a slot when the A1 module is used. For the temperature compensation of the thermocouple, a PT1000 resistor must be attached on pin 1 instead.

For each temperature sensor, a characteristic is required, which provides the temperature from the relevant resistance or voltage values. The characteristics for the twelve most common temperature sensor types (including the thermocouple) are saved in the control unit and can be selected with the configuration type.


The characteristic for NTC sensors and five further freely selectable characteristics for resistance sensors can be assigned themselves as required, as with NTC sensors in particular, there are a large number with different characteristics. It is important to remember that the free types 17..19 have a value range up to 5 kΩ, while the types 16, 20 and 21 go up to 60 kΩ.

Configuration	Channel type	Characteristic
5	Thermocouple, type K	fixed
6	Thermocouple, type J	fixed
7	Thermocouple, type N	fixed
8	Thermocouple, type R	fixed
9	Thermocouple, type B	fixed
10	Thermocouple, type T	fixed
11	Thermocouple, type E	fixed
12	PT100	fixed
13	PT200	fixed
14	PT1000	fixed
15	Ni1000	fixed
16	NTC 0 – 60000 Ω	7700 <i>TempLinNTC:Ohm</i> 7720 <i>TempLinNTC:T</i>
17	freely definable temperature sensor, 0 – 5000 Ω	7740 <i>TempLinUser1:Ohm</i> 7760 <i>TempLinUser1:T</i>
18	freely definable temperature sensor, 0 – 5000 Ω	7780 <i>TempLinUser2:Ohm</i> 7800 <i>TempLinUser2:T</i>
19	freely definable temperature sensor, 0 – 5000 Ω	7820 <i>TempLinUser3:Ohm</i> 7840 <i>TempLinUser3:T</i>
20	freely definable temperature sensor, 0 – 60000 Ω	7860 <i>TempLinUser4:Ohm</i> 7880 <i>TempLinUser4:T</i>
21	freely definable temperature sensor, 0 – 60000 Ω	7900 <i>TempLinUser5:Ohm</i> 7920 <i>TempLinUser5:T</i>

Table 89: XIOS – port configuration temperature sensors

19.8.6.3 PWM input

Of all ports, only port 89 can be used as the PWM input on the C module. All relevant parameters are listed below.



Port 89 is not available as a PWM input, if it is used for a speed or frequency input (↑ 19.12.6.5 Speed and frequency inputs).

Parameter	Meaning
24088 <i>P089_(MC.D11)_Config</i>	24: Selection as PWM input

Table 90: XIOS – port configuration PWM input

19.8.6.4 Binary inputs

The modules C, D, A3, A4 and A7 are available for binary inputs. The A modules can be connected to any slot. This means that ports 1 to 90, 93 to 107 and 110 to 117 can be used.

The table shows the parameter for port 1 as an example.

Parameter	Meaning
24000 <i>P001_(C1.1)_Config</i>	Selection as binary input 22: Binary input 23: Binary input with internal pull-up

Table 91: XIOS – port configuration binary inputs

Module A4 has max. two galvanically isolated binary inputs, which means that, here too, only the first two ports of the relevant slot can be used. The remaining six ports must be configured with 0.

Module A7 is the only module with 6 inputs, i.e. all ports and all eight pins of the connector strip on the relevant slot are used. This means that the analogue input, GND and sensor supply are no longer available on this slot of the C or D module.

19.8.6.5 Speed and frequency inputs

The ports 89 and 90 on the C module and 104 and 105 on the D module can be used as speed or frequency inputs. The ports 89 and 90 on module C are only approved for Hall sensors and ports 104 and 105 on module D are only approved for inductive sensors.

Hall sensors must be supplied and 5 V or 12 V are available as POW SIC. A second sensor supply POW SID is available on the expansion module D, which can also be configured on 5 V or 12 V:

4032 *SensorSupplyMC5VOr12V* 1 = 5 V, 0 = 12 V

4033 *SensorSupplyMD5VOr12V* 1 = 5 V, 0 = 12 V

The input frequency of the ports must not exceed 15 kHz.



Info

Port 89 is not available as a speed or frequency input if it is used for a PWM input (↑ 19.12.6.3 PWM input).

19.8.6.5.1 Speed measurement

The table shows the parameter for port 90 as an example.

Parameter	Meaning
24089 <i>P090_(MC.DI2)_Config</i>	Selection as speed input 25: Reaction to falling edge 26: Reaction to rising edge

Table 92: XIOS – port configuration speed inputs

After one or two ports have been configured as speed inputs, the assignment to Pickup1 and possibly Pickup2 still has to be carried out.

Parameter	Meaning
4030 <i>PickUp1PortNo</i>	Definition of the channel that Pickup1 is connected to only 89, 90, 104 or 105 possible Use only if 4000 <i>PickUp1On</i> = 1
4031 <i>PickUp2PortNo</i>	Definition of the channel that Pickup2 is connected to only 89, 90, 104 or 105 possible Use only if 4002 <i>PickUp2On</i> = 1

Table 93: XIOS – port assignment to pickup sensors

19.8.6.5.2 Frequency measurement

The table shows the parameter for port 90 as an example.

Parameter	Meaning
24089 <i>P090_(MC.DI2)_Config</i>	Selection as frequency input 27: Reaction to falling edge 28: Reaction to rising edge

Table 94: XIOS – port configuration frequency inputs

19.8.6.6 Analogue outputs

The modules A2, A5 and A6 are available for analogue outputs. They can be connected anywhere, meaning that ports 1 to 84 can be used. The example shows parametrisation as performed on port 1.

Parameter	Meaning
24000 P001_(C1.1)_Config	Selection of the analogue output type 29: 0...5 V 30: 0...24 mA

Table 95: XIOS – port configuration analogue outputs

A maximum of 2 galvanically isolated analogue outputs can be connected to modules A5 and A6. Therefore, only the first 2 ports of the slot that is in use can be configured in this case – the other 6 ports must receive 0 as the configuration value. Module A2 can operate four analogue outputs - here too, the remaining four ports must be configured with 0.

19.8.6.7 PWM outputs

The modules A2 and A8 are available for PWM outputs. They can be connected anywhere, meaning that ports 1 to 84 can be used. The example shows parametrisation as performed on port 1.

Parameter	Meaning
24000 P001_(C1.1)_Config	Selection of the PWM output type 33: high side 34: low side 35: half bridge

Table 96: XIOS – port configuration PWM outputs

A maximum of 2 PWM outputs can be connected to module A8. Therefore, only the first 2 ports of the respective slot can be used in this case – the other 6 ports must receive 0 as the configuration value. Module A2 can operate four PWM outputs, the remaining four ports must therefore be configured with 0.

19.8.6.8 Binary outputs

The modules C, D, A2, A5 and A8 are available for binary outputs. The A modules A2 and A5 can be connected anywhere, meaning that ports 1 to 88, 91, 92, 108 and 109 can be used. The example shows parametrisation as performed on port 1.

Parameter	Meaning
24000 <i>P001_(C1.1)_Config</i>	Selection of the binary output type 31: high side 32: low side

Table 97: XIOS – port configuration binary outputs

A maximum of 2 binary outputs can be connected to modules A5 and A8. Therefore, only the first two ports of the slot that is in use can be configured in this case – the other 6 ports must be given 0 as the configuration value. Module A2 can operate four binary outputs, the remaining four ports must be configured with 0.

19.8.6.9 Actuator configuration

Module A9 is used for actuator control and feedback. Actuator 1 is assigned to slot C1, actuator 2 is operated via slot C2 and actuator 3 via slot C5, other slots are not approved for the A9 module.

It is essential that both the control and the feedback channel are configured for the required actuators (up to three). It is also essential that the actuator 1 on slot C1 is used for speed governors (diesel or gas engine). On dual-fuel engines, the diesel actuator is on slot 1 and one or two gas actuators are on slot 2 and 3 if the gas is not supplied via an external device.

19.8.6.9.1 Control

The first channel of the A9 module is available for the control, which means that channels 1, 9 and 33 can be used for this.

Actuator	Parameter	Meaning
1	24000 <i>P001_(C1.1)_Config</i>	36: Selection as actuator control (amplifier)
2	24008 <i>P009_(C2.1)_Config</i>	
3	24032 <i>P033_(C5.1)_Config</i>	

Table 98: XIOS – port configuration actuator control

19.8.6.9.2 Feedback

HEINZMANN actuators use either an analogue signal with a voltage range of approx. 1.6 V to 2.8 V for the feedback, or a high-precision digital, so-called ElySION feedback. The 0...5 V input of the C module on the relevant slot is used for the analogue feedback. This is therefore no longer available separately. In this case, it is wired internally with a pull-up resistor. This is a safety requirement if the feedback fails.

The second port of the A9 module must be used for the feedback parametrisation, which means that the channels 2, 10 and 34 are available.

Actuator	Parameter	Meaning
1	24001 <i>P002_(C1.2)_Config</i>	Selection of the feedback type
2	24009 <i>P010_(C2.2)_Config</i>	37: ElySION feedback
3	24033 <i>P034_(C5.2)_Config</i>	38: Analogue feedback

Table 99: XIOS – port configuration actuator feedback

20 Configuring the control's inputs and outputs

20.1 Digital inputs

Configuring of digital inputs is described in detail in chapter [↑ 18 Configuration of switching functions](#).

20.2 Analogue inputs

20.2.1 Calibration of current/voltage inputs

Sensors convert physical quantities (e.g., pressure) to electric quantities (voltage, current). The control unit measures voltage/current and indicates them directly (ARCHIMEDES, ORION, PANDAROS) or in digits/percent (HELENOS, PRIAMOS) of the sensor range. To enable the control to operate with the physical value transmitted by the sensor, it is necessary that the control be provided with two reference values informing it about the relation between the electrically measured values and the actual physical quantities. The two reference values are the sensor output values associated with the minimum and maximum measuring. With this information, the control is capable of normalizing the measured values and of displaying them specified in per cent of the sensor range or directly in terms of their physical values.




Fig. 44: Calibration procedure

Each of the voltage/current inputs is associated with a low reference value (parameters 15xx *AnalogInx_RefLow*) and a high reference value (parameters 15xx *AnalogInx_RefHigh*). If the sensor signal is inverted the low reference value absolutely may be higher than the high reference value.

Parameterizing example for HELENOS/PRIAMOS:

A boost pressure sensor has been connected to input 3. Its measuring range is supposed to be from 0.5 bar to 3.5 bar and is to be converted into voltages ranging from 1.0 V to 4.8 V. At minimum voltage the parameter 3531 *AnalogIn3_Value* will indicate a value of 9,000 and at maximum voltage a value of 35,000. The parameter 3530 *AnalogIn3* will display the actual measurement as related to the reference values in per cent, and the parameter 2904 *BoostPressure* will read the converted measuring value in bar.

Number	Parameter	Value	Unit
904	<i>AssignIn_BoostPress</i>	3	
982	<i>BoostPressSensorLow</i>	0.5	bar
983	<i>BoostPressSensorHigh</i>	3.5	bar
1530	<i>AnalogIn3_RefLow</i>	9000	digit
1531	<i>AnalogIn3_RefHigh</i>	35000	digit
4904	<i>ChanType_BoostPress</i>	0	

Parameterizing example for ARCHIMEDES, ORION, PANDAROS:

A boost pressure sensor has been connected to input 2. Its measuring range is supposed to be from 0.5 bar to 3.5 bar and is to be converted into voltages ranging from 1.0 V to 4.8 V. Parameter 3520 *AnalogIn2* will display the actual measurement in V and parameter 2904 *BoostPressure* will read the converted measuring value in bar.

Number	Parameter	Value	Unit
904	<i>AssignIn_BoostPress</i>	2	
982	<i>BoostPressSensorLow</i>	0.5	bar
983	<i>BoostPressSensorHigh</i>	3.5	bar
1530	<i>AnalogIn3_RefLow</i>	1.0	V
1531	<i>AnalogIn3_RefHigh</i>	4.8	V
4904	<i>ChanType_BoostPress</i>	0	

20.2.1.1 Using current/voltage inputs for temperature sensors

If the number of available temperature inputs is not sufficient for the required sensors, the temperature sensors may also be connected to the first four current or voltage inputs via a transducer. This function is available on request. To make the temperatures known to the control device a linearization characteristic must be enabled starting from parameter 7800 as for the temperature inputs.

78xx SensorLinx:digit and *78xx SensorLinx:T*

Assignment of one of these characteristics to an analogue input starting from 5512 is done with

55xx AnalogInx_TempLin characteristic selection for analogue input x.

To select the first of the characteristics, enter the value from 1, 2 for the second, and so on. If a 0 is assigned, the related current/voltage input will not be used for a temperature.

When a temperature characteristic is used, the parameters *15xx AnalogInx_RefLow* and *15xx AnalogInx_RefHigh* are no longer necessary.

20.2.2 Calibration of temperature inputs

Due to the non-linear behaviour of temperature sensor signals, two reference values will not suffice to precisely determine temperature. For this reason, linearization characteristics must be introduced. In most control units the number of defined characteristics is equal to the number of temperature inputs although this is not necessary for so many different sensor types are rarely used.

By means of the parameters *TempInx_SensorType* it is decided for each single temperature channel by which characteristic the respective sensor is to be scaled. The parameters relating to sensor type are to be found starting from the following numbers:

ARCHIMEDES:	<i>5570 TempIn1_SensorType</i>
HELENOS:	<i>5550 TempIn1_SensorType</i>
ORION:	no temperature input
PANDAROS:	<i>5540 TempIn_SensorType</i>
PRIAMOS:	<i>5590 TempIn1_SensorType</i>

The value "0" selects the first linearization characteristic, the value "1" the second etc.

The values defining temperature linearization are stored at the parameter positions following *7900 TempLin1:digit(0)* and *7920 TempLin1:T(0)*. To parameterize the characteristics up to 10 pairs of values are available for each.

In most control units the possible temperature sensor types are pre-defined in the factory. If other types of sensor are used, the characteristics may be adapted accordingly. This applies in particular to NTC sensors, since their characteristic is not standardized, but may change according to the sensor used. It must be noted that in all cases the control unit hardware pre-determines the possible sensor type (e.g., PT 1000 or PT 200).

20.2.3 Filtering of analogue inputs

The measured value of an analogue input can be filtered through a digital filter. The respective parameters are stored at the numbers *15x4 AnalogInx_Filter*.

Each of these parameters is to hold a filter value ranging from 1 to 255. The value 1 signifies that there will be no filtering. The filtering time constant for the control units HELENOS and PRIAMOS can be derived from the filter values by the following equation:

$$\tau = \frac{\text{filtering value}}{64} \text{ [s].}$$

For control units of the types ARCHIMEDES, ORION and PANDAROS the equation is the following

$$\tau = \frac{\text{filtering value}}{62.5} \text{ [s].}$$

For normally fast sensor changes filter value 8 will be best suited. For measuring quantities that change more slowly, such as temperatures, a filter value of about 50 can be used. The filtering time constant should correspond approximately to the sensor's time constant.

Parameterizing Example:

Number	Parameter	Value	Unit
1524	AnalogIn2_Filter	8	

Time constant for HELENOS, PRIAMOS:

$$\tau = \frac{8}{64} \text{ [s]} = 0.125 \text{ s}$$

Time constant for ARCHIMEDES, ORION, PANDAROS:

$$\tau = \frac{8}{62.5} \text{ [s]} = 0.128 \text{ s}$$

20.2.4 Error detection for analogue inputs

If a sensor fails (e.g., by short circuit or cable break), the control will read voltages or currents lying outside the normal measuring range. These irregular measuring values can be used to define inadmissible operating ranges by which the control can recognize that the sensor is at fault.

The error limits are entered in electric units for the control units ARCHIMEDES, ORION and PANDAROS and in digits for the control units HELENOS and PRIAMOS.

The parameters 15x2 *AnalogInx_ErrorLow* and *TempInx_ErrorLow* define the lower error limits. The parameters 15x3 *AnalogInx_ErrorHigh* and *TempInx_ErrorHigh* determine the upper error limits.

Parameterizing Example:

The boost pressure sensor connected to analogue input 3 normally supplies measuring values ranging between 9,000 and 35,000. In case of a short circuit or a cable break the measurements will be below or above these values, respectively. The ranges below 7,000 and above 38,000 are defined as inadmissible by the following parameters:

Number	Parameter	Value	Unit
--------	-----------	-------	------

904	<i>AssignIn_BoostPress</i>	3
1530	<i>AnalogIn3_RefLow</i>	9000.0
1531	<i>AnalogIn3_RefHigh</i>	35000.0
1532	<i>AnalogIn3_ErrorLow</i>	7000.0
1533	<i>AnalogIn3_ErrorHigh</i>	38000.0
4904	<i>ChanType_BoostPress</i>	0

These error limits should not be chosen too close to the minimum and maximum values in order to prevent natural fluctuations of the values measured by the sensors from being mistaken as errors. On the other hand, it must be ensured that short circuits or cable breaks are unambiguously recognized as such.

Once an error is detected, the sensor error parameter (error flag) associated with the analogue input is set. For the actions to be taken in the event that any such error occurs, please refer to chapter [↑ 27.8 Error parameter list](#). If an analogue input is not used due to not being assigned to a sensor it will not be monitored for errors.

20.2.5 Overview of the parameters associated with analogue inputs

For inputs relating to setpoints and pressure the following parameters are provided:

Parameter	Meaning
15x0 <i>AnalogInx_RefLow</i>	lower reference value
15x1 <i>AnalogInx_RefHigh</i>	upper reference value
15x2 <i>AnalogInx_ErrLow</i>	lower error limit
15x3 <i>AnalogInx_ErrHigh</i>	upper error limit
15x4 <i>AnalogInx_Filter</i>	filtering constant
35x0 <i>AnalogInx</i>	current measuring value in %
35x1 <i>AnalogInx_Value</i>	current measuring value in digits (HELENOS, PRIAMOS) or electrical unit (others) ARCHIMEDES: referenced by 3603 <i>5VRefAnalog/TempIn1</i> to 3606 <i>5VRefAnalog/TempIn4</i> PANDAROS/ORION: referenced by 3603 <i>5V_Ref</i>
55xx <i>AnalogInx_TempLin</i>	selection of linearization characteristic if the input is used for a temperature sensor (on request)

Table 100: Parameters for analogue inputs

For temperature inputs the following parameters are provided:

Parameter	Meaning
15x2/7 <i>TempIny_ErrorLow</i>	lower error limit
15x3/8 <i>TempIny_ErrorHigh</i>	upper error limit
15x4/9 <i>TempIny_Filter</i>	filtering constant
35x0/5 <i>TempIny</i>	current measuring value in °C
35x1/6 <i>TempIny_Value</i>	current measuring value in digits ARCHIMEDES: referenced by 3603 <i>5VRefAnalog/TempIn1</i> to 3606 <i>5VRefAnalog/TempIn4</i> PANDAROS/ORION: referenced by 3603 <i>5V_Ref</i>
55x0 <i>TempIny_SensorType</i>	selection of linearization characteristic for temperature sensor

Table 101: Parameters for temperature inputs

Any inputs that have not been assigned a sensor (\uparrow 17 *Configuration of sensors*) will not be monitored for errors, and indicate only the measuring value 35xx *AnalogInx_Value* resp. *TempIny_Value*.

20.3 PWM inputs

Transmission of the PWM signal typically uses a range from 5 % to 95 % PWM. To standardize the measuring range, the lower reference values must be entered in parameters 1500 *PWMInx_RefLow* and the upper reference values in parameters 1501 *PWMInx_RefHigh*. If the sensor signal is inverted the low reference value absolutely may be higher than the high reference value.

The measuring parameters starting from 3500 *PWMInx* will indicate the PWM ratio, and the measuring parameters starting from 3501 *FrequencyInx* the PWM frequency.

Selection as a PWM sensor is to be made as described in chapter \uparrow 17 *Configuration of sensors*. Assignment to the sensors is to be conducted as explained in chapter \uparrow 17.3 *Assigning the inputs to the sensors and setpoint adjusters*.

Parameterizing Example:

The setpoint adjuster 2 is to set speed by means of a PWM ratio of between 5% and 95%.

Number	Parameter	Value	Unit
901	<i>AssignIn_Setp2Ext</i>	1	
1500	<i>PWMIn1_RefLow</i>	5	%
1501	<i>PWMIn1_RefHigh</i>	95	%
4901	<i>ChanTyp_Setp2Ext</i>	1	

20.3.1 Error detection at PWM inputs

The following failure causes will be detected at the PWM input and indicated as errors of the assigned sensor:

- PWM signal is missing
- Frequency exceeds the maximum admissible frequency by 25% (ARCHIMEDES and PANDAROS: 500 Hz, HELENOS and PRIAMOS: 1000 Hz). In this case, the PWM input is switched off in order to minimize interrupt stress for the control.
- The PWM ratio lies outside the error limits, that are equivalent to half the lower reference parameter (starting from 1500 *PWMIn1_RefLow*) and the average between the higher reference parameter (starting from 1501 *PWMIn1_RefHigh*) and 100%.

20.4 XIOS

20.4.1 Current/voltage inputs

The following parameters are available for all analogue inputs, port 1 is shown as an example:

Parameter	Meaning
30020 <i>P001_(C1.1)_IO_RefLow</i>	lower reference value or threshold, below which the binary value 0 is generated (during assignment to the switching function)
30021 <i>P001_(C1.1)_IO_RefHigh</i>	upper reference value or threshold, above which the binary value 1 is generated (during assignment to the switching function)
30022 <i>P001_(C1.1)_AI_ErrLow</i>	lower error limit
30023 <i>P001_(C1.1)_AI_ErrHigh</i>	upper error limit
30024 <i>P001_(C1.1)_AI_Filter</i>	filtering constant
32020 <i>P001_(C1.1)_AI</i>	current measured value in %
32021 <i>P001_(C1.1)_AI_Value</i>	current measured value in electric unit

Table 102: XIOS – parameters analogue inputs

The meaning of the reference values and of the error limits is explained in [↑ 19.8 XIOS](#). A filter value of 0.12 s must be used for normally fast sensor changes. For measuring quantities that change more slowly, such as temperatures, a filter value of about 0.8 can be used. The filtering time constant should correspond approximately to the sensor's time constant.

While binary inputs are usually assigned to the switching functions, it is also possible to assign analogue inputs to enable the switching function to be monitored for cable breaks. In this case, 30020 *P001_(C1.1)_IO_RefLow* is not the low reference, but the threshold below which the binary value 0 is generated and 30021 *P001_(C1.1)_IO_RefHigh* is the threshold above which the binary value 1 is applied. The other parameters retain their meaning.

20.4.2 Temperature inputs

The following parameters are available for temperature inputs, port 1 is shown as an example:

Parameter	Meaning
30022 <i>P001_(C1.1)_AI_ErrLow</i>	lower error limit
30023 <i>P001_(C1.1)_AI_ErrHigh</i>	upper error limit
30024 <i>P001_(C1.1)_AI_Filter</i>	filtering constant
32020 <i>P001_(C1.1)_AI</i>	current measured value in °C
32021 <i>P001_(C1.1)_AI_Value</i>	current measured value in Ω or mV

Table 103: XIOS – parameter temperature inputs

20.4.3 PWM input

Of all ports, only port 89 can be used as the PWM input on the C module. All relevant parameters are listed below.

Parameter	Meaning
30012 <i>P089_(MC.D11)_IO_RefLow</i>	Lower duty cycle
30013 <i>P089_(MC.D11)_IO_RefHigh</i>	Upper duty cycle
30014 <i>P089_(MC.D11)_PI_Filter</i>	Filter value
32012 <i>P089_(MC.D11)_PI_PWMIn</i>	current PWM measured value
32013 <i>P089_(MC.D11)_PI_PWMFreq</i>	current PWM frequency

Table 104: XIOS – parameter PWM input

The duty cycle can be [0, 100]%, but [10, 90]% of the PWM ratio is normally used in order to enable monitoring.

If RefLow is smaller than RefHigh, [10, 90] % duty cycle results in a sensor value of [0,100] %. However, if the low duty cycle is entered in RefHigh and the high duty cycle is entered in RefLow, the sensor signal is read in inverted, meaning that [10, 90] % results in a sensor value of [100, 0] %.

A filter value of 0.12 s must be used for normally fast sensor changes. The filtering time constant should correspond approximately to the connected sensor's time constant.

The following error causes are detected on the PWM input and displayed as an error on the assigned sensor:

- PWM signal is missing
- The frequency is 25 % higher than the maximum permitted frequency of 1000 Hz. In this case, the PWM input is switched off in order to minimize interrupt stress for the control unit.
- The PWM ratio is not within the error limits, which correspond respectively to half of the low duty cycle and the mid-point between the high duty cycle and 100 %.

20.4.4 Binary inputs

The assignment of a binary input to switching functions is described in [↑ 20.4.4 Binary inputs](#).

20.4.5 Frequency inputs

Two frequency inputs are on the C module and two on the D module. The table shows the parameters for port 90 on the C module as an example.

Parameter	Meaning
30003 P090_(MC.DI2)_FI_TOutFact	timeout factor
30004 P090_(MC.DI2)_FI_ErrLimit	error limit
30005 P090_(MC.DI2)_FI_Filter	filtering constant
32003 P090_(MC.DI2)_FI_FreqIn	measured frequency

Table 105: XIOS – parameters frequency inputs

The timeout factor can be used to specify when a missing signal should result in an error. The period after which the missing signal is detected depends on the last measured valid frequency with the relevant factor applied.

The error limit (max. 15 kHz) is used to monitor the frequency, which must not exceed this value, in order to minimize the interrupt stress on the system.

The assignment of a frequency input to sensors, e.g. a speed sensor, is described in [↑ 18 Configuration of switching functions](#).

20.5 Analogue outputs

20.5.1 Assignment of output parameters to analogue outputs

Every parameter of the control unit can be read out via analogue outputs. This is achieved by assigning to the desired output x starting from 1640 *AnalogOutx_Assign* the parameter number of the measuring value that is to be read out.



Note

Output parameters are named AnalogOut if the output signal can be configured as current or voltage. Otherwise they are named according to signal type CurrentOut or VoltOut .

Parameterizing Example:

We want to read out speed (indication parameter 2000) from analogue output 1 and fuel quantity (indication parameter 2350) from analogue output 2.

Number	Parameter	Value	Unit
1640	<i>AnalogOut1_Assign</i>	2000	
1645	<i>AnalogOut2_Assign</i>	2350	



Note

Signal output can be inverted (e.g., low current for high speeds) by entering the parameter numbers negative in sign.

20.5.2 Value range of output parameters

When values are read out, sometimes it is convenient not to read out the entire range but only a part of it, for instance one might not wish to see the whole control unit's speed range of 0..4000 rpm on an instrument but only the actually used range of 700..2100 rpm.

It is therefore possible to limit the output range with parameters 16x3 *AnalogOutx_ValueMin* and 16x4 *AnalogOutx_ValueMax*.

As there are a great many different value ranges, these parameters are to be set to the required low and high output values specified in per cent of the value range of the respective output parameter. If the entire value range is required, the minimum value is to be set to 0 % and the maximum value to 100 %.



Note

The PC programme DcDesk 2000 allows to display output ranges in the parameter's specific measurement unit.

Parameterizing Example:

Current speed 2000 *Speed* is to be read out via a current output of 4..20 mA. The output range shall be restricted to 500 rpm through 1500 rpm. i.e., 500 rpm correspond to 4 mA and 1500 rpm to 20 mA. Since the values of this parameter have a range from 0 to 4000 rpm, output will have to be adjusted accordingly:




Fig. 45: Reading out a parameter via an analogue output

$$1643 \text{ AnalogOut1_ValueMin} = \frac{500}{4000} * 100\% = 12,5\%$$

$$1644 \text{ AnalogOut1_ValueMax} = \frac{1500}{4000} * 100\% = 37,5\%$$

<u>Number</u>	<u>Parameter</u>	<u>Value</u>	<u>Unit</u>
1640	AnalogOut1_Assign	2000	
1643	AnalogOut1_ValueMin	12.5	%
1644	AnalogOut1_ValueMax	37.5	%

20.5.3 Value range of analogue outputs

Analogue outputs can be defined as current outputs or as voltage outputs.

In the majority of cases, particularly with current outputs, not the maximum output range of approx. 0..22 mA is required but the standard output range of 4..20 mA.

Parameters 16x1 *AnalogOutx_RefLow* and 16x2 *AnalogOutx_RefHigh* are provided to adapt the output range. The value to be entered relates to the maximum output value and must be specified in per cent for HELENOS and PRIAMOS type control units. For all other control units the output range may be specified directly in electric units.



Note

The determination of the connection type (current or voltage) cannot be altered during operation. It will therefore be necessary to save the data (↑ 3.2 Saving data) and restart the control unit with a ↑ 3.10 Reset of control unit after configuration. The value ranges of analogue outputs then must be adapted again to the newly chosen electric unit.

Parameterizing Example:

Current speed 2000 *Speed* is to be output out via a current output of 4..20 mA, but with the range restricted to 500 rpm to 1500 rpm, Only the range from 500 rpm to 1500 rpm is to be output, i.e., 500 rpm correspond to 4 mA and 1500 rpm correspond to 20 mA.

Parametrizing example for ARCHIMEDES/PANDAROS:

Number	Parameter	Value	Unit
1640	<i>CurrentOut1_Assign</i>	2000	
1641	<i>CurrentOut1_RefLow</i>	4.00	mA
1642	<i>CurrentOut1_RefHigh</i>	20.00	mA
1643	<i>CurrentOut1_ValueMin</i>	12.5	%
1644	<i>CurrentOut1_ValueMax</i>	37.5	%

Parameterizing example for HELENOS/PRIAMOS:

$$1641 \text{ CurrentOut1_RefLow} = \frac{4}{22} * 100\% = 18,2\%$$

$$1642 \text{ CurrentOut1_RefHigh} = \frac{20}{22} * 100\% = 90,9\%$$

Number	Parameter	Value	Unit
1640	<i>CurrentOut1_Assign</i>	2000	
1641	<i>CurrentOut1_RefLow</i>	18.2	%
1642	<i>CurrentOut1_RefHigh</i>	90.9	%
1643	<i>CurrentOut1_ValueMin</i>	12.5	%
1644	<i>CurrentOut1_ValueMax</i>	37.5	%



Note

Due to component tolerances of the series HELENOS and PRIAMOS the output range for the same parameter values may differ from one control unit to the next. To ensure accuracy of output, the output ranges should be measured and the parameters accordingly adjusted. When parameters are copied from one control unit to another this set of configuration values should be excluded.

20.6 PWM outputs

20.6.1 Assignment of PWM outputs

Every parameter of the control unit can be read out via PWM outputs. To this purpose, all you have to do is to assign its parameter number to the desired output to 1600 *PWMOut1_Assign*. This makes sense only for measurement or indication values with a value range greater than [0,1], but in the control itself no limitations are implemented.

Signal output can be inverted (e.g., small PWM ratio for high speeds) by entering the parameter numbers negative in sign. The effect of the parameter number being entered with a negative sign will be that there is a long high-phase for small output values and a short high-phase for large ones.

Parameterizing Example:

PWM output 1 is to be used to read out speed (indication parameter 2000 *Speed*), and output 2 to read out injection quantity (indication parameter 2350 *FuelQuantity*).

Number	Parameter	Value	Unit
1600	<i>PWMOut1_Assign</i>	2000	
1605	<i>PWMOut2_Assign</i>	2350	

20.6.2 Value range of output parameters

When values are to be read out, it will sometimes not be the entire range that is of interest but only a restricted one. Therefore, output via the first PWM output can be adapted to the desired range by means of parameters 1603 *PWMOut1_ValueMin* and 1604 *PWMOut1_ValueMax*. As there are a great many different value ranges, these parameters are to be set to the required low and high output values specified in per cent of the value range of the respective output parameter.

If the entire value range is required, the minimum value is to be set to 0 % and the maximum value to 100 %.

Parameterizing Example:

Actual speed 2000 *Speed* is to be read out via a PWM output, restricted to the range from 500 rpm to 1500 rpm. i.e., 500 rpm correspond to 5 % and 1500 rpm correspond to 95 %. As the values of this parameter have a range from 0 to 4000 rpm, output will have to be adapted:

$$\text{PWMOut1_ValueMin} = \frac{500}{4000} * 100\% = 12,5\%$$

$$\text{PWMOut1_ValueMax} = \frac{1500}{4000} * 100\% = 37,5\%$$

Number	Parameter	Value	Unit
1600	<i>PWMOut1_Assign</i>	2000	
1603	<i>PWMOut1_ValueMin</i>	12.5	%
1604	<i>PWMOut1_ValueMax</i>	37.5	%




Fig. 46: Reading out a parameter via a PWM output

20.6.3 Value range of PWM outputs

Normally, only a PWM ratio between 5 % and 95 % will be required.

To adapt the output range of the first PWM output the parameters 1601 *PWMOut1_RefLow* and 1602 *PWMOut1_RefHigh* are to be used. The limit values may be specified directly in per cent PWM ratio.

The frequency of the PWM signals can be jointly adjusted for all outputs by means of the parameter 1625 *PWMOutFrequency*. For the power output (PWM output 5) of the control unit HELENOS (↑ *Table 44: HELENOS: PWM outputs*) the frequency is determined separately with parameter 1626 *PowerOutFrequency*.

Parameterizing Example:

Actual speed 2000 *Speed* is to be read out via PWM output 1 using a pulse-pause-ratio of 5..95 %. Only the range from 500 rpm to 1500 rpm is to be output, i.e. 500 rpm will correspond to 5 % and 1500 rpm to 95 % PWM ratio. Frequency is to be set to 500 Hz.

Number	Parameter	Value	Unit
1600	<i>PWMOut1_Assign</i>	2000	
1601	<i>PWMOut1_RefLow</i>	5	%
1602	<i>PWMOut1_RefHigh</i>	95	%
1603	<i>PWMOut1_ValueMin</i>	12.5	%
1604	<i>PWMOut1_ValueMax</i>	37.5	%
1625	<i>PWMOutFrequency</i>	500	Hz

20.7 Dedicated alarm outputs

The control units of the PRIAMOS and HELENOS series provide dedicated outputs that have been pre-configured for indication of errors and overspeed.

With both series, the overspeed output is provided as a relay output to enable a separate overspeed protection to be activated by this output. For a description of how to adjust overspeed, chapter [↑ 6.4 Overspeed monitoring](#) offers a description of adjustment of overspeed and of the control unit's response to overspeeding.

As to its meaning, the output "Control unit operative" is identical with the overspeed output and serves to indicate that no fatal error such as overspeed has occurred and that the governor is able to control engine speed.

The common alarm output is activated when the control has detected at least one error. The output may be used for a visual or audible signal. The common alarm output is described in detail in the chapter [↑ 27.3.1 Common alarm output](#), which will also deal with the possible error causes.



Note

When initializing the PRIAMOS system, the common alarm output is activated for about 500 ms.

20.8 Digital outputs

A digital output may be assigned to each measurement or indication value with value range [0,1] in parameter list 2. Two variants are possible, only one of which is implemented in the firmware of the control unit. Either each digital output is assigned exactly one output value (so called simple allocation) or several values may be assigned to each digital output (so called multiple allocation – only on request).

The values currently output are displayed by parameter 2851 *DigitalOut1* and subsequent parameters.



Note

The parameter settings described in the following sections – in particular multiple allocation – can be achieved in an easy and comfortable way using a dedicated window of DcDesk 2000. In addition, this window allows to conduct a test of the digital output's connections.

20.8.1 Simple allocation

Assignment is made by means of the parameters starting from 851 *DigitalOut1_Assign*. The parameter numbers of the desired measuring values must be entered there. If inverted output of the measurement is desired, the number of the measuring parameter is to be entered negative in sign.

Parameterizing Example:

Output 1 is to indicate "Fuel quantity limited by boost pressure" (\uparrow 2714 *BoostLimitActive*) and output 2 to indicate "Oil pressure warning" (\uparrow 3030 *ErrOilPressWarn*). You wish output 3 to be active as long as engine start has not been enabled (i.e., as long as \uparrow 3806 *EngineRelease* has not been activated).

<u>Number</u>	<u>Parameter</u>	<u>Value</u>	<u>Unit</u>
851	<i>DigitalOut1_Assign</i>	2714	
852	<i>DigitalOut2_Assign</i>	3030	
853	<i>DigitalOut3_Assign</i>	-3806	

20.8.2 Multiple allocation

Using multiple allocation, up to 8 output values may be assigned to each digital output. The maximum amount is defined in the firmware and cannot be augmented. But it is possible to use less values than the maximum.

This type of allocation makes sense whenever it is necessary to visualize a number of error parameters greater than the number of available digital outputs. The related parameter numbers must be entered in the parameter fields starting from 8800 *DigitalOut1:Param(0)..(7)*. If you wish to negate an allocation parameter, its parameter number must be entered with negative sign.

The current values of these single output parameter now may either be linked by logic operator for output on the digital output or configured to produce different blinking codes. The preferred alternative may be chosen separately for each digital output.

To do this, indicate the logical link you wish to use or the value 80 Hex if your prefer a blinking code in the parameters starting from 4851 *DigitalOut1:Logic*.

If only one parameter is to be assigned to an output (as in simple allocation) a "0" must be entered in the respective parameter starting from 4851 *DigitalOut1:Logic*.

20.8.3 Logical operators

The value for the logical operation in 4851 *DigitalOut1:Logic* consists of single bits. Bit value 0 corresponds to the logic operator AND and bit value 1 to the logic operator OR. The lowest bit represents the operator between the allocation parameters 1 and 2, the following bit between assignment parameters 2 and 3 and so forth. With a maximum of eight allocation parameters this allows a maximum of seven operators, equivalent to a value between 0 and 7F Hex. The processing

sequence is from the lowest to the highest allocation parameter. Bracketing is not possible.

20.8.3.1 Blinking signals

If, instead of a logical operation the value 80 Hex was entered in 4851 *DigitalOut1:Logic*, the digital output visualizes blinking signals. If the first allocation parameter is active, the output emits the following blinking signal:

2 short, 1* long, 2* short*

for the second allocation parameter

2 short, 2* long, 2* short*

for the third

2 short, 3* long, 2* short*

and so on. In between signals there is a pause to better distinguish the single errors. If, for instance, both the first and the third allocation parameters are active, the resulting blinking signal is as follows:




Fig. 47: Blinking signal

By counting along with the long blinks it is possible to determine which parameter is active. The operator of the system must be informed which type of blinking signal is assigned to which error.

20.8.3.2 Blinking and continuous light

Operators frequently wish to visualize error messages in form of blinking signals, and to allocate a continuous light to one or more specific errors of particular importance (values with high priority). The parameters starting from 4880 *DigitalOut1:Prior* can be used for this purpose.

Each set bit means that the active state of the related parameter in 8800 *DigitalOut1:Param(0)..(7)* is to generate a continuous light on the digital output. All other values with a 0 in the priority bit continue to generate blinking signals – please note that these are visible only if no value of higher priority is active.

It is recommended to start the allocation of parameter numbers to the digital output from the blinking signals and to put the ones with high priority at the end of the field.

Parameterizing Example:

The control unit allows to indicate up to four parameters for each digital output.

- output 1 is to
 - blink once if oil pressure is too low (3030 *ErrOilPressWarn*),
 - blink twice if coolant temperature is too high (3032 *ErrCoolantTempWarn*),

blink thrice if exhaust gas temperature is too high (3041

ErrExhaustTempWarn),

be lit continuously if oil pressure is so low that engine has to be stopped (3031

ErrOilPressEcy)

- we want output 2 to indicate pick-up errors (3001 *ErrPickUp1* or 3002 *ErrPickUp2*)
- output 3 is to be active as long as engine start has not been enabled (i.e., as long as 3806 *EngineRelease* has not been activated).

Number	Parameter	Value	Unit
4851	<i>DigitalOut1:Logic</i>	80	Hex (blinking)
4852	<i>DigitalOut2:Logic</i>	01	Hex (logical OR)
4853	<i>DigitalOut3:Logic</i>	00	Hex (single parameter)
4880	<i>DigitalOut1:Prior</i>	08	Hex (continuously lit 4 th parameter)
4881	<i>DigitalOut2:Prior</i>	00	Hex (not used)
4882	<i>DigitalOut3:Prior</i>	00	Hex (not used)
8800	<i>DigitalOut1:Param(0)</i>	3030	
8801	<i>DigitalOut1:Param(1)</i>	3032	
8802	<i>DigitalOut1:Param(2)</i>	3041	
8803	<i>DigitalOut1:Param(3)</i>	3031	
8810	<i>DigitalOut2:Param(0)</i>	3001	
8811	<i>DigitalOut2:Param(1)</i>	3002	
8812	<i>DigitalOut2:Param(2)</i>	0	
8813	<i>DigitalOut2:Param(3)</i>	0	
8820	<i>DigitalOut3:Param(0)</i>	-3806	
8821	<i>DigitalOut3:Param(1)</i>	0	
8822	<i>DigitalOut3:Param(2)</i>	0	
8823	<i>DigitalOut3:Param(3)</i>	0	

20.8.4 XIOS

20.8.4.1 Analogue outputs

The example shows parametrisation as performed on port 1.

Parameter	Meaning
30020 <i>P001_(1.1)_IO_RefLow</i>	Lower reference value, e.g. 0.5 V or 4 mA
30021 <i>P001_(1.1)_IO_RefHigh</i>	Upper reference value, e.g. 4.5 V or 20 mA

Table 106: XIOS – analogue outputs

20.8.4.2 PWM outputs

The example shows parametrisation as performed on port 1.

Parameter	Meaning
-----------	---------

Parameter	Meaning
30020 <i>P001_(1.1)_IO_RefLow</i>	low duty cycle, e.g. 10 %
30021 <i>P001_(1.1)_IO_RefHigh</i>	high duty cycle, e.g. 90 %
30025 <i>P001_(1.1)_PO_Freq</i>	Output frequency

Table 107: XIOS – PWM outputs

20.8.5 Other control units

20.8.5.1 Analogue outputs

The analogue outputs can be designed as current outputs or voltage outputs. However, for the voltage outputs in particular, it is usually not the maximum output range of approx. 0...22 mA that is desired but the standard output range of 4...20 mA.

The parameters

1641 *AnalogOutx_RefLow*

1642 *AnalogOutx_RefHigh*

are available for adjusting the output range. The value to be entered relates to the maximum output value and must be specified in per cent for DC 1 and DC 2 type control units. In all other control units, the output range can be parametrised in the electrical unit itself.



The definition of the connection type (current or voltage) cannot be altered during operation. It will therefore be necessary to save the parameters (↑ 3.2 Saving data) and reset the control unit (↑ 3.10 Reset of control unit) after configuration. The value ranges of analogue outputs must then be adapted to the newly selected electric unit.

Parametrization example:

A value is to be output over a current output with 4..20 mA.

Parametrization example DC 1/DC 2:

$$1641 \text{ CurrentOut1_RefLow} = \frac{4}{22} * 100\% = 18,2\%$$

$$1642 \text{ CurrentOut1_RefHigh} = \frac{20}{22} * 100\% = 90,9\%$$

Number	Parameter	Value	Unit
1641	<i>CurrentOut1_RefLow</i>	18.2	%
1642	<i>CurrentOut1_RefHigh</i>	90.9	%



Due to component tolerances of the series DC 1 and DC 2 the output range for the same parameter values may differ from one control unit to the next. To ensure accuracy of output, the output ranges should be measured and the parameters adjusted accordingly. When copying parameters from one control unit to another, these configuration values must therefore be excluded or at least noted down separately and transferred back.

Parametrization example otherwise:

<u>Number</u>	<u>Parameter</u>	<u>Value</u>	<u>Unit</u>
1641	<i>CurrentOut1_RefLow</i>	4,00	mA
1642	<i>CurrentOut1_RefHigh</i>	20,00	mA

20.8.5.2 PWM outputs

A PWM ratio of between 10 and 90 % is normally desired. The parameters 1601 *PWMOut1_RefLow* and 1602 *PWMOut1_RefHigh* should be used to adjust the output range. The limits are entered directly as a percentage of the PWM ratio.

On the DC 7, there are two separate frequency parameters 1625 *PWMOut1_Frequency* and 1626 *PWMOut2_Frequency* for the two PWM outputs.

For the power output (PWM output 5) of the control unit DC 2, the frequency is determined separately with parameter 1626 *PowerOutFrequency*.

Otherwise, the frequency of the PWM signals can be set for all PWM outputs together with the parameter 1625 *PWMOutFrequency*.

Parametrization example:

PWM output 1 should be operated with 5..95 % pulse-pause ratio. A frequency of 500 Hz must be set.

<u>Number</u>	<u>Parameter</u>	<u>Value</u>	<u>Unit</u>
1601	<i>PWMOut1_RefLow</i>	5	%
1602	<i>PWMOut1_RefHigh</i>	95	%
1625	<i>PWMOutFrequency</i>	500	Hz

21 Technical data

21.1 ARCHIMEDES

The system ARCHIMEDES is based on DC 5 type control units. To these control units the following technical data apply.

21.1.1 General

Rated voltage	12 V DC or 24 V DC,
Min. voltage	8 V DC (for a short time during engine start)
Reverse polarity protection	yes
Max. voltage	32 V DC
Current consumption	max. 7 A, max. 11 A for max. 60 seconds
Fuse protection of control unit	35 A
Storage temperature	-40°C to +85°C
Operating temperature range	-40°C to +80°C
EMI	Directives RL95/54/EC, EN13309, ISO13766, EN55011 K1.A, EN50081-2 CE: EN 61000-6-2, Road vehicles, resistance to electric disturbances: ISO 11452-2, -5 Road vehicles, impulses: ISO 7637-2, ISO 7637-3

21.1.2 Inputs and outputs

2 measured speed inputs	for inductive sensors, with $f_i = 25$ to 9000 Hz, $U_i = 0.5$ to 30 V AC $R_{pu} = 10$ k Ω
Analogue inputs 1..4	$U = 0.5$ V, $R_e = 220$ k Ω , $f_g = 15$ Hz
Analogue input 5	$U = 0.5$ V, $R_e = 100$ k Ω , $f_g = 15$ Hz or $I = 4 \dots 20$ mA, $V_{source} > 7$ V, $R_e = 200$ Ω , $f_g = 15$ Hz
Analogue input 6	$U = 0.37$ V, $R_e = 34.8$ k Ω , $f_g = 15$ Hz
Temperature inputs 1..4	for PT1000, NI1000 or NTC
4 reference voltages for	$U_{ref} = 5$ V ± 125 mV, $I_{ref} < 30$ mA analogue inputs 1..4 and temperature inputs 1..4
Digital inputs 1..6	$U_0 < 1$ V, $U_1 > 6$ V, $R_{pd} = 64$ k Ω
Digital inputs 1..6	together optionally $R_{pu/pd} = 4.75$ k Ω , on request
Digital input 7	$U_0 < 1$ V, $U_1 > 6$ V, $R_{pd} = 64$ k Ω , optional $R_{pu/pd} = 4.75$ k Ω , on request
Digital input 8	$U_0 < 1$ V, $U_1 > 6$ V, $R_{pd} = 64$ k Ω , optional $R_{pu/pd} = 4.75$ k Ω , on request
PWM output 1..2	$I_{sink} < 0.43$ A, low-side switching
PWM output 3	$I_{sink} < 1.3$ A, low-side switching

Digital outputs 1..4	$I_{\text{source}} < 2.5 \text{ A}$, high-side
Digital outputs 5..6	$I_{\text{source}} < 12 \text{ A}$, high-side
Digital output 7	$I_{\text{sink}} < 0.43 \text{ A}$, low-side switching
Switching output error lamp	$I_{\text{sink}} < 0.43 \text{ A}$, low-side switching
Operating magnet output	$I < 7 \text{ A}$, $I < 11 \text{ A}$ for $T < 60 \text{ s}$, PWM
Actuator travel monitoring	inside actuator, with reference feedback
Serial communication	HZM interface, up to 57600 baud
CAN communication	ISO/DIS 11898, standard/extended identifier, baud rate up to 1 MBit/s
Modbus communication	RS 232

21.2 HELENOS

The system HELENOS is based on DC 2-01 type control units. It is suited for connection of HEINZMANN actuators and the Bosch EDC pump. To these control units the following technical data apply.

21.2.1 General

Rated voltage	24 VDC (12 VDC special variant on request)	
Min. voltage	9 V DC (for a short time during engine start)	
Max. voltage	35 V DC	
Residual ripple at max. current	max. 10% at 100Hz	
Fuse protection of control unit	16 A	
Max. current consumption	200 mA + actuator current	
Storage temperature	-55°C to +85°C	
Operating temperature range	-40°C to +70°C	
Air humidity	up to 98% % at 55°C, condensing	
Shock	50 g, 11 ms- half sine	
Isolation resistance	> 1 MOhm at 48 V DC	
Protection grade	DC ...2 - 01 - 00	IP 00
	DC ...2 - 01 - 55	IP 55
Weight	DC ...2 - 01 - 00	approx. 1.2 kg
	DC ...2 - 01 - 55	approx. 3 kg
EMI	EN 50081-1, EN50082-2	

21.2.2 Inputs and outputs

2 speed inputs	for inductive sensors, $f_i = 25..9000\text{Hz}$, $U_i = 0.5..30\text{VAC}$ for hall sensor on request
Actuator output	PWM with 2000Hz, $I_{\text{eff}} < 6.4\text{A}$
Reference voltage for setpoint adjuster	$U_{\text{ref}} = 5\text{VDC}$ $I_{\text{max}} = 20\text{mA}$ (10mA 12V variant)

Actuator travel monitoring	inside actuator with reference feedback $U_{\text{Reg.weg}} = 1.4..3.0\text{V}$, $U_{\text{ref}} = 8\text{ VDC}$, $I_{\text{ref}} < 20\text{mA}$
1 temperature input	for PT 1000 (PT 200, NTC on request PT 200: measuring range $100^{\circ}\text{C}..850^{\circ}\text{C}$)
1 temperature input	for NTC (PT1000, PT200 on request PT 200: measuring range $100^{\circ}\text{C}..850^{\circ}\text{C}$)
2 analogue voltage inputs	$U = 0..5\text{V}$, $f_g = 16\text{ Hz}$ for use with LMG 10 and SyG 02 on request
2 analogue current inputs	current input on request $I = 4..20\text{mA}$, $f_g = 16\text{ Hz}$ voltage inputs on request
4 digital inputs	$R_{\text{pd}} = 2.2\text{k}\Omega$, $f_g = 160\text{ Hz}$
4 digital/PWM inputs/outputs	$R_{\text{pu}} = 2.2\text{k}\Omega$, $I_{\text{sink}} < 0.1\text{A}$, $f_g = 160\text{Hz}$ - as inputs, low-side switching with internal pull-up - for outputs the relay interface RIF 01 is available, that respects the strict bus driver specification on the HELENOS side and on the output side allows a maximum current of 3 A at 24 V. Ordering Number: 620-00-041-00.
2 analogue current outputs	$I_{\text{out}} = 0..22.5\text{mA}$, $R_{\text{max}} = 470\Omega$ (125 Ω 12 V variant)
2 analogue voltage outputs	$U_{\text{out}} = 0..5\text{V}$ or $0..10\text{ V}$ (configurable), $R_{\text{min}} = 250\Omega$ (500 Ω 12 V variant)
1 PWM output	$I_{\text{sink}} < 3\text{ A}$ low-side switching
2 switching outputs error lamp	$I_{\text{sink}} < 3\text{ A}$ high-side switching
Serial interface	HZM interface, up to 57600 baud
CAN communication	on request, ISO/DIS 11898, standard/extended identifier, baud rate up to 1 MBit/s
Modbus communication	on request, RS 232 and RS 485

21.3 PANDAROS

The system PANDAROS is based on DC 6 type control units. To these control units the following technical data apply.

21.3.1 General

Rated voltage	12 V DC or 24 V DC,
Min. voltage	9 V DC (for a short time during engine start)
Max. voltage	32 V DC
Current consumption	max. 7 A max. 11 A for max. 60 secs
Fuse protection of control unit	12 A

Storage temperature	-40°C to +85°C
Operating temperature range	-40°C to +80°C
Operating temperature LCD	0°C to +50°C optionally -20°C to +70°C
Air humidity	up to 98% % at 55°C, condensing
Vibration	max. ±1.75 mm maximum at 10 to 21 Hz, max. 0.24 m/s maximum at 21 to 45 Hz max. 7 g at 45 to 400 Hz
Shock	30 g, 11 ms- half sine
Protection grade	IP 00
Insulation resistance	> 1 MOhm at 48 V DC
Weight	approx. 0.5 kg
EMI	EMI directives: 89/336/EEC, 95/54/EEC CE: EN 61000-6-2, EN 61000-6-4 Road vehicle: resistance to electric disturbances ISO 11452-2, -5 Road vehicle, impulses: ISO 7637-2, ISO 7637-3

21.3.2 Inputs and outputs

All inputs and outputs are reverse polarity protected and short-circuit-proof against battery plus and minus.

2 Speed inputs	- for inductive sensor - for Hall sensor or terminal W with $f_i = 25$ to 9000 Hz, $U_i = 0.5$ to 30 V AC
Temperature input	PT1000/NTC $U_i = 0..5V$, $R_i = 1.2$ k Ω
Reference voltage setpoint adjuster	$U_{ref} = 5$ V $\pm 125mV$, $I_{ref} < 30$ mA
Setpoint adjustment analogue	$U = 0..5$ V, $R_e = 100$ k Ω , $f_g = 15$ Hz or $I = 4 .. 20$ mA, $R_e = 200$ Ω , $f_g = 15$ Hz
Setpoint adjustment digital 1	$U_0 < 1$ V, $U_1 > 6$ V, $R_{pd} = 100$ k Ω
Setpoint adjustment digital 2	$U_0 < 1$ V, $U_1 > 6$ V, $R_{pd} = 100$ k Ω , optionally $R_{pu/pd} = 4.75$ k Ω
Digital input engine stop	$U_0 < 1$ V, $U_1 > 6$ V, $R_{pd} = 100$ k Ω , optionally $R_{pu/pd} = 4.75$ k Ω
Actuator travel monitoring	inside actuator, with reference feedback
Operating magnet output	$I < 7$ A, $I < 11$ A for $T < 60$ s, PWM
Digital output error lamp	$I_{sink} < 0.3$ A, low-side switching
2 multifunctional ports:	
Voltage input	$U_e = 0..10$ V, $R_e = 20$ k Ω , $f_g = 15$ Hz
or voltage input	$U_e = 0..5$ V, $R_e = 100$ k Ω , $f_g = 15$ Hz
or current input	$I_e = 4 .. 20$ mA, $R_e = 200$ Ω , $f_g = 15$ Hz
or digital input	$U_0 < 1$ V, $U_1 > 6$ V, $R_{pd} = 100$ k Ω , optionally $R_{pu/pd} = 4.75$ k Ω

or current output	$I_a = 4 \dots 20 \text{ mA}$
or digital output	$I_{\text{sink}} < 0.3 \text{ A}$, low-side switching optionally $R_{\text{pu/pd}} = 4.75 \text{ k}\Omega$
Serial communication	HZM interface, up to 57600 baud
CAN communication	ISO/DIS 11898, standard/extended identifier, baud rate up to 1 MBit/s

21.4 ORION

The digital system ORION is based on DC 9 type control units. To these control units the following technical data apply.

21.4.1 General

Operating voltage	12 V DC or 24 V DC,
Max. voltage	32 V DC
Min. voltage	9 V DC (for a short time during engine start)
Fuse protection of control unit	12 A
Current consumption total	max. 5 A in stable state 1.7 A
Storage temperature	-40°C to +85°C
Ambient temperature during operation	-40°C to +80°C
Air humidity	up to 98% % at 55°C, condensing
Vibration	max. $\pm 1.75 \text{ mm}$ at 10 to 21 Hz, max. 0.24 m/s at 21 to 45 Hz max. 7 g at 45 to 400 Hz
Shock	30 g, 11 ms- half sine
Protection grade	IP 00
Insulation resistance	> 1 MOhm at 48 V DC
Weight	approx. 0.5 kg
EMI	EMI directives: 89/336/EEC CE: EN 61000-6-2, EN 61000-6-4

21.4.2 Inputs and outputs

All inputs and outputs are reverse polarity protected and short-circuit-proof against battery plus and minus.

2 Speed inputs	- for inductive sensor - for Hall sensor or terminal W with $f_i = 25 \text{ to } 9000 \text{ Hz}$, $U_i = 0.5 \text{ to } 30 \text{ V AC}$
Actuator travel monitoring	inside actuator, with reference feedback
Operating magnet output	$I_{\text{max}} = 6.4 \text{ A}$, $I_{\text{dauer}} = 3.5 \text{ A}$
Digital output error lamp	$I_{\text{sink}} < 0.3 \text{ A}$, low-side switching
Reference voltage setpoint adjuster	$U_{\text{ref}} = 5 \text{ V} \pm 125 \text{ mV}$, $I_{\text{ref}} < 30 \text{ mA}$

Input terminal 7	analogue 0..5 V or 4..20 mA or digital $U_0 < 1 \text{ V}$, $U_1 > 6 \text{ V}$, $R_{pd} = 100 \text{ k}\Omega$
Analogue input terminal 4	0..5 V
Digital input terminal 9	$U_0 < 1 \text{ V}$, $U_1 > 6 \text{ V}$, $R_{pd} = 100 \text{ k}\Omega$
Digital input terminal 11	$U_0 < 1 \text{ V}$, $U_1 > 6 \text{ V}$, $R_{pd} = 100 \text{ k}\Omega$
Serial communication	HZM interface, up to 57600 baud

21.5 PRIAMOS

The system PRIAMOS is based on DC 1-03 type control units. It is suited for connection of HEINZMANN actuators and the Bosch EDC pump. For these control units the following technical data apply.

21.5.1 General

Rated op. voltage 1 (electronics)	24 V DC
Min. voltage	8 V DC (5 V DC for $t < 10\text{s}$) If supply voltage can fall below 8V for a prolonged period of time, an undervoltage protection is required; a stable 5V supply to external sensors is not guaranteed in this case.
Max. voltage	33 V DC
Current consumption	typically 250mA @ 24V (w/o CAN module) typically 0.68A @ 8V
Rated op. voltage 2 (end stage)	36 V DC STG90 requires a voltage limiter SBG01 to limit return voltage
Min. voltage	18V DC (36V DC for STG90)
Max. voltage	40 V DC
max. current consumption	12A peak for $t < 0.1\text{s}$
Residual ripple at max. actuator current	max. 10% @ 100Hz
Admissible voltage drop at max. power consumption	max. 10 % at control unit
Fuse protection of control unit	electronics 3A end stage 16A
Storage temperature	-55°C to +85°C
Operating temperature range	-40°C to +70°C
Air humidity	up to 98% % at 55°C, condensing
Vibration	$\leq 1\text{g}$, $\leq 100\text{Hz}$
Shock	50 g, 11 ms- half sine
Protection grade	IP 55
Insulation resistance	$> 1 \text{ MOhm}$ at 100 V DC

Weight	approx. 3 kg
EMI	EN 55011:1991-03 prEN50082-2:1994-08 GL Type-Approval-1:1993 DIN 40839 and VDE0879

21.5.2 Inputs and outputs

Speed inputs	2 * for inductive sensor (hall sensor on request) $f_i = 30..10\text{kHz}$, $U_i = 0.5..30\text{VAC}$, $f_g = 4.2\text{kHz}$ operating frequency range 200..6000Hz
Actuators output	1 * max. 9A / 12A peak
Actuator travel monitoring	inside actuator with reference feedback $U_{\text{Reg.weg}} = 1.6..2.8\text{V}$, $U_{\text{ref}} = 7.5\text{VDC}$, $I_{\text{ref}} < 10\text{mA}$ or PWM f. EDC pump
Reference voltage for setpoint adjuster	2 * 5V DC $\leq 30\text{mA}$ @24V (15mA @12V DC) rated operating voltage
Power supply for handheld programmer	8.2V / 100mA
Reference voltage for setpoint potentiometers	$U_{\text{ref}} = 5\text{V DC}$, $I_{\text{max}} = 20\text{mA}$ (10 mA)
Temperature inputs	1 * Ni1000 -50...+150°C 1 * NTC -40...110°C
Digital inputs	10 * 24VDC electroplated sep. with common ground $R_E = 5.7\text{k}\Omega$, $f_g = 300\text{Hz}$, "0" $\leq 2\text{V DC}$, "1" $\geq 5.5\text{V DC}$
PWM inputs	1x 5V..24V $R_E = 10\text{k}\Omega$, $f_g = 3\text{kHz}$ 1x 5V..10V $R_E = 2\text{k}\Omega$, $f_g = 10\text{kHz}$
Analogue inputs	5 * 4..20mA (or 0..5V)
Analogue outputs	2 * 0..5V (and 4..20mA)
Digital outputs	1 * low-side switch 3A with current measurement 3 * low-side switches 2.5A (PWM) with recovery diode 1x high-side output 2A
Serial communication	HZM interface, up to 57600 baud
CAN communication	ISO/DIS 11898, standard/extended identifier, baud rate up to 1 MBit/s

21.6 PRIAMOS III

The system PRIAMOS III is based on DC 1-04 type control units. It is suited for connection of HEINZMANN actuators and the Bosch EDC pump. To these control units the following technical data apply.

21.6.1 General

Rated operating voltage 1 (electronics)	24 V DC
Min. voltage	8 V DC (5 V DC for $t < 10s$) If supply voltage can fall below 8V for a prolonged period of time, an undervoltage protection is required; a stable 5V supply to external sensors is not guaranteed in this case.
Max. voltage	33 V DC
Current consumption	typically 320mA @ 24V (w/o CAN module) typically 1A @ 8V DC
Rated operating voltage 2 (end stage)	36 V DC STG90 and STG180 require a voltage limiter SBG01 to limit return voltage
Min. voltage	18V DC (36V DC for STG90, STG180)
Max. voltage	40 V DC
Max. current consumption	24A peak for $t < 0.1s$
Residual ripple at max. actuator current	max. 10% @ 100Hz
Admissible voltage drop at max. power consumption	max. 10 % at control unit
Fuse protection of control unit	electronics 3A end stage 16A
Storage temperature	-55°C to +85°C
Operating temperature range	-40°C to +70°C
Air humidity	up to 98% % at 55°C, condensing
Vibration	$\leq 1g$, $\leq 100Hz$
Shock	50 g, 11 ms- half sine
Protection type	IP 55
Insulation resistance	> 1 MOhm at 100 V DC
Weight	approx. 5 kg
EMI	EN 55011:1991-03 prEN50082-2:1994-08

21.6.2 Inputs and outputs

Speed inputs	2 * for inductive sensor (hall sensor on request) $f_i = 30..10\text{kHz}$, $U_i = 0.5..30\text{VAC}$, $f_g = 4.2\text{kHz}$ operating frequency range 200..6000Hz
Actuator outputs	3 * max. 9A / 12A peak
Actuator travel monitoring	inside actuator with reference feedback 1 * $U_{\text{Reg.weg}} = 1.6..2.8\text{V}$, $U_{\text{ref}} = 7.5\text{VDC}$, $I_{\text{ref}} < 10\text{mA}$ or PWM f. EDC pump 2 * $U_{\text{Reg.weg}} = 1.6..2.8\text{V}$, $U_{\text{ref}} = 7.5\text{VDC}$, $I_{\text{ref}} < 30\text{mA}$
Reference voltage for setpoint adjuster	2 * 5V DC $\leq 30\text{mA}$ @24V (15mA @12V DC) rated operating voltage
Power supply for handheld programmer	8.2V / 100mA
Reference voltage for setpoint potentiometers	$U_{\text{ref}} = 5\text{V DC}$, $I_{\text{max}} = 20\text{mA}$ (10 mA)
Temperature inputs	1 * Ni1000 -50...+150°C 1 * NTC -40...110°C
Digital inputs	10 * 24VDC electroplated sep. with common ground $R_E = 5.7\text{k}\Omega$, $f_g = 300\text{Hz}$, "0" $\leq 2\text{V DC}$, "1" $\geq 5.5\text{V DC}$
PWM inputs	1x 5V..24V $R_E = 10\text{k}\Omega$, $f_g = 3\text{kHz}$ 1x 5V..10V $R_E = 2\text{k}\Omega$, $f_g = 10\text{kHz}$
Analogue inputs	8 * 4..20mA (or 0..5V)
Analogue outputs	2 * 0..5V (and 4..20mA)
Digital outputs	1 * low-side switch 3A with current measurement 3 * low-side switches 2.5A (PWM) with recovery diode 1x high-side output 2A 2x low-side switches 500mA with recovery diode
Serial communication	HZM interface, up to 57600 baud
CAN communications	ISO/DIS 11898, standard/extended identifier, baud rate up to 1 MBit/s

21.7 XIOS

The technical data of this highly complex control unit is described in detail in $\hat{\uparrow}$ *XIOS universal control unit and extended I/O-modules, publication no. UC 14 001-d.*

21.7.1 Terminal 15

The XIOS control units from revision 7 are equipped with a so-called "terminal 15" function (in automotive electrics, the terminal designation is an ID number to make connecting cables easier. In Germany, the terminal designations are standardized in the DIN 72552.)

"Terminal 15" is a switched plus which is used to switch on the control unit. Even if the supply to the power section and the electronics is ensured, the control unit cannot be switched on without this contact.

If terminal 15 is removed, the control unit is not deactivated automatically, but enters a so-called follower control, where the engine is stopped immediately first of all and other tasks, such as saving the operating hours counter, are completed. Only then does the control unit switch off automatically.

The status of terminal 15 can be seen on parameter 3790 *IgnitionOn*. If this value is zero and the control unit is not yet deactivated, it is in follower control.



Warning

We strongly recommend shutting down the control unit via the terminal 15. A direct switch-off of the supply to the power section and the electronics prevents follower control from being carried out and may therefore only be carried out in absolute emergencies.

21.7.2 Terminal RC

The control units XIOS from revision 7 are equipped with a so-called "terminal RC" – "Ripcord" function. With the "Ripcord" function, the amplifiers are switched off in the hardware if a voltage over +8 V is measured on the terminal RC. If the voltage is below +3 V, the amplifiers work in normal operation. This means that there is the option of triggering an immediate shut down of the amplifiers externally. HEINZMANN recommends that the quick-closing valve should also be activated if the diesel supply is specified via one or several amplifiers.



Warning

On dual-fuel engines, the gas supply must be interrupted first before the diesel actuator is switched off for safety reasons!

22 Integrated control elements

22.1 Push buttons in PANDAROS and ORION series

On the left edge of the control unit's circuit board – above the 9-pin communication plug – there is a push button that can be used to request automatic actuator adjustment.

22.2 Rotary switches in PRIAMOS series

On the pc board of the control unit - immediately beside the seven-segment display and the LED display - a rotary switch is located which can be used to implement application specific functions. The current value of the rotary switch is displayed in parameter 2800 *RotarySwitch*. It can be read out only on turning the control on.

If the rotary switch is in position “1” ($2800 \text{ RotarySwitch} = 1$) during the control unit's start-up or reset, an automatic actuator calibration will be carried out once.

23 Bus Protocols

In many cases, data may have to be transferred from the control unit to an external device via a communication bus or it may be necessary to receive sensor values and/or switching functions from the external device. To this end, almost all HEINZMANN control units have at least one CAN bus interface, and sometimes also Modbus interfaces.

The control units DC 1 and DC 2 may be equipped with an add-on board featuring a CAN controller and corresponding CAN protocol. The add-on board of the DC 2 control unit also features an interface switchable from RS232 to RS485 and back, making it possible to have either a Modbus point-to-point connection or integration in a Modbus system in addition to the CAN protocol.

The DC 5 control unit features two integrated CAN controllers and an additional RS232 interface, allowing two CAN protocols and a Modbus point-to-point connection at the same time.

The DC 9 control unit is a stand-alone system that cannot be connected to a bus system, neither a CAN bus nor a Modbus system.

All other control units are equipped with an integrated CAN controller, but have no Modbus interface except for the XIOS.

	CAN controller	Modbus interface
DC 1	1 (on request)	-
DC 2	1 (on request)	RS232/RS485 (on request)
DC 5	2	RS232 (on request)
DC 6, DC 7	1	-
DC 8	1 (+1 on request)	-
DC 9	-	-
DC 10, DC 11, DC 12	1	-
XIOS	2	RS485

Table 108: Bus interfaces

The hardware interface is just one side of the coin. The most important thing is which protocol is running on the bus. ↑ *Tab. 2: Bus protocols* lists which firmware variants are implemented or can be integrated on request.

A CAN controller is normally able to run only one of the listed CAN protocols. If the HZM-CAN protocol is used, however, it will nevertheless be possible to use one of the two 11-bit protocols (CANopen or DeviceNet) on the same bus – if busload is high, a gateway may be required.

Bus system	Protocol	Note
CAN 29 bit identifier	HZM-CAN	between all digital HEINZMANN devices
	SAE J1939	standard for automotive applications
CAN 11 bit identifier	CANopen	CANopen slave, 12 additional TPDOs
	DeviceNet	slave in predefined master / slave connection set
	WAGO®	CANopen master
	ICENI®	CANopen master
Serial RS232	Modbus	Point-to-point connection
Serial RS485		Bus system

Table 109: Bus protocols

On request, customer-specific protocols can be integrated at any time if the hardware requirements are met.

The firmware variants of the HEINZMANN basic software can also be delivered with one of the above protocols as standard. A relevant protocol ID is added to the version number yy of the software number 00.yy.zz:

Protocol	ID
HZM-CAN customer module	50
Modbus	60
DeviceNet	70
SAE J1939	80
CANopen	90

Table 110: Firmware variants with bus protocols

The generator application 00.3.zz therefore becomes e.g. 00.63.zz if Modbus is implemented, or the vehicle application 00.1.zz becomes 00.81.zz if SAE J1939 is integrated. Otherwise, the function remains the same.

23.1 CAN protocol HZM-CAN

The HZM CAN protocol is a proprietary protocol for HEINZMANN control units and customer modules, i.e. customer units, which have been included in this protocol. It is based on the CAN specification 2.0B with a 29-bit identifier.

Each individual unit in the HZM-CAN bus is clearly identified by the defined unit type and the node number to be assigned via parametrisation.

The following unit types are defined:

ID	Meaning	Control unit
DC	Digital control	Speed governors
GC	GENERATOR CONTROL	GENERATOR CONTROL UNITS
PE	Peripheral extension	Extension modules
AC	Accessory control	Additional units
CM	Customer modules	Customer units (third-party units)
PC	Personal computer	Communication modules
ALL	All types except PE and PC	Used for transfers to all

Table 111: Node types

All parameters relating to the relevant unit type contain the specified letter ID in the parameter name e.g. 403 *CanCMNodeNumber* for the node number of a customer module or 404 *CanPENodeNumber* and 407 *CanPENodeType* for the node numbers and the node types of periphery modules to be connected.

The value 2 must be entered as a channel type for sensors and switching functions if they are received by a HZM-CAN periphery module. The value 14 must be entered if they come via a HZM-CAN multipoint connection. The communication between the HEINZMANN control units and the necessary parametrisation is described in detail in [↑] *Basic information HEINZMANN-CAN, publication no. DG 13 002-d.*

23.2 CAN protocol HZM-CAN customer module

Implementing the HZM-CAN protocol in external devices enables external access to measured and calculated values of the HEINZMANN control unit and also enables sensors and switching functions to be transferred to HEINZMANN control units.

The HEINZMANN control unit allows all receive and send values to be parametrized. The values of the customer modules in the CAN bus can be assigned to the relevant sensors or switching functions in the control unit. The value 8 must be entered as the channel type.

The implementation of the HZM-CAN customer module protocol in external devices is addressed in detail in *HZM-CAN customer module, publication no. DG 05 007-d.*

23.3 CAN protocol SAE J1939

The SAE J1939 protocol is a standard protocol used primarily in automotive applications. It describes both the way data is transmitted as the content of the data. In general, it is the firmware of the control device that decides which data can be received and sent. The single telegrams may be enabled and disabled with parameter settings. Each telegram source and transmission rate may be parametrized separately.

The HEINZMANN control unit allows all receive and send values to be parametrized. The values of the SAE J1939 modules in the CAN bus can be assigned to the relevant sensors or switching functions in the control unit. The value 7 must be entered as the channel type.

The SAE J1939 connection in the HEINZMANN control units is explained in *SAE J1939 Telegrams 2012-03-20* .

23.4 CAN protocol CANopen

The CANopen protocol is an open protocol with general validity for the most varied applications. It defines the way data is transmitted but not the contents of the resulting communication. Data transmission therefore must be agreed between the users on both sides. The HEINZMANN devices are designed as slaves in the predefined master/slave connection set. In addition to the standard four TPDOs, an additional 12 TPDOs are available on request.

The HEINZMANN control unit allows all receive and send values to be parametrized. The values of the CANopen master can be assigned to the relevant sensors or switching functions in the control unit. The value 4 must be entered as the channel type.

The parametrization of the CANopen integration in the HEINZMANN control units is described in detail in *CANopen Implementation, publication no. DG 06 002-d* .

23.5 CAN protocol DeviceNet

The DeviceNet protocol is an open protocol with general validity for the most varied applications. It defines the way data is transmitted but not the contents of the resulting communication. The HEINZMANN control unit allows all receive and send values to be parametrized.

The HEINZMANN devices only support part of the complete protocol, the so called Predefined Master/Slave Connection Set. This establishes a master/slave connection, where all HEINZMANN devices act as slaves. The respective messages are exclusively Group 2 Messages, i.e. the HEINZMANN devices support only Group 2 Only Messages.

The HEINZMANN control unit allows all receive and send values to be parametrized. The values of the DeviceNet master can be assigned to the relevant sensors or switching functions in the control unit. The value 5 must be entered as the channel type.

The parametrization of the DeviceNet integration in the HEINZMANN control units is described in *DeviceNet, publication no. DG 06 003-d*.

23.6 CAN protocol WAGO® (CANopen) and AXIOMATIC® (CANopen)

Under the parameter ID "Wago", the HEINZMANN control units act as a simple CANopen master, which is responsible for the communication with modules from the companies WAGO® and AXIOMATIC®.

At the current time, communication with the following WAGO modules from the 750 series is implemented, for which the field bus coupler CANopen 750-337 is required.

Type	Meaning	Order no.
0	Thermoelement (0.1°C per digit)	750-469
1	0-20 mA	750-452
	4-20 mA	750-454
3	PT100 / PT1000 (0.1°C per digit)	750-460-003

Table 112: WAGO® analogue input modules

Communication with the AXIOMATIC module AX030100/AX030101 (CANopen) is also possible:

Type	Meaning
2	0-5 V
4	4-20 mA
5	0-20 mA

Table 113: AXIOMATIC® analogue input modules

Additional modules can be added to these tables on request. In the HEINZMANN control unit, a maximum of 64 binary inputs and 76 sensor values can be received from these modules, although the actual maximum number is defined by the control unit firmware.

The parametrisation of the baud rate and the node numbers (identifiers) of the CANopen slaves in the master must be carried out for the CAN communication (HEINZMANN control unit).

21700 Wago:Baudrate

Permissible values for the baud rate are 125, 250, 500 and 1000 kBaud. All other values are set to 250 kBaud internally.

One or multiple node numbers are required depending on how many receipt telegrams RPDO are required to cover the connected modules. A node number (identifier) is always responsible for a group of four RPDO. Up to 64 binary inputs and three analogue inputs can be received via the first RPDO, the following RPDO transfer four analogue inputs each.

The node numbers (identifiers) start at the parameter value of

21701 Wago:SlaveID for max. 64 binary inputs and 3 analogue inputs

or *21701 Wago:SlaveID+0_1* for max. 64 binary inputs and 7 analogue inputs

...

or 21701 *Wago:SlvID+0_1_2_3_4* for 64 binary inputs and 19 analogue inputs.

This means that the number of identifiers specified in the parameter name is firmly agreed based on the parameter. These RPDOs are required to cover the fixed maximum number of inputs specified in the HEINZMANN control unit. It is important to note that these identifiers may not be used for other control units in the bus, even if fewer analogue inputs are read by the WAGO or AXIOMATIC module.

The transmission rate at which the WAGO or AXIOMATIC module should transmit the measured values to the master must be specified for each of the max. 20 RPDO (four per identifier). If only one group with 4 RPDOs is planned or required, the send rate is entered in

21702 *Wago:ModulSendRate*

otherwise, it is entered separately for each module:

21702 *Wago:SendRateDI01-64*

21703 *Wago:SendRateAI01-04*

21704 *Wago:SendRateAI05-08* etc.

The type from ↑ *Tab. 5: WAGO® analogue* input modules or ↑ *Tab. 6: AXIOMATIC® analogue* input modules is entered for each used input in the parameter from 25710 *Wago:ClampTypeAII*. The channel numbering must be observed. For more than four RPDOs with 12 analogue inputs in total, the additional parameters are located from 25630 *Wago:ClampTypeAII3*.

The value range must also be parametrised for each input:

21710 *Wago:AII_RefLow* lower reference value of the input

21711 *Wago:AII_RefHigh* upper reference value of the input.

The receipt values of WAGO or AXIOMATIC modules can be assigned to the relevant sensors (or switching functions) in the control unit. The value 10 must be entered as the channel type.

23.7 CAN protocol ICENI® (CANopen)

Under the parameter ID ICENI, the HEINZMANN control units act as a simple CANopen master, which is responsible for the communication with modules from the company RE REGULATEURS EUROPA®. Documents on the ICENI system or its individual modules can be downloaded from the

http://www.regulateurseuropa.com/download-etm/cat_view/415-datasheets/408-iceni-distributed-system

website.

A maximum of 16 analogue or digital modules can be connected to each ICENI master module MA-02. Each module has up to 8 channels depending on the type.

The implementation in the HEINZMANN system has been achieved as follows:

The communication currently takes place with the "ICENI AI-03 T/C Inputs Module". There are a maximum of four modules.

"ICENI AI-03 T/C Inputs Module" has 4 temperature input channels and an internal reference temperature per module. Each input signal measures the sensor signal and calculates the temperature. This calculation includes a cold junction compensation.

The following sensor types are supported

E type: -50 °C to +1000 °C (-58 °F to 1832 °F)

J type: -50 °C to +1200 °C (-58 °F to 2192 °F)

K type: -50 °C to +1372 °C (-58 °F to 2501 °F)

N type: -50 °C to +1300 °C (-58 °F to 2372 °F)

and the following types with reduced accuracy

E type: -270 °C to -50 °C (-454 °F to -58 °F)

J type: -210 °C to -50 °C (-346 °F to -58 °F)

K type: -270 °C to -50 °C (-454 °F to -58 °F)

N type: -270 °C to -50 °C (-454 °F to -58 °F)

Expansions are possible on request.

A maximum of 20 sensor values (16 temperature values and 4 reference values) can be received, although the actual maximum number is defined by the control unit firmware.

The parametrisation of the baud rate and the node numbers (identifiers) of the CANopen slaves in the master must be carried out for the CAN communication (HEINZMANN control unit).

21550 Iceni:Baudrate

Permissible values for the baud rate are 126, 250, 500 and 1000 kBaud. All other values are set to 250 kBaud internally.

The node numbers (identifiers) are entered in

21551 Iceni:SlaveID

and the send rates in

21552 Iceni:ModulSendRate.

The value range must also be parametrised for each input:

21560 Iceni:All_RefLow lower reference value of the input

21561 *Iceni:All_RefHigh* upper reference value of the input

The receipt values of ICENI modules can be assigned to the relevant sensors (or switching functions) in the control unit. The value 13 must be entered as the channel type.

23.8 Serial protocol Modbus

The Modbus protocol is an open protocol with general validity for the most varied applications. It defines the way data is transmitted but not the contents of the resulting communication. The HEINZMANN control unit allows all receive and send values to be parametrized.

The HEINZMANN control unit allows all receive and send values to be parametrized. The values of the Modbus remote station(s) can be assigned to the relevant sensors or switching functions in the control unit. The value 6 must be entered as the channel type.

The Modbus connection to HEINZMANN control devices is described in detail in *Modbus, publication no. DG 05 002-d*.

23.9 Summary of bit values

Only words can be sent via the communication protocols \uparrow 22.2 CAN protocol HZM-CAN customer module, \uparrow 22.4 CAN protocol CANopen, \uparrow 22.5 CAN protocol DeviceNet and \uparrow 22.8 Serial protocol Modbus (16 bit). This also applies if the parameter numbers of a bit value are specified in the assignment fields, i.e. one with the value range [0, 1].

23.9.1 BitCollection

To enable these bit values to be transferred in compressed format, fields with 16 elements each are provided from 29900 *BitCollParamSet*, which can be used to collect bit values into words. The parameter numbers of the bit parameters are entered in these field elements.

If individual bit values are to be sent inverted, the parameter numbers must be entered in negative format in the elements from 29900 *BitCollParamSet* for all control units except XIOS. For XIOS, the field 29932 *BitCollParamInverted* is available instead, where the inverting should be carried out in hexadecimal form for an entire block of 16

The current values of the assignments also appear collected in hexadecimal form under 23720 *BitCollection*. The parameter numbers from 23720 must finally be entered in the assignment fields of the individual communication protocols.

23.9.2 Error status

For the compressed transmission of error states via the protocols \uparrow 22.5 CAN protocol DeviceNet and \uparrow 22.8 Serial protocol Modbus, parameters are also available in the control unit, with numbers that can be entered in the assignment fields of the protocol.

23.9.2.1 XIOS

The display values from 23680 *ErrorState* contain one bit each for an error number, which shows the current status of this error (\uparrow 28.8.1 XIOS). The bit number corresponds to the error number from 3000 to 3099, whereby the value 3000 must be deducted. This is followed by the errors from 13000, which are located on bits 200 to 199 accordingly. These are followed by the errors from 23000 on bits 200 to 299. After these errors come those on 33000...33099, 43000...43099 and 53000...53011. These 512 errors therefore result in a maximum of 32 words to be transferred, although how many error numbers are actually required depends on the firmware.

Each error number corresponds to an entire group of up to 14 error states. The transferred bit 1 means that at least one error is active in the group, while 0 indicates that the entire group is free from errors.

23.9.2.2 Other control units

The display values from 23700 *ErrorState* contain one bit each for an error number, which shows the current status of this error. The bit numbers in the first six words correspond to the error numbers between 3000 and 3094 (-3000), followed by six words for the errors 13000 to 13094 (-13000) and the final six words contain the errors between 23000 and 23094 (-23000). This means that 6, 12 or 18 words are transferred depending on the control unit and firmware. A 0 in a bit means that the corresponding error is not active. A value of 1 means that the error is active.

23.10 CAN or Modbus networks

If a control unit is to communicate via one of the above mentioned bus systems, the following aspects must be observed to avoid problems.

- Special cabling should be used for each communication network in order to satisfy the respective requirements of CAN and Modbus. Recommended cable types are listed in the table below.
- All communication cables should be shielded and the shielding should be grounded in one place in each network.
- Connections between CAN repeaters and control units count as separate networks.
- Each network must be terminated on both ends with a 120 ohm terminator.
- When planning network structures, stubs should be limited to a max. length of 2.0 meters.
- Avoid kinks and sharp bends of the cables.



Some HEINZMANN control units feature an integrated terminating resistor or can be factory-terminated. Consultation is required before designing the

network. Detailed documentation is available in "Basic information HEINZMANN-CAN, publication no. DG 13 002-d".

Supplier	CAN		Modbus	
	2 wires	4 wires	2 wires	4 wires
HELU (Art. numbers)	81286 81911	81284 81912		
BELDEN (Trade numbers)	9841	9842	9841+ (1 pair) 3105A (1 pair) 3106A (1.5 pairs)	3107A (2 pairs) 3108A (3 pairs)

Table 114: Cable types for CAN and Modbus systems

24 Actuator trigger with position feedback

The HEINZMANN control units with conventional injection can work with actuators with different methods of operation and feedback. Up to three actuators can be triggered directly by the DC 1-04 and XIOS, while all other control units can drive precisely one actuator directly.

For the DC 6, there is a hardware version with 200 mA amplifier and for the DC 8, there is a hardware version with 1 A amplifier. Here, a setpoint for an external actuator is output via the amplifier without carrying out a back measurement of the position. For the XIOS, it is important to remember that the ports for actuator control and feedback must be configured before the actuators can be accessed. If HZM-CAN periphery modules are connected, additional actuators can be operated in this way. Although the configuration of the actuators takes place on the periphery module side in this case, the process is identical to the information in this section.

It is also possible to connect external positioners, which receive their setpoints via the CAN protocol SAE J1919. These positioners are suitable for exhaust flaps, waste gate or bypass controls, but HEINZMANN strongly recommends that only direct control actuators are used for the speed control. The time delay via the CAN bus is not determined, which means that the positioning of external actuators can result in the system swinging up here.

24.1 Actuator control

Actuators with two-quadrant operation (2Q, electrically energized on one side, with a strong spring return) or with four-quadrant operation (4Q, electrically energized on both sides) can be used depending on the control unit type.

Control unit	Actuator control			
	Two quadrant		Four quadrant	
	Linear actuator	Rotary magnet	Rotary magnet	Servo motor
DC 1-03, DC 2 DC 11, XIOS	-	X	X	X
DC 1-04	-	only amplifier 1	X	X
DC 6, DC 8, DC 9, DC 12	X	X	X	X
DC5, DC 7, DC 10	X	X	-	-

Tab. 201: Actuator control

The five tables below show which actuator can be (usefully) connected to which control unit.

The first two tables show actuators with two-quadrant control, divided according to linear actuators and actuators with a rotary magnet.

The third and fourth tables show actuators with four-quadrant control, divided according to operation with a rotary magnet or a servo motor. It should be noted that some actuators can be used for both two-quadrant and four-quadrant operation, e.g. the StG 3010. Here, the desired control type must be specified explicitly in the order.

The last table contains electrically commutated actuators.

Although, in principle, more control units can operate two-quadrant actuators than are listed below, some are nevertheless oversized for the small engines that these actuators are reasonably used on. That is why they are not listed here.

It should also be noted that not all actuators operate all feedback variants, which could result in further restrictions depending on the control unit type. It is advisable to select actuators with the required adjustment force and then to compare the feedback type of the actuator and control unit to find the suitable combination.

Actuator	Adjustment force max. [N]	Adjustment range	Feedback type	DC						
				5	6	7	8	9	10	12
LA 25	25	19.5 mm	Digital	X	X	X	X	X	X	X
LA 30	30	15.5 mm	Digital	X	X	X	X	X	X	X
LA 35	35	12.5 mm	Digital	X	X	X	X	X	X	X

Tab. 202: Linear actuator with 2Q control

Actuator	Torque max. [Nm]	Adjustment range	Feedback type	DC						
				5	6	7	8	9	10	12
StG 3005	0.3	53°	Digital	X	X	X	X	X	X	X
StG 3010	0.6	50°	Digital	X	X	X	X	X	X	X
StG 2005	0.8	32°	Digital	X	X	X	X	X	X	X
StG 2040DP	5.6	36°	Digital	X	X	X	X	X	X	X

Tab. 203: Actuators with rotary magnet and 2Q control

Actuator	Torque max. [Nm]	Adjustment range	Feedback type	DC						XIOS
				2	6	8	9	11	12	
StG 3005	0.3	53°	Digital		X		X		X	

Actuator	Torque max. [Nm]	Adjustment range	Feedback type	DC						XIOS
				2	6	8	9	11	12	
StG 3010	0.6	50°	Digital		X		X		X	
StG 2005	0.8	32°	Digital		X		X		X	
StG 2005DP	0.8	32°	Digital		X		X		X	
StG 2010	1.4	68°	Analogue		X	X	X			X
StG 2010	2	36°	Analogue		X	X	X			X
StG 2040DP	5.6	36°	Digital		X		X		X	
StG 2040	5.6	68°	Analogue		X	X	X	X*		X
StG 2040	7.4	36°	Analogue		X	X	X	X*		X
StG 2080	8.4	68°	Analogue		X	X	X	X*		X
StG 2080	11	36°	Analogue		X	X	X	X*		X
StG 2120	13	68°	Analogue	X						

* Control unit integrated in the actuator

Tab. 204: Actuators with rotary magnet and 4Q control

Actuator	Torque max. [Nm]	Adjustment range	Feedback type	DC					XIOS [#]
				1-03	1-04	2	6 [#]	9 [#]	
StG 6-01	4	36°	Analogue		X*	X	X	X	X
StG 6-02V	6	36°	Analogue		X*	X	X	X	X
StG 10	10	36°	Analogue		X*	X	X	X	X
StG 16	15	42°	Analogue		X*	X	X	X	X
StG 30	31.5	42°	Analogue	X	X	X	X	X	X
StG 30.90	31.5	90°	Analogue	X	X	X	X	X	X
StG 40	44	42°	Analogue	X	X	X			X
StG 40.90	40	90°	Analogue	X	X	X			X
StG 64	64	42°	Analogue	X	X				
StG 90	90	42°	Analogue	X	X				
StG 180	180	42°	Analogue		X				

* only amplifier 2 and/or 3

only with external coil unit

Tab. 205: Actuators with servo motor and 4Q control

The actuator StG 180 requires two amplifiers for the control. It can therefore only be used with the control device from the DC 1-04 series. In this case, a specific firmware is required. For StG 180, amplifiers 2 and 3 of the control unit are used for actuator 1, and amplifier 1 is free for use for a second actuator, e.g., for a gas actuator in dual fuel operation. The parameter names of Actuator/Actuator2, Fuel/Fuel2 and Servo/Servo2 will in this case refer to other amplifiers and feedbacks than when utilizing one to three smaller actuators.

Actuator	Torque max. [Nm]	Adjustment range	Feedback type	DC 8 integrated
StG-EC 40	> 40	90°	ElySION I ² C	X
StG-EC 250	> 250	90°	ElySION I ² C	X

Tab. 206: Electrically commutated actuators with ElySION feedback

24.2 Actuator feedback

The feedback of the current actuator position on the control unit is an important signal for checking whether the actuator is complying with the specification. If this is not the case, various different errors are generated, which, in the worst case scenario, must result in an engine shutdown.

Depending on the actuator type, an analogue or a digital signal is used to feed back the actuator position. With an analogue signal, the information about the actuator position is contained in the size of the DC voltage signal, whereas with a digital feedback the actuator position is computed from time intervals between pulses.

As well as the measurement signal for the actuator position, actuators with digital feedback have a reference signal. The reference signal is used to compensate for temperature variations in the feedback which might affect the measurement signal.

Actuators with an ElySION PWM measurement system send a specially prepared PWM signal, which enables extremely long transmission lines (i.e. connection to a normal PWM input is not possible). These actuators are used in applications requiring a highly accurate measurement signal.

The following table shows a list of which actuator feedbacks can be processed by the individual control units. However, these are always hardware versions, which must be specified explicitly when placing the order for the control unit.

Control unit	Actuator feedback			
	Analogue 1.6...2.8 V	Digital	ElySION	
			PWM	I ² C
DC 1	X	-	-	-
DC 2, DC 6, DC 9, DC 10	X	X	-	-
DC 5, DC 7, DC 12	-	X	-	-
DC 8 (separate)	X	-	-	-
DC 8 (integrated in actuator)	-	-	-	StG-EC 40 StG-EC 250

DC 11	X	-	on request	-
XIOS	X	-	X	-

Tab. 207: Actuator feedback

In the following, all three actuator parameters are always shown. If the control unit currently in use can only control one actuator, the first parameter always applies.

The relevant actuator is enabled with parameter

5910 Actuator(1)On

5930 Actuator2On

5940 Actuator3On.

The operation of the amplifiers is selected with the parameters

5911 Amplifier(1)_2Qor4Q

5931 Amplifier2_2Qor4Q

5941 Amplifier3_2Qor4Q,

where 0 refers to the 4-quadrant amplifier and 1 refers to the 2-quadrant amplifier (with return springs).

If the actuator transmits its feedback data via the high-precision ElySION-PWM feedback,

5953 Feedback(1)ElySIONOn

5963 Feedback2ElySIONOn

5973 Feedback3ElySIONOn

must be activated with 1. If this parameter is not present or is set to 0,

5950 FeedbDigitalOrAnalog = 0 analogue feedback

5950 FeedbDigitalOrAnalog = 1 digital feedback

determines the feedback type. If present, this parameter only applies for the first actuator or several actuators. If this parameter is (also) not present, the only option defined in the hardware and software for the control unit to address an actuator applies automatically (analogue only or digital only).

For some actuators, the evaluation of the feedback must be inverted (small feedback signal with a large filling and vice versa). The following parameters are used to set separately for each individual actuator whether the feedback signal is rising or falling with increasing filling:

5951 Feedb(1)SlopeFallOrRise

5961 Feedb2SlopeFallOrRise

5971 Feedb3SlopeFallOrRise

The value 0 is used to indicate that the feedback signal of the actuator is rising with increasing filling, 1 indicates that it is falling with increasing filling.



The parameters 59_x1 Amplifier(y)2Qor4Q, 5950 FeedbDigitalOrAnalog and 59_z1 FeedbySlopeFallOrRise only become active after saving data and reset of control unit (x = 1,3,4, y = 1,2,3, z = 5,6,7).

If the feedback signals are not linear with respect to the actuator positions, a separate linearisation curve with 10 value pairs can be provided for each actuator on request. The measured values are entered in the parameters from

7980 *Feedback(1):digit(0)*
8000 *Feedback2:digit(0)*
8020 *Feedback3:digit(0)*

and the respective actuator positions in the parameters from

7990 *Feedback(1):Pos(0)*
8010 *Feedback2:Pos(0)*
8030 *Feedback3:Pos(0)*.

The linearization curves are enabled with parameter

5952 *Feedback(1)LinearOn*
5962 *Feedback2LinearOn*
5972 *Feedback3LinearOn*.

Following a restart, reset or if the engine was switched off either intentionally or due to an error, the actuator is energized for 5 seconds with simultaneous output of an actuator position setpoint 0 % for safety. The power is then switched off until an actuator setpoint is specified (again).

During the emergency engine shutdown due to a pickup error, the actuator is even taken to 0 % for 5 minutes before the power is switched off to ensure that the engine is really switched off (a check is not possible due to the absence of the speed signal).



Control of the actuator StG 180 requires two amplifiers, which means it can only be used in combination with the control device of the DC 1-04 series. In this case, a specific firmware is required. For StG 180, amplifiers 2 and 3 of the control device are used for actuator 1, and amplifier 1 is free for use for a second actuator, e.g., for a gas actuator in dual fuel operation or a wastegate. The parameter names of Actuator/Actuator2, Fuel/Fuel2 and Servo/Servo2 will in this case refer to other amplifiers and feedbacks than when utilizing one to three smaller actuators.

24.3 Calibrating the actuator

Before the control unit can compute the exact position of the control path, reference values must tell it the relationship between the control path measured value and the position of the actuator. These reference values correspond to the control unit's measured values at the

minimum and maximum position of the actuators. In the case of actuators with digital feedback, the reference signal must also be measured.

Calibration can be carried out automatically or manually. The actuators must be capable of reaching the minimum and maximum positions in all cases. The actuator should therefore be calibrated without its linkage if possible.



Actuator calibration must be carried out for every control unit with its associated actuator, otherwise component tolerances of both the actuator and the control unit will affect control quality and especially the compliance of the limiting functions. Actuators must be re-calibrated in particular if the actuator or the control unit have been replaced.

24.3.1 Manual calibration

Manual calibration is performed similarly to the calibration of analogue inputs. The actuator must be moved to the minimum and maximum position, with the control unit measured value

3950 *Feedback(1)*
 3960 *Feedback2*
 3970 *Feedback3*

being entered in the parameters

1950 *Feedback(1)Ref_0%*
 1960 *Feedback2Ref_0%*
 1970 *Feedback3Ref_0%*

for the minimum position and in the parameters

1951 *Feedback(1)Ref_100%*
 1961 *Feedback2Ref_100%*
 1971 *Feedback3Ref_100%*

for the maximum position (in older firmware versions, these parameters are called *FeedbackRefLow* and *FeedbackRefHigh*, but have the same meaning).

For actuators with digital feedback, the reference signal 3955 *FeedbackReference* must also be entered in parameter 1955 *FeedbackReference*. The reference signal does not change over the entire range of the actuator.



With manual calibration, these parameters are only active after saving data and reset of control unit.

The control unit is then able to standardise the measured value of the feedback and display it exactly in 3951 *FeedbackCorrection* (note that, currently, all control units

have a maximum of one digital feedback). The actuator position can be verified with the parameter

2300 *Act(1)Pos*
 2302 *Act2Pos*
 2303 *Act3Pos*,

that indicates the current actuator travel.

24.3.2 Automatic calibration

Automatic calibration can be started from the PC or hand programmer (\uparrow 3.3 *DcDesk 2000*) on request.


In the basic system DC 1, the calibration of actuator 1 is also possible by putting the rotary switch in position 1 (only after power-up) and in basic systems DC 6, 8 and 9 by pressing a push-button on the circuit board. For the first or only actuator, the activation can also take place via the switching function 2845 *SwitchAutoAdjust*.



Warning

For this, \uparrow 24.3 *Calibrating the actuator must be observed!*

With automatic calibration, the control unit measures the reference values by itself. It does this by energizing the selected actuator for a certain time to ensure that the minimum or maximum position is positively reached, then measures the reference values.



Info

Automatic actuator calibration cannot be started if a fatal error is present.

The measured values are entered in the corresponding parameters

1950 *Feedback(1)Ref_0%*
 1960 *Feedback2Ref_0%*
 1970 *Feedback3Ref_0%*

for the minimum position and

1951 *Feedback(1)Ref_100%*
 1961 *Feedback2Ref_100%*
 1971 *Feedback3Ref_100%*

for the maximum position (in older firmware versions, these parameters are called *FeedbackRefLow* and *FeedbackRefHigh*, but have the same meaning) and

1955 *FeedbackReference*

for the reference of the digital feedback. In contrast to manual calibration, these values are available immediately.

The time during which the control unit energizes the actuator and waits for the minimum or maximum position to be positively reached is defined by the parameter

1900 *Feedback(1)AdjustTime*

1930 *Feedback2AdjustTime*

1940 *Feedback3AdjustTime*

The level of current for automatic calibration is determined by the parameter

1919 *Servo(1)CurrentAdjust*

1939 *Servo2CurrentAdjust*

1949 *Servo3CurrentAdjust.*

During automatic calibration, the errors

3059 *ErrFeedback(1)Adjust* or 3050 *ErrActuator(1).bFeedbackAdjust*

3060 *ErrFeedbackAdjust2* or 3051 *ErrActuator2.bFeedbackAdjust*

3061 *ErrFeedbackAdjust3* or 3052 *ErrActuator3.bFeedbackAdjust*

can occur (the right column applies to the XIOS, the left column applies to all other control units). These errors are fatal and therefore prevent the engine start.

24.3.3 Automatic zero-position calibration at each engine stop

If drifting in the feedback values is identified over time on actuators with analogue feedback, which is indicated by the engine not reaching the maximum power, then it is advisable to carry out the automatic calibration automatically with each engine stop. In this case, only the zero-position is calibrated and the expansion range between

1950 *Feedback(1)Ref_0%* and 1951 *FeedbackRef_100%*

1960 *Feedback2Ref_0%* and 1961 *Feedback2Ref_100%*

1970 *Feedback3Ref_0%* and 1971 *Feedback3Ref_100%*

remains the same. The newly obtained parameters are saved immediately in the control unit.



Warning

For this, ↑ 24.3 *Calibrating the actuator must be observed!*

This function is activated with

5900 *FeedbZeroPosAdjustOn*

or, on the XIOS, with

5900 *Act1ZeroPosAdjustOn*

5934 *Act2ZeroPosAdjustOn*

5944 *Act3ZeroPosAdjustOn*

In the XIOS, only one actuator may receive this calibration. If the function is activated for several actuators, it is not carried out. The calibration is only of use for the actuator that is assigned to the speed governor.

24.3.4 Saving the calibration data

When automatic calibration is initiated with DcDesk 2000 or the hand programmer, the device asks if you wish to save the results in the read-only memory. It is therefore the responsibility of the operator to decide whether to accept the settings as final.

If the calibration is initiated with the rotary switch, switching function or push-button, however or via the function zero setting the calibration values will be automatically saved following successful automatic calibration.

The time for the calibration itself is determined by

1900 *Feedback(1)AdjustTime*
 1939 *Feedback2AdjustTime*
 1949 *Feedback3AdjustTime*.

– once on the 0 % and once on the 100 % position. The control unit requires an additional approx. 60 s for saving the calculated values automatically. Only then can the control unit be switched off, i.e. never at the same time as the engine stop request. The automatic calibration function must also not be activated during an engine stop, if the engine was shut down by switching off the voltage supply instead of via a stop signal.



After calibration, wait for at least twice the calibration time + 60 s before the control unit is de-energised or a reset is otherwise triggered! If this cannot be ensured by personnel, a delay circuit must be built in.

24.3.5 Error detection during feedback

Similarly to sensors at analogue inputs, the feedback has error limits by which the control unit can detect when a measured value is prohibited. The error limits must be entered by hand with both manual and automatic calibration.

In this process, a measured value that is below the lower error limit

1952 *Feedback(1)ErrLow*
 1962 *Feedback2ErrLow*
 1972 *Feedback3ErrLow*

and above the upper error limit

1953 *Feedback(1)ErrHigh*
 1963 *Feedback2ErrHigh*
 1973 *Feedback3ErrHigh*

is defined as prohibited. The error limits are designated "Low/High" and refer to the minimum and maximum measured value respectively – not to the actuator position.

Similarly, the error limits 1956 *FeedbackRefErrLow* and 1957 *FeedbackRefErrHigh* apply for the reference value in the case of digital feedback.

These error limits should not be too close to the minimum and maximum value to prevent natural measured value fluctuations in the feedback causing error detection. A short circuit or open circuit in the supply or signal line must be positively detected however.

A detected error sets the corresponding error parameter of the feedback.

3050 <i>ErrFeedback(1)</i>	or 3050 <i>ErrActuator(1).bFeedback</i>
3051 <i>ErrFeedback2</i>	or 3051 <i>ErrActuator2.bFeedback</i>
3052 <i>ErrFeedback3</i>	or 3052 <i>ErrActuator3.bFeedback</i>

These errors are fatal and therefore result in the engine being shut down or prevent the engine start.

24.4 Limiting the actuator stroke

Absolute limiting of the actuator's control path is also provided to protect the actuator from mechanical and thermal overload. This limiting provides a safety distance ahead of the actuator's mechanical limit stops.

The minimum position of the control path is limited by parameter

310 *ActPos(1)SecureMin*
 314 *ActPos2SecureMin*
 316 *ActPos3SecureMin*

The parameter

312 *ActPos(1)SecureMax*
 315 *ActPos2SecureMax*
 317 *ActPos3SecureMax*

provides a limit for the maximum position of the control path and should therefore be above the filling limitations. The following values are usually used for these two parameters:

Number	Parameter	Value	Unit
310	<i>ActPosSecureMin</i>	3.0	%
312	<i>ActPosSecureMax</i>	97.0	%

When the actuator is used on throttle valves, clearance may be required for the full range [0, 100] %.



*The parameters described above may be used only as a protection for the actuator. A limitation of the injection quantity is set with the parameter 711 *FuelLimitMaxAbsolute*. For limitation in the minimum filling direction, the zero-fuel curve is used.*

24.5 Servo loop

The speed governor control unit calculates a filling setpoint 2350 *FuelQuantity* from which a setpoint position for the actuator must be calculated. As 2350 *FuelQuantity* is provided in % of the injection quantity, with linear linkage – and in particular on the diesel engine – the actuator setpoint

2330 *Act(1)PosSetpoint*
 2332 *Act2PosSetpoint*
 2333 *Act3PosSetpoint*

can be taken directly from

2350 *FuelQuantity*

or, on the V-type engine, from

2351 *FuelQuantityBank1*
 2352 *FuelQuantityBank2*

This also applies for other setpoints in XIOS applications, which can be assigned to an actuator.

In certain cases however it may be necessary to take the actuator setpoint from a filling-dependent curve. This is especially useful with nonlinear linkages or throttles, or if the actuator is mounted directly without any linkage.

When the pump map is known, it can also be useful to activate a pump map calculating the actuator position from the required filling depending on the speed.

24.5.1 Actuator curve

For the fuel quantity dependent actuator position, the curve in 7300 *FuelToActSp:f* and 7315 *FuelToActSp:Pos* is provided, which is activated with 4721 *FuelToActPosCurveOn*. 2330 *ActPosSetpoint* indicates the resulting actuator position.

7300 <i>FuelToAct(1)Sp:f(0)</i>	Fill values of the curve for actuator 1
7315 <i>FuelToAct(1)Sp:Pos(0)</i>	Position values of the curve for actuator 1
4721 <i>FuelToActPos(1)CurveOn</i>	Activation of the curve for actuator 1
2330 <i>Act(1)PosSetpoint</i>	Resulting setpoint for actuator 1
7330 <i>FuelToAct2Sp:f(0)</i>	Fill values of the curve for actuator 2
7345 <i>FuelToAct2Sp:Pos(0)</i>	Position values of the curve for actuator 2
4722 <i>FuelToActPos2CurveOn</i>	Activation of the curve for actuator 2
2332 <i>Act2PosSetpoint</i>	Resulting setpoint for actuator 2
7360 <i>FuelToAct3Sp:f(0)</i>	Fill values of the curve for actuator 3
7375 <i>FuelToAct3Sp:Pos(0)</i>	Position values of the curve for actuator 3
4723 <i>FuelToActPos3CurveOn</i>	Activation of the curve for actuator 3
2333 <i>Act3PosSetpoint</i>	Resulting setpoint for actuator 3

24.5.2 Pump map

If the relation between an actuator position and injection quantity is linear, the setpoint position for the actuator 2330 *ActPosSetpoint* is equivalent to the fuel setpoint. When the pump map is known, it might be useful to activate a pump map calculating the actuator position from the required speed-dependent fuel quantity. This function is available from engine manufacturers on request.



No to

The pump map only applies for the actuator, which is assigned to the speed governor. On the DC 1-04, this can also be the StG 180.

The pump map is determined on the pump testing stand and entered in parameters

7200 <i>InjectorMap:n(x)</i>	engine speed values for pump map
7250 <i>InjectorMap:f(y)</i>	fill values for pump map
7300 <i>InjectorMap:Pos(z)</i>	actuator position from pump map

The pump map is activated with 4300 *InjectorPumpMapOn*.

24.5.3 Servo control loop

The servo loop or position control loop serves the purpose of making the actuator travel to the setpoint position. The servo loop is an autonomous control loop which is subordinate to the speed governor. In the same way as for the speed governor, there are PID parameters provided for this control loop, separate parameters for each actuator. There is also an additional DD parameter for the servo loop to counteract the acceleration of the actuator. This parameter is used primarily with the particularly fast actuators in the 2000 series.

1911 <i>Servo(1)Gain</i>	P-ratio for servo loop of actuator 1
1912 <i>Servo(1)Stability</i>	I-ratio for servo loop of actuator 1
1913 <i>Servo(1)Derivative</i>	D-ratio for servo loop of actuator 1
1914 <i>Servo(1)Acceleration</i>	DD-ratio for servo loop of actuator 1
2300 <i>Act(1)Pos</i>	current value of actuator 1
2330 <i>Act(1)PosSetpoint</i>	setpoint position for actuator 1
1931 <i>Servo2Gain</i>	P-ratio for servo loop of actuator 2
1932 <i>Servo2Stability</i>	I-ratio for servo loop of actuator 2
1933 <i>Servo2Derivative</i>	D-ratio for servo loop of actuator 2
1934 <i>Servo2Acceleration</i>	DD-ratio for servo loop of actuator 2
2302 <i>Act2Pos</i>	current value of actuator 2
2332 <i>Act2PosSetpoint</i>	setpoint position for actuator 2
1941 <i>Servo3Gain</i>	P-ratio for servo loop of actuator 3
1942 <i>Servo3Stability</i>	I-ratio for servo loop of actuator 3
1943 <i>Servo3Derivative</i>	D-ratio for servo loop of actuator 3
1944 <i>Servo3Acceleration</i>	DD-ratio for servo loop of actuator 3

2303 <i>Act3Pos</i>	current value of actuator 3
2333 <i>Act3PosSetpoint</i>	setpoint position for actuator 3

The values for the servo loop vary depending on the actuator type and must be set accordingly. The initial settings are made at the factory by HEINZMANN when the control unit is shipped and do not normally need to be altered.

24.5.3.1 Monitoring of the actuator position

The setpoint position of the actuator

2330 *Act(1)PosSetpoint*
 2332 *Act2PosSetpoint*
 2333 *Act3PosSetpoint*

is constantly compared with the measured actual position

2300 *Act(1)Pos*
 2302 *Act2Pos*
 2303 *Act3Pos*

if the actuator is activated and energised. With a deviation of more than 10 % over a second, the error

3053 *ErrActuatorDiff(1)* or 3050 *ErrActuator(1).0*
 3054 *ErrActuatorDiff2* or 3051 *ErrActuator2.0*
 3055 *ErrActuatorDiff3* or 3052 *ErrActuator3.0*

is reported (the right column applies to the XIOS, the left column applies to all other control units). This can happen when the fuel injection pump, the throttle valve, the linkage or the actuator sticks or is not connected.

If this type of error is so severe in an application that the engine has to be stopped, the error message can be classed as fatal. For this, the parameters

5153 *EcyActuatorDiff(1)On* or 5150 *EcyActuatorDiff(1)On*
 5154 *EcyActuatorDiff2On* or 5151 *EcyActuatorDiff2On*
 5155 *EcyActuatorDiff3On* or 5152 *EcyActuatorDiff3On*

must be set. In this case, this type of error results in an engine shut-down or engine start prevention.

24.5.3.2 Correction of the servo PID parameters for static operation

In a similar way as for the speed control loop, a simple correction of the PID parameters of the servo loop is possible if the actuator is in static operation.

If the actuator position deviation between target and actual position is within the range 1906 *ServoCorrRange*, then the PID parameters are corrected with the value 1905 *ServoCorrFactor*.

The normal parameters are used outside the double range. Between these two values, interpolation is used to achieve a smooth transition. This function is always active. A value of 100% means no influence on the servo loop parameters. The current correction factor is displayed in the parameter 3905 *ServoPIDCorr*.

1906 <i>Servo(1)CorrRange</i>	1905 <i>Servo(1)CorrFactor</i>	3905 <i>Servo(1)PIDCorr</i>
1908 <i>Servo2CorrRange</i>	1907 <i>Servo2CorrFactor</i>	3935 <i>Servo2PIDCorr</i>
1910 <i>Servo3CorrRange</i>	1909 <i>Servo3CorrFactor</i>	3945 <i>Servo3PIDCorr</i>

24.5.4 Actuator current

The servo loop will calculate the current for the actuators based on the servo loop parameters.

3916 *Servo(1)CurrentSetp* 3936 *Servo2CurrentSetp* 3946 *Servo3CurrentSetp*.

To prevent the actuators from being overloaded, the maximum current can be limited with parameter 1917 *ServoCurrentMax*. The maximum current can be tolerated briefly for position changes, but over longer periods the current has to be reduced to prevent the actuator being thermally overloaded. This is why the servo controller reduces the current under static load by an exponential function with a time constant of approx. one minute to the value set with parameter 1918 *ServoCurrentRed*. The reduction only begins after the delay time 1916 *ServoCurrentRedDelay*. If this parameter does not exist, the reduction begins without a delay.

1917 <i>Servo(1)CurrentMax</i>	1918 <i>Servo(1)CurrentRed</i>	1916 <i>Servo(1)CurrRedDelay</i>
1937 <i>Servo2CurrentMax</i>	1938 <i>Servo2CurrentRed</i>	1936 <i>Servo2CurrRedDelay</i>
1947 <i>Servo3CurrentMax</i>	1948 <i>Servo3CurrentRed</i>	1946 <i>Servo3CurrRedDelay</i>




Fig. 48: Current reduction under static load

The maximum current is still available for dynamic position changes. When setting the current reduction, the current must be measured in the supply cable to the actuators, with the corresponding cable length. It must be remembered that the current cannot be measured until the actuators have warmed up (static operation) because the flowing current changes as temperature rises.

For test purposes, the current setpoint can be specified directly via the PC, this function cannot be saved, however, i.e. it is automatically switched off after a control unit reset. 1920 *ServoCurrentPC* is used for specifying the test values and 5920 *ServoCurrentPCOn* is used to activate the test mode.

24.5.4.1 DC 5, DC 6, DC 8, DC 9, DC 10, DC 11 and DC 12

These control units are equipped with a current controlled amplifier. The current setpoint 3916 *ServoCurrentSetpoint* is output directly on the amplifier here.

The current flowing through the amplifier is read back and displayed in the control units DC 8, DC 11 and DC 12 in

3920 *ServoCurrLowSidePos*

3921 *ServoCurrLowSideNeg*

3922 *ServoCurrHighSide*

The DC 10 shows the measured value in 3609 *ServoCurrentLowSide* .

24.5.4.2 DC 1, DC 2, DC 7 and XIOS

These control units output a PWM ratio to the actuator, from which the actual flowing current is derived. Due to cable lengths and the actuator types being used, however, there may be differences between the required current and the flowing current.

To enable the maximum current to be set exactly, 5920 *ServoCurrentPCOn* = 1 is used to activate the test mode. Now, a PWM ratio can be specified in 1920 *ServoCurrentPC* and the current in the engine cable can be measured with a suitable measuring device. The PWM ratio in 1920 *ServoCurrentPC* must be changed until the permissible maximum current is flowing.

It should be noted that the current specification is output on all activated actuators at the same time. If you do not want this, the actuators must be activated individually with

5910 *Actuator(1)On*

5930 *Actuator2On*

5940 *Actuator3On*

so that only one is energised.

The maximum value determined in this way is then entered in

1917 *Servo(1)CurrentMax*

1937 *Servo2CurrentMax*

1947 *Servo3CurrentMax*

When conducting this adjustment, it is important to note that a certain amount of time must elapse before the current that is actually flowing can be measured.

The current setpoint from the actuators can be read from the parameter

3916 *Servo(1)CurrentSetp*

3937 *Servo2CurrentSetp*

3947 *Servo3CurrentSetp*

The unit of the parameter is percent. The sign indicates the current direction.

Since the current actually flowing through the actuator will, however, depend on the amplifier voltage. The parameter

5915 *Servo(1)CurrentCorrOn*

5935 *Servo2CurrentCorrOn*

5945 *Servo3CurrentCorrOn*

can therefore be used to activate a current correction for the actuator.

With current correction activated, the current setpoint as calculated from the servo loop is correlated to a standard voltage of 24 V using the current measured supply voltage 3600 *PowerSupply*. The corrected value is displayed in the

3917 *Servo(1)CurrentCorr*

3937 *Servo2CurrentCorr*

3947 *Servo3CurrentCorr*

parameters.

With the DC 1 series, the actuators can be supplied with 40 V. The amplifier voltage is therefore displayed here in 3600 *PowerSupply* instead of the supply voltage and used for standardisation. The amplifier voltage of the additional board on the DC 1-04 is shown in 3601 *PowerSupplyExt* and is also used for current correction of the actuators on connector V.

In XIOS control units with up to three connectible actuators, the power to the control unit can be activated permanently on request

5916 *Servo(1)CurrentPermOn*

5936 *Servo2CurrentPermOn*

5946 *Servo3CurrentPermOn*.

In this case, the power is only switched off in the event of a pickup error, after the actuator has been supplied with power in the position 0 direction for five minutes to stop the fuel supply.

24.5.4.3 Monitoring of the actuator current

All control units apart from DC 1 and DC 2 monitor the amplifier current. A group error from hardware and software monitoring is reported in 3060 *ErrAmplifier* or, for XIOS, in 3050 *ErrActuator1.4*, 3052 *ErrActuator2.4* and 3053 *ErrActuator3.4*. In the DC 10 3084 *ErrLowSideCurrent* is also shown.

In the event of an overcurrent fault, the amplifier is always switched off to protect the actuator and control unit. Amplifier errors result in an emergency shutdown which means that the engine is switched off or is prevented from starting up.

On the XIOS with three actuators, the actuator where a fatal error may not result in an emergency shutdown, but merely trigger a suitable error reaction, can be defined in customer-specific firmware depending on the application. In a dual-fuel application, for example, it would make sense for a fatal error to only be triggered on the diesel actuator (because this means that the engine can no longer be operated), but not on the gas actuators (work could continue here with pure diesel).

24.6 Positioner mode

Speed control will not be satisfactory unless the actuator is positioning precisely. PID parameters to match the actuator are set at the factory. But when mounted on the engine, the actuator will be subject to influences both by the mechanical assembly with the linkage and by the dimensions of the control rods.

In order to optimize the servo loop parameters without being influenced by the control unit, the positioner mode has been provided. It is used exclusively for testing and adjustment purposes, i.e. this function cannot be saved, and it is switched off automatically following a control unit reset.

The positioner mode can only be started if the switching function 2833 *SwitchForcedStart* is inactive, the actuator selected for the positioner test has been switched on with

5910 *Actuator(1)On*

5930 *Actuator2On*

5940 *Actuator3On*

and if there is no speed and no fatal error active.



Info

*On control units with older firmware, the positioner mode is only permitted if the function 2810 *SwitchEngineStop* is deactivated.*

For safety reasons, the program will automatically exit the positioner mode when the speed pickups detect speed.

With the parameter 5700 *PositionerOn* = 1, the positioner mode is switched on for all activated actuators at the same time. If you do not want this, the actuators must be activated individually so that only one is tested at a time.

If an actuator setpoint is now selected with parameter 1700 *PositionerSetpoint*, the actuator's reaction can be observed and/or measured via the feedback. The current actuator position is displayed in

2300 *Act(1)Pos*
 2302 *Act2Pos*
 2303 *Act3Pos*.

By changing the setpoint, the step response of the relevant actuator can be monitored and optimised by adjusting the PID values.

To be able not only to check the static setting, but also to optimise the much more important dynamic response of the actuator, the change in setpoint selection can be automated via 5701 *PositionerMode*:

- 5701 *PositionerMode* = 0 1700 *PositionerSetpoint* is output unchanged
- 5701 *PositionerMode* = 1 1700 *PositionerSetpoint* receives the value from 1701 *PositionerAmplitude* in positive and negative form alternately. The result is a square-wave function.
- 5701 *PositionerMode* = 2 1700 *PositionerSetpoint* and 1701 *PositionerAmplitude* form a triangle function
- 5701 *PositionerMode* = 3 1700 *PositionerSetpoint* and 1701 *PositionerAmplitude* form a sine function.

The frequency of the positioning change is pre-set in 1702 *PositionerFrequency*.

After completing the servo loop settings in positioner mode, these settings will have to be tested with the engine running and adjusted if necessary. Due to the engine's vibrations the friction torque may be considerably reduced and require other parameter settings than with the engine at standstill. In extreme cases, this can even result in the actuator positioning very badly when the engine is at standstill, whereas the governing results obtained with the engine running are most satisfactory.

24.7 Actuators on HZM-CAN periphery modules

In the control unit, the current back measurement of the actuator position appears from 2200 (previously 2305) *PEActPos* (corresponds to 2300 *ActPos* in the relevant periphery module) and whether or not the actuator is activated is visible from 2210 (previously 2320) *PEActuatorOn* (corresponds to 5910 *ActuatorOn* in the periphery module).

From 2380 *PEActuatorError* or from 23030 *ErrCanPEAct* on the XIOS, the condensed error state is shown per periphery module actuator. The individual bits have the following meaning:

Error bit	Error	Reference
0	Actuator difference error	↑ 3053 <i>ErrActuatorDiff</i>
1	Actuator calibration error	↑ 3059 <i>ErrFeedbackAdjust</i>
2	Feedback error	↑ 3050 <i>ErrFeedback</i>
3	Feedback error of the reference	↑ 3056 <i>ErrFeedbackRef</i>
4	Overcurrent ID	↑ 3060 <i>ErrAmplifier</i>

Fig. 49: Actuator errors on a periphery module

It must be decided in the relevant application whether errors reported by the periphery module are important enough for the speed governor that the engine has to be shut down. A situation like this could arise, for example, if the speed governor control unit controls the actuator on one side of a V-type engine and the periphery module for a second actuator is used on the other side of the V-type engine. Errors in the actuator control of the periphery module, which mean that this side of the V-type engine is no longer operated correctly, are therefore fatal for the entire engine and should result in an engine stop.

The decision takes place in two steps per periphery module and per actuator on periphery modules, as a periphery module can have several actuators.

In the first step, an error mask *5380 ErrMaskPEActuator(x)* or *25030 ErrMaskPEActuator(x)* in the XIOS speed governor, must be defined for each actuator on periphery modules. The structure corresponds exactly to the table above. If a bit is set to 1, the relevant error is important for the master (i.e. the speed governor). If the bit is set to 0, the corresponding error is not so important for the master that the engine has to be stopped.

The second step is used to define whether an actuator error with this type of mask in a specific periphery module must result in an engine stop in the master.

In all control units except for XIOS, the parameter *5189 EcyPEFatalErrorOn* must be activated first.

Finally, there are the mask parameters per periphery module from *5440 ErrMaskPEModul* or, in the XIOS, from *25002 EcyMaskPEModul*. If bit 4 is set here for actuator errors for a periphery module, one of the actuator errors selected above results in *3800 EmergencyAlarm = 1* in the master, which means that the engine is stopped immediately due to a fatal error.



NO 10

The HEINZMANN PC program ↑ 3.3 DcDesk 2000 makes setting the masks easy, as all errors are listed in an easily legible way and exact knowledge of bit positions is not required.

25 Current-controlled valves on hydraulic actuators

Some control units have the necessary hardware requirements for activating a current-controlled proportional valve for controlling a hydraulic actuator instead of a HEINZMANN actuator.

For the DC 6, there is a hardware version with 200 mA amplifier and for the DC 8, there is a hardware version with 1 A amplifier instead of the actuator output. On the XIOS, assignment parameters can be used to decide whether an actuator or a proportional valve is connected on each of the three actuator outputs.

For all other control units and all other hardware versions of the DC 6 and DC 8, HEINZMANN actuators must be connected.

25.1 DC 6 and DC 8

25.1.1 Current setpoint

The current setpoint 3916 *ServoCurrentSetpoint* on the DC 6 and DC 8 is determined directly from the fuel setpoint 2350 *FuelQuantity* and output on the amplifier.

The current flowing through the amplifier is read back and displayed in the control units DC 8 with 1 A-amplifier in

3920 *ReadBackAmpl1000*

while the DC 6 with 200 mA-amplifier displays the current divided into HighSide and LowSide in

3920 *ServoCurrHighSide*

3921 *ServoCurrLowSide*

25.1.2 Monitoring

The amplifier current is monitored, an error appears in 3064 *ErrAmplCurrent*. A group error from hardware and software monitoring is also reported in 3060 *ErrAmplifier*.

In the event of an overcurrent fault, the amplifier is always switched off to protect the control unit. Amplifier errors result in an emergency shutdown, which means that the engine is switched off or is prevented from starting up. [↑]27.8 *Error parameter list* describes possible causes for these errors and includes instructions on how to remedy them.

DC 6 shows more measured values and corresponding errors for a more detailed description:

3601 <i>AmplifierTemp</i>	3066 <i>ErrAmplTempWarn</i>
	3067 <i>ErrAmplTemp</i>
3602 <i>AmplifierSupply</i>	3068 <i>ErrAmplSupply</i>
3604 <i>Int13V</i>	3069 <i>ErrInt13V</i>
3605 <i>AmplifierVoltage.</i>	

25.2 XIOS

The control and monitoring of the current outputs is activated with the

14400 *Amplifier1On*
 14405 *Amplifier2On*
 14410 *Amplifier3On*

functions.

If a HZM-CAN periphery module type XIOS is connected, additional current-controlled valves can be operated in this way. Although the configuration of the valves takes place on the periphery module side in this case, the process is identical to the information in this section.

25.2.1 Current setpoint

The setpoints which have been assigned to the individual outputs are used to calculate the following current setpoints

12400 *Amplifier1CurrentSetp*
 12405 *Amplifier2CurrentSetp*
 12410 *Amplifier3CurrentSetp.*

The current flowing through the amplifiers and the voltages are read back and displayed in

12401 <i>Amplifier1Current</i>	12402 <i>Amplifier1Voltage</i>
12406 <i>Amplifier2Current</i>	12407 <i>Amplifier2Voltage</i>
12411 <i>Amplifier3Current</i>	12412 <i>Amplifier3Voltage</i>

The current difference between the setpoint and actual current is shown in

12403 *Amplifier1CurrentDiff*

12408 *Amplifier2CurrentDiff*

12413 *Amplifier3CurrentDiff*.

25.2.2 Monitoring

A group error from hardware and software monitorings is reported in

13080 *ErrAmplifier1*

13081 *ErrAmplifier2*

13082 *ErrAmplifier3*

↑27.8 *Error parameter list* describes possible causes for these errors and includes instructions on how to remedy them.

Amplifier errors result in an emergency shutdown as standard, which means that the engine is switched off or is prevented from starting up if ↑25.2.2.1 *Deactivation of the emergency shutdown* does not apply.

There is an overcurrent detection function in the hardware and, in the software, the amplifier current can be monitored in two ways after a start delay of 10400 *AmplifierCurrCheckStartDelay*:

Undercurrent and overcurrent monitoring is active as soon as the amplifier of the current output is activated. The permissible lower and upper limit is set with the parameters

10401 *Amplifier1CurrentErrLow* 10402 *Amplifier1CurrentErrHigh*

10406 *Amplifier2CurrentErrLow* 10407 *Amplifier2CurrentErrHigh*

10411 *Amplifier3CurrentErrLow* 10412 *Amplifier3CurrentErrHigh*

The function switches

14403 *Amplifier1CurrDiffCheckOn*

14408 *Amplifier2CurrDiffCheckOn*

14413 *Amplifier3CurrDiffCheckOn*

can also be used to monitor for the tolerated deviation between the setpoint and actual value being exceeded. The tolerance range is defined with the parameters

10403 *Amplifier1CurrentDiff*

10408 *Amplifier2CurrentDiff*

10413 *Amplifier3CurrentDiff*

25.2.2.1 Deactivation of the emergency shutdown

Depending on the application, it is possible to define on which current output a fatal error should potentially not result in the standard emergency shutdown and should only trigger a suitable error response. In a dual-fuel application, for example, it would make sense for a fatal error to only be triggered on the valve that controls the diesel supply (because this means that the engine can no longer be operated), but not on the gas controls (work could continue here with pure diesel).

The software monitorings described above do not result in an emergency shutdown error if the relevant corresponding function

14404 *EcyAmplifier1ErrorOn*

14409 *EcyAmplifier2ErrorOn*

14414 *EcyAmplifier3ErrorOn*

is deactivated.



Attention

HEINZMANN recommends taking particular care when deactivating the emergency shutdown, because there is a risk of engine overspeed in the event of incorrect use!

26 Data management

The control provides various parameters for information on control device type, software version, hardware version, etc.

26.1 Serial number of control unit

Each individual control unit is unambiguously identified by a serial number. The first 4 digits identify the year of production and the month of delivery. The other digits represent the serial production number. The serial number is to be found on the **HEINZMANN** type plate or can be viewed by the following parameters:

3844 <i>SerialDate</i>	year and month of production
3845 <i>SerialNumber</i>	serial production number

26.2 Identification of control unit

The application-dependent functionality of a control is unambiguously defined by the firmware, which runs only on exactly one specific type of hardware.

3840 <i>HardwareVersion</i>	version number of control unit hardware
3841 <i>AddHardwareVersion</i>	version number of hardware modifications
3842 <i>SoftwareVersion</i>	version number of control unit firmware
3843 <i>BootSoftwareVersion</i>	version number of bootloader software

The software version identifier consists of a unique two to four digit customer number x defined by **HEINZMANN**, by a one to two digit variant number y and by a two digit revision index z. Either

xx.y.zz or xxxx.yy.zz

DcDesk2000 and the handheld programmer will allow the customer access only to control devices with a specific **HEINZMANN** basic software 00.yy.zz or to a custom firmware xxxx.yy.zz with the proprietary customer number x. The variants y serve to define different firmware implementations, e.g., for different engines of a manufacturer or for different applications of a certain type engine. Due to software extensions there may exist different revision stages z for the same variant with every higher ranking revision index encompassing the one below it and replacing it completely (↑ 2.2 Firmware).

26.3 Identification number of PC-programme / handheld programmer

Each dongle for the **HEINZMANN** PC programme DcDesk 2000 and each **HEINZMANN** handheld programmer (↑ 3.3 *DcDesk 2000*), required for the setting of parameters has its own specific identification number that is passed on to the control. The current identification number of the PC programme or handheld programmer is displayed in parameter 3850 *Identifier*. The identification number of the dongle or handheld programmer which was utilized last for storing parameter changes in the control can be

viewed by the parameter 3851 *LastIdentifier*. The user of this identifier is responsible for the setting of parameters.

CAN and Modbus communications modules also allow to change and save parameters in the control unit. In such cases a fixed identifier number is registered in 3851 *LastIdentifier*.

Communications module	Identifier
Modbus	94
CANopen	95
SAE J1939	96
DeviceNet	97
Custom protocol	98
Integrated control panel	99

27 Error Handling

27.1 General

HEINZMANN control units include an integrated error monitoring system by which errors caused by sensors, speed pickups, etc., may be detected and reported.

27.2 Error types

The following basic error types can be identified:

- ◆ Errors in configuring and parametrizing the control unit

These errors as caused by incorrect inputs made by the user and which the PC or hand programmer cannot intercept. They do not occur with a series-produced control unit.

- ◆ Errors during ongoing operation

These errors are the most important errors in a control unit in serial operation. Errors such as failures of speed pickups, setpoint adjusters, pressure and temperature sensors, or logical errors such as excessive temperatures or low boost pressure are typical of this category.

- ◆ Internal computing errors of the control unit

These errors can be due to faulty components or other unacceptable operating conditions. They do not occur in normal circumstances.

The various errors may be taken from the parameters 3000...3099, 13000...13095 and 23000...23095. When an error is currently present the value is set to 1, otherwise it is 0.

When rectifying an error, you should first eliminate the cause and then clear the current errors (reset). Some errors also reset by themselves as soon as the cause has been removed.

Errors can be reset with a PC, a hand programmer or, given the appropriate configuration, with the switching function 2828 *SwitchErrorReset*. If the error is still present, you will need to continue looking for the cause.

The control unit always starts with the assumption that no error is present and then checks the error conditions. The control unit can therefore be put in an error-free condition by a [↑]3.10 Reset of control unit, currently present errors are immediately displayed again, however.

27.3 Alarm display

The errors are divided into two basic groups. There are errors where powered mode can be continued although functionality may be restricted (e.g. sensor errors). The other category consists of so-called fatal errors that will cause an emergency shutdown of the engine (e.g., overspeeding, failure of both speed pickups).

These two error groups are signalled by the following parameters:

- 3799 *CommonWarning* all errors are only warnings (XIOS)
- 3800 *EmergencyAlarm*
- 3801 *CommonAlarm*

The parameter 3801 *CommonAlarm* will be set on the occurrence of any error, 3799 *CommonWarning* if all errors are only warnings (XIOS only) and 3800 *EmergencyAlarm* for fatal errors only (\uparrow 28.7 *Notabschaltfehler*). This means that 3800 *EmergencyAlarm* cannot occur by itself.

For type DC 1 and DC 2 control units, both the common alarm and the emergency alarm are output via two fixed binary outputs (\uparrow 28.3.2 *Error outputs of the control units DC 1 and DC 2*) and can therefore be linked with a visual or acoustic signal. With these two unit types and control unit types DC 8 and DC 10, there is also the option of carrying out an initial diagnosis via the \uparrow 28.3.4 *Error indication by LEDs* and, with the DC 1, also via the \uparrow 28.3.3 *Seven-segment display of the DC 1 series*.

27.3.1 Common alarm output

Control units of the types DC 5, 6, 7 and 11 are equipped with a dedicated binary error output for the transmission of the common alarm.

The DC 8 has an error LED fed to the outside and one on the circuit board, which are assigned to the common alarm. The circuit board LED is located to the left of the 9-pin communication connector (the bottom LED in the direction of the LEDs fed to the outside).

In the control units DC 9, 10 and 12, the only binary output can be freely parametrized. It is assigned the common alarm parameter 3801 *CommonAlarm* as standard.



*For the control unit types DC 5, 6, 7, 9 and 11, it should be noted that the error output or the only binary output is commuted by the bootloader during the control unit start-up (\uparrow 28.5.1 *Bootloader start tests*). With the DC 8, it is only the error LED on the circuit board, while the error LED visible on the outside is not affected by this.*

As to the common alarm, there is also the option of making the output flash at a frequency of 1 Hz for identifying warnings. For this purpose, the parameter 5101 *CommAlarmWarnFlashOn* = 1 must be set. As soon as at least one true error (no warning) is present, the common alarm output remains continuously active.

The common alarm output can also be configured so that it is reset for 0.5 s when a new additional error occurs. A PLC connected to this output can therefore detect the new error. For this, 5102 *CommonAlarmResetOn* = 1 must be set and the above flashing function disabled (5101 *CommAlarmWarnFlashOn* = 0). To also obtain an edge change when an error clears, 5103 *CommonAlarmResetBoth* must also be set to 1.



The flashing or the edge change are also shown in the parameter 3801 *CommonAlarm*. If this parameter is assigned to a binary output on the DC 8, 9, 10, 12 or XIOS, the reaction is therefore the same as on control units with a fixed assignment to the error output.

27.3.2 Error outputs of the control units DC 1 and DC 2

Emergency alarm and common alarm are each assigned to a dedicated binary output (\uparrow 19.3.9 *Feste Alarmausgänge*) to indicate the error state. The emergency alarm is output inverted (low-active) and interpreted as the "*Control ready*" signal, which would also signal a fatal error in case of missing power supply.

With this assignment, the outputs are to be interpreted as follows:

State "Common alarm"	State "Control ready"	Meaning
not active	not active	no power supply
not active	active	no error
active	not active	emergency alarm
active	active	common alarm

Tab. 1: Error outputs of DC 1 and DC 2

The "*Control ready*" output, i.e., the inverted emergency alarm signal, is usually used to activate the overspeed protection device.

27.3.3 Seven-segment display of the DC 1 series

With the DC 1 system, the operating state of the control unit or the engine can be viewed on a seven-segment display and an initial error diagnosis can be carried out in the event of severe errors if the cover is removed.

The operating states are indicated by a number. These numbers correspond to the values of parameter \uparrow 3830 *Phase*:

- 0: Waiting for engine start
- 1: Starting phase 1
- 2: Starting phase 2
- 3: Starting phase 3
- 4: Speed governor enabled, limiting functions disabled
- 5: Speed governor enabled, limiting functions enabled
- 6: Speed governor enabled, lower limit enabled
- 7: Speed governor enabled, upper limit enabled
- 8: Autoadjustment
- 9: Positioner

Severe errors are indicated by a letter:

- d Data record error: The control unit cannot continue working, as there is no valid data record available. This error corresponds to the errors 3090 *ErrData* or 3091 *ErrLogical*.
- E Fatal error: This error is indicated in case of particularly severe input and output errors (e.g. actuator cycle not completed, both speed pickups out of order etc.), causing the control unit to stop working. This indication is equivalent to the errors causing an emergency shutdown.
- E. Exception error: Internal computing error. This error is equivalent to the error 3094 *ErrIntern*.

27.3.4 Error indication by LEDs

The circuit boards of DC 1 control units have ten LEDs, DC 2 circuit boards have five LEDs, DC 8 circuit boards have six LEDs and DC 10 circuit boards have three LEDs, all providing further information on the operating and error state of the control unit. The majority of these LEDs are represented by parameters so that their states may also be examined with the housing closed.

27.3.4.1 LED error indication in the DC 1 series

LED no.	Colour	Parameter	Meaning
1	Red	-	The watchdog processor (CPU2) has detected an error.
2	Green	3821 <i>LED_CPU</i>	The main processor is working.
3	Red	3822 <i>LED_SpeedPickUp1Off</i>	There are no pulses on speed pickup 1.
4	Red	3823 <i>LED_SpeedPickUp2Off</i>	There are no pulses on speed pickup 2.
5	Red	3824 <i>LED_Actuator</i>	An actuator error has occurred. This LED will come on if one of the following errors occurs 3050 <i>ErrorFeedback</i> , 3053 <i>ErrActuatorDiff</i> , 3059 <i>ErrFeedbackAdjust</i> .
6	Red	3825 <i>LED_PowerSupply</i>	An error in the supply voltage has occurred and 3085 <i>ErrPowerSupply</i> or 3086 <i>ErrPowerSupplyExt</i> has occurred on DC 1-04.
7	Red	3826 <i>LED_CommonAlarm</i>	At least one error has occurred. This LED is the equivalent of the common alarm output 3801 <i>CommonAlarm</i> .
8	Red	3827 <i>LED_FuellLimitBoost</i>	The filling is being limited by 2714 <i>BoostLimitActive</i> is set to 1.

9	Red	3828 <i>LED_FuelLimitMax</i>	The filling is being limited by 2711 <i>FuelLimitMaxActive</i> is set to 1.
10	Red	3829 <i>LED_FuelLimitMin</i>	The filling setpoint is 0 % and 2710 <i>FuelLimitMinActive</i> is set to 1.

Tab. 2: LED error indication DC 1

27.3.4.2 LED error indication in the DC 2 series

LED	Colour	Parameter	Meaning
1	Green	3821 <i>LED_CPU</i>	The main processor is working.
2	Red	3822 <i>LED_SpeedPickUp1Off</i>	There are no pulses on speed pickup 1.
3	Red	3823 <i>LED_SpeedPickUp2Off</i>	There are no pulses on speed pickup 2.
4	Red	3824 <i>LED_Actuator</i>	An actuator error has occurred. This LED will come on if one of the following errors occurs 3050 <i>ErrorFeedback</i> , 3053 <i>ErrActuatorDiff</i> , 3059 <i>ErrFeedbackAdjust</i> .
5	Red	3825 <i>LED_CommonAlarm</i>	At least one error has occurred. This LED is the equivalent of the common alarm output 3801 <i>CommonAlarm</i> .

Tab. 3: LED error indication DC 2

27.3.4.3 LED error indication in the DC 8 series

LED	Colour	Parameter	Meaning	
			flashing (2 Hz)	permanently active
1	Green	2858 <i>LED_PowerSupply</i>	An error has occurred on the supply voltage, 3085 <i>ErrPowerSupply1</i> = 1 or 3086 <i>ErrPowerSupply2</i> = 1.	The supply voltage is OK.
2	Green	2859 <i>LED_SpeedPickUp1</i>	An error has occurred on speed pickup 1. This flashing is the equivalent of 3001 <i>ErrPickUp1</i> = 1.	There are pulses on speed pickup 1. This indication is the equivalent of 2006 <i>PickUp1Active</i> = 1.
3	Green	2860 <i>LED_SpeedPickUp2</i>	An error has occurred	There are pulses on

			on speed pickup 2. This flashing is the equivalent of 3002 <i>ErrPickUp2 = 1</i> .	speed pickup 2. This indication is the equivalent of 2007 <i>PickUp2Active = 1</i> .
4	Orange	2861 <i>LED_OverTemp</i>	The circuit board temperature is too high. This flashing is the equivalent of the error 3075 <i>ErrOverTemp</i> .	-
5	Red	2862 <i>LED_Feedback</i>	An actuator error has occurred. This flashing is the equivalent of the error 3053 <i>ErrActuatorDiff</i> .	An actuator error has occurred. This indication is activated if 3050 <i>ErrorFeedback</i> or 3059 <i>ErrFeedbackAdjust</i> have occurred.
6	Red	2863 <i>LED_Alarm</i>	At least one non-fatal error has occurred. This flashing is the equivalent of 3801 <i>CommonAlarm = 1</i> , 3800 <i>Emergency Alarm = 0</i> .	A fatal error occurred and the engine had to be switched off. This indication is the equivalent of 3800 <i>EmergencyAlarm = 1</i> .

Tab. 4: LED error indication DC 8

27.3.4.4 LED indicator in the DC 10 series

The HEINZMANN control units from the DC 10 series can be equipped with three indicator LEDs (hardware version). The green LED shows whether the power supply to the control unit is on. The red LED is connected to the binary output (terminal 13), which is freely parametrizable, but is usually parametrized with the error indication 3801 *CommonAlarm*. The yellow status LED is freely parametrizable.

LED	Colour	Assignment parameter / meaning
1	Green	Power supply to the control unit is on
2	Yellow	852 <i>StatusLED_Assign</i>
3	Red	851 <i>DigitalOut_Assign</i>

Tab. 5: LED error indication DC 10

27.4 Error memory

When the control unit is powered off, it loses all its information about the current errors. However, the unit has an integral permanent error memory that provides an overview of errors that have occurred. Every error that has occurred at least once since the last time the error memory was cleared is entered here.

All control units except for DC 1 and DC 2 contain an extended error memory as standard (↑ 28.4.1 Operating data memory and extended error memory), which logs the number of occurrences and the times when the error occurred. On request, the DC 2 system may also be equipped with an extended error memory.

All firmware variants of the DC 1 system and the basic software of the DC 2 system only show that an error has occurred, however, and do not indicate the order or the time of their occurrence (simple error memory).

For the firmware, the values in the error memory are just display values and are not otherwise relevant. It only responds to the occurrence of errors during ongoing operation.

The permanent error memory can be inspected via the parameters 3100, 13100 or 23100 upwards respectively. In simple error memories, only 0 or 1 is indicated here, in the extended memory, an error counter is included. The numbers of these historic errors are incremented by 100 compared to their associated current error.

Once a system has been commissioned, the error memory must always be cleared to ensure that errors which occurred, e.g. due to sensors that are not yet connected, are not subsequently evaluated as errors during engine operation.



When parameter 5100 NoStoreSErrOn = 1 is set and the error memory is then cleared, no errors will be stored in the error memory until the next ↑ 3.10 Reset des Steuergerätes. This means that a control unit with a customised data record can be shipped in error-free condition without the inputs having to be stimulated with the correct values. Parameter 5100 itself cannot be stored.

The permanent error memory can only be reset with the PC or hand programmer. The control unit then starts to accumulate new errors in the empty error memory. The error memory must therefore be cleared after each successful service.

27.4.1 Operating data memory and extended error memory

All control units except for DC 1 and DC 2 contain an operating data memory and an extended error memory as standard.

On request, the DC 2 system can be provided with an operating data memory and an extended error memory on the CAN or Modbus additional module respectively. This is true irrespective of whether CAN or Modbus protocols are used.

The logged operating data consists of the number of engine starts in 2250 *EngineStartCounter* and the operating hours, i.e. the number of hours the engine is running, in 3871 *OperatingHourMeter* and 3872 *OperatingSecondMeter*.

For each error that has occurred since the last error memory reset, there is an error counter and the time of the first and last occurrence. These times are shown in operating hours. Up to 12 environmental data can also be logged with each error, to match the time of the last occurrence. The maximum number of environmental data is set by the firmware that is used, and cannot be changed. However, the choice of environmental data can be freely configured by the user in the error memory window of DcDesk 2000. This should take place when the system is commissioned and the values should not be changed at a later stage unless absolutely necessary.

In all systems except for XIOS, the error counters are displayed in the error memory parameters starting from 3101 *SErr....* The times of the first and last occurrence and the environmental data can be viewed in the error memory window of DcDesk 2000 or ARGOS or on the hand programmer HP 03.

27.5 Bootloader

The HEINZMANN control units contain a so-called bootloader. This part of the program is located in a certain section of the ROM and is programmed at the factory. The bootloader cannot be erased.

When the control unit is started by switching on the supply voltage or a reset, the bootloader program is always run first. It executes important tests which tell it whether the actual control unit program can function or not. The bootloader then decides whether the rest of the program sequence can be sent to the control unit program or whether it should stay in bootloader mode for the safety of personnel and the machine. As long as the program is in bootloader mode, the engine cannot be started.



All tests on the bootloader and the subsequent initialization of the main program take approx. 500 ms in DC 1 and DC 2, in the other control units, the process takes approx. 200...300 ms.

27.5.1 Bootloader start tests

In the following, you will find a description of the tests performed by the bootloaders of all control units and the resulting actions. Communication with the unit is not possible while the tests are in progress, especially when the program sticks in an endless loop because of a fatal error. This is why different types of display on the control units are used to indicate the current test mode. Unfortunately, DC 12 and XIOS do not have an option for these displays, but, of course, also carry out these tests.

- ◆ Watchdog test

Control unit	Error indication type
DC 1	one bar of the seven-segment display
DC 2	LED 5 is lit
DC 8	Error LED on the circuit board is on
other (except for DC 12 and XIOS)	Error output on (on DC 9, the binary output)

Tab. 6: Bootloader: Watchdog test

The test checks whether the watchdog built into the processor is operational. The purpose of the test is to ensure that, in an undefined program sequence, the control unit enters a safe state after a defined time. If the watchdog test is negative, the bootloader program stays in an endless loop and the said display stays on.

◆ External RAM test

Control unit	Error indication type
DC 1	two bars of the seven-segment display
DC 2	LEDs 5 and 4 are lit
other	-

Tab. 7: Bootloader: RAM test

During this test, various binary patterns are written to the external RAM memory on the control circuit board and read out again. If at least one cell does not contain the expected code, the bootloader program enters an endless loop and the said display stays on.

◆ Internal RAM test

Control unit	Error indication type
DC 1	two bars of the seven-segment display
DC 2	LEDs 5 and 4 and 3 are lit
DC 8	Error LED on the circuit board is on
other (except for DC 12 and XIOS)	Error output on (on DC 9, the binary output)

Tab. 8: Bootloader: Internal RAM test

Different bit patterns are read to the internal processor RAM and read back again. If at least one cell does not contain the expected code, the bootloader program enters an endless loop and the said display stays on.

◆ Bootloader program test

Control unit	Error indication type
DC 1	three bars of the seven-segment display
DC 2	LEDs 5, 4, 3 and 2 are lit
DC 8	Error LED on the circuit board is on
other (except for DC 12 and XIOS)	Error output on (on DC 9, the binary output)

Tab. 9: Bootloader: Bootloader program test

A checksum is calculated over the memory area that contains the bootloader program and is compared with the checksum programmed at the factory. If they do not match, the bootloader program stays in an endless loop and the said display stays on.

◆ Control unit program test

Control unit	Error indication type
DC 1	three bars and dot in the seven-segment display
DC 2	all five LEDs are lit
DC 8	error LED on the circuit board flashing: three short flashes, long off, three short flashes, ...
other (except for DC 12 and XIOS)	error output flashing (binary output on DC 9): three short flashes, long off, three short flashes, ...

Tab. 10: Bootloader: Control unit program test

A checksum is calculated over the memory area that contains the control unit program and is compared with the programmed checksum. If they do not match, the bootloader enters a state in which the error 3087 *ErrMainCheckSum* is displayed via the serial communication (DcDesk 2000 PC program or hand programmer).

◆ Watchdog trigger

The bootloader enters a state in which the watchdog error 3089 *ErrWatchdog* is displayed via the serial communication (DcDesk 2000 PC program or hand programmer).

27.5.2 Bootloader communication

Communication between DcDesk 2000 or a hand programmer and the bootloader can commence when

- DC 1: "b" appears in the seven-segment display
- DC 2: the five LEDs are running completely
- DC 5, 6, 7, 9, 11: the error output on the control units is flashing (binary output on DC 9)
- DC 8: the error LED on the circuit board is flashing and all LEDs visible on the outside are deactivated
- DC 12, XIOS:

In this condition, errors are indicated and it is also the starting point for the download of a new control unit program (only with DcDesk 2000) which is performed by the bootloader.



Note

On the DC 1, the rotary switch should be in position 0 before communication with DcDesk 2000 is started (↑ 19.2.3 Drehschalter).

27.5.3 Bootloader error

The error indications of the bootloader can be found under ↑ 28.8 Fehlerparameterliste.

27.6 Configuration errors

If the configuration of the control device is faulty, this will be indicated in 3092 *ErrConfiguration*. A faulty configuration may result for instance if during parameter setting for inputs and outputs the channel type was not indicated.

In addition to 3092 *ErrConfiguration* an error code is output in 3000 *ConfigurationError*, which gives information about the type of error occurred. The message displayed in 3000 *ConfigurationError* changes every second and shows all currently present configuration errors.



Note

The communication programme DcDesk2000 displays the error message for configuration errors in the window "Current errors".

A configuration error can be deleted with the command "Clear error" but this does not correct the cause of the error. Most configuration errors are checked only when the control device starts. Therefore a reset will be necessary after the parameters have been changed and saved in the control device.

The following tables give an overview of the error codes and their meaning. It depends on the version of the control device software whether one of the mentioned communications protocols is supported or less. In other words, not all the errors mentioned here will occur in a specific control unit.

Variable Ports	
10	Port used as analogue input but not so configured

15	Port used as analogue output but not so configured
20	Port used as PWM input but not so configured
25	Port used as PWM output but not so configured
30	Port used as digital input but not so configured
35	Port used as digital output but not so configured
41	Channel type not applicable to this port

DC 6	
11	LMG on analogue input 1, but not configured to 0..5V or 5230 LoadControlOrPot <> 1
12	SyG on analogue input 2, but not configured to 0..5V

DC 5	
105	Port as frequency output 1 configured but as digital output 8 used
106	Port as frequency output 2 configured but as digital output 9 used
120	Port as PWM input 1 configured but as digital input 1 used
125	Port as PWM output 1 configured but as digital output 10 used
126	Port as PWM output 2 configured but as digital output 9 used
130	Port as digital input 1 configured but as PWM input 1 used
135	Port as frequency output 2 or as digital output 9 configured but as PWM output 2 used
136	Port as digital output 10 configured but as PWM output 1 used
140	The 37 V channel or one of the temperature channels is assigned to a current or voltage sensor
141	There is another channel assigned to the alternator than the 37 V channel
142	There is another channel assigned to a temperature sensor than a temperature channel

DC 10	
200	Port 3 als Analog- oder Binäreingang konfiguriert aber nicht verfügbar
201	Port 4 als Analog- oder Binäreingang konfiguriert aber nicht verfügbar

202	Port 6 ist als analoger oder digitaler Eingang benutzt, ist aber nicht verfügbar (altes Layout)
203	Kanal 7 ist verwendet (Temp Eingang), ist aber nicht verfügbar (altes Layout)
204	Einem Sensor ist dem Temperaturkanal (7) zugeordnet, Port 5 ist aber nicht als Temperatureingang konfiguriert
205	PU1 ist an , Port 6 ist aber nicht als Pickup-Eingang konfiguriert
206	PU2 ist an , Port 5 ist aber nicht als Pickup-Eingang konfiguriert
207	Port 5 Pull-up-Widerstand ist konfiguriert, ist aber nicht verfügbar (altes Layout)
208	CAN-Kommunikation ist konfiguriert, ist aber nicht verfügbar (Hardware-Variante ohne CAN)
209	Endstufe ist an (ActuatorOn), ist aber nicht verfügbar (Variante ohne Endstufe)
210	LED-Ausgang ist zugewiesen, ist aber nicht vorhanden
211	Port 7 ist als digitaler Eingang benutzt, ist aber nicht verfügbar (altes Layout)
212	PU1 nicht verfügbar (altes Layout)
213	Lambda-Sensor ist auf dem Kanal nicht zuweisbar
214	Lambda-Sensor ist auf Port 3 zugewiesen. Port 3 ist aber nicht als Lambda-Sensor-Eingang konfiguriert
215	Lambda-Sensor ist auf Port 6 zugewiesen. Port 6 ist aber nicht als Lambda-Sensor-Eingang konfiguriert

DC 8

300	Analogeingang 2 kann nicht als Stromeingang konfiguriert werden
-----	---

Ausgangs-Zuweisung

700	unbekannter Ausgangs-Kanaltyp zugewiesen
701	Ausgangs-Kanaltyp wird nicht unterstützt
702	Kanaltyp Binärausgang wird nicht unterstützt
703	Kanaltyp Analogausgang wird nicht unterstützt
704	Kanaltyp PWM-Ausgang wird nicht unterstützt
705	Kanaltyp Stellgeräteausgang wird nicht unterstützt
706	Kanalnummer für Binärausgang zu groß
707	Kanalnummer für Analogausgang zu groß

708	Kanalnummer für PWM-Ausgang zu groß
709	Kanalnummer für Stellgeräteausgang zu groß oder nicht zuweisbar
710	zugewiesene Parameternummer existiert nicht
711	zugewiesener Parameter ist kein Bitwert

Configuration errors – switching functions allocation	
800	Channel type was assigned to a switching function not supported by the software
804	Channel number too high for customer protocol switching function
805	Channel number too high for CANopen switching function
806	Channel number too high for DeviceNet switching function
807	Channel number too high for Modbus switching function
808	Channel number too high for SAE J1939 sensor input.
809	Channel number too high for HZM-CAN customer module switching function
810	Channel number too high for HZM-CAN twin-module switching function
811	Channel number too high for WAGO module switching function
812	More than 32 switching functions set
854	Customer protocol inactive or not supportive of switching functions
855	CANOpen inactive or not supportive of switching functions
856	DeviceNet inactive or not supportive of switching functions
857	Modbus inactive or not supportive of switching functions
858	SAE J1939 protocol not active or without digital inputs
859	HZM-CAN customer module inactive or not supportive of switching functions
860	HZM-CAN twin-module inactive or not supportive of switching functions
861	WAGO inactive or not supportive of switching functions
863	HZM-CAN-PE-module switching input inactive or not supportive of digital inputs

Configuration errors - sensor allocation	
900	Channel type was assigned to sensor not supported by the software
901	Channel number too high for analogue sensor input
902	Channel number too high for PWM sensor input
903	Channel number too high for HZM-CAN-PE module sensor input
904	Channel number too high for customer protocol sensor input

Configuration errors - sensor allocation	
905	Channel number too high for CANopen sensor input
906	Channel number too high for DeviceNet sensor input
907	Channel number too high for Modbus sensor input
908	Channel number too high for SAE J1939 sensor input.
909	Channel number too high for HZM-CAN customer module sensor input
910	Channel number too high for HZM-CAN twin-module sensor input
911	Channel number too high for WAGO module switching function
912	A HZM-CAN PE module type was assigned that is not configured or is not equipped with sensors.
916	HZM-CAN-ALL sensor not supported
917	Knotennummer des Sensor-Senders über HZM_CAN_ALL nicht belegt
918	DC-Knoten zugewiesen, der nicht konfiguriert ist oder keine Sensoren besitzt
919	Kanalnummer für ICENI-Sensoreingang zu groß
920	Kanalnummer für Frequenz-Sensoreingang zu groß
921	Sensorkanal zugewiesen, der nicht als Analogeingang konfiguriert ist
922	Sensorkanal zugewiesen, der nicht als PWM-Eingang konfiguriert ist
923	Sensorkanal zugewiesen, der nicht als Frequenzeingang konfiguriert ist

Configuration error – Engine configuration	
1000	Frequency resulting from teeth number and maximum required speed is too high.
1012	No pickup available, one pickup must be activated at least
1015	With odd teeth number it is not possible to filter over only one crank shaft revolution

Configuration error – Dual fuel engine	
1100	Gas PE node number not defined or node type false
1101	Gas PE node number defined but actuator by own hardware activated
1102	Gas PE node number defined but actuator/fuel telegram not activated
1103	Gas setpoint has no destination
1104	Supervisor mode configured but nevertheless control functions activated
1105	zu viele Ausgänge für Drosselklappen konfiguriert

Fahrgeschwindigkeit	
----------------------------	--

1150	Velocity gefordert, aber Eingang nicht konfiguriert
------	---

Funktionale Fehler	
---------------------------	--

3000	Relative Leistung nicht parametrier
------	-------------------------------------

Stellgerät	
-------------------	--

3950	Kanal zugewiesen, der nicht als Stellgeräterückführung möglich ist
3951	Kanal zugewiesen, der nicht als Stellgeräteendstufe möglich ist
3952	Die Hardware unterstützt keine Elyson-Rückführung
3953	Elyson-Rückführung darf nicht doppelt linearisiert werden
3954	Autoabgleich an Nullposition ist nur mit einem Stellgerät möglich
3955	Autoabgleich an Nullposition ist am V-Motor nicht möglich
3956	bei Ausgabe an Stellgerät ist der volle Wertebereich des Parameters gefordert
3957	Zuweisungsparameter für Ausgabe an Stellgerät nicht zugelassen
3958	Stellgerät aktiviert aber kein Zuweisungsparameter konfiguriert
3959	Stellgerät aktiviert aber kein Port konfiguriert

XIOS	
-------------	--

4000	unbekanntes Modul
4002	Modul existiert nicht
4003	Pickup-Konfiguration passt nicht zur Hardware (FPGA)
4009	IP6K9K Software passt nicht zur IP00-Hardware und umgekehrt (FPGA)

Communication protocol HZM-CAN PE	
11000	No master activated for periphery module
11001	PE module type is not supported by master
11002	Number of nodes for this PE module type exceeded
11003	PE module node number assigned twice
11004	PE-node not activated
11005	More than one master defined for periphery module
11006	No PE-module with actuator or valve output implemented

Communication protocol WAGO module	
21700	WAGO module not active, but values from it have been requested

Communication protocol CANopen	
21750	CANopen not active, but values from it have been requested

Communication protocol Modbus	
21800	Modbus not active, but values from it have been requested

Communication protocol DeviceNet	
21850	DeviceNet not active, but values from it have been requested
21851	A DeviceNet sensor that is not transmitted was allocated

Communication protocol SAE J1939	
21900	SAE J1939 not active, but values from it have been requested

Communication protocol HZM-CAN CM	
21950	HZM-CAN CM not active, but values from it have been requested

27.7 Emergency shutdown errors

The following list offers a summary of all errors that will cause an emergency shutdown during operation or inhibit engine start. When at least one so-called fatal error has occurred 3800 *EmergencyAlarm* is activated and in the control units HELENOS and PRIAMOS the signal "Control ready" is cancelled. These errors are described in detail in chapter ↑ 27.8 *Error parameter list*.

In custom firmware other errors may lead to an engine shutdown, e.g., when in a system with V-engines with two actuators and a connection via HZM-CAN the CAN connection fails or the second actuator reports an error.

Errors	Reason
3001 <i>ErrPickup1</i>	Error at pickup 1
3002 <i>ErrPickup2</i>	Error at pickup 2
3004 <i>ErrOverspeed</i>	Overspeed
3031 <i>ErrOilPressEcy</i>	Oil pressure below speed dependent shutdown threshold
3047 <i>ErrMisfireEcy</i>	Misfire signal over speed-dependent threshold
3050 <i>ErrFeedback</i>	Error at feedback of actuator 1
3051 <i>ErrFeedback2</i>	Error at feedback of actuator 2 (PRIAMOS III)
3052 <i>ErrFeedback3</i>	Error at feedback of actuator 3 (PRIAMOS III)
3056 <i>ErrFeedbackRef</i>	Error at feedback reference of actuator 1
3059 <i>ErrFeedbackAdjust</i>	Error during automatic actuator adjustment with actuator 1
3060 <i>ErrAmplifier</i>	Error end stage (ARCHIMEDES, ORION, PANDAROS)
3060 <i>ErrFeedbackAdjust2</i>	Error during actuator auto-adjust of actuator 2 (PRIAMOS III)
3061 <i>ErrFeedbackAdjust3</i>	Error during actuator auto-adjust of actuator 3 (PRIAMOS III)
3075 <i>ErrClearFlash</i>	Error at erasing the flash memory
3076 <i>ErrParamStore</i>	Error at saving of the parameters in flash memory (HELENOS and PRIAMOS) or E ² PROM memory (ARCHIMEDES; ORION, PANDAROS)
3077 <i>ErrProgramTest</i>	Error during permanent check of programme memory
3078 <i>ErrRAMTest</i>	Error during permanent check of RAM memory
3089 <i>ErrWatchdog</i>	Undefined programme flow, internal programming error (indication in bootloader)
3090 <i>ErrData</i>	No parameters or wrong check sum over parameters (always active after programme download in ARCHIMEDES, ORION or PANDAROS)
3091 <i>ErrLogical</i>	Error in parameter structure
3093 <i>ErrStack</i>	Stack overflow, internal programming error
3094 <i>ErrIntern</i>	Exception, internal programming error



Note

If a fatal error is reported, automatic calibration of actuators is not possible.

27.8 Error parameter list

The following error parameter list indicates the causes of each single error and the respective response of the control. Furthermore, it lists the appropriate actions to be taken to eliminate the respective error.

The errors are stored in the volatile error memory under the parameter numbers 3000/13000/23000 and higher and in the permanent error memory under the parameter numbers from 3100/13100/23100 onward.

The errors are sorted by ascending numbers with the parameter on the left indicating the actual error as stored in the volatile memory and with the parameter on the right indicating the one stored as a sentinel in the permanent error memory. As explained above, the control will only react to actual errors whereas the permanent error memory serves no other purpose than to accumulate information on the occurrences of errors.

3000 ConfigurationError

Cause: Configuration error.

Response: Error message.

Action: Check and correct control unit configuration, save parameters and reset control unit.

Reference: *↑ 27.6 Configuration errors*

3001 ErrPickUp1

3101 SErrPickUp1

Cause:

- Speed pickup 1 is at fault.
- Distance between speed pickup 1 and gear rim is too large.
- Speed pickup 1 is supplying faulty redundant pulses.
- Interruption of cable from speed pickup 1.
- Speed pickup 1 wrongly mounted.

Response:

- Control continues operation with speed pickup 2 if available.
- Emergency shutdown if there is no pickup 2 or it is also at fault.

Action:

- Check distance between speed pickup 1 and gear rim.
- Check preferred direction of pickup.
- Check cable to speed pickup 1.
- Check speed pickup 1, replace if necessary.

Reference: *↑ 6 Speed sensing*

3002 ErrPickUp2**3102 SErrPickUp2**

- Cause:
- Speed pickup 2 is at fault.
 - Distance between speed pickup 2 and gear rim is too large.
 - Speed pickup 2 sends additional error pulses
 - The cable from pickup 2 is interrupted
 - Speed pickup 2 wrongly mounted.
- Response:
- Control unit continues working with pickup 1.
 - Emergency shutdown if speed pickup 1 is also at fault.
- Action:
- Check distance between speed pickup 2 and gear rim.
 - Check preferred direction of pickup.
 - Check cable to speed pickup 2.
 - Check speed pickup 2, replace if necessary.
- Reference: ↑ *6 Speed sensing*

3003 ErrCamIndex**3103 SErrCamIndex**

- Cause:
- Cam index is at fault.
 - Distance between cam index and camshaft is too large.
 - Cam index sends additional error pulses
 - The cable from cam index is interrupted
 - Cam index wrongly mounted.
- Response: Single cylinder recognition no further available.
- Action:
- Check distance between cam index and camshaft.
 - Check cable to cam index.
 - Check cam index, replace if necessary.
- Reference: ↑ *10.8.1 Single cylinder recognition*

3004 ErrOverSpeed**3104 SErrOverSpeed**

- Cause: Engine speed was/is exceeding overspeed.
- Response: Emergency shutdown.
- Action:
- Check overspeed parameter (*21 SpeedOver*).
 - Check adjustment of set speed.
 - Check PID adjustment.
 - Check mechanical parts, linkage is possibly jamming.
 - Check actuator.
 - Check cable to actuator.
 - Substitute actuator.
 - Check pickup, possibly it sends wrong speed data.

- Check numbers of teeth (1 *TeethPickUp1* and 2 *TeethPickUp2*).
- With vehicle operation, check whether overspeed was due to thrust operation.

Reference: ↑ *6.4 Overspeed monitoring*

3005 ErrSetpoint1Extern	3105 SErrSetpoint1Extern
3006 ErrSetpoint2Extern	3106 SErrSetpoint2Extern
3007 ErrLoadCtrlInput	3107 SErrLoadCtrlInput
3008 ErrSyncInput	3108 SErrSyncInput
3009 ErrBoostPressure	3109 SErrBoostPressure
3010 ErrOilPressure	3110 SErrOilPressure
3011 ErrAmbientPressure	3111 SErrAmbientPressure
3012 ErrCoolantTemp	3112 SErrCoolantTemp
3013 ErrChargeAirTemp	3113 SErrChargeAirTemp
3014 ErrOilTemp	3114 SErrOilTemp
3015 ErrFuelTemp	3115 SErrFuelTemp
3016 ErrExhaustTemp	3116 SErrExhaustTemp
3019 ErrExcitReduct	3119 SErrExcitReduct
3020 ErrSpeedReduct /	3120 SErrSpeedReduct /
3020 ErrAlternator	3120 SErrAlternator
3021 ErrCoolantPressure	3121 SErrCoolantPressure
3022 ErrAsymmetricLoad	3122 SErrAsymmetricLoad
3023 ErrMeasuredPower	3123 SErrMeasuredPower
3024 ErrPowerSetpoint	3124 SErrPowerSetpoint
3025 ErrTurboOilTemp	3125 SErrTurboOilTemp
3026 ErrFuelPress	3126 SErrFuelPress
3027 ErrOilLevel	3127 SErrOilLevel
3028 ErrFuelLimitExtern	3128 SErrFuelLimitExtern
3029 ErrTransOilPressure	3129 SErrTransOilPressure

Cause: Some error has been detected for the respective sensor input (e.g., short circuit or cable break).

Response: Error may disappear by itself if configuration is adequate, i.e., when control unit measuring values return inside admissible limits.

Action: - Check sensor cable for short circuit or cable break.
 - Check the respective sensor, replace if necessary.
 - Check error limits for this sensor.

Reference: - ↑ *20.2.4 Error detection for analogue inputs*
 - ↑ *20.3.1 Error detection at PWM inputs*

3030 ErrOilPressWarn**3130 SErrOilPressWarn**

- Cause: Oil pressure has dropped below the speed dependent oil pressure warning characteristic.
- Response: - Error message.
- Error is cleared automatically when oil pressure is back above the oil pressure warning characteristic.
- Action: - Check engine (oil level, oil pump, etc.).
- Check oil pressure sensor.
- Check cable of oil pressure sensor.
- Check oil pressure warning characteristic
- Reference: *↑ 10.6 Speed dependent oil pressure monitoring*

3031 ErrOilPressEcy**3131 SErrOilPressEcy**

- Cause: Oil pressure has fallen below the speed dependent oil pressure emergency shutdown characteristic.
- Response: Emergency shutdown.
- Action: - Check engine (oil level, oil pump, etc.).
- Check oil pressure sensor.
- Check cable of oil pressure sensor.
- Check oil pressure emergency stop characteristic.
- Reference: *↑ 10.6 Speed dependent oil pressure monitoring*

3032 ErrCoolantTempWarn**3132 SErrCoolantTempWarn****3033 ErrChargeAirTempWarn****3133 SErrChargeAirTempWarn****3034 ErrOilTempWarn****3134 SErrOilTempWarn****3041 ErrExhaustTempWarn****3141 SErrExhaustTempWarn**

- Cause: Temperature has exceeded the warning threshold.
- Response: - Error message.
- Error is cleared automatically when coolant temperature returns below the warning characteristic.
- Action: - Check temperature.
- Check temperature sensor.
- Check temperature sensor cable.
- Check warning threshold.

- Reference:
- ↑ 10.1 Coolant temperature warning
 - ↑ 10.2 Charge air temperature warning
 - ↑ 10.3 Oil temperature warning
 - ↑ 10.4 Exhaust gas temperature warning
-

3039 ErrStarter
3139 SErrStarter

- Cause: Engine has not started after the max. number of cranking attempts.
- Response:
- Error message.
 - The starting request is terminated. A repetition of cranking attempts is possible by setting the starting request again.
- Action:
- Check alternator
 - Check starter
- Reference: ↑ 11.3 Starting request
- Note: *This parameter is implemented only in the ARCHIMEDES series.*
-

3040 ErrAlternatorWarn
3144 SErrAlternatorWarn

- Cause: Alternator voltage has dropped below a minimum value and cannot load the battery.
- Response:
- Error message.
 - Error is cleared automatically when alternator voltage returns above parameterized threshold
- Action:
- Check alternator
 - Check thresholds
- Reference: ↑ 10.9 Alternator charge monitoring
- Note: *This parameter is implemented only in the ARCHIMEDES series.*
-

3044 ErrCoolantPressWarn
3144 SErrCoolantPressWarn

- Cause: Coolant pressure has dropped below the speed dependent coolant pressure warning characteristic.
- Response:
- Error message.
 - Error is cleared automatically when coolant pressure is back above the coolant pressure warning characteristic.
- Action:
- Check engine (coolant level, coolant pump...)
 - Check coolant pressure sensor
 - Check cable of coolant pressure sensor
 - Check coolant pressure warning characteristic
- Reference: ↑ 10.7 Speed dependent coolant pressure monitoring

3045 ErrCoolantPressIdle**3145 SErrCoolantPressIdle**

Cause: Coolant pressure has dropped below the speed dependent coolant pressure forced idle speed characteristic.

Response: Forced idle speed

Action: - Check engine (coolant level, coolant pump...)
 - Check coolant pressure sensor
 - Check cable of coolant pressure sensor
 - Check coolant pressure forced idle speed characteristic

Reference: *↑ 10.5 Forced idle speed in locomotive applications*

3046 ErrMisfireWarn**3146 SErrMisfireWarn**

Cause: The calculated misfire value is below the load dependent characteristic.

Response: - Error message.
 - Error is cleared automatically when the calculated misfire value returns above the characteristic.

Action: Check

Reference: *↑ 10.8 Misfire monitoring in generator operation*

3047 ErrMisfireEcy**3147 SErrMisfireEcy**

Cause: The calculated misfire value is below the load-dependent emergency shutdown characteristic.

Response: Emergency shutdown

Action: Check

Reference: *↑ 10.8 Misfire monitoring in generator operation*

3048 ErrPowerDifference**3148 SErrPowerDifference**

Cause: The integrated power control outputs a difference between power setpoint and measured power for a period longer than set in 1240 *MaxPowerDiffMaxTime* and greater than set in 1239 *MaxPowerDifference*.

Response: - Error message.
 - Error is cleared automatically when power difference returns to admissible range.

Action: Check.

Reference: *↑ 14.2.3 Integrated power governor*

3048 ErrTwinEngine
3148 SErrTwinEngine

Cause: Power setpoint transmission from master to slave is disturbed.

Response: Both controls go into droop mode.

Action: - Check CAN connection
- Check CAN modules

Reference: - ↑ *15.1 Master/slave operation*

3049 ErrPECommonAlarm
3149 SErrPECommonAlarm

Cause: At least one of the HZM-CAN PE modules reports an error.

Response: Depends on the application

Action: - Parameter 2440 *CanPEError* gives detailed information for each PE module:

Bit number	Meaning
0	fatal error in periphery module
1	common alarm in periphery module
2	pickup error
3	I/O error
4	actuator or feedback error
5	velocity measurement error
6	cylinder error

- Check PE module

3050 ErrFeedback
3150 SErrFeedback
3051 ErrFeedback2
3151 SErrFeedback2
3052 ErrFeedback3
3152 SErrFeedback3

Cause: Error in feedback system of first, second or third actuator, actuator not connected.

Response: - Control unit cannot be put into operation
- Emergency shutdown.

Action: - Check feedback cable to actuator.
- Check actuator, replace actuator if necessary.
- Check error limits for feedback:
1952 FeedbackErrLow / 1953 FeedbackErrHigh

1962 *FeedbackErrLow2* / 1963 *FeedbackErrHigh2*
 1972 *FeedbackErrorLow3* / 1973 *FeedbackErrorHigh3*

Reference: —

Note: *The parameters for a second and third actuator are implemented only in the PRIAMOS III series.*

3053 ErrActuatorDiff

3054 ErrActuatorDiff2

3055 ErrActuatorDiff3

3153 SerrActuatorDiff

3154 SErrActuatorDiff2

3155 SErrActuatorDiff3

Cause: The difference between set actuator travel and actual actuator travel has exceeded 10 % of the total actuator travel for more than one second. This error will occur if the injection pump or the actuator are jamming or are not connected.

Response: - Error message.
 - Error will be cleared automatically, as soon as the difference falls below 10%.

Action: - Check injection pump / throttle valve, replace if necessary.
 - Check mechanical parts (linkage).
 - Check cables to actuator.
 - Check actuator, replace if necessary.

Reference: —

Note: *The parameters for a second and third actuator are implemented only in the PRIAMOS III series.*

3056 ErrFeedbackRef

3156 SerrFeedbackRef

Cause: Error in feedback system of actuator, actuator not connected.

Response: - Control unit cannot be put into operation
 - Emergency shutdown.

Action: - Check feedback cable to actuator.
 - Check actuator, replace actuator if necessary.
 - Check error limits for feedback reference:
 1956 *FeedbackRefErrLow* / 1957 *FeedbackRefErrHigh*

Reference: —

3059 ErrFeedbackAdjust

3060 ErrFeedbackAdjust2

3061 ErrFeedbackAdjust3

3159 SErrFeedbackAdjust

3160 SErrFeedbackAdjust2

3161 SErrFeedbackAdjust3

Cause: Automatic calibration of the actuator could not be performed, wrong input of reference values for actuator.

Response: Control unit cannot be put into operation

Action:

- Check voltage supply and supply lines to actuator.
- Check feedback cable to actuator.
- Check actuator, replace actuator if necessary.
- For actuators with 2-quadrant operation the engine stop switch must be opened (indication parameter 2810 *SwitchEngineStop* = 0) to perform automatic calibration of actuator.
- Check reference values and error limits for feedback
- Error thresholds
 - 1952 *FeedbackErrorLow* = 0
 - 1953 *FeedbackErrorHigh* = 65535
 - 1956 *FeedbackRefErrLow* = 0
 - 1957 *FeedBackRefErrHigh* = 65535
 for feedback and store values,
 restart governor by reset and repeat automatic calibration.
- Set error limits again.

Reference: —

Note: *The parameters for a second and third actuator are implemented only in the PRIAMOS III series.*

3060 ErrAmplifier

3160 SErrAmplifier

Cause: Overcurrent in actuator addressing

Response:

- Engine cannot be started
- Emergency shutdown.

Action: Check actuator, replace actuator if necessary.

Note: *These parameters are implemented only in the ARCHIMEDES, ORION and PANDAROS series.*

3061 ErrDigiIO1

3161 SErrDigiIO1

3062 ErrDigiIO2

3162 SErrDigiIO2

3063 ErrDigiIO3

3163 SErrDigiIO3

3064 ErrDigiIO4

3164 SErrDigiIO4

Cause: Hardware component has detected overload.

Response: Error message.

Action:

- Check digital IOs.
- Clear error.
- Insert relay interface module RIF 01

Reference: *↑ 19.3.7 Digital outputs*

Note: *These parameters are implemented only in the HELENOS series.*

3065 ErrISOCCommLine

3165 SErrISOCCommLine

Cause: Error at hardware component.

Response: Communication is not possible

Action: - Restart control with *↑ 3.10 Reset of control unit*
 - Notify **HEINZMANN**.

Note: *These parameters are implemented only in the HELENOS series.*

3070 ErrCanBus

3170 SErrCanBus

3072 ErrCanBus2

3172 SErrCanBus2

Cause: The CAN controller reports errors such as BusStatus, ErrorStatus or DataOverrun. In spite of resetting the controller, it may sometimes not be possible to clear the errors permanently.

Response: Depends on the application

Action: - Check CAN module
 - Check CAN connection

Reference: —

Note: *The parameters for the second CAN controller are available only in the ARCHIMEDES series.*

3071 ErrCanComm

3171 SErrCanComm

3073 ErrCanComm2

3173 SErrCanComm2

Cause: There is an overrun in the destination buffer or a message cannot be fed into CAN bus.

Response: Depends on the application

Action: - Check CAN module
 - Check CAN connection

Reference: —

Note: *The parameters for the second CAN controller are available only in the ARCHIMEDES series.*

3074 ErrModbusComm

3174 SErrModbusComm

Cause: Error in Modbus communication

Response: Depends on the application

Action: - Check the Modbus module
- Check the Modbus connection

3075 ErrClearFlash
3175 SErrClearFlash

Cause: Error on clearing the control's flash memory.

Response: - Engine cannot be started
- Emergency shutdown.

Action: - Restart control with \uparrow 3.10 *Reset of control unit.*
- Notify **HEINZMANN**.

3076 ErrParamStore
3176 SErrParamStore

Cause: Occurrence of an error on programming the control's parameter memory.

Response: - Engine cannot be started
- Emergency shutdown.

Action: - Restart control with \uparrow 3.10 *Reset of control unit.*
- Notify **HEINZMANN**.

3077 ErrProgramTest
3177 SErrProgramTest

Cause: Actual monitoring of the programme memory reports an error.

Response: - Engine cannot be started
- Emergency shutdown.

Action: - Restart control with \uparrow 3.10 *Reset of control unit.*
- Notify **HEINZMANN**.

3078 ErrRAMTest
3178 SErrRAMTest

Cause: Current RAM monitoring reports an error.

Response: - Engine cannot be started
- Emergency shutdown.

Action: - Write down values of parameters 3895 *RAMTestAddrHigh* and 3896 *RAMTestAddrLow*
- Restart control with a \uparrow 3.10 *Reset of control unit.*
- Notify **HEINZMANN**.

3079 ErrInternTemp1
3179 SErrInternTemp1
3080 ErrInternTemp2
3180 SErrInternTemp2

- Cause: Error at internal temperature starting from 3607 *InternTempIn1*.
- Response: - Error message.
- Error is cleared automatically as soon as temperature is back within the normal range.
- Note: *These parameters are implemented only in the ARCHIMEDES series.*

3080 ErrDisplay**3180 SErrDisplay**

- Cause: Integrated display cannot be addressed.
- Response: Error message.
- Action: Check display
- Note: *These parameters are implemented only in the PANDAROS series.*

3081 Err5V_Ref**3181 SErr5V_Ref**

- Cause: The internal 5V supply for sensor reference 3603 *5V_Ref* is not within the permissible range between 4.5 and 5.5 V.
- Response: - Error message.
- Error is cleared automatically as soon as the voltage is back within normal range.
- Action: Check sensor supply
- Note: *These parameters are implemented only in the ORION and PANDAROS series.*

3081 Err5VRefAna/TempIn1**3181 SErr5VRefAna/TempIn1****3082 Err5VRefAna/TempIn2****3182 SErr5VRefAna/TempIn2****3083 Err5VRefAna/TempIn3****3183 SErr5VRefAna/TempIn3****3084 Err5VRefAna/TempIn4****3184 SErr5VRefAna/TempIn4**

- Cause: The internal 5V supply for sensor reference 3603 *5VRefAnalog/TempIn1* is not within the permissible range between 4.5 and 5.5 V.
- Response: - Error Message
- Error is cleared automatically as soon as the voltage is back within normal range.
- Action: Check sensor supply
- Note: *These parameters are implemented only in the ARCHIMEDES series.*

3085 ErrVoltage**3185 SErrVoltage****3085 ErrPowerSupply****3185 SErrPowerSupply**

Cause: Power supply to the control unit is not within the permissible range between 9 and 32 V for ARCHIMEDES, ORION and PANDAROS, respectively between 8 to 33 V for HELENOS or 8 to 45 V for PRIAMOS.

Response: - Error message
- Error is cleared automatically as soon as the voltage is back within normal range.

Action: Check power supply.

3086 ErrVoltageExt**3186 SErrVoltageExt**

Cause: The supply voltage for the extension board is not within the permissible range from 8 to 45 V.

Response: - Error message
- Error is cleared automatically as soon as the voltage is back within normal range.

Action: Check power supply.

Note: These parameters are implemented only in the PRIAMOS III series.

3086 ErrPowerSupplyEDCFb**3186 SErrPowerSupplyEDCFb**

Cause: The supply voltage for EDC-actuator feedback 3602 *PowerSupplyEDCFeeDb* is not within the permissible range from 4.5 to 5.5 V.

Response: - Error message
- Error is cleared automatically as soon as the voltage is back within normal range.

Action: Check power supply.

Note: These parameters are implemented only in the ARCHIMEDES series.

3087 ErrCPU2**3187 SErrCPU2**

Cause: CPU 2 of control units of the PRIAMOS type has failed.

Response: Error message

Action: Notify **HEINZMANN**.

Reference: ↑ 27.9 *Watchdog processor CPU2 in PRIAMOS series*

Note: These parameters are implemented only in the PRIAMOS III series.

3087 ErrSupply7.5V**3187 SErrSupply7.5V**

- Cause: The internal 7.5V supply 3601 *Supply7.5V* is not within the permissible range between 7 and 8 V.
- Response: - Error message
- Error is cleared automatically as soon as the voltage is back within normal range.
- Action: Check power supply.
- Note: *These parameters are implemented only in the ARCHIMEDES series.*

3087 ErrMainChecksum

- Cause: Check-sum of control programme is wrong.
- Response: Control unit cannot be put into operation
- Action: - Restart control with \uparrow 3.10 *Reset of control unit.*
- Notify **HEINZMANN**.
- Reference: \uparrow 27.5 *Bootloader*
- Note: *This error will only be displayed by the bootloader.*

3088 ErrDigitalOut

3188 SErrDigitalOut

- Cause: An error was recognized at one or more digital outputs.
- Response: - Depends on the application.
- Action: - The parameters starting from 3631 *DigitalOut1:ErrType* give detailed information in case of error:

Bit number	Meaning
0	short against Ubatt
1	short against GND
2	OpenLoad or short against Ubatt
3	OpenLoad or short against GND

- the parameters starting from 3611 *DigitalOut1:Feedback* show the feed back output signal
- Reference: \uparrow 19.2.7 *Digital outputs*
- Note: *These parameters are implemented only in the ARCHIMEDES series.*

3089 ErrPEFatal
3189 SErrPEFatal

Cause: At least one of the HZM-CAN PE modules reports a fatal error.

Response: Depends on the application

Action: - Parameter 2440 *CanPEError* gives detailed information for each PE module:

Bit number	Meaning
0	fatal error in periphery module
1	common alarm in periphery module
2	pickup error
3	I/O error
4	actuator or feedback error
5	velocity measurement error
6	cylinder error

- Check PE module

Reference: —

3089 ErrWatchdog

Cause: Internal computing error, so-called "watchdog error" .

Response: - Control unit cannot be put into operation
- Emergency shutdown

Action: - Restart control with \uparrow 3.10 *Reset of control unit*.
- Notify **HEINZMANN**.

Reference: \uparrow 27.5 *Bootloader*

Note: *This error will only be displayed by the bootloader.*

3090 ErrData
3190 SErrData

Control devices of the type HELENOS and PRIAMOS

Cause: No data found or check sum over data is wrong.

Response: - Engine cannot be started
- Control unit is operating with default parameters

Action: - Check data for correct setting,
- Save parameters \uparrow 3.2 *Saving data* and restart control unit by a \uparrow 3.10 *Reset of control unit*.

Note: *This error will occur only when adjusting and saving parameters.*

3090 ErrData**3190 SErrData**

Control devices of the type ARCHIMEDES, ORION and PANDAROS

Cause: Parameter 3099 *EEPROMErrorCode* gives detailed information on error type.

Bit	Meaning
0	Programme recognition in E ² PROM is not valid, programme remains in bootloader, engine start is not possible
1	Operational data memory 1 in E ² PROM is not valid, operational data are cancelled, engine start is possible
2	Operational data memory 2 in E ² PROM is not valid, operational data are cancelled, engine start is possible
3	Serial number memory in E ² PROM is not valid, engine start is possible (level of integrated display is set to „1“)
4	Error memory in E ² PROM is not valid, error memory is cancelled, engine start is possible
5	Parameter memory in E ² PROM is not valid, standard firmware parameters are used, engine start is not possible
6	Exceptions memory in E ² PROM is not valid, engine start is possible

Action: - Check data for correct setting,
 - Restart governor with a \uparrow 3.10 *Reset of control unit*
 - Notify **HEINZMANN**

Note: *The error appears only after a reset of the control unit. Bit 5 is reported after every programme download.*

3091 ErrLogical**3191 SErrLogical**

Cause: Data structure error

Response: - Engine cannot be started
 - Control unit is operating with default parameters

Action: - Check data for correct setting,
 - Restart governor with a \uparrow 3.10 *Reset of control unit*
 - Notify **HEINZMANN**

3092 ErrConfiguration
3192 SErrConfiguration

- Cause: Configuration error
- Response: - Engine cannot be started
- Control unit is operating with default parameters
- Action: - Check data for correct setting,
- Restart governor with a \uparrow 3.10 *Reset of control unit*
- Notify HEINZMANN
- Reference: \uparrow 27.6 *Configuration errors*
-

3093 ErrStack
3193 SErrStack

- Cause: Internal programming or computing error, "stack-overflow".
- Response: - Engine cannot be started
- Emergency shutdown.
- Action: - Note down the value of parameter 3897 *StackTestFreeBytes* (HELENOS, PRIAMOS)
or 3897 *CStackTestFreeBytes* and 3898 *IStackTestFreeBytes* (ARCHIMEDES, ORION, PANDAROS)
- Notify HEINZMANN.
- Restart control with \uparrow 3.10 *Reset of control unit*.
-

3094 ErrIntern
3194 SErrIntern
3095 ExceptionNumber
3195 SExceptionNumber
3096 ExceptionAddr1High
3196 SExceptionAddr1High
3097 ExceptionAddr1Low
3197 SExceptionAddr1Low
3098 ExceptionAddr2High
3198 SExceptionAddr2High /
3198 SExceptionFlag
3099 ExceptionAddr2Low
3199 SExceptionAddr2Low

- Cause: Internal programming or computing error, so-called "EXCEPTION" error.
- Response: - Engine cannot be started
- Emergency shutdown.
- Action: - Note down the values of the parameters 3195 to 3199
- Notify HEINZMANN
- Restart control with \uparrow 3.10 *Reset of control unit*
- Note: *In control units of the ARCHIMEDES, ORION and PANDAROS series only the parameters of the error memory are shown.*

27.8.1 XIOS

The following error parameter list of the XIOS describes the causes of the individual errors and the reaction of the control unit. It also indicates actions to rectify the errors.

The errors are sorted in ascending order by number 3001...3099, 13000...13099, 23000...23099. Each number corresponds to an error group of up to 14 individual error states and two pieces of additional information. The error states are shown coded by bit (\uparrow Tab. 37). If several errors in an error group occur at the same time, the relevant combination or error bits is shown in hexadecimal format. DcDesk 2000 has one special window for displaying the current errors and one for the saved errors, where the individual error states are shown along with a brief description.

At least one of the errors 0 to 13 (0x0001..0x2000) from each error group has a meaning, which is described in the following tables.

Error 14 (0x4000) is set if all other active errors from this error group are only warnings.

Error 15 (0x8000) indicates that at least one of the errors 0...13 in this error group has resulted in an emergency shutdown.

Unused errors between 0 and 13 are not described.

The following table provides an overview of the individual errors in an error group and the corresponding ID, along with a description of the two errors 14 and 15, which are present in every error group. The errors 14 and 15 are not referred to again in the subsequent description of the individual error groups.

Error	ID	Meaning
0	0x0001	
1	0x0002	
2	0x0004	
3	0x0008	
4	0x0010	
5	0x0020	
6	0x0040	
7	0x0080	
8	0x0100	
9	0x0200	
10	0x0400	
11	0x0800	

Error	ID	Meaning
12	0x1000	
13	0x2000	
14	0x4000	Warning At least one error in this group has triggered a warning. → indication only
15	0x8000	Emergency shutdown At least one error in this group has triggered an emergency shutdown. → Engine is shut down or can not be started.

Tab. 37: XIOS: General error status

27.8.1.1 Speed sensors

3001 *ErrPickUp1*

3002 *ErrPickUp2*

Error	Meaning
0	<p>Speed pickup has failed or the cable of the speed pickup is broken or disconnected.</p> <ul style="list-style-type: none"> - No signal is measured over a specific period of time (monitoring only if $2000 \text{ Speed} > 256 \text{ StartSpeed2}$). - The camshaft index encoder has measured one rotation and there is no signal from the speed pickup. - The fail-safe camshaft index encoder is synchronised and there is no signal from the speed pickup. <p>→ The speed pickup is deactivated, redundant speed pickup takes over (if possible)</p> <ul style="list-style-type: none"> • Check the distance between the speed pickup and the toothed gear • Check the cable to the speed pickup • Check the speed pickup and replace if necessary
1	<p>Speed pickup does not start or is too far away from the toothed gear</p> <ul style="list-style-type: none"> - There is no signal from the speed pickup, even though the redundant speed pickup measures a speed. Only with redundant speed pickups 1 and 2. <p>→ The speed pickup is deactivated, redundant speed pickup takes over (if possible)</p> <ul style="list-style-type: none"> • Check the distance between the speed pickup and the toothed gear • Check the cable to the speed pickup • Check the speed pickup and replace if necessary

Error	Meaning
3	<p>The frequency delivered by the speed pickup is too high</p> <ul style="list-style-type: none"> - The interrupt difference over several periods is below 500 μs, which means that the input frequency is too high. <p>→ The speed pickup is deactivated, redundant speed pickup takes over (if possible)</p> <ul style="list-style-type: none"> • Check the speed pickup and replace if necessary

Tab. 38: XIOS: Possible errors speed sensors

27.8.1.2 Overspeed

3004 *ErrOverSpeed*

Error	Meaning
0	<p>Overspeed PickUp1</p> <ul style="list-style-type: none"> - The speed on PickUp1 was/is higher than the overspeed. - The combination of the number of teeth on PickUp1 and maximum speed/overspeed delivers a measurement frequency that is higher than the permitted value. <p>→ Emergency shutdown</p> <ul style="list-style-type: none"> • Check the parameter for overspeed (21 <i>SpeedOver</i>). • Check the speed setting. • Check the PID setting. • Check whether the overspeed was caused by overrun mode.
1	<p>Overspeed pickup 2</p> <ul style="list-style-type: none"> - The speed on PickUp2 was/is higher than the overspeed. - The combination of the number of teeth on PickUp1 and maximum speed/overspeed delivers a measurement frequency that is higher than the permitted value. <p>→ Emergency shutdown</p> <ul style="list-style-type: none"> • Check the parameter for overspeed (21 <i>SpeedOver</i>). • Check the speed setting. • Check the PID setting. • Check whether the overspeed was caused by overrun mode.

Tab. 39: XIOS: Possible errors overspeed

27.8.1.3 Setpoint adjusters and sensors

- 3005 *ErrSetpoint1Extern*
- 3006 *ErrSetpoint2Extern*
- 3007 *ErrLoadCtrlInput* (generator)
- 3008 *ErrSyncInput* (generator)
- 3009 *ErrBoostPressure/ErrBoostPressure1*
- 3010 *ErrOilPressure*
- 3011 *ErrAmbientPressure*
- 3012 *ErrCoolantTemp*
- 3013 *ErrChargeAirTemp*
- 3014 *ErrOilTemp*
- 3015 *ErrFuelTemp*
- 3016 *ErrExhaustTemp*
- 3019 *ErrExcitReduct* (locomotives)
- 3020 *ErrSpeedReduct* (locomotives)
- 3021 *ErrCoolantPressure*
- 3022 *ErrAsymmetricLoad* (ship)
- 3023 *ErrTractionVoltage* (locomotives)
- 3023 *ErrMeasuredPower* (generator)
- 3024 *ErrTractionCurrent* (locomotives)
- 3024 *ErrPowerSetpoint* (generator)
- 3025 *ErrTurboOilTemp*
- 3026 *ErrFuelPress*
- 3027 *ErrOilLevel*
- 3028 *ErrFuelLimitExtern*
- 3029 *ErrTransOilPressure*

- 13040 *ErrExhaustTempCyl11* – 13063 *ErrExhaustTempCyl124*
- 13064 *ErrAirMass*
- 13065 *ErrAlternatorVoltage* (XIOS, vehicle)
- 13066 *ErrBoostPressure2*
- 13067 *ErrLambda1*
- 13068 *ErrLambda2*
- 13069 *ErrNOx* (↑ 28.8.1.22 *Smart NOx and O2 sensor*)
- 13070 *ErrO2* (↑ 28.8.1.22 *Smart NOx and O2 sensor*)
- 13071 *ErrGasTemp* (DualFuel)
- 13072 *ErrGasPosition* (DualFuel)
- 13073 *ErrGasRailPressure* (DualFuel)
- 13074 *ErrGasValveCheckPr* (DualFuel)
- 13075 *ErrIgnitionOffset* (DualFuel)

Monitoring only if the sensor is received via an analogue or PWM input or a communication module.

Error	Meaning
0	<p>Signal short circuit to ground</p> <ul style="list-style-type: none"> - The measured value of the corresponding input value is below the lower error threshold. <p>→ Reaction according to the configuration of the sensor error handling</p> <ul style="list-style-type: none"> • Check the sensor cable. • Check the sensor. • Check the parameters for the error limits.
1	<p>Signal short circuit to supply voltage</p> <ul style="list-style-type: none"> - The measured value of the corresponding input value is above the upper error threshold. <p>→ Reaction according to the configuration of the sensor error handling</p> <ul style="list-style-type: none"> • Check the sensor cable. • Check the sensor. • Check the parameters for the error limits.
2	<p>Sensor supply voltage cable break or short circuit to ground</p> <ul style="list-style-type: none"> - The measured value of the corresponding reference voltage is below 4.5 V - Monitoring only during temperature input or if sensor referencing is activated. <p>→ Reaction according to the configuration of the sensor error handling</p> <ul style="list-style-type: none"> • Check the sensor cable. • Check the sensor.
3	<p>Sensor supply voltage short circuit to supply voltage</p> <ul style="list-style-type: none"> - The measured value of the corresponding reference voltage is higher than 5.5 V - Monitoring only during temperature input or if sensor referencing is activated. <p>→ Reaction according to the configuration of the sensor error handling</p> <ul style="list-style-type: none"> • Check the sensor cable. • Check the sensor.
4	<p>Error via communication module</p> <ul style="list-style-type: none"> - The connection to the communication module has failed. - The communication module reports an incorrect sensor value. <p>→ Reaction according to the configuration of the sensor error handling</p> <ul style="list-style-type: none"> • Check the connection to the communication module. • Check the sensor cable. • Check the sensor.

Error	Meaning
5	Threshold 1 exceeded or not reached - The sensor value has exceeded/not reached threshold 1 and the corresponding delay time has expired. Warning message or emergency shutdown depending on the monitoring configuration
6	Threshold 2 exceeded or not reached - The sensor value has exceeded/not reached threshold 2 and the corresponding delay time has expired. → Warning message or emergency shutdown depending on the monitoring configuration

Tab. 40: XIOS: Possible errors adjusters and sensors

27.8.1.4 Misfire monitoring (generator)

3047 *ErrMisfireDetection*

Error	Meaning
5	Warning threshold exceeded - 2050 <i>SpeedVariance</i> has exceeded the warning threshold - Monitoring only if 4055 <i>MisfireWarnCurveOn</i> is set → Warning message
6	Switch-off threshold exceeded - 2050 <i>SpeedVariance</i> has exceeded the switch-off threshold - Monitoring only if 4056 <i>MisfireEcyCurveOn</i> is set → Emergency shutdown

Tab. 41: XIOS: Possible errors misfire monitoring

27.8.1.5 Twin-engine applications (ship)

3048 *ErrTwinEngine*

Error	Meaning
0	Error in the transfer via HZM-CAN - The CAN controller reports an error 3070 <i>ErrCanBus1</i> - The transfer message is in timeout 3071 <i>ErrCanComm1</i> (opposite side is not transmitting). - Monitoring only if 5251 <i>TwinEngineEnable</i> and 4400 <i>CanCommDCOn</i> are set

Error	Meaning
	<p>→ the CAN connection is switched off and both engines run in droop mode</p> <ul style="list-style-type: none"> • Check the CAN cables. • Check the CAN terminating resistor. • Check the baud rate. • Configure the unit numbers 401 <i>CanMyNodeNumber</i> and 402 <i>CanOtherNodeNumber</i> correctly

Tab. 42: XIOS: Possible errors twin-engine applications (ship)

27.8.1.6 Integrated power governor

3048 *ErrPowerGovernor*

Error	Meaning
0	<p>Control deviation too large</p> <ul style="list-style-type: none"> - The difference between the actual power and the setpoint power is over 1240 <i>MaxPowerDiffMaxTime</i> seconds higher than the 1239 <i>MaxPowerDifference</i>. - Monitoring only if 5233 <i>PowerGovernorOrLMG</i> = 1. <p>→ Error message, error is self-cleaning</p>

Tab. 43: XIOS: Possible errors integrated power governor

27.8.1.7 Actuator error

3050 *ErrActuator/ErrActuator1*

3051 *ErrActuator2*

3052 *ErrActuator3*

Error	Meaning
0	<p>Actuator difference</p> <ul style="list-style-type: none"> - The difference between the target control path and the actual control path exceeds 10% of the total control path for more than one second. This situation exists when the fuel injection pump, the throttle valve, the linkage or the actuator sticks or is not connected. <p>→ Error display. The error clears when the difference is below 10% again.</p>

Error	Meaning
1	Autoadjustment error - Error during autoadjustment. → Engine start not possible.
2	Feedback error - Measured values outside the error limits → Engine start not possible, fatal error, amplifier switched off.
3	-
4	Overcurrent error - Overcurrent ID → Engine start not possible, fatal error, amplifier switched off.

27.8.1.8 CAN bus

3070 ErrCanBus1

3072 ErrCanBus2

Error	Meaning
0	BusOff detected - The CAN controller reports BusOff. → CAN telegrams can no longer be sent or received. <ul style="list-style-type: none"> • Check the CAN cables. • Check the CAN terminating resistor. • Check the baud rate.

Tab. 44: XIOS: Possible errors CAN bus

27.8.1.9 CAN communication

3071 ErrCanComm1

3072 ErrCanComm2

Error	Meaning
0	Timeout for receipt - The parameter 2403 <i>CanRxTimeout</i> shows which device type the timeout occurred in. → Reaction depends on the device type and application.
1	Overflow of the receive buffer - The receive buffer has overflowed. Some messages could not be received. The parameter 2402 <i>CanRxBufferState</i> shows which device type the receive buffer overflow occurred in.

Error	Meaning
	→ error message only
2	Overflow of the send buffer - The send buffer has overflowed. Some messages could not be sent. The parameter 2401 <i>CanTxBufferState</i> shows which device type the send buffer overflow occurred in. → error message only
3	Incorrect unit configuration - Two units with the same unit number and the same unit type are connected to the CAN network. The CAN communication is deactivated. → CAN telegrams are no longer sent or received. <ul style="list-style-type: none"> • Parametrize the unit numbers clearly.

Tab. 45: XIOS: Possible errors CAN communication

27.8.1.10 Internal temperature measurement

3079 *ErrInternTemperature*

Error	Meaning
5	Internal temperature too high - The internal temperature is higher than 100 °C for longer than 1 s. → Warning message
6	Internal temperature extremely high - The internal temperature is higher than 110 °C for longer than 1 s. → Warning message

Tab. 46: XIOS: Possible errors internal temperature measurement

27.8.1.11 Ethernet

3080 *ErrEthernet1*

3082 *ErrEthernet2*

Error	Meaning
0	Hardware error during initialization - The Ethernet component is not synchronized → Error message and communication is not possible via this connection
1	Broadcast server could not be created - Server for DcDesk unit search could not be started → Error message and the unit can not be found via DcDesk

Error	Meaning
2	Main server could not be created - Server for DcDesk communication could not be started → Error message and communication is not possible via this connection
3	Ethernet test - Error in the Ethernet test function (only available with special software) → error message only

Tab. 47: XIOS: Possible errors Ethernet

27.8.1.12 Voltage supply

3085 *ErrPowerSupply*

Error	Meaning
0	Supply voltage too low - The supply voltage 3606 <i>BoardVoltageVBAT</i> of the control unit is lower than 5 V or lower than 9 V for 0.5 s → Emergency shutdown <ul style="list-style-type: none"> • Check the supply voltage.
1	Supply voltage too high - The supply voltage 3606 <i>BoardVoltageVBAT</i> of the control unit is higher than 35 V for longer than 0.5 s → Emergency shutdown <ul style="list-style-type: none"> • Check the supply voltage.
7	Current consumption too high - More than 22 A is drawn, indication in 3607 <i>BoardCurrentSupply</i> → Emergency shutdown <ul style="list-style-type: none"> • Check cabling.

Tab. 49: XIOS: Possible errors voltage supply

27.8.1.13 Data storage

3087 ErrEEPROM

Error	Meaning
0	<p>Error during EEPROM access</p> <ul style="list-style-type: none"> - The data storage cannot be read or written on. → Error during reading: emergency shutdown, standard program parameters are used (this error can only be read during control unit start) → Error during saving: error message only, saving is not possible
1	<p>Parameter storage fault</p> <ul style="list-style-type: none"> - There is a fault in the data area for the parameter storage (this error can only be read during control unit start) → Emergency shutdown, standard program parameters are used
2	<p>Parameter storage invalid</p> <ul style="list-style-type: none"> - EEPROM can not be read (see error 0) (this error can only be read during control unit start) - First control unit start after program download → Emergency shutdown, standard program parameters are used
3	<p>ECU page fault</p> <ul style="list-style-type: none"> - There is a fault in the data area for the control unit identification. → error message only, data is still used
4	<p>NMI page fault</p> <ul style="list-style-type: none"> - There is a fault in the data area for the NMI data (e.g. operating seconds). → error message only, data is still used
5	<p>Workdata page fault</p> <ul style="list-style-type: none"> - There is a fault in the data area for the operating data. → the error memory is cleared, other data is still used
7	<p>Temperature page fault</p> <ul style="list-style-type: none"> - There is a fault in the data area for the calibration of resistance temperature sensors. → error message only, data is still used

Tab. 50: XIOS: Possible errors data storage

27.8.1.14 File system

3088 *ErrFilesys*

Error	Meaning
1	Access not possible - → Error message File system could not be connected <ul style="list-style-type: none"> • Hardware error
2	Driver initialization fault - → Error message File system driver could not be initialized Hardware error

Tab. 51: XIOS: Possible errors file system

27.8.1.15 USB host

3089 *ErrUSBHost*

Error	Meaning
0	- USB host functions could not be initialized → Error message <ul style="list-style-type: none"> • Disconnect the connected unit, carry out a reset and connect the unit again
1	- Read or write error → error message only <ul style="list-style-type: none"> • Data could not be read or written

Tab. 52: XIOS: Possible errors USB host

27.8.1.16 FPGA

3090 *ErrFPGA*

Error	Meaning
0	<p>No access</p> <ul style="list-style-type: none"> - No access to FPGA <p>→ FPGA is either faulty or not programmed</p> <ul style="list-style-type: none"> • Check the following parameters for reasonable content <ul style="list-style-type: none"> 3831 <i>CompileTimeFPGAMC</i> 3832 <i>CompileDateFPGAMC</i> 3833 <i>CompileYearFPGAMC</i> 3852 <i>FpgaIdMC</i> • FPGA must be reprogrammed
1	<p>DPRAM fault</p> <ul style="list-style-type: none"> - RAM test during initialization failed <p>→ FPGA is either faulty or not programmed</p> <ul style="list-style-type: none"> • Check the following parameters for reasonable content <ul style="list-style-type: none"> 3831 <i>CompileTimeFPGAMC</i> 3832 <i>CompileDateFPGAMC</i> 3833 <i>CompileYearFPGAMC</i> 3852 <i>FpgaIdMC</i> <p>FPGA must be reprogrammed</p>

Tab. 53: XIOS: Possible errors FPGA

27.8.1.17 Engine-specific error

3091 *ErrEngine*

Error	Meaning
0	<p>Charge control alternator</p> <ul style="list-style-type: none"> - The battery is not charged via the alternator. <p>→ error message only</p> <ul style="list-style-type: none"> • Check the connection between the alternator and battery
1	<p>Starter</p> <ul style="list-style-type: none"> - The starter can not start the engine. <p>→ error message only</p>

Tab. 54: XIOS: Possible errors engine-specific errors

27.8.1.18 Configuration

3092 *ErrConfiguration*

Error	Meaning
0	<p>Configuration errors</p> <ul style="list-style-type: none"> - There is a fault in at least one configuration of the control unit. <p>→ error message only</p> <ul style="list-style-type: none"> • The configuration error is displayed in the parameter 3000 <i>ConfigurationError</i> • Check the control unit configuration and rectify, save parameters and perform a control unit reset

Tab. 55: XIOS: Possible errors configuration

27.8.1.19 Internal errors

3094 *ErrIntern*

Error	Meaning
0	<p>Stack overflow</p> <ul style="list-style-type: none"> - The storage area available for the stack is full. <p>→ Emergency shutdown</p> <ul style="list-style-type: none"> • Note down parameters 3190 to 3198 • Note down parameter 3897 <i>StackTestFreeBytes</i> • Carry out a reset to restart the control unit and inform HEINZMANN
1	<p>Exception error</p> <ul style="list-style-type: none"> - The control unit reported an internal computing error. <p>→ Emergency shutdown</p> <ul style="list-style-type: none"> • Note the parameters 3190 <i>ExceptionNumber</i> to 3198 <i>ExceptionInfo2Low</i> • Carry out a reset to restart the control unit and inform HEINZMANN
2	<p>Error in the cyclical program test</p> <ul style="list-style-type: none"> - The checksum calculated continuously via the program does not match the saved checksum. <p>→ Emergency shutdown</p> <ul style="list-style-type: none"> • Note down parameters 3190 to 3198 • Carry out a reset to restart the control unit and inform HEINZMANN

Error	Meaning
3	<p>Error in the cyclical RAM test</p> <ul style="list-style-type: none"> - The running RAM test reports an error. → Emergency shutdown <ul style="list-style-type: none"> • Note down parameters 3190 to 3198 • Note 3895 <i>RAMTestAddrHigh</i> and 3896 <i>RAMTestAddrLow</i> • Carry out a reset to restart the control unit and inform HEINZMANN
4	<p>Overflow in the error memory</p> <ul style="list-style-type: none"> - The space available for the error memory is full. → error message only → new errors are no longer recorded in the error memory. <ul style="list-style-type: none"> • The error memory must be read out and cleared
5	<p>Error index too large</p> <ul style="list-style-type: none"> - An error is to be set, for which no parameter is available. → error message only <ul style="list-style-type: none"> • Carry out a reset to restart the control unit and inform HEINZMANN

Tab. 56: XIOS: Possible errors internal computing error

27.8.1.20 Dual fuel

13030 *ErrGasRailStatus*

Error	Meaning
0	<p>Gas section not OK</p> <ul style="list-style-type: none"> - External gas section monitoring was not completed successfully → The switch to dual fuel mode does not take place <ul style="list-style-type: none"> • Check the gas supply • Check the gas section
6	<p>The gas alarm external switch is active</p> <ul style="list-style-type: none"> - The external monitoring device has triggered a gas alarm → The switch to dual fuel mode does not take place Gas speed governor: The dual fuel mode is exited via the fast ramp Diesel reduction governor: The dual fuel mode is exited immediately without a ramp <ul style="list-style-type: none"> • Check the external monitoring device • Check 2847 <i>SwitchExternGasAlarm</i> (2871 <i>SwitchExternGasAlarm</i> with the XIOS)

Error	Meaning
7	<p>Gas pressure not in the range for gas operation</p> <ul style="list-style-type: none"> - Relative gas pressure is not in the range for dual-fuel mode <p>→ The switch to dual fuel mode does not take place.</p> <p>Gas speed governor: If the gas pressure is too high, the dual fuel mode is exited immediately without a ramp, otherwise via the normal ramp</p> <p>Diesel reduction governor: If the gas pressure is too high, the dual fuel mode is exited immediately without a ramp, otherwise via the fast ramp</p> <ul style="list-style-type: none"> • Check the gas pressure • Check the boost pressure • Check the limit values
8	<p>Gas temperature is not in the range for dual fuel operation</p> <ul style="list-style-type: none"> - Gas temperature is not in the range for dual fuel mode <p>→ The switch to dual fuel mode does not take place.</p> <p>The dual fuel mode is exited with the normal ramp</p> <ul style="list-style-type: none"> • Check the gas temperature • Check the temperature limits
9	<p>Gas does not bring any power</p> <ul style="list-style-type: none"> - Diesel speed governor does not react to the addition of gas in dual fuel mode, i.e. the diesel quantity does not fall <p>→ The dual fuel mode is exited immediately without a ramp</p> <ul style="list-style-type: none"> • Check the gas valves • Check the actuator on the throttle valve or MEGASOL control unit

Tab. 57: XIOS: Possible errors gas section
13031 ErrGasConditions

Error	Meaning
0	<p>Conditions for gas incorrect</p> <ul style="list-style-type: none"> - Dual fuel operation is required $2837 \text{ SwitchGasOrDiesel} = 1$, but at least one of the conditions does not apply <p>→ The switch to dual fuel mode does not take place</p> <p>Dual fuel mode is exited</p> <ul style="list-style-type: none"> • Check the conditions • Gas speed governor: evaluate the individual error messages
1	<p>Speed is not in the range for dual fuel operation</p> <ul style="list-style-type: none"> - Speed is not in the range for dual fuel mode <p>→ The switch to dual fuel mode does not take place</p> <p>The dual fuel mode is exited with the normal ramp</p>

Error	Meaning
	<ul style="list-style-type: none"> • Check the speed • Check the limit values
2	<p>Power is not in the range for dual fuel operation</p> <ul style="list-style-type: none"> - Power is not in the range for dual fuel mode <p>→ The switch to dual fuel mode does not take place The dual fuel mode is exited with the normal ramp</p> <ul style="list-style-type: none"> • Check the power • Check the limit values
3	<p>Diesel filling is not in the range for dual fuel operation</p> <ul style="list-style-type: none"> - Diesel filling is not in the range for dual fuel mode in diesel operation <p>→ The switch to dual fuel mode does not take place</p> <ul style="list-style-type: none"> • Check the diesel filling • Check the limit values
4	<p>Boost pressure is not in the range for dual fuel operation</p> <ul style="list-style-type: none"> - Boost pressure is not in the range for dual fuel mode <p>→ The switch to dual fuel mode does not take place The dual fuel mode is exited with the normal ramp</p> <ul style="list-style-type: none"> • Check the boost pressure • Check the limit values
5	<p>Oil pressure is not in the range for dual fuel operation</p> <ul style="list-style-type: none"> - Oil pressure is not in the range for dual fuel mode, i.e. the oil pressure warning is active <p>→ The switch to dual fuel mode does not take place The dual fuel mode is exited with the normal ramp</p> <ul style="list-style-type: none"> • Check the oil pressure
6	<p>Coolant temperature is not in the range for dual fuel operation</p> <ul style="list-style-type: none"> - Coolant temperature is not in the range for dual-fuel mode <p>→ The switch to dual fuel mode does not take place The dual fuel mode is exited with the normal ramp</p> <ul style="list-style-type: none"> • Check the coolant temperature • Check the temperature limits
7	<p>Charge air temperature is not in the range for dual fuel operation</p> <ul style="list-style-type: none"> - Charge air temperature is not in the range for dual fuel mode <p>→ The switch to dual fuel mode does not take place The dual fuel mode is exited with the normal ramp</p> <ul style="list-style-type: none"> • Check the charge air temperature • Check the temperature limits

Error	Meaning
8	<p>Exhaust temperature is not in the range for dual fuel operation</p> <ul style="list-style-type: none"> - Exhaust temperature is not in the range for dual fuel mode <p>→ The switch to dual fuel mode does not take place The dual fuel mode is exited with the normal ramp</p> <ul style="list-style-type: none"> • Check the exhaust temperature • Check the temperature limits
9	<p>Exhaust temperature difference is not in the range for dual fuel operation</p> <ul style="list-style-type: none"> - Exhaust temperature difference between the hottest and the coldest cylinder is not in the range for dual fuel operation <p>→ The switch to dual fuel mode does not take place The dual fuel mode is exited with the normal ramp</p> <ul style="list-style-type: none"> • Check the cylinder temperatures • Check the temperature parity of the cylinders • Check the temperature limits
10	<p>Ariadne reports a light knocking</p> <ul style="list-style-type: none"> - Light knocking <p>→ Gas speed governor: Gradual increase of the ignition oil quantity. Dual fuel mode is exited with the normal ramp if the maximum permissible increase is reached and the engine is still knocking</p> <p>Diesel reduction governor: Gradual increase of the diesel position setpoint. Dual fuel mode is exited with the fast ramp if the maximum permissible increase is reached and the engine is still knocking.</p> <ul style="list-style-type: none"> • Raise the absolute minimum ignition oil quantity 10055 <i>PilotDslAbsMinimum</i> • Gas speed governor: Raise the ignition oil quantity 10060 <i>PilotDieselSetpoint</i> (or curve) • Diesel reduction governor: Raise the diesel position setpoint 10060 <i>DieselSetpoint</i> (or curve)
11	<p>Ariadne reports heavy knocking</p> <ul style="list-style-type: none"> - Heavy knocking <p>→ The dual fuel mode is exited immediately without a ramp</p> <ul style="list-style-type: none"> • Raise the absolute minimum ignition oil quantity 10055 <i>PilotDslAbsMinimum</i> • Gas speed governor: Raise the ignition oil quantity 10060 <i>PilotDieselSetpoint</i> (or curve) • Diesel reduction governor: Raise the diesel position setpoint 10060 <i>DieselSetpoint</i> (or curve)

Error	Meaning
12	<p>MEGASOL gas positioner not synchronised</p> <ul style="list-style-type: none"> - MEGASOL gas positioner is not synchronised, although the diesel speed governor is running and a gas setpoint is transferred → The dual fuel mode is exited immediately without a ramp <ul style="list-style-type: none"> • Check the MVC control unit • Check the speed sensors on MVC
13	<p>Diesel filling is below ignition oil quantity</p> <ul style="list-style-type: none"> - In dual fuel operation, diesel filling is below 12060 <i>PilotFuelPresent</i> → The dual fuel mode is exited immediately without a ramp <ul style="list-style-type: none"> • Check the diesel filling • Check ignition oil quantity • Check the limit values

Tab. 58: XIOS: Possible errors gas conditions

13032 *ErrDualFuelStatus*

Error	Meaning
0	<p>Gas positioner is not responsive</p> <ul style="list-style-type: none"> - The control unit that the gas actuator or the gas valves are connected to reports an error → The switch to dual fuel mode does not take place The dual fuel mode is exited immediately without a ramp <ul style="list-style-type: none"> • Check the gas actuator • Check the gas control unit
1	<p>Ariadne is not responsive</p> <ul style="list-style-type: none"> - ARIADNE knock detection module has failed or CAN connection is faulty, no knock detection monitoring → The switch to dual fuel mode does not take place The dual fuel mode is exited immediately without a ramp <ul style="list-style-type: none"> • Check the CAN connection • Check ARIADNE
2	<p>Emergency stop command via external input</p> <ul style="list-style-type: none"> - 2873 <i>SwitchEmergencyStop</i> is active → Emergency shutdown

Tab. 59: XIOS: Possible errors dual fuel status

27.8.1.21 Smart NO_x and O₂ sensor
13033 ErrSNSNO_x, 13034 ErrSNSO₂

Error	Meaning
0	Sensor supply - Voltage supply not in the permissible range. • Check the sensor supply voltage.
1	Heating - Short circuit. •
2	Heating - Interrupted power circuit. •
3	Sensor - Short circuit. •
4	Sensor - Interrupted power circuit. •
5	SAE J1939 CAN transfer - RX message not consistent. •
6	SAE J1939 CAN transfer - RX message in timeout. •

Tab. 60: XIOS: Possible errors Smart NO_x and O₂ sensor

Additional information:

27.8.1.22 Exhaust temperature
13039 ErrExhaustTempMax

Error	Meaning
4	Error via HZM-CAN periphery module - The connection to the periphery module has failed. • Check the connection to the periphery module.

Tab. 61: XIOS: Possible errors maximum exhaust temperature

27.8.1.23 Error at valves with current control loop

13080 ErrAmplifier1

13081 ErrAmplifier2

13082 ErrAmplifier3

Error	Meaning
0	Error current deviation - Difference between current set-point and actual value is larger than allowed deviation for more than 100 ms. This occurs when the cable is broken for example <ul style="list-style-type: none"> • Error indication
1	—
2	Error of current value - Measured value beyond limit <ul style="list-style-type: none"> • Engine start not possible, fatal error, end stage shut down
3	—
4	Overcurrent error - Overcurrent detection <ul style="list-style-type: none"> • Engine start not possible, fatal error, end stage shut down

Tab. 61: XIOS: Possible errors maximum exhaust temperature

27.9 Watchdog processor CPU2 in PRIAMOS series

The controls of the PRIAMOS/PRIAMOS III type are equipped with a second processing unit CPU2. CPU2 serves for monitoring the main processor itself and for additional monitoring of overspeed which is also being supervised by the main processor. In vehicle applications, CPU2 can also be used for monitoring the gas pedal thus offering a second way of engine shutdown in case of failure, independently of the main processor.

Between the main processor and the watchdog processor two signals are continuously exchanged representing a sign of life of the respective sender. If the main processor's signal to the CPU2 fails this will be interpreted to imply that the main processor's performance is disturbed and that it is no longer capable of reliably governing the engine. For this reason the CPU2 will inhibit energizing of the actuator and trigger a permanently active reset by the main processor. By this, the engine is stopped and the main processor turned off.

Should the signal from the watchdog processor to the main CPU fail then only the error message 3087 *ErrCPU2* will be output and a common alarm issued. The alarm alerts to the

fact that the main processor is no longer monitored. In this event, the control unit should be exchanged as soon as possible for reasons of safety.

For additional monitoring of overspeed the parameter 22 *SpeedOverCPU2* has to be set. Overspeed as monitored by the CPU2 should be above overspeed 21 *SpeedOver* as monitored by the main processor in order to prevent this rather tough way of executing a shutdown from acting earlier than the controlled shutdown as executed by the programme of the main processor. This is of particular importance in case the main programme is to handle overrun conditions.

In vehicle operation, the CPU2 may be used to implement a second way of supervising the gas pedal and the actuator independently of the main processor.

To implement this monitoring function vehicle mode must have been selected. In addition, the gas pedal must have been connected to the analogue input 1 and an actuator with two-quadrant control such as the Bosch EDC pump must be used. Actuators of this type are energized only in direction of 100 % whereas a return spring is provided for acting in direction of 0 %. Besides, the signals of specific digital inputs must be set to certain values in order to activate monitoring: The digital input 2 must have been set to high, and the digital inputs 5 and 7 to low. This should be kept in mind when assigning these digital inputs to certain switching functions.

For this method of monitoring the following parameters must be set:

23 <i>SpeedSetpCPU2</i> = ...	Idle speed in CPU2
811 <i>FunctIdleSpeed</i> = 2	Idle speed switch
1200 <i>CPU2StartTimOutDelay</i> = ...	Delay time for shutdown test
1512 <i>AnalogIn1_ErrorLow</i> = ...	Low error threshold for gas pedal
1513 <i>AnalogIn1_ErrorHigh</i> = ...	High error threshold for gas pedal
1810 /3810 <i>OperationMode</i> = 1	Vehicle mode in main programme
1921 <i>ServoCurrentCPU2</i> = ...	Actuator current for shutdown test in CPU2
1922 <i>ServoCurrentStartTest</i> = ...	Actuator current for shutdown test in main processor
5200 <i>CPU2VehicleMode</i> = 1	Vehicle mode in CPU2
5911 <i>Amplifier2Qor4Q</i> = 1	Actuator with two-quadrant control

On powering up the control unit, a test is performed to ascertain whether the actuator can be controlled. This is done by being fully energized by the main processor. The CPU2 measures current that must be higher than 1921 *ServoCurrentCPU2*. Once the delay time 1200 *CPU2StartTimOutDelay* has elapsed, the CPU2 will turn energizing off and measure current once more. If it has remained above 1921 *ServoCurrentCPU2*, then the CPU2 will take this as a symptom that the actuator cannot be controlled properly. In either case the CPU2 will inhibit any engine start. This is achieved by turning the main processor off through a permanent reset.

For monitoring the gas pedal, the error thresholds of the analogue input will be checked and verified. Besides, a logical check of the gas pedal value is performed by means of the

signal from the idle speed switch 2811 *SwitchIdleSpeed* and the currently sensed speed. If the gas pedal is in position of 0 %, the idle speed switch must be active and speed may not exceed 23 *SpeedSetpCPU2*. All other combinations point to an error and lead to a current shut-off for actuators and main processor.

Whenever the CPU2 executes an error shutdown, this state is indicated by two LEDs on the casing. The first LED of the control unit (located directly at the edge of the casing) will light up red. The second LED indicating normally by green that the main processor is operating will darken.

When the main processor is turned off by the CPU2, communication or diagnostics by handheld programmers or by the PC programme DcDesk 2000 will no longer be possible. This is why this information is output via the LEDs.

28 Parameter description

Table *Parameter groups* provides an overview of which number ranges which functions can be found in. The following four sections list each individual parameter with a brief description and make reference to the detailed explanation of the parameter in this document or other publications.

These four parameter lists explain all parameters that can be defined in the control units with conventional injection. Not all of these parameters will appear in special firmware, however, in particular due to the different hardware requirements and the application or customer-specific implementation of functions that must be achieved. For this reason, only the available parameters determine the potential functionality of a control unit. Claims relating to certain functions cannot be made on the basis of the list provided here.

The defined level is given for each parameter. An operating tool such as DcDesk 2000, ARGOS or a hand programmer can only be used to view parameters with a level that is no higher than the level of the tool.

Parameters that require saving and a control unit reset after a change are marked by (RESET) ([↑ 3.2 Saving data](#), [↑ 3.10 Reset of control unit](#)).

Functional parameters that only apply to specific base systems have a list of the associated control units in italics alongside the parameter name, while device-specific (hardware dependent) parameters are set out in separate subordinate lists (e.g. the XIOS configuration). The identification DC 1 includes DC 1-03 and DC 1-04 if this is not explicitly noted. Parameters that are described in detail elsewhere but are included here for the sake of completeness can also be found in separate lists (e.g. CANopen parameters).

Only the first field parameter is given for curves and maps; the parameter number is labelled "ff" (and following). Groups of parameters that follow on from each other with consecutive numbering and the same name, e.g. 1510 *AnalogIn1_RefLow*, 1520 *AnalogIn2_RefLow*, are also listed under the first number with the label "ff". The numbers in parameter names are replaced by "x" or "y".

Parameters that have the same meaning in the control units but have slightly different names, e.g. 703 *SpeedLimitTempHigh* and 703 *SpeedLimitCoolTempHigh*, are listed under the same number with both names. In a small number of cases, the same parameter number has different functions in different applications. These numbers then occur multiple times with an indication of the application (e.g. Marine operation or locomotive operation).

No.	Parameters	No.	Measured values	No.	Functions	No.	Curves
1	Number of teeth, speed	2000	Speed pickup, speed	4000	Speed pickup, speed	6000	Misfire detection
50	Misfire detection	2050	Misfire detection	4050	Misfire detection		
100	Stability, droop	2100	Stability, droop	4100	Stability, droop	6100	Stability map, speed governor (speed values)
						6150	Stability map, speed governor (fuel quantity values)
200	Ramp			4200	Ramp	6200	Stability map, speed governor (correction values)
		2200	PE module actuator travel				
250	Engine start	2250	Engine start counter				
300	Actuator travel	2300	Actuator travel			6300	Stability curve, power governor
330	HZM-CAN ALL			4330	HZM-CAN ALL		
350	Fuel quantity	2350	Fuel quantity	4350	HZM-CAN	6350	Stability map, speed governor (performance values)
400	HZM-CAN	2400	HZM-CAN	4400	HZM-CAN	6400	Boost-pressure dependent fuel quantity and power limitation
500	Monitoring of pressures, temperatures, filling level, alternator			4500	Monitoring of pressures, temperatures, filling level, alternator	6500	Monitoring of oil pressure and coolant pressure
600	Excitation control PitchControl	2600	Excitation control PitchControl	4600	Excitation control PitchControl	6600	Excitation control PitchControl
680	Exhaust recycling Intake air throttle valve Wastegate Bypass valve	2680	Exhaust recycling Intake air throttle valve Wastegate Bypass valve	4680	Exhaust recycling Intake air throttle valve Wastegate Bypass valve		
700	Fuel quantity limitation	2700	Fuel quantity limitation Fuel quantity reduction	4700	Fuel quantity limitation Fuel quantity reduction	6700	Speed-dependent fuel quantity limitation 1
800	Binary switching functions	2800	Switching functions	4800	Configuration of input/output channels	6800	Speed-dependent fuel quantity limitation 2
850	Binary outputs (single assignment)	2850	Binary outputs	4850	Binary outputs (multiple assignment)		
900	Setpoint adjusters and sensors	2900	Setpoint adjusters and sensors	4900	Setpoint adjusters and sensors	6900	Notches, speed-dependent power limitation
1000	Error handling for setpoint adjusters and sensors	3000	Current errors	5000	Error handling for setpoint adjusters and sensors	7000	Speed-dependent and ambient pressure-dependent power reduction
		3100	Error memory	5100	Error handling	7100	Temperature dependent power reduction
1200	Generator	3200	Generator	5200	Generator	7200	Zero-fuel curve or pump map
1250	Marine	3250	Marine	5250	Marine		
1300	Vehicle speed	3300	Velocity	5300	Vehicle speed	7300	Actuator characteristic
1350	Locomotive	3350	Locomotive	5350	Locomotive		
1500	Analogue inputs	3500	PWM inputs Analogue inputs	5500	Configuration of analogue input/output channels	7500	Fuel temperature dependent target quantity correction
1600	PWM outputs Analogue outputs	3600	Internal measured values, feedback, binary outputs	5600	Analogue outputs	7600	
1700	Positioner			5700	Positioner	7700	Temperature sensors

No.	Parameters	No.	Measured values	No.	Functions	No.	Curves
1800	State	3800	State			7800	Temperature sensors
1900	Servo loop	3900	Servo loop	5900	Servo loop	7900	Temperature sensors
1950	Feedback	3950	Feedback	5950	Feedback	7980	Feedback
						8100	Drive map
						8300	Exhaust recycling
						8400	Intake air throttle valve
						8500	Wastegate
						8600	Bypass valve
						8800	Binary outputs (multiple assignment)
						9000	HZM-CAN
						9900	Stability map 2 (correction values)
10000	Dual fuel	12000	Dual fuel	14000	Dual fuel	16000	Dual fuel
10900	Sensors	12900	Sensors	14900	Sensors		
11000	Error handling, sensors	13000	Current errors	15000	Error handling, sensors		
		13100	Error memory				
11400	CommonOutput	13400	CommonOutput	15400	CommonOutput		
20000	XIOS IP addresses	22000	XIOS port functions	24000	XIOS port configuration		
		22120	XIOS module types				
		22150	XIOS feedback, binary outputs				
20800	Communication switching functions			24800	Communication switching functions		
		23000	Current errors	25000	Error handling		
		23100	Error memory				
21550	ICENI			25550	ICENI		
21700	WAGO	23700	Bit collections	25700	WAGO		
21750	CANopen	23750	CANopen	25750	CANopen		
21800	Modbus	23800	Modbus	25800	Modbus		
21850	DeviceNet	23850	DeviceNet	25850	DeviceNet		
21890	XCP			25890	XCP		
21900	SAE J1939	23900	SAE J1939	25900	SAE J1939		
21950	HZM-CAN Customer module			25950	HZM-CAN Customer module		
						28500	DO-Collections
						29000	CANopen
						29200	Modbus
						29400	DeviceNet
						29600	SAE J1939
						29800	HZM-CAN Customer module
						29900	Bit collections
30000	XIOS frequency, PWM and analogue inputs and outputs	32000	XIOS frequency, PWM and analogue inputs				

Tab. 157: Parameter groups

28.1 List 1: Parameters

No.	Name	Meaning
1	TeethPickup1	
	Level: 4	Number of teeth on the measuring wheel for speed
	Range: 0...400	pickup 1 (RESET)
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
2	TeethPickup2	
	Level: 4	Number of teeth on the measuring wheel for speed
	Range: 0...400	pickup 2 (RESET)
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
10	SpeedMin SpeedMin1	
	Level: 2	Minimum speed for first or only speed range
	Range: 0...4000 rpm	
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
11	SpeedMin2	
	Level: 2	Minimum speed for second speed range
	Range: 0...4000 rpm	
	Page(s): Fehler! Textmarke nicht definiert.	
12	SpeedMax SpeedMax1	

No.	Name	Meaning
	Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Maximum speed for first or only speed range
13	SpeedMax2 Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	Maximum speed for second speed range
14	PickUpSpeedDiffMax Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	Maximum permitted variation between 2001 <i>SpeedPickUp1</i> and 2002 <i>SpeedPickUp2</i> for the duration 15 <i>PickUpSpeedDMaxTime</i>
15	PickUpSpeedDMaxTime Level: 2 Range: 0...10 s Page(s): Fehler! Textmarke nicht definiert.	Maximum duration for a difference between 2001 <i>SpeedPickUp1</i> and 2002 <i>SpeedPickUp2</i> , that is greater than 14 <i>PickUpSpeedDiffMax</i>
17	SpeedFix SpeedFix1 Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	First or only fixed speed

No.	Name	Meaning
18	SpeedFix2 Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Second fixed speed
20	SpeedSetpPC Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Speed setpoint set by PC
21	SpeedOver Level: 4 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 410, Fehler! Textmarke nicht definiert.	Speed for emergency shutdown due to overspeed
24	SpeedMinAbsolute Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	Minimum idle speed for reduction in zero load locomotive operation
25	SpeedGradientMax Level: 4 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	Maximum permissible rate of change of speed gradient
26	SpeedGradientTime Level: 4 Range: 0...100 s Page(s): Fehler! Textmarke nicht definiert.	Time window for the number of permissible overruns of the speed gradient
27	SpeedGradientMaxCnt Level: 4 Range: 1...1000 Page(s): Fehler! Textmarke nicht definiert.	Number of permissible overruns of the speed gradient within the time window

No.	Name	Meaning
28	DT1SpeedThreshold Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Speed threshold above which the rate of change is monitored
29	DT1SpSetpDiffThresh Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	Speed setpoint jump threshold, speed gradient is only monitored below this
30	DT1SpeedDiffMax Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	Speed range around speed setpoint for detection of load or speed jump compensation
31	DT1SpeedDiffTime Level: 2 Range: 1...1000 Page(s): Fehler! Textmarke nicht definiert.	Time for detection of load or speed jump compensation
32	SpeedGradDT1Thresh Level: 2 Range: 0...2000 rpm/s Page(s): Fehler! Textmarke nicht definiert.	Threshold for speed gradient, outside this DT1-factor is calculated
33	SpeedGradDT1Filter Level: 2 Range: 1...255 Page(s): Fehler! Textmarke nicht definiert.	Filter for determination of speed gradient
34	PowerGradDT1Thresh Level: 2 Range: 0...50 %/s Page(s): Fehler! Textmarke nicht definiert.	Threshold for load gradient, outside this DT1-factor is calculated
35	PowerGradDT1Filter Level: 2 Range: 1...255 Page(s): Fehler! Textmarke nicht definiert.	Filter for determination of load gradient
50	SpeedVarSampleSize	<i>All except DC 5</i>

No.	Name	Meaning
	Level: 4 Range: 1...20 Page(s): Fehler! Textmarke nicht definiert.	Sample size for best detection of cylinder misfires
51	SpeedVarFilterConst Level: 4 Range: 0...100 s Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>All except DC 5</i> Filter constant for determination of speed variation 2050 <i>SpeedVariation</i>
52	CamIndexOffset Level: 1 Range: 0...720°crank Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>All except DC 5</i> Offset of camshaft index sensor compared to cylinder A1 TDC
55	MisfireWarnDelay Level: 4 Range: 0...100 s Page(s): Fehler! Textmarke nicht definiert.	Delay until new misfire warning is output
56	MisfireEcyDelay Level: 4 Range: 0...100 s Page(s): Fehler! Textmarke nicht definiert.	Delay before an emergency shutdown due to misfires
60	SpeedMinAtTempLow Level: 3 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	Idle speed for cold engine
61	SpeedMinTempLow Level: 3 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	Lower temperature limit for temperature dependent idle speed

No.	Name	Meaning
62	SpeedMinTempHigh Level: 3 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	Upper temperature limit for temperature dependent idle speed
90 ff	SpeedSwitchx Level: 3 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	Switching speed x x = 1...3
100	Gain Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Gain for speed governor
101	Stability Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Stability for speed governor
102	Derivative Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Derivative for speed governor
103	SpeedDT1 Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	DT1-factor for speed gradient for speed governor
104	PowerDT1 Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	DT1-factor on power gradient for speed governor
105	Gain2	

No.	Name	Meaning
	Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	Gain 2 for speed governor if 2842 <i>SwitchPID2Or1</i> = 1
106	Stability2 Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	Stability 2 for speed governor if 2842 <i>SwitchPID2Or1</i> = 1
107	Derivative2 Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	Derivative 2 for speed governor if 2842 <i>SwitchPID2Or1</i> = 1
110	StaticCorrFactor Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	Correction factor of PID values in static operation
111	StaticCorrRange Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	Speed range for correction factor
120	Droopx	
125	Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Droop x x = 1...2
121	DroopxRefLow	
126	Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Fuel quantity reference value at zero-fuel for droop x x = 1...2
122	DroopxRefHigh	

No.	Name	Meaning
127	Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Fuel quantity reference value at full load for droop x x = 1...2
123	DroopxSpeedRef	
128	Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Speed reference point for droop x x = 1...2
129	TwinEcyDroop Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation twin-engine system</i> Droop for emergency operation in master/slave systems
130	IMRampUp Level: 2 Range: 0...800 %/s Page(s): Fehler! Textmarke nicht definiert.	<i>Vehicle operation</i> Fuel quantity ramp upwards with idle / maximum speed governor
130	TwinEcyDroopRefLow Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation twin-engine system</i> Fuel quantity reference point at zero-fuel for droop in emergency operation in master/slave systems
131	IMRampDown Level: 2 Range: 0...800 %/s Page(s): Fehler! Textmarke nicht definiert.	<i>Vehicle operation</i> Fuel quantity ramp downwards with idle / maximum speed governor
131	TwinEcyDroopRefHigh Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation twin-engine system</i> Fuel quantity reference point at full load for droop in emergency operation in master/slave systems
132	TwinEcyDroopSpeedRef Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation twin-engine system</i> Speed reference point for droop during emergency operation in master/slave systems
140	IMIdleDroop Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Vehicle operation</i> Droop for idle governing for idle / maximum speed governor

No.	Name	Meaning
141	IMMaximumDroop	<i>Vehicle operation</i>
	Level:	2 Droop for maximum governing for idle / maximum speed governor
	Range:	0...100 %
	Page(s):	Fehler! Textmarke nicht definiert.
142	IMDroopRefLow	<i>Vehicle operation</i>
	Level:	2 Reference point at zero-fuel for droop for idle / maximum speed governor
	Range:	0...100 %
	Page(s):	Fehler! Textmarke nicht definiert.
143	IMDroopRefHigh	<i>Vehicle operation</i>
	Level:	2 Reference point at full load for droop for idle / maximum speed governor
	Range:	0...100 %
	Page(s):	Fehler! Textmarke nicht definiert.
150	IMSpeedIncrease	<i>Vehicle operation</i>
	Level:	2 Speed increase for loaded idle speed
	Range:	0...4000 rpm
	Page(s):	Fehler! Textmarke nicht definiert.
160	PID_ColdCorr	
	Level:	3 PID correction factor for cold engine
	Range:	0...400 %
	Page(s):	Fehler! Textmarke nicht definiert.
161	PID_CorrTempLow	
	Level:	3 Lower temperature limit for temperature dependent PID correction
	Range:	-100...+1000 °C
	Page(s):	Fehler! Textmarke nicht definiert.
162	PID_CorrTempHigh	
	Level:	3 Upper temperature limit for temperature dependent PID correction
	Range:	-100...+1000 °C
	Page(s):	Fehler! Textmarke nicht definiert.
230	SpeedRampUp	
	Level:	2 Factor for upward speed ramps (speed increase per second)
	Range:	0...4000 rpm
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.
231	SpeedRampDown	

No.	Name	Meaning
	Level: 2	Factor for downward speed ramps (speed decrease per second)
	Range: 0...4000 rpm	
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
232	SpeedRampUp2	
	Level: 2	Factor for second upward speed ramp (speed increase per second)
	Range: 0...4000 rpm	
	Page(s): Fehler! Textmarke nicht definiert.	

No.	Name	Meaning
233	SpeedRampDown2 Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	Factor for second downward speed ramp (speed decrease per second)
234	SpeedRampUp3 Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	Factor for third upward speed ramp (speed increase per second)
235	SpeedRampDown3 Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	Factor for third downward speed ramp (speed decrease per second)
236	SpeedSwitchToRamp2 Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	Speed for switching to second speed ramp
237	SpeedSwitchToRamp3 Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	Speed for switching to third speed ramp
240	StartSpeedRampUp Level: 3 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	Factor for speed increase during start-up (speed increase per second)
241	SpeedMinAbsRampDown Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	Factor for speed decrease during idle speed reduction in locomotive operation (speed decrease per second)
242	SpeedMinAbsDelay Level: 2 Range: 0...x s Page(s): Fehler! Textmarke nicht definiert.	Delay before start of idle speed reduction in locomotive operation x = XIOS: 600 s, others: 1000 s
250	StartType Level: 3 Range: 1...3 Page(s): Fehler! Textmarke nicht definiert.	Type of starting fuel limitation: 1: Fixed starting fuel limitation 2: Variable starting fuel limitation 3: Temperature dependent starting fuel limitation

No.	Name	Meaning
251	LimitsDelay	
	Level:	3
	Range:	0...100 s
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.
		Delay for enabling limitation functions. This time starts running when the control unit detects that the engine has started

No.	Name	Meaning
252	ForcedStartSupvTime Level: 3 Range: 0...100 s Page(s): Fehler! Textmarke nicht definiert.	Delay during which a speed signal must be detected after a forced start
255	StartSpeed1 Level: 3 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Minimum speed above which starting of the engine is detected (beginning of starting phase 1)
256	StartSpeed2 Level: 3 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert., 251, 409	Minimum speed above which engine starting is detected
257	StartSpeed3 Level: 3 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	With starting speed ramp function enabled, the control unit starts the engine at the set speed <i>StartSpeed3</i> and then ramps up to the setpoint speed.
260	StartFuel1 Level: 3 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Starting fuel 1
261	StartFuel2 Level: 3 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Starting fuel 2 (only necessary for start types 2 and 3)

No.	Name	Meaning
265	StartDuration1 Level: 3 Range: 0...100 s Page(s): Fehler! Textmarke nicht definiert.	Stop time during which the engine works with starting fuel 1 (only required for start type 2)
266	StartDuration2 Level: 3 Range: 0...100 s Page(s): Fehler! Textmarke nicht definiert.	Time during which the starting fuel is increased on a linear basis from 260 <i>StartFuel1</i> for 261 <i>StartFuel2</i> (only necessary for start type 2)
270	StartTempWarm Level: 3 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	Temperature of warm engine at which the engine is started with 260 <i>StartFuel1</i> (only necessary for start type 3)
271	StartTempCold Level: 3 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	Temperature of cold engine at which the engine is started with 261 <i>StartFuel2</i> (only necessary for start type 3).

No.	Name	Meaning
280	StarterCrankTimeMax	<i>DC 5, XIOS</i>
	Level: 4	Maximum starter time
	Range: 0...x s	x =
	Page(s): Fehler! Textmarke nicht definiert.	DC 5: 1000 s XIOS: 600 s
281	StarterInterlockTime	<i>DC 5, XIOS</i>
	Level: 4	Waiting time between two starter cranking operations
	Range: 0...x	x = XIOS: 600 s, DC 5: 1000 s
	Page(s): Fehler! Textmarke nicht definiert.	
282	StarterCrankAttempts	<i>DC 5, XIOS</i>
	Level: 4	Maximum number of cranking attempts
	Range: 1...255	
	Page(s): Fehler! Textmarke nicht definiert.	
290	AlternatorStartDelay	<i>DC 5, XIOS</i>
	Level: 4	Delay time after starting the engine before the alternator
	Range: 0...x s	voltage (charging the battery) can be monitored
	Page(s): Fehler! Textmarke nicht definiert.	x = XIOS: 600 s, DC 5: 1000 s
291	AlternatorLowValue	<i>DC 5</i>
	Level: 4	Permitted minimum value for the alternator voltage in
	Range: 0...37.2 V	order to charge the battery
	Page(s): Fehler! Textmarke nicht definiert.	
292	AlternatorHighValue	<i>DC 5</i>
	Level: 4	Permitted maximum value for the alternator voltage in
	Range: 0...37.2 V	order to charge the battery
	Page(s): Fehler! Textmarke nicht definiert.	
310	ActPosxSecureMin	
314	Level: 6	Minimum actuator travel to protect actuator x against
316	Range: 0...100 %	mechanical and thermal overload (approx. 3 %)
	Page(s): 357	x = 1..3
312	ActPosxSecureMax	
315	Level: 6	Maximum actuator travel to protect actuator x against
317	Range: 0...100 %	mechanical and thermal overload (approx. 97 %)
	Page(s): 357	x = 1...3
320	CurrxShutOffGradient	
323	Level: 6	Threshold for speed gradient for activating current
326	Range: 0...4000 rpm	shutoff
	Page(s): Fehler! Textmarke nicht definiert.	x = 1...3, if actuator x is assigned to speed governor
321	CurrentxShutOffTime	

No.	Name	Meaning
324	Level:	6 Maximum duration of current shutoff
327	Range:	0...200 ms x = 1...3, if actuator x is assigned to speed governor
	Page(s):	Fehler! Textmarke nicht definiert.

No.	Name	Meaning
322	CurrentxShutOff	
325	Level:	6 Pre-set current for current shutoff
328	Range:	0...100 % <i>DC 1, DC 2, DC 7, DC 10, XIOS</i> or 0...8 A <i>DC 8, DC 11, DC 12</i> or 0...12.5 A <i>DC 5, DC 6, DC 9</i>
	Page(s): Fehler! Textmarke nicht definiert.	x = 1...3, if actuator x is assigned to speed governor
332	CanPowerSrcNodeNo	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6 Node number of sender of relative power via
	Range:	0...31 HZM_CAN_ALL, used if 5232 <i>CanPowerPercentOn = 1</i>
333	CanPowerSrcNodeType	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6 Node type of the sender of relative power via
	Range:	0...31 HZM_CAN_ALL
338	CanBoostSrcNodeNo	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6 Node number of the sender of the boost pressure sensor
	Range:	0...31 via HZM_CAN_ALL
339	CanBoostSrcNodeType	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6 Node type of the sender of the boost pressure sensor via
	Range:	0...31 HZM_CAN_ALL
342	CanExhTempSrcNodeNo	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6 Node number of the sender of the exhaust temperature
	Range:	0...31 sensor via HZM_CAN_ALL Maximum of all exhaust temperatures if the sender measures multiple values, otherwise value of the only sensor
343	CanExhTmpSrcNodeType	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6 Node type of the sender of the exhaust temperature
	Range:	0...31 sensor via HZM_CAN_ALL
352	FuelAtZeroLoad	
	Level:	3 Zero-fuel quantity for rapid reaction during load
	Range:	0...100 % shedding
	Page(s): Fehler! Textmarke nicht definiert.	
397	PartnerDCNodeNumber	<i>Marine operation multi-engine system</i> <i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6 Node number of the other engine on the same throttle
	Range:	1...31 lever
	Page(s): Fehler! Textmarke nicht definiert.	
398	ThirdDCNodeNumber	<i>Marine operation multi-engine system</i> <i>See basic information HZM-CAN DG 13 002-d</i>

No.	Name	Meaning
	Level:	6 Node number of the first engine on the other throttle
	Range:	1...31 lever
	Page(s):	Fehler! Textmarke nicht definiert.

No.	Name	Meaning
399	FourthDCNodeNumber	<i>Marine operation multi-engine system</i> <i>See basic information HZM-CAN DG 13 002-d</i>
	Level: 6	Node number of the second engine on the other
	Range: 1...31	throttle lever
	Page(s): Fehler! Textmarke nicht definiert.	
400	CanStartTimeOutDelay	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level: 6	Delay in HZM-CAN-connection monitoring after reset
	Range: 0...100 s	
	Page(s): Fehler! Textmarke nicht definiert.	
401	CanMyNodeNumber	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level: 6	Own node number in HZM-CAN network
	Range: 1...31	(RESET)
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 414	
402	CanOtherNodeNumber	<i>Marine operation twin-engine system</i>
	CanDCNodeNumber	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level: 6	Node number of the other speed governor control unit
	Range: 1...31	in the HZM-CAN network
	Page(s): Fehler! Textmarke nicht definiert., 414	
403	CanCMNodeNumber	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level: 6	Node number of the customer module in the HZM-
	Range: 1...31	CAN network
	Page(s): 339	
404 ff	CanPENodeNumber(x)	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level: 6	Node number of x-the periphery module in
	Range: 0...31	HZM-CAN bus, x = 0..2
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 339, 238	Node number = 0: not assigned (RESET)
407 ff	CanPENodeType(x)	

No.	Name	Meaning
	Level:	6
	Range:	0...18
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 339, 255
		Type of x-th periphery module in HZM-CAN bus x = 0...2 0 = PE 2 12 PE MVC03 1 = PE 6-07 13 PE 11 3 = PE 1-03 14 PE 10 4 = PE 1-04 15 PE 8 6 = PE MVC01 16 PE MVC04 8 = PE XIOS 18 PE 12
		Possible types and maximum possible number per type are specified by the firmware, see 2489 <i>PEModulesMax</i> and 2490 <i>PEModulesMaxType(x)</i> (RESET)
410 ff	CanxPrescaler	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6
	Range:	0...63
		Prescaler for HZM-CAN baud rate when 4416/4426 <i>CanxSegmentOrBaudrate</i> = 1 CAN controller x = 1...2

No.	Name	Meaning
411 ff	CanxSyncJumpWidth	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6 Synchronising jump width for HZM-CAN baud rate
	Range:	0...3 when 4416/4426 <i>CanxSegmentOrBaudrate</i> = 1 CAN controller x = 1...2
412 ff	CanxSamplingMode	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6 Sampling mode for HZM-CAN baud rate when
	Range:	0/1 4416/4426 <i>CanxSegmentOrBaudrate</i> = 1 CAN controller x = 1...2
413 ff	CanxPhaseSegment1	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6 Phase segment 1 for HZM-CAN baud rate when
	Range:	0...15 4416/4426 <i>CanxSegmentOrBaudrate</i> = 1 CAN controller x = 1...2
414 ff	CanxPhaseSegment2	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6 Phase segment 2 for HZM-CAN baud rate when
	Range:	0...7 4416/4426 <i>CanxSegmentOrBaudrate</i> = 1 CAN controller x = 1...2
415 ff	CanxPropSegment	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6 Propagation segment for HZM-CAN baud rate when
	Range:	0...7 4416/4426 <i>CanxSegmentOrBaudrate</i> = 1 CAN controller x = 1...2
416 ff	CanxBaudrate	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4 HZM-CAN baud rate when
	Range:	125,250,500,1000 kBaud 4416/4426 <i>CanxSegmentOrBaudrate</i> = 0 (Standard) CAN controller x = 1...2
430 ff	CanACNodeNumber(x)	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4 Node number of x-th add-on module in HZM-CAN bus,
	Range:	0...31 x = 0...4
	Page(s):	173, 199 Node number = 0: not assigned (RESET)
435 ff	CanACNodeType(x)	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4 Type of x-th add-on module in HZM-CAN bus
	Range:	0...1 x = 0...4
	Page(s):	173, 199 0: Type not specified 1: Elektra FlowControl
		Possible types and maximum possible number per type are specified by the firmware, see 2549 <i>ACModulesMax</i> and 2550 <i>ACModulesMaxType(x)</i> (RESET)
440	PEFuelSetpSendRate	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6 Transmission rate of fuel quantity setpoint to HZM-
	Range:	0...100 s CAN periphery modules 0 s means at each main loop cycle, if value is changed (recommended)

No.	Name	Meaning
441	PEDigOutSendRate	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6
	Range:	0...100 s
		Transmission rate of binary output values to HZM-CAN periphery modules 0 s means at each main loop cycle, if value is changed (recommended)
442	PEAnalogOutSendRate	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6
	Range:	0...100 s
		Transmission rate of analogue output values to HZM-CAN periphery modules
443	PEPWMOutSendRate	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6
	Range:	0...100 s
		Transmission rate of PWM output values to HZM-CAN periphery modules
450 ff	PEDigOutx_Assign	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 9, DC 10</i> <i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	6
	Range:	-29999...+29999
	Page(s):	
		Direct assignment of a parameter to digital output x of HZM-CAN periphery modules x = 1...Total digital outputs of all periphery modules used
455 ff	PEPWMOutx_Assign	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 9, DC 10</i> <i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4
	Range:	-29999...+29999
		Assignment of a parameter to PWM output x of HZM-CAN periphery modules x = 1... Total PWM outputs of all periphery modules used
458 ff	PEPWMOutx_ValueMin	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 9, DC 10</i> <i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4
	Range:	0...100 %
		Minimum value in percent of value range of output parameter at PWM output x of HZM-CAN periphery module (x: See 455 <i>PEPWMOutx_Assign</i>)
459 ff	PEPWMOutx_ValueMax	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 9, DC 10</i> <i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4
	Range:	0...100 %
		Maximum value in percent of value range of output parameter at PWM output x of HZM-CAN periphery module (x: See 455 <i>PEPWMOutx_Assign</i>)
480 ff	PEAnaOutx_Assign	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 9, DC 10</i> <i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4
	Range:	-29999...+29999
		Assignment of a parameter to analogue output x of HZM-CAN periphery modules x = 1... Total analogue outputs of all periphery modules used

No.	Name	Meaning
483 ff	PEAnaOutx_ValueMin	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 9, DC 10</i> <i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4
	Range:	0...100 %
		Minimum value in percent of value range of output parameter at analogue output x of HZM-CAN periphery module (x: See 480 <i>PEAnaOutx_Assign</i>)
484 ff	PEAnaOutx_ValueMax	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 9, DC 10</i> <i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4
	Range:	0...100 %
		Maximum value in percent of value range of output parameter at analogue output x of HZM-CAN periphery module (x: See 480 <i>PEAnaOutx_Assign</i>)
500	OilPressStartDelay	
	Level:	4
	Range:	0...x s
	Page(s):	Fehler! Textmarke nicht definiert.
		Start delay for speed-dependent oil pressure monitoring x = XIOS: 600 s, others: 100 s
501	OilPressWarnDelay	
	Level:	4
	Range:	0...x s
	Page(s):	Fehler! Textmarke nicht definiert.
		Delay for oil pressure warning x = XIOS: 600 s, others: 100 s
502	OilPressEcyDelay	
	Level:	4
	Range:	0...x s
	Page(s):	Fehler! Textmarke nicht definiert.
		Delay for oil pressure emergency shutdown x = XIOS: 600 s, others: 100 s
503	OilPressHysteresis	<i>XIOS</i>
	Level:	4
	Range:	0...10 bar
	Page(s):	Fehler! Textmarke nicht definiert.
		Hysteresis for oil pressure monitoring
505	CoolPressStartDelay	
	Level:	4
	Range:	0...x s
	Page(s):	Fehler! Textmarke nicht definiert.
		Start delay for speed-dependent coolant pressure monitoring x = XIOS: 600 s, others: 100 s
506	CoolPressWarnDelay	<i>Not XIOS</i>
	Level:	4
	Range:	0...100 s
	Page(s):	Fehler! Textmarke nicht definiert.
		Delay for coolant pressure warning
506	CoolPressDelay1	<i>XIOS</i>

No.	Name	Meaning
Level:	4	Delay for 1st monitoring threshold
Range:	0...600 s	
Page(s):	Fehler! Textmarke nicht definiert.	
507	CoolPressIdleDelay	<i>Not XIOS</i>
Level:	4	Delay for coolant pressure at forced idle speed
Range:	0...100 s	
Page(s):	Fehler! Textmarke nicht definiert.	

No.	Name	Meaning
507	CoolPressDelay2 Level: 4 Range: 0...600 s Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Delay for 2nd monitoring threshold
508	CoolPressHysteresis Level: 4 Range: 0...10 bar Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Hysteresis for coolant pressure monitoring
510	CoolantTempLimit Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>Not XIOS</i> Temperature limit for coolant temperature warning
511	CoolantTempIdleDelay Level: 4 Range: 0...1000 s Page(s): Fehler! Textmarke nicht definiert.	<i>Not XIOS</i> Delay for temperature dependent forced idle speed in locomotive operation
515	ChargeAirTempLimit Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	<i>Not XIOS</i> Temperature limit for charge air temperature warning
520	OilTempLimit Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>Not XIOS</i> Temperature limit for oil temperature warning
521	OilTempIdleDelay Level: 4 Range: 0...1000 s Page(s): Fehler! Textmarke nicht definiert.	<i>Not XIOS</i> Delay for temperature dependent forced idle speed in locomotive operation
525	ExhaustTempLimit Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	<i>Not XIOS</i> Temperature limit for oil temperature warning
545	AlternatorHysteresis	<i>XIOS</i>

No.	Name	Meaning
	Level: 4 Range: 0...36 V Page(s): Fehler! Textmarke nicht definiert.	Alternator voltage hysteresis
546	AlternatorLimit1 Level: 4 Range: 0..36 V Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Monitoring threshold 1 for alternator voltage monitoring
547	AlternatorDelay1 Level: 4 Range: 0..600 s Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Delay at monitoring threshold 1 for alternator voltage monitoring

No.	Name	Meaning
548	AlternatorLimit2	<i>XIOS</i>
	Level: 4	Monitoring threshold 2 for alternator voltage
	Range: 0...36 V	monitoring
	Page(s): Fehler! Textmarke nicht definiert.	
549	AlternatorDelay2	<i>XIOS</i>
	Level: 4	Delay at monitoring threshold 2 for alternator voltage
	Range: 0...600 s	monitoring
	Page(s): Fehler! Textmarke nicht definiert.	
550	CoolTempHysteresis	<i>XIOS</i>
	Level: 4	Coolant temperature hysteresis
	Range: 0...150 °C	
	Page(s): Fehler! Textmarke nicht definiert.	
551	CoolTempLimit1	<i>XIOS</i>
	Level: 4	Monitoring threshold 1 for coolant temperature
	Range: -100...+1000 °C	monitoring
	Page(s): Fehler! Textmarke nicht definiert.	
552	CoolTempDelay1	<i>XIOS</i>
	Level: 4	Delay at monitoring threshold 1 for coolant temperature
	Range: 0...600 s	monitoring
	Page(s): Fehler! Textmarke nicht definiert.	
553	CoolTempLimit2	<i>XIOS</i>
	Level: 4	Monitoring threshold 2 for coolant temperature
	Range: -100...+1000 °C	monitoring
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
554	CoolTempDelay2	<i>XIOS</i>
	Level: 4	Delay at monitoring threshold 2 for coolant temperature
	Range: 0...600 s	monitoring
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
555	ChAirTempHysteresis	<i>XIOS</i>
	Level: 4	Charge air temperature hysteresis
	Range: 0...150 °C	
	Page(s): Fehler! Textmarke nicht definiert.	
556	ChAirTempLimit1	<i>XIOS</i>

No.	Name	Meaning
	Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	Monitoring threshold 1 for charge air temperature monitoring
557	ChAirTempDelay1 Level: 4 Range: 0...600 s Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Delay at monitoring threshold 1 for charge air temperature monitoring
558	ChAirTempLimit2 Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Monitoring threshold 2 for charge air temperature monitoring

No.	Name	Meaning
559	ChAirTempDelay2 Level: 4 Range: 0...600 s Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Delay at monitoring threshold 2 for charge air temperature monitoring
560	OilTempHysteresis Level: 4 Range: 0...150 °C Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Oil temperature hysteresis
561	OilTempLimit1 Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Monitoring threshold 1 for oil temperature monitoring
562	OilTempDelay1 Level: 4 Range: 0...600 s Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Delay at monitoring threshold 1 for oil temperature monitoring
563	OilTempLimit2 Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>XIOS</i> Monitoring threshold 2 for oil temperature monitoring
564	OilTempDelay2 Level: 4 Range: 0...600 s Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>XIOS</i> Delay at monitoring threshold 2 for oil temperature monitoring
565	FuelTempHysteresis Level: 4 Range: 0...150 °C Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Fuel temperature hysteresis
566	FuelTempLimit1 Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Monitoring threshold 1 for fuel temperature monitoring
567	FuelTempDelay1	<i>XIOS</i>

No.	Name	Meaning
	Level: 4 Range: 0...600 s Page(s): Fehler! Textmarke nicht definiert.	Delay at monitoring threshold 1 for fuel temperature monitoring
568	FuelTempLimit2 Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Monitoring threshold 2 for fuel temperature monitoring
569	FuelTempDelay2 Level: 4 Range: 0...600 s Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Delay at monitoring limit 2 for fuel temperature monitoring

No.	Name	Meaning
570	ExhaustTempHysteres Level: 4 Range: 0...150 °C Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Exhaust temperature hysteresis
571	ExhaustTempLimit1 Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Monitoring threshold 1 for exhaust temperature monitoring
572	ExhaustTempDelay1 Level: 4 Range: 0...600 s Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Delay at monitoring threshold 1 for exhaust temperature monitoring
573	ExhaustTempLimit2 Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Monitoring threshold 2 for exhaust temperature monitoring
574	ExhaustTempDelay2 Level: 4 Range: 0...600 s Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Delay at monitoring threshold 2 for exhaust temperature monitoring
575	TurboOilTempHysteres Level: 4 Range: 0...150 °C Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Turbocharger oil temperature hysteresis
576	TurboOilTempLimit1 Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Monitoring threshold 1 for turbocharger oil temperature monitoring
577	TurboOilTempDelay1 Level: 4 Range: 0...600 s Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Delay at monitoring threshold 1 for turbocharger oil temperature monitoring
578	TurboOilTempLimit2 Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Monitoring threshold 2 for turbocharger oil temperature monitoring

No.	Name	Meaning
579	TurboOilTempDelay2	<i>XIOS</i>
	Level:	4
	Range:	0...600 s
	Page(s): Fehler! Textmarke nicht definiert.	
580	FuelPressHysteresis	<i>XIOS</i>
	Level:	4
	Range:	0...10 bar
	Page(s): Fehler! Textmarke nicht definiert.	

No.	Name	Meaning
581	FuelPressLimit1	<i>XIOS</i>
	Level: 4	Monitoring threshold 1 for fuel pressure monitoring
	Range: 0...10 bar	
	Page(s): Fehler! Textmarke nicht definiert.	
582	FuelPressDelay1	<i>XIOS</i>
	Level: 4	Delay at monitoring threshold 1 for fuel pressure monitoring
	Range: 0...600 s	
	Page(s): Fehler! Textmarke nicht definiert.	
583	FuelPressLimit2	<i>XIOS</i>
	Level: 4	Monitoring threshold 2 for fuel pressure monitoring
	Range: 0...10 bar	
	Page(s): Fehler! Textmarke nicht definiert.	
584	FuelPressDelay2	<i>XIOS</i>
	Level: 4	Delay at monitoring threshold 2 for fuel pressure monitoring
	Range: 0...600 s	
	Page(s): Fehler! Textmarke nicht definiert.	
585	OilLevelHysteresis	<i>XIOS</i>
	Level: 4	Oil level hysteresis
	Range: 0...100 %	
	Page(s): Fehler! Textmarke nicht definiert.	
586	OilLevelLimit1	<i>XIOS</i>
	Level: 4	Monitoring threshold 1 for oil level monitoring
	Range: 0...100 %	
	Page(s): Fehler! Textmarke nicht definiert.	
587	OilLevelDelay1	<i>XIOS</i>
	Level: 4	Delay at monitoring threshold 1 for oil level monitoring
	Range: 0...600 s	
	Page(s): Fehler! Textmarke nicht definiert.	
588	OilLevelLimit2	<i>XIOS</i>
	Level: 4	Monitoring threshold 2 for oil level monitoring
	Range: 0...100 %	
	Page(s): Fehler! Textmarke nicht definiert.	
589	OilLevelDelay2	<i>XIOS</i>
	Level: 4	Delay at monitoring threshold 2 for oil level monitoring
	Range: 0...600 s	
	Page(s): Fehler! Textmarke nicht definiert.	

No.	Name	Meaning
590	TrOilPressHysteresis	<i>XIOS</i>
	Level:	4 Transmission oil pressure hysteresis
	Range:	0..40 bar
	Page(s): Fehler! Textmarke nicht definiert.	
591	TrOilPressLimit1	
	Level:	4 Monitoring threshold 1 for transmission oil pressure
	Range:	0...40 bar monitoring
	Page(s): Fehler! Textmarke nicht definiert.	

No.	Name	Meaning
592	TrOilPressDelay1 Level: 4 Range: 0...600 s Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Delay at monitoring threshold 1 for transmission oil pressure monitoring
593	TrOilPressLimit2 Level: 4 Range: 0...40 bar Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Monitoring threshold 2 for transmission oil pressure monitoring
594	TrOilPressDelay2 Level: 4 Range: 0...600 s Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Delay at monitoring threshold 2 for transmission oil pressure monitoring
600	ExcitCntrlFactor Level: 2 Range: -400...+400 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Amplification factor for excitation control
605	ExcitLimitForced1 Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Limitation of the excitation signal when 2823 <i>SwitchExcitLimit1 = 1</i>
606	ExcitLimitForced2 Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Limitation of the excitation signal when 2824 <i>SwitchExcitLimit2 = 1</i>
610	ExcitCntrlRampUp Level: 2 Range: 0...800 %/s Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Factor for upward ramp for excitation control (percent per second)
611	ExcitCntrlRampDown Level: 2 Range: 0...800 %/s Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Factor for downward ramp for excitation control (percent per second)
620	ExcitSlideDec	<i>Locomotive operation</i>

No.	Name	Meaning
	Level: 2 Range: -50...+50 % Page(s): Fehler! Textmarke nicht definiert.	Reduction value for excitation reduction when wheel sliding is detected
621	ExcitSlideDuration Level: 2 Range: 0...100 s Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Waiting time after excitation setpoint signal has been reduced after detection of wheel sliding
630	ExcitGovGain Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Gain for excitation governor

No.	Name	Meaning
630	PitchGovGain Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation</i> Gain for adjustable propeller governor
631	ExcitGovStability Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Stability for excitation governor
631	PitchGovStability Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation</i> Stability for adjustable propeller governor
632	ExcitGovDerivative Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Derivative for excitation governor
632	PitchGovDerivative Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation</i> Derivative for adjustable propeller governor
633	ExcitationSetpFilter Level: 2 Range: 1...255 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Filter constant for excitation signal filtering
633	PitchSetpFilter Level: 2 Range: 1...255 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>Marine operation</i> Filter constant for adjustable propeller signal filtering
635	ExcitationSetpPC Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Excitation signal set by PC
635	PitchSetpPC	<i>Marine operation</i>

No.	Name	Meaning
	Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	Adjustable propeller signal set by PC
636	ExcitFuelOffset Level: 2 Range: -50...50 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Offset for fuel quantity value from power characteristic
637	ExcitFuelLimForced1 Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Limitation of fuel quantity setpoint for power limitation when 2823 <i>SwitchExcitLimit1</i> = 1

No.	Name	Meaning
638	ExcitFuelLimForced2 Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> 2. Limitation of fuel quantity setpoint for power limitation when 2824 <i>SwitchExcitLimit2</i> = 1
640	ExcitGovSetpRampUp Level: 2 Range: 0...800 %/s Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Factor for upward ramp for setpoint (percent per second)
640	PitchGovFuelRampUp Level: 2 Range: 0...800 %/s Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation</i> Factor for upward ramp for fuel quantity (percent per second)
641	ExcitGovSetpRampDown Level: 2 Range: 0...800 %/s Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Factor for downward ramp for setpoint (percent per second)
641	PitchGovFuelRampDown Level: 2 Range: 0...800 %/s Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation</i> Factor for downward ramp for fuel quantity (percent per second)
650	ExcitLimitTempDec Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Fuel quantity reduction for temperature dependent lowering of the fuel quantity setpoint characteristic during excitation control with warm engine
651	ExcitLimitTempLow Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Lower limit for temperature dependent lowering of the fuel quantity setpoint characteristic during excitation control
652	ExcitLimitTempHigh Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Upper limit for charge air temperature dependent lowering of the fuel quantity setpoint characteristic during excitation control
657	ExcitTrPowLimForced Level: 4 Range: 0...x kW Page (s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Limitation of traction power setpoint when 2823 <i>SwitchExcitLimit1</i> = 1 x: Depending on application

No.	Name	Meaning
658	ExcitTrPowLimForced2	<i>Locomotive operation</i>
	Level:	4 2. Limitation of traction power setpoint when 2824
	Range:	0...x kW <i>SwitchExcitLimit2 = 1</i>
	Page (s): Fehler! nicht definiert.	Textmarke x: Depending on application

No.	Name	Meaning
670	ExcitLimTrPowTmpDec Level: 4 Range: 0...x kW Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Maximum reduction of traction power setpoint when the cooling water temperature exceeds 652 <i>ExcitLimitTempHigh</i> (no reduction if the cooling water temperature remains below 651 <i>ExcitLimitTempLow</i> , linear interpolation of reduction value between these two points) x: Depending on application
676	TractionVoltageHyst Level: 4 Range: 0...x V Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Hysteresis for traction voltage dependent limitation of the excitation signal x: Depending on application
677	TractionCurrentHyst Level: 4 Range: 0...x A Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Hysteresis for traction current dependent limitation of the excitation signal x: Depending on application
678	TractPowLimGain Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Gain for the traction voltage and/or traction current dependent limiting governor for the excitation signal
679	TractPowLimStability Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Stability for the traction voltage and/or traction current dependent limiting governor for the excitation signal
680	TractPowLimDerivativ Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert. Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Derivative for the traction voltage and/or traction current dependent limiting governor for the excitation signal
690	SpeedLimChAirTempDec Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	Fuel quantity reduction for charge air temperature dependent lowering of full load curve for warm engine
691	SpeedLimChAirTempLow Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert., 228	Lower limit for charge air temperature dependent lowering of full load characteristic
692	SpeedLimChAirTmpHigh	

No.	Name	Meaning
Level:	4	Upper limit for charge air temperature dependent
Range:	-100...+1000 °C	lowering of full load characteristic
Page(s): Fehler! Textmarke nicht definiert. , 228		
695	SpeedLimExhTempDec	
Level:	4	Fuel quantity reduction for exhaust temperature
Range:	0...100 %	dependent lowering of full load curve for warm engine
Page(s): Fehler! Textmarke nicht definiert.		

No.	Name	Meaning
696	SpeedLimExhTempLow Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert., 229	Lower limit for exhaust temperature dependent lowering of full load characteristic
697	SpeedLimExhTempHigh Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert., 229	Upper limit for exhaust temperature dependent lowering of full load characteristic
701	SpeedLimitTempDec SpeedLimCoolTempDec Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	Fuel quantity reduction for (coolant) temperature dependent lowering of full load curve for warm engine
702	SpeedLimitTempLow SpeedLimCoolTempLow Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert., 230	Lower limit for (coolant) temperature dependent lowering of full load characteristic
703	SpeedLimitTempHigh SpeedLimCoolTempHigh Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert., 230	Upper limit for (coolant) temperature dependent lowering of full load characteristic
705	SpeedLimOilTempDec Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	Fuel quantity reduction for oil temperature dependent lowering of full load curve for warm engine
706	SpeedLimOilTempLow Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	Lower limit for oil temperature dependent lowering of full load characteristic
707	SpeedLimOilTempHigh Level: 4 Range: -100...+1000 °C Page(s): Fehler! Textmarke nicht definiert.	Upper limit for oil temperature dependent lowering of full load characteristic
711	FuelLimitMaxAbsolute	

No.	Name	Meaning
Level:	4	Absolute fuel quantity limitation
Range:	0...100 %	
Page(s): Fehler! Textmarke nicht definiert. , 357		
715	FuelLimitForced	
Level:	4	Fill limit with power limitation enabled using 2813
Range:	0...100 %	<i>SwitchForcedLimit</i>
Page(s): Fehler! Textmarke nicht definiert. , Fehler! Textmarke nicht definiert.		

No.	Name	Meaning
724	FuelLimitDistance	
	Level:	4 Distance to current fuel quantity limitation, within
	Range:	0...100 % which 2724 <i>NearFuelLimitActive</i> is enabled
	Page(s):	Fehler! Textmarke nicht definiert.
809	EngineStopExtraTime	
	Level:	4 Extra time for engine stop request
	Range:	0...100 s
	Page(s):	252
810 ff	Funct...	
	Level:	6 Configuration of a switching function via binary input
	Range:	-x...x x:
	Page(s):	248, 252, 254, 256, 258
		DC 1-03: 12 DC 8: 8
		DC 1-04: 11 DC 9: 3
		DC 2: 8 DC 10: 6
		DC 5: 8 DC 11: 6
		DC 6: 5 DC 12: 2
		DC 7: 10 XIOS: 117 ports
		With HZM-CAN periphery modules: Up to 32
		With analogue inputs: Up to 127
		Assignment 0: Not used
		Switching functions see 2810 <i>Switch... ff</i>
851 ff	DigitalOutx_Assign	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 9, DC 10</i>
	Level:	6 Configuration of binary output x (direct simple
	Range:	-29999...+29999 assignment):
	Page(s):	Fehler! Textmarke nicht definiert., 378
		DC 1-03: 3 DC 6: 2
		DC 1-04: 5 DC 7: 7
		DC 2: 5 DC 9: 1
		DC 5: 11 DC 10: 1
		Assignment 0: Not used
900 ff	AssignIn_...	
	Level:	6 Input configuration for a setpoint adjuster or sensor via
	Range:	0...x channel x:
	Page(s):	Fehler! Textmarke nicht definiert., 239
		DC 1-03: 7 DC 8: 8
		DC 1-04: 10 DC 9: 2
		DC 2: 6 DC 10: 6
		DC 5: 10 DC 11: 6
		DC 6: 4 DC 12: 5
		DC 7: 7 XIOS: 117 ports
		Communication modules: Depending on application
		Assignment 0: Not used
		Sensors see 2900 ff, channel type see 4900 ff

No.	Name	Meaning
966	AirMassSensorLow	
	Level:	4 Minimum air mass sensor value
	Range:	0...1000
	Page(s):	241
967	AirMassSensorHigh	
	Level:	4 Maximum air mass sensor value
	Range:	0...1000
	Page(s):	241
968	NOxSensorLow	
	Level:	4 Minimum nitrogen sensor value
	Range:	0...5000 ppm
	Page(s):	241
969	NOxSensorHigh	
	Level:	4 Maximum nitrogen sensor value
	Range:	0...5000 ppm
	Page(s):	241
970	O2SensorLow	
	Level:	4 Minimum oxygen sensor value
	Range:	-12...+21.02707 %
	Page(s):	241
971	O2SensorHigh	
	Level:	4 Maximum oxygen sensor value
	Range:	0...1000
	Page(s):	241
972	Lambda1SensorLow	
	Level:	4 Minimum value of first lambda sensor
	Range:	0...30
	Page(s):	241
973	Lambda1SensorHigh	
	Level:	4 Maximum value of first lambda sensor
	Range:	0...30
	Page(s):	241
974	Lambda2SensorLow	
	Level:	4 Minimum value of second lambda sensor
	Range:	0...30
	Page(s):	241
975	Lambda2SensorHigh	
	Level:	4 Maximum value of second lambda sensor
	Range:	0...30
	Page(s):	241
976	BoostPress2SensLow	
	Level:	4 Minimum value of second boost pressure sensor
	Range:	0...5 bar
	Page(s):	241

No.	Name	Meaning
977	BoostPress2SensHigh Level: 4 Range: 0...5 bar Page(s): 241	Maximum value of second boost pressure sensor
978	CoolPressSensorLow Level: 4 Range: 0...10 bar Page(s): 241	Minimum coolant pressure sensor value
979	CoolPressSensorHigh Level: 4 Range: 0...10 bar Page(s): 241	Maximum coolant pressure sensor value
980	OilPressSensorLow Level: 4 Range: 0...20 bar Page(s): 241	Minimum oil pressure sensor value
981	OilPressSensorHigh Level: 4 Range: 0...20 bar Page(s): 241	Maximum oil pressure sensor value
982	BoostPressSensorLow BoostPress1SensLow Level: 4 Range: 0...5 bar Page(s): 241	<i>If second boost pressure sensor exists</i> Minimum value of first or only boost pressure sensor
983	BoostPressSensorHigh BoostPress1SensHigh Level: 4 Range: 0...5 bar Page(s): 241	<i>If second boost pressure sensor exists</i> Maximum value of first or only boost pressure sensor
984	AmbPressSensorLow Level: 4 Range: 0...2000 mbar Page(s): 241	Minimum ambient pressure sensor value
985	AmbPressSensorHigh Level: 4 Range: 0...2000 mbar Page(s): 241	Maximum ambient pressure sensor value
986	CoolTempSensorLow Level: 4 Range: -100...1000 °C Page(s): 241	Minimum coolant temperature sensor value if sensor is already linearised (otherwise \uparrow 5540 <i>TempIn_SensorType</i>)

No.	Name	Meaning
987	CoolTempSensorHigh Level: 4 Range: -100...1000 °C Page(s): 241	Maximum coolant temperature sensor value if sensor is already linearised (otherwise ↑5540 <i>TempIn_SensorType</i>)
988	ChAirTempSensorLow Level: 4 Range: -100...1000 °C Page(s): 241	Minimum charge air temperature sensor value if sensor is already linearised (otherwise ↑5540 <i>TempIn_SensorType</i>)
989	ChAirTempSensorHigh Level: 4 Range: -100...1000 °C Page(s): 241	Maximum charge air temperature sensor value if sensor is already linearised (otherwise ↑5540 <i>TempIn_SensorType</i>)
990	GasTempSensorLow Level: 4 Range: -100...1000 °C Page(s): 241	<i>Dual fuel</i> Minimum gas temperature sensor value if sensor is already linearised (otherwise ↑5540 <i>TempIn_SensorType</i>)
991	GasTempSensorHigh Level: 4 Range: -100...1000 °C Page(s): 241	<i>Dual fuel</i> Maximum gas temperature sensor value if sensor is already linearised (otherwise ↑5540 <i>TempIn_SensorType</i>)
991	SpeedRedSensorHigh Level: 4 Range: 0...4000 rpm Page(s): 241	Maximum value of sensor for speed reduction for slide protection in locomotive operation
992	MeasPowerSensorLow Level: 4 Range: 0...100 % or 0...x kW Page(s): 241, 244	<i>Generator operation</i> Minimum actual pressure sensor value x: Depending on application
992	TractVoltSensorHigh Level: 4 Range: 0..x V Page(s): 241	<i>Locomotive operation</i> Maximum traction voltage sensor value x: Depending on application
993	MeasPowerSensorHigh Level: 4 Range: 0...100 % or 0..x kW Page(s): 241, 244	<i>Generator operation</i> Maximum actual pressure sensor value x: Depending on application
993	TractCurrSensorHigh Level: 4 Range: 0...x A Page(s): 241	<i>Locomotive operation</i> Maximum traction current sensor value x: Depending on application

No.	Name	Meaning
994	PowerSetpSensorLow	<i>Generator operation</i>
	Level: 4	Minimum power setpoint sensor value
	Range: 0...100 % or 0...x kW	x: Depending on application
	Page(s): 241, 244	
995	PowerSetpSensorHigh	<i>Generator operation</i>
	Level: 4	Maximum power setpoint sensor value
	Range: 0...100 % or 0...x kW	x: Depending on application
	Page(s): 241, 244	
996	FuelPressSensorLow	
	Level: 4	Minimum fuel pressure sensor value
	Range: 0...10 bar	
	Page(s): 241	
996	GasRailPrSensorLow	<i>Dual fuel</i>
	Level: 4	Minimum gas pressure sensor value
	Range: 0...10 bar	
	Page(s): 241	
997	FuelPressSensorHigh	
	Level: 4	Maximum fuel pressure sensor value
	Range: 0...10 bar	
	Page(s): 241	
997	GasRailPrSensorHigh	<i>Dual fuel</i>
	Level: 4	Maximum gas pressure sensor value
	Range: 0...10 bar	
	Page(s): 241	
998	TrOilPressSensorLow	
	Level: 4	Minimum transmission oil pressure sensor value
	Range: 0...40 bar	
	Page(s): 241	
999	TrOilPressSensorHigh	
	Level: 4	Maximum value of transmission oil pressure sensor
	Range: 0...40 bar	
	Page(s): 241	
1000ff	Subst...	
	Level: 4	Substitute value for setpoint adjuster or sensor in case
	Range: 0...x	of error
	Page(s): 245	x: Depending on sensor
		For sensors see 2900 ff
1210	DigitalPotSpeedRamp	

No.	Name	Meaning
Level:	2	Rate of change of speed setpoint when using speed
Range:	0...4000 rpm	increase/decrease switches
Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	

No.	Name	Meaning
1220	SynchronFactor Level: 2 Range: -100...+100 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Amplification factor for synchronisation signal for analogue setpoint adjustment
1221	SynchronReference Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	Reference value for the synchronisation signal
1222	SyncAnaErrLimitDelay Level: 2 Range: 0...x s Page(s): Fehler! Textmarke nicht definiert.	Time delay before 2903 <i>SyncInput</i> is reported as an error when the error limits are exceeded x = XIOS: 600 s, others 1000 s particularly necessary for HZM SyG
1228	LoadCtrlErrLimDelay Level: 2 Range: 0...x s Page(s): Fehler! Textmarke nicht definiert.	Time delay before 2902 <i>LoadControlInput</i> is reported as an error when the error limits are exceeded x = XIOS: 600 s, others 1000 s particularly necessary for HZM LMG
1229	LoadControlDiffMax Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	Limitation of the difference between 2902 <i>LoadControlInput</i> and 1231 <i>LoadControlReference</i> has the same effect as a ramp
1230	LoadControlFactor Level: 2 Range: -100...+100 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Amplification factor of power governing signal for analogue setpoint adjustment
1231	LoadControlReference Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Reference value of power governing signal
1232	RatedPower	<i>Generator operation</i>

No.	Name	Meaning
	Level: 2 Range: 0...100 % or 0...x kW	Nominal power x: Depending on application
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 225, 226, 241, 242	
1232	TractionPowerHigh	<i>Locomotive operation</i>
	Level: 2 Range: 0...x kW	Max. traction power x: Depending on application
	Page(s): Fehler! Textmarke nicht definiert., 167, 237, 241	
1233	PowerGovGain	
	Level: 2 Range: 0...100 %	Gain for integrated power governor
	Page(s): Fehler! Textmarke nicht definiert.	
1234	PowerGovStability	
	Level: 2 Range: 0...100 %	Stability for integrated power governor
	Page(s): Fehler! Textmarke nicht definiert.	
1235	PowerGovDerivative	
	Level: 2 Range: 0...100 %	Derivative for integrated power governor
	Page(s): Fehler! Textmarke nicht definiert.	
1239	MaxPowerDifference	
	Level: 2 Range: 0...100 % or 0...x kW	Maximum permissible setpoint/actual power difference for integrated power governor x: Depending on application
	Page(s): Fehler! Textmarke nicht definiert., 414, Fehler! Textmarke nicht definiert.	
1240	MaxPowerDiffMaxTime	
	Level: 2 Range: 0...x s	Maximum permissible duration for the maximum permissible setpoint/actual power difference for integrated power governor x = XIOS: 600 s, others 1000 s
	Page(s): Fehler! Textmarke nicht definiert., 414, Fehler! Textmarke nicht definiert.	
1241	PowerSetpRampUp	

No.	Name	Meaning
	Level: 2 Range: 0...800 %/s or 0...x kW/s	Factor for upward power ramp for integrated power governor (power increase per second) x: Depending on application
	Page(s): Fehler! Textmarke nicht definiert.	
1242	PowerSetpRampDown	
	Level: 2 Range: 0...800 %/s or 0...x kW/s	Factor for downward power ramp for integrated power governor (power decrease per second) x: Depending on application
	Page(s): Fehler! Textmarke nicht definiert.	
1243	PowerSetpointPC	
	Level: 2 Range: 0...100 % or 0...x kW	Power setpoint specified using PC for integrated power governor x: Depending on application
	Page(s): Fehler! Textmarke nicht definiert.	
1245	KnockPowerReduction	
	Level: 2 Range: 0...100 % or 0...x kW	Reduction value for power reduction after identification of engine knocking (integrated power governor) x: Depending on application
	Page(s): Fehler! Textmarke nicht definiert.	
1246	KnockDuration	
	Level: 2 Range: 0...100 s	Waiting time until next reduction after one reduction in the power setpoint after detection of engine knocking (integrated power governor)
	Page(s): Fehler! Textmarke nicht definiert.	

No.	Name	Meaning
1247	JetAstMaxBoostDiff Level: 2 Range: 0...5 bar Page(s): Fehler! Textmarke nicht definiert.	Distance to fuel quantity dependent minimum boost pressure curve, below which 3247 <i>JetAstActive</i> is enabled
1248	JetAstMaxBoostDTime Level: 2 Range: 0...100 s Page(s): Fehler! Textmarke nicht definiert.	Maximum duration for boost signal 3247 <i>JetAstActive</i>
1250	PositionIUpperRef Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation setpoint adjuster with direction</i> Upper reference of throttle lever in position I (marine setpoint with direction information)
1250	FuelAtZeroLoad Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation twin-engine system</i> Fuel quantity value for zero fuel in master / slave mode
1251	Position0UpperRef Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation setpoint adjuster with direction</i> Upper reference of throttle lever in position 0 (marine setpoint with direction information)
1251	FuelAtFullLoad Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation twin-engine system</i> Fuel quantity value for full load in master / slave mode
1252	PositionIIILowerRef Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation setpoint adjuster with direction</i> Lower reference of throttle lever in position III (marine setpoint with direction information)
1252	SlaveLoadForDeClutch Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation twin-engine system</i> Own load setpoint in master / slave mode
1253	PositionIRange Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation setpoint adjuster with direction</i> Range of throttle lever in position I (marine setpoint with direction information)

No.	Name	Meaning
1253	SlaveLoadRampUp	<i>Marine operation twin-engine system</i>
	Level:	4
	Range:	0...100 %
	Page(s): Fehler! Textmarke nicht definiert.	
1254	Position0Range	<i>Marine operation setpoint adjuster with direction</i>
	Level:	4
	Range:	0...100 %
	Page(s): Fehler! Textmarke nicht definiert.	

No.	Name	Meaning
1254	SlaveLoadRampDown Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation twin-engine system</i> Fuel quantity setpoint for slave in master / slave mode
1255	PositionIIIRange Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation setpoint adjuster with direction</i> Range of throttle lever in position III (marine setpoint with direction information)
1255	LowerSpeedClutchIn Level: 4 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation twin-engine system</i> Minimum engagement speed
1256	PositionISpeedInc Level: 4 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation setpoint adjuster with direction</i> Speed increase during engagement in position I (marine setpoint with direction information)
1256	UpperSpeedClutchIn Level: 4 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation twin-engine system</i> Maximum engagement speed
1257	PositionIIISpeedInc Level: 4 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation setpoint adjuster with direction</i> Speed increase during engagement in position III (marine setpoint with direction information)
1258	PositionIDelay Level: 4 Range: 0...100 s Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation setpoint adjuster with direction</i> Delay of setpoint selection during engagement in position I (marine setpoint with direction information)
1259	PositionIIIDelay Level: 4 Range: 0...100 s Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation setpoint adjuster with direction</i> Delay of setpoint selection during engagement in position III (marine setpoint with direction information)
1260	IdleSpeedRange Level: 4 Range: 0...100 s Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>Marine operation setpoint adjuster with direction</i> Range around the idle speed within which forward or reverse gear can be engaged (marine setpoint with direction information)

No.	Name	Meaning
1350	DigSlideSpeedDec	<i>Locomotive operation</i>
	Level:	2
	Range:	0...4000 rpm
	Page(s):	Fehler! Textmarke nicht definiert.
1355	DigSlideDuration	<i>Locomotive operation</i>
	Level:	2
	Range:	0...100 s
	Page(s):	Fehler! Textmarke nicht definiert.

No.	Name	Meaning
1356	AnaSlideSpeedMin	<i>Locomotive operation</i>
	Level: 2	Absolute minimum speed during reduction with analogue slide protection
	Range: 0...4000 rpm	
	Page(s): Fehler! Textmarke nicht definiert.	
1500ff	PWMInx_RefLow	<i>Not XIOS</i>
	Level: 4	Lower reference value of PWM input x:
	Range: 0...100 %	DC 1-03: 2 DC 8: 2
	Page(s): Fehler! Textmarke nicht definiert.	
		DC 1-04: 1 DC 9: 1
		DC 2: 4 DC 10: 1
		DC 5: 1 DC 11: 3
		DC 6: 3 DC 12: 1
		DC 7: 2
1501ff	PWMInx_RefHigh	<i>Not XIOS</i>
	Level: 4	Upper reference value of PWM input
	Range: 0...100 %	x: see 1500 <i>PWMInx_RefLow</i>
	Page(s): Fehler! Textmarke nicht definiert.	
1510ff	AnalogInx_RefLow	<i>Not XIOS</i>
	Level: 4	Lower reference value of analogue input x = 1:
	Range: 0...65472	DC 1-03: 5 DC 8: 6
	or 0...65520	DC 1-04: 8 DC 9: 2
	or 0...5 V	DC 2: 4 DC 10: 6
	or 0...10 V	DC 5: 6 DC 11: 5
	or 0...37.2 V	DC 6: 3 DC 12: 3
	or 0..22 mA	DC 7: 4
	or 0...25 mA	
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 256, 431, 467	
1511ff	AnalogInx_RefHigh	<i>Not XIOS</i>
	Level: 4	Upper reference value of analogue input x:
	Range:	x and range: see 1510 <i>AnalogInx_RefLow</i>
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 256	
1512ff	AnalogInx_ErrorLow	<i>Not XIOS</i>
	TempIny_ErrorLow	

No.	Name	Meaning
	Level:	4 Lower error limit of analogue input x x and range for analogue inputs: see 1510 <i>AnalogInx_RefLow</i>
	Range:	Temperature input y = 1..:
	0...65472	DC 1: 2 DC 8: 2
	or 0...65520	DC 2: 2 DC 9: -
	or 0...60000 Ω	DC 5: 4 DC 10: 1
	or 0...65000 Ω	DC 6: 1 DC 11: 1
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	DC 7: 3 DC 12: 2

No.	Name	Meaning
1513ff	AnalogInx_ErrorHigh TempIny_ErrorHigh	<i>Not XIOS</i>
	Level: 4	Upper error limit of analogue input x or temperature input y
	Range:	
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	x and range for analogue inputs: see 1510 <i>AnalogInx_RefLow</i> , y and range for temperature inputs: see 1512 <i>TempIny_ErrorLow</i>
1514ff	AnalogInx_Filter TempIny_Filter	<i>Not XIOS</i>
	Level: 4	Filter value of analogue input x or temperature input y
	Range: 1...255	(x: see 1510 <i>AnalogInx_RefLow</i> , y: see 1512 <i>TempIny_ErrorLow</i>)
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
1600ff	PWMOutx_Assign	<i>DC 1, DC 2, DC 5, DC 6, DC 7</i>
	Level: 4	Parameter assignment to PWM output x:
	Range: -26999...+26999	DC 1: 3 DC 6: 2
	Page(s): Fehler! Textmarke nicht definiert.	DC 2: 5 DC 7: 2 DC 5: 2
1601ff	PWMOutx_RefLow	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 8, DC 11</i>
	Level: 4	Minimum value of PWM output x = 1:
	Range: 0...100 %	DC 1: 3 DC 7: 2
	Page(s): Fehler! Textmarke nicht definiert.	DC 2: 5 DC 8: 1 DC 5: 2 DC 11: 2 DC 6: 2
1602ff	PWMOutx_RefHigh	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 8, DC 11</i>
	Level: 4	Maximum value of PWM output x
	Range: 0..100 %	(x: see 1601 <i>PWMOutx_RefLow</i>)
	Page(s): Fehler! Textmarke nicht definiert.	
1603ff	PWMOutx_ValueMin	<i>DC 1, DC 2, DC 5, DC 6, DC 7</i>
	Level: 4	Minimum value in percent of value range of output parameter at PWM output x
	Range: 0...100 %	(x: see 1600 <i>PWMOutx_Assign</i>)
	Page(s): Fehler! Textmarke nicht definiert.	
1604ff	PWMOutx_ValueMax	<i>DC 1, DC 2, DC 5, DC 6, DC 7</i>
	Level: 4	Maximum value in percent of value range of output parameter at PWM output x
	Range: 0...100 %	(x: see 1600 <i>PWMOutx_Assign</i>)
	Page(s): Fehler! Textmarke nicht definiert.	
1625ff	PWMOutxFrequency	<i>Not XIOS</i>

No.	Name	Meaning
	Level: 4	Frequency of PWM outputs (DC 7: x = 1..2)
	Range: 50...500 Hz	DC 5, DC 6, DC 7, DC 8, DC 11
	128...4000 Hz	DC 1, DC 2 (with DC 2 for PWM outputs 1 ... 4)
	Page(s): Fehler! Textmarke nicht definiert.	
1626	PowerOutFrequency	<i>DC 2</i>
	Level: 4	Frequency of power output (PWM output 5)
	Range: 128...4000 Hz	
	Page(s): Fehler! Textmarke nicht definiert.	
1640ff	AnalogOutx_Assign	<i>DC 1, DC 5</i>
	CurrentOutx_Assign	<i>DC 2, DC 6</i>
	VoltOutx_Assign	<i>DC 2, DC 10</i>
	Level: 4	Function assignment to analogue output x:
	Range: -26999...+26999	DC 1: 2 DC 6: 2
	or -9999...+9999	DC 2: 2+2 DC 10: 1
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	DC 5: 1
1641ff	AnalogOutx_RefLow	<i>DC 1, DC 5, DC 12</i>
	CurrentOutx_RefLow	<i>DC 2, DC 6, DC 8, DC 11</i>
	VoltOutx_RefLow	<i>DC 2, DC 10</i>
	Level: 4	Minimum value of analogue output x
	Range: 0...100 %	DC 1: 2 DC 8: 1
	or 0...22 mA	DC 2: 2+2 DC 10: 1
	or 0...5 V	DC 5: 1 DC 11: 2
	or 0...10 V	DC 6: 2 DC 12: 1
	Page(s): 324	
1642ff	AnalogOutx_RefHigh	<i>DC 1, DC 5, DC 12</i>
	CurrentOutx_RefHigh	<i>DC 2, DC 6, DC 8, DC 11</i>
	VoltOutx_RefHigh	<i>DC 2, DC 10</i>
	Level: 4	Maximum value of analogue output x
	Page(s): 324	x and range: see 1641 <i>AnalogOut_RefLow</i>
1643ff	AnalogOutx_ValueMin	<i>DC 1, DC 5</i>
	CurrentOutx_ValueMin	<i>DC 2, DC 6</i>
	VoltOutx_ValueMin	<i>DC 2, DC 10</i>
	Level: 4	Minimum value in percent of value range of output
	Range: 0...100 %	parameter at analogue output x
	Page(s): Fehler! Textmarke nicht definiert. x: see 1640 <i>AnalogOutx_Assign</i>	
1644ff	AnalogOutx_ValueMax	<i>DC 1, DC 5</i>
	CurrentOutx_ValueMax	<i>DC 2, DC 6</i>
	VoltOutx_ValueMax	<i>DC 2, DC 10</i>

No.	Name		Meaning
1905	ServoxCorrFactor		
1907	Level:	6	Correction factor of PID values for servo loop x x = 1...3
1909	Range:	0...400 %	
	Page(s):	360	
1906	ServoxCorrRange		
1908	Level:	6	Position range for correction factor for servo loop x x = 1...3
1910	Range:	0...50 %	
	Page(s):	360	
1911	ServoxGain		
1931	Level:	6	Gain for servo loop x x = 1...3
1941	Range:	0...100 %	
	Page(s):	359	
1912	ServoxStability		
1932	Level:	6	Stability for servo loop x x = 1...3
1942	Range:	0...100 %	
	Page(s):	359	
1913	ServoxDerivative		
1933	Level:	6	Derivative for servo loop x x = 1...3
1943	Range:	0...100 %	
	Page(s):	359	
1914	ServoxAcceleration		
1944	Level:	6	DD factor for servo loop x x = 1...3
1954	Range:	0...100 %	
	Page(s):	359	
1916	ServoxCurrentRedDelay		
1936	Level:	6	Delay time for the start of current reduction in servo loop x x = 1...3
1946	Range:	0...100 s	
	Page(s):	361	

No.	Name	Meaning
1917	ServoxCurrentMax	
1937	Level:	6 Maximum current for actuator x (in motion)
1947	Range:	0...100 % <i>DC 1, DC 2, DC 7, DC 10, XIOS</i> or 0...8 A <i>DC 8, DC 11, DC 12</i> or 0...12.5 A <i>DC 5, DC 6, DC 9</i>
	Page(s):	Fehler! Textmarke nicht definiert. , 361, 363
1918	ServoxCurrentRed	
1938	Level:	6 Reduced current for static state of actuator x
1948	Range:	0...100 % <i>DC 1, DC 2, DC 7, DC 10, XIOS</i> or 0...8 A <i>DC 8, DC 11, DC 12</i> or 0...12.5 A <i>DC 5, DC 6, DC 9</i>
	Page(s):	x = 1...3 361
1919	ServoxCurrentAdjust	
1939	Level:	6 Current for automatic calibration of actuator x
1949	Range:	0...100 % <i>DC 1, DC 2, DC 7, DC 10, XIOS</i> or 0...8 A <i>DC 8, DC 11, DC 12</i> or 0...12.5 A <i>DC 5, DC 6, DC 9</i>
	Page(s):	x = 1...3 355
1920	ServoCurrentPC	
	Level:	6 Test mode for current specification using PC for all enabled actuators
	Range:	-100...100 % <i>DC 1, DC 2, DC 7, DC 10, XIOS</i> or -8...8 A <i>DC 8, DC 11, DC 12</i> or -12.5...12.5 A <i>DC 5, DC 6, DC 9</i> or 0...200 mA <i>DC 6 with 200 mA amplifier</i>
	Page(s):	362 <i>5929 ServoCurrentPCOn cannot be saved</i>
1950	FeedbackxRef_0% FeedbackxRefLow (<i>outdated</i>)	
1960	Level:	4 0 % reference value for feedback of actuator x
1970	Range:	0...65535 x = 1...3 (RESET)
	Page(s):	353, 355
1951	FeedbackxRef_100% FeedbackxRefHigh (<i>outdated</i>)	
1961	Level:	4 100 % reference value for feedback of actuator x
1971	Range:	0...65535 x = 1...3 (RESET)
	Page(s):	353, 355
1952	FeedbackxErrLow	
1962	Level:	4 Lower error value for feedback of actuator x
1972	Range:	0...65535 x = 1...3
	Page(s):	356, Fehler! Textmarke nicht definiert.
1953	FeedbackxErrHigh	

No.	Name	Meaning
1963	Level: 4	Upper error value for feedback of actuator x
1973	Range: 0...65535 Page(s): 356, Fehler! Textmarke nicht definiert.	x = 1...3
1955	FeedbackReference Level: 4 Range: 0...65535 Page(s): 353	<i>DC 2, DC 6, DC 9, DC 10</i> Reference value for the actuator reference coil with digital feedback (RESET)
1956	FeedbackRefErrLow Level: 4 Range: 0...65535 Page(s): 357, Fehler! Textmarke nicht definiert.	<i>DC 2, DC 6, DC 9, DC 10</i> Lower error value for the actuator reference coil with digital feedback
1957	FeedbackRefErrHigh Level: 4 Range: 0...65535 Page(s): 357, Fehler! Textmarke nicht definiert.	<i>DC 2, DC 6, DC 9, DC 10</i> Upper error value for the actuator reference coil with digital feedback
10000 ff		<i>Dual fuel parameters are described in the subchapter</i>
10900 ff	AssignIn_ExhTempCyl1 AssignIn_ExhTempCylx Level: 4 Range: 0...117 Page(s): 239	<i>XIOS</i> Input configuration for exhaust temperature sensors via port x or communication module channel x = 1...24
11000 ff	SubstExhaustTempCyl1 SubstExhaustTempCylx Level: 4 Range: -100...+1000 °C Page(s): 246	<i>XIOS</i> Substitution value for exhaust temperature sensor x = 1...24
11400 ff	Out1:Assign Outx:Assign Level: 6 Range: 0...9999 or 0...29999 or 0...65535 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>DC 8, DC 11, DC 12, XIOS</i> Assignment parameter for an output x = 1..120 or lower, application-specific, by default total outputs in own hardware and all connected communication modules
11401 ff	Out1:ValueMin Outx:ValueMin	<i>DC 8, DC 11, DC 12, XIOS</i>

No.	Name	Meaning
	Level: 6	Minimum value in percent of value range of output
	Range: 0...100.0 %	parameter
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	x see 11400 <i>Out1:Assign</i>
11402	Out1:ValueMax	<i>DC 8, DC 11, DC 12, XIOS</i>
ff	Outx:ValueMax	
	Level: 6	Maximum value in percent of value range of output
	Range: 0...100.0 %	parameter
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	x see 11400 <i>Out1:Assign</i>

No.	Name	Meaning
11403	Out1:DigOutBitMask	<i>XIOS</i>
ff	Outx:DigOutBitMask	
	Level: 6	Mask for error bits if an error parameter is assigned
	Range: 0...FFFF Hex	x see 11400 <i>Out1:Assign</i>
	Page(s): Fehler! Textmarke nicht definiert.	
20810	Comm...	
ff	Level: 6	Configuration of input channel number for a switching function received by a communication module
	Range: 0...x	x Number of possible input channels, depending on application
	or -x...x	Switching functions see 2810 <i>Switch... ff</i>
	Page(s): 248, 254, 257, 258	

Tab. 158: Parameters

28.1.1 DC 1

Here, the parameters are described which are only available in DC 1 type control units due to the special hardware requirements.

No.	Name	Meaning
22	SpeedOverCPU2	
	Level: 6	Overspeed for monitoring by CPU2
	Range: 0...4000 rpm	(RESET)
	Page(s): Fehler! Textmarke nicht definiert.	
23	SpeedIdleCPU2	
	Level: 6	Idle speed for monitoring by CPU2
	Range: 0...4000 rpm	(RESET)
	Page(s): Fehler! Textmarke nicht definiert.	
1200	CPU2StartTimOutDelay	
	Level: 4	Delay time for start of monitoring by CPU2
	Range: 0...100 s	(RESET)
	Page(s): Fehler! Textmarke nicht definiert.	
1921	ServoCurrentCPU2	
	Level: 4	Maximum actuator current for monitoring by CPU2
	Range: 0...100 s	(RESET)
	Page(s): Fehler! Textmarke nicht definiert.	

Tab. 159: DC 1 parameters

28.1.2 DC 5

Here, the parameters are described which are only available in DC 5 type control units due to the special hardware requirements.

No.	Name	Meaning
50	SpeedFreqOut1SwOff	
	Level:	6 Lower speed below which the speed output 1 is disabled (static high)
	Range:	0...4000 rpm
	Page(s):	Fehler! Textmarke nicht definiert. only if 4801 <i>FREQOut1OrDigOut8</i> = 1
51	SpeedFreqOut2SwOff	
	Level:	6 Lower speed below which the speed output 2 is disabled (static high)
	Range:	0...4000 rpm
	Page(s):	Fehler! Textmarke nicht definiert. only if 4802 <i>FREQOut2OrPWMO2_DO9</i> = 1
52	SpeedFreqOut1SwOn	
	Level:	6 Upper speed above which the speed signal from pickup 1 is looped through to speed output 1
	Range:	0...4000 rpm
	Page(s):	Fehler! Textmarke nicht definiert. only if 4801 <i>FREQOut1OrDigOut8</i> = 1
53	SpeedFreqOut2SwOn	
	Level:	6 Upper speed above which the speed signal from pickup 2 is looped through to speed output 2
	Range:	0...4000 rpm
	Page(s):	Fehler! Textmarke nicht definiert. only if 4802 <i>FREQOut2OrPWMO2_DO9</i> = 1

Tab. 160: DC 5 parameters

28.1.3 DC 10

Here, the parameters are described which are only available in DC 10 type control units due to the special hardware requirements.

No.	Name	Meaning
1110	DO_SupviseDelayTime	
	Level:	4 Delay time after edge change for monitoring of binary output
	Range:	0...5.00 s
	Page(s):	Fehler! Textmarke nicht definiert.

Tab. 161: DC 10 parameters

28.1.4 XIOS

Here, the parameters are described which are only available in type XIOS control units due to the special hardware requirements.

No.	Name	Meaning
10400	AmplifierCurrCheckStartDelay	
	Level:	4 Delay time after starting control unit before current monitoring starts
	Range:	0...600 s
	Page(s):	369
10401	AmplifierxCurrErrLow	
10406	Level:	4 Lower current limit at which an error is reported
10411	Range:	0...12.5 A x = 1...3
	Page(s):	369
10402	AmplifierxCurrErrHigh	
10407	Level:	4 Upper current limit at which an error is reported
10412	Range:	0...12.5 A x = 1...3
	Page(s):	369
10403	AmplifierxCurrDiff	
10408	Level:	4 Limit for the difference between setpoint and actual current at which an error is reported
10413	Range:	0...12.5 A x = 1...3
	Page(s):	369
20000	EthernetA_IPAddress	
ff	Level:	4 IP address for Ethernet node A
	Range:	0...255
	Page(s):	
20004	EthernetA_SubnetMask	
ff	Level:	4 Subnet mask for Ethernet node A
	Range:	0...255
	Page(s):	
20008	EthernetB_IPAddress	
ff	Level:	4 IP address for Ethernet node B
	Range:	0...255
	Page(s):	
20012	EthernetB_SubnetMask	
ff	Level:	4 Subnet mask for Ethernet node B
	Range:	0...255
	Page(s):	
30000	Px_(My.DI1)_FI_TOutFact	
ff	Level:	4 TimeOut factor of the frequency input
	Range:	2...50 if the port has been configured as a frequency input
	Page(s):	314 x = Port 089, 090, 104, 105 y = Module C or D

No.	Name	Meaning
30001	Px_(My.DI1)_FI_ErrLimit	
ff	Level: 4	Error limit of the frequency input if the port has been configured as a frequency input
	Range: 0...20000 Hz	
	Page(s): 314	x = Port 089, 090, 104, 105 y = Module C or D
30002	Px_(My.DI1)_FI_Filter	
ff	Level: 4	Filter value of the frequency input if the port has been configured as a frequency input
	Range: 0...100 s	
	Page(s): 314	x = Port 089, 090, 104, 105 y = Module C or D
30012	P089_(MC.DI1)_PI_RefLow	
	Level: 4	Low duty cycle of the PWM input at port 89 (module C)
	Range: 0...100 %	
	Page(s): 313	if the port has been configured as a PWM input
30013	P089_(MC.DI1)_PI_RefHigh	
	Level: 4	High duty cycle of the PWM input at port 89 (module C)
	Range: 0...100 %	
	Page(s): 313	if the port has been configured as a PWM input
30014	P089_(MC.DI1)_PI_Filter	
	Level: 4	Filter value of the PWM input at port 89 (module C)
	Range: 0...100 s	if the port has been configured as a PWM input
	Page(s): 313	

No.	Name	Meaning
30020	P001_(SL1.1)_IO_RefLow	
ff	Px_(wy.z)_IO_RefLow	
	Level: 4	Lower reference
	Range: Analogue input: 0...5 V or 0...10 V or 0...36 V or 0...31.24 mA	if the port is used as an analogue/temperature or thermocouple input or as an analogue or PWM output
	Temperature input: 0...5000 Ω or 0...60000 Ω	Slots for A modules on module C w = SL, MC, MD x = Port 1..117 y = Slot 1 to 11 for A-modules z = Channel 1..4
	Thermocouple input: -18.938...+70.47 mV or -13.801...+50.242 mV or -11.244...+43.989 mV or -22.157...+83.592 mV or -11.654...+25.722 mV or -4.308...+22.619 mV or -3.107...+16.309 mV	
	Analogue output: 0...22.222 mA or 0...24 mA	
	PWM output: 0...100 %	
	Page(s): Fehler! Textmarke nicht definiert. , 312, 323, 256	
30021	P001_(SL1.1)_IO_RefHigh	
ff	Px_(wy.z)_IO_RefHigh	
	Level: 4	Upper reference
	Range:	if the port is used as an analogue/temperature or thermocouple input or as an analogue or PWM output
	Page(s): Fehler! Textmarke nicht definiert. , 312, 323, 256	w, x, y, z and range see 30020 P001_(SL1.1)_IO_RefLow
30022	P001_(SL1.1)_AI_ErrLow	
ff	Px_(wy.z)_AI_ErrLow	
	Level: 4	Lower error limit
	Range:	if the port is used as an analogue/temperature or thermocouple input
	Page(s): 312	w, x, y, z and range see 30020 P001_(SL1.1)_IO_RefLow
30023	P001_(SL1.1)_AI_ErrHigh	
ff	Px_(wy.z)_AI_ErrHigh	
	Level: 4	Upper Error limit
	Range:	if the port is used as an analogue/temperature or thermocouple input
	Page(s): 312	w, x, y, z and range see 30020 P001_(SL1.1)_IO_RefLow

No.	Name	Meaning
30024	P001_(SL1.1)_AI_Filter	
ff	Px_(wy.z)_AI_Filter	
	Level:	4 Filter value
	Range:	0...100 s if the port is used as an analogue/temperature or
	Page(s):	312 thermocouple input
		w, x, y, z see 30020 <i>P001_(SL1.1)_IO_RefLow</i>
30025	P001_(SL1.1)_PO_Freq	
ff	Px_(wy.z)_PO_Freq	
	Level:	4 Frequency
	Range:	126...15626 Hz if the port is used as a PWM output
	Page(s):	324 w, x, y, z see 30020 <i>P001_(SL1.1)_IO_RefLow</i>

Tab. 162: Parameter XIOS

28.1.5 Dual fuel

↑ 16 Speed control for dual fuel engines (ARTEMIS) and separate ARTEMIS manuals

No.	Name	Meaning
10002	GasModeChAirTempMin	
	Level:	4 Minimum charge air temperature for dual fuel operation
	Range:	-100...1000 °C
	Page(s):	190
10003	GasModeChAirTempMax	
	Level:	4 Maximum charge air temperature for dual fuel operation
	Range:	-100...1000 °C
	Page(s):	190
10004	GasModeChAirTempHyst	
	Level:	4 Charge air temperature hysteresis
	Range:	-100...1000 °C
	Page(s):	191
10005	GasModeGasRPressMin	
	Level:	3 Minimum gas rail pressure for dual fuel operation
	Range:	0...10 bar
	Page(s):	194
10006	GasModeGasRPressMax	
	Level:	3 Maximum gas rail pressure for dual fuel operation
	Range:	0...10 bar
	Page(s):	179, 194
10007	GasModeGasRPressHyst	
	Level:	3 Gas rail pressure hysteresis
	Range:	0...10 bar
	Page(s):	195
10008	GasModeGasAtLimitMax	
	Level:	3 Time period for how long gas rail pressure is permitted to be outside of the limits before dual fuel operation is switched off because of this
	Range:	0...100 s
	Page(s):	194
10010	GasModeSpeedMin	
	Level:	3 Minimum speed for dual fuel operation
	Range:	0...4000 rpm
	Page(s):	195
10011	GasModeSpeedMax	
	Level:	3 Maximum speed for dual fuel operation
	Range:	0...4000 rpm
	Page(s):	195
10012	GasModeSpeedHyst	
	Level:	3 Speed hysteresis
	Range:	0...4000 rpm
	Page(s):	196

No.	Name	Meaning
10013	GasModePowerMin	
	Level:	3
	Range:	0...200 % or 0...x kW
	Page(s):	185
		Minimum power for dual fuel operation, relative power x: Depending on application
10014	GasModePowerMax	
	Level:	3
	Range:	0...200 % or 0...x kW
	Page(s):	185, 226
		Maximum power for dual fuel operation, relative power x: Depending on application
10015	GasModePowerHyst	
	Level:	3
	Range:	0...100 % or 0..x kW
	Page(s):	185, 225
		Power hysteresis, relative power x: Depending on application
10016	GasModeBoostHyst	
	Level:	3
	Range:	0...5 bar
	Page(s):	193
		Boost pressure hysteresis (minimum boost pressure is taken from characteristic)
10017	GasModeExhTempMax	
	Level:	3
	Range:	-100...1000 °C
	Page(s):	186
		Maximum exhaust temperature for dual fuel operation
10018	GasModeExhTempHyst	
	Level:	3
	Range:	0...100 °C
	Page(s):	187
		Exhaust temperature hysteresis
10019	GasModeExhTempDiff	
	Level:	3
	Range:	0...100 °C
	Page(s):	187
		Max. permissible exhaust temperature difference between coldest and warmest cylinder in diesel operation to enable dual fuel operation
10020	GasModeCoolTempMin	
	Level:	3
	Range:	-100...1000 °C
	Page(s):	189
		Minimum coolant temperature for dual fuel operation
10021	GasModeCoolTempMax	
	Level:	3
	Range:	-100...1000 °C
	Page(s):	189
		Maximum coolant temperature for dual fuel operation
10022	GasModeCoolTempHyst	
	Level:	3
	Range:	0...100 °C
	Page(s):	190
		Coolant temperature hysteresis

No.	Name	Meaning
10023	GasModeGasTempMin	
	Level:	3 Minimum gas temperature for dual fuel operation
	Range:	-100...1000 °C
	Page(s):	191
10024	GasModeGasTempMax	
	Level:	3 Maximum gas temperature for dual fuel operation
	Range:	-100...1000 °C
	Page(s):	191
10025	GasModeGasTempHyst	
	Level:	3 Gas temperature hysteresis
	Range:	0...100 °C
	Page(s):	192
10027	GasModeGasExhTmpDiff	
	Level:	3 Max. permissible exhaust temperature difference
	Range:	-100...1000 °C between coldest and warmest cylinder in dual fuel
	Page(s):	187 operation
10028	GasModeExhTempDelay	
	Level:	4 Delay in monitoring the exhaust temperature after
	Range:	0...100 s switching to gas
	Page(s):	188
10055	PilotDslAbsMinimum	
	Level:	6 Absolute minimum value for diesel ignition oil quantity
	Range:	0...100 % in dual fuel operation
	Page(s):	164, 197, 217
10056	KnockModulACIndex	
	Level:	6 Index for ARIADNE knock module in 430
	Range:	0...5 <i>CanACNodeNumber</i> / 435 <i>CanACNodeType</i>
	Page(s):	199
10080	GasValveCheckDelay	
	Level:	4 Delay time within which the external gas release must
		come once it has been released internally
		<i>x = XIOS: 600 s, others 1000 s</i>
	Range:	0...x s
	Page(s):	184
10100	GasReductChAirTmpDec	<i>Not XIOS</i>
	Level:	4 Charge air temperature dependent reduction of the gas
	Range:	0...100 s fuel quantity setpoint: Max. reduction value with 10102
	Page(s):	228 <i>GasRedChAirTHotHigh</i>
10103	GasReductExhTempDec	<i>Not XIOS</i>
	Level:	4 Exhaust temperature dependent reduction of the gas
	Range:	0...100 s fuel quantity setpoint: Max. reduction value with 10105
	Page(s):	229 <i>GasReductExhTHotHigh</i>

No.	Name	Meaning
10106	GasReductCoolTempDec	<i>Not XIOS</i>
	Level:	4
	Range:	0...100 s
	Page(s):	230
		Coolant temperature dependent reduction of the gas fuel quantity setpoint: Max. reduction value with 10108
		<i>GasRedCoolTHotHigh</i>

Tab. 163: Dual fuel parameters (general)

28.1.5.1 Gas speed governor

No.	Name	Meaning
10030	GasGain	
	Level:	2
	Range:	0...100 %
	Page(s):	208
		Gain for gas speed governor
10031	GasStability	
	Level:	2
	Range:	0...100 %
	Page(s):	208
		Stability for gas speed governor
10032	GasDerivative	
	Level:	2
	Range:	0...100 %
	Page(s):	208
		Derivative for gas speed governor
10033	ConversionStability	<i>Gas speed governor</i>
	Level:	2
	Range:	0...100 %
	Page(s):	Fehler! Textmarke nicht definiert., 207, 210
		Stability increase for diesel speed governor during switching diesel \leftrightarrow gas
10034	GasSpeedDT1	
	Level:	2
	Range:	0...100 %
	Page(s):	208
		DT1-factor for speed gradient for gas speed governor
10035	GasPowerDT1	
	Level:	2
	Range:	0...100 %
	Page(s):	208, 217
		DT1-factor for power gradient for gas speed governor
10036	GasStaticCorrFactor	
	Level:	2
	Range:	0...100 %
	Page(s):	208
		Correction factor for gas PID values in static operation of the gas speed governor
10037	GasStaticCorrRange	
	Level:	2
	Range:	0...4000 rpm
	Page(s):	208
		Speed range for correction factor of the gas speed governor

No.	Name	Meaning
10050	DieselToGasRampLow	
	Level:	6 Gas ramp during switch from diesel to gas with low gas
	Range:	0...800%/s proportion (fast)
	Page(s):	209 Ramp becomes slower as gas fuel quantity increases
10051	DieselToGasRampHigh	
	Level:	4 Gas ramp during switch from diesel to gas with high
	Range:	0...800%/s gas proportion (slow)
	Page(s):	209 Ramp becomes slower as gas fuel quantity increases
10052	GasToDieselRampLow	
	Level:	4 Gas ramp during switch from gas to diesel with low gas
	Range:	0...800 %/s proportion (slow)
	Page(s):	210 Ramp becomes slower as gas fuel quantity decreases
10053	GasToDieselRampHigh	
	Level:	4 Gas ramp during switch from gas to diesel with high
	Range:	0...800%/s gas proportion (fast)
	Page(s):	210 Ramp becomes slower as gas fuel quantity decreases
10054	FastGasToDieselRamp	
	Level:	4 Fast ramp from gas to diesel on request with 2838
	Range:	0...800%/s <i>SwitchFastToDiesel</i>
	Page(s):	210
10057	KnockPilotDslOffset	
	Level:	6 Gradual increase in ignition oil quantity with Ariadne
	Range:	0...100 % knock warning in dual fuel operation
	Page(s):	200
10058	KnockPilotDslOffsMax	
	Level:	6 Max. cumulative offset for ignition oil quantity
	Range:	0...100 %
	Page(s):	200
10059	KnockPilotDOffsDelay	
	Level:	6 Delay between two increases of the offset value for the
	Range:	0...100 s ignition oil quantity
	Page(s):	200
10060	PilotDieselSetpoint	
	Level:	6 Ignition oil quantity parameter, if not derived from map
	Range:	0...100 %
	Page(s):	165
10061	PilotDieslHysteresis	
	Level:	6 Ignition oil quantity hysteresis to detect whether or not
	Range:	0...100 % diesel is at ignition oil quantity
	Page(s):	196
10063	GasFuelLimitMaxAbs	
	Level:	4 Absolute gas fuel quantity limit
	Range:	0...100 %
	Page(s):	219

No.	Name	Meaning
10065	GasDecrAtDieselStart	
	Level:	4 Reduction of the gas fuel quantity at the moment of switching to diesel to force the diesel controller
	Range:	0...100 %
	Page(s):	198, 210
10066	GasFuelLimitForced	
	Level:	4 Gas fuel quantity limitation with power limitation enabled using 2813 <i>SwitchForcedLimit</i>
	Range:	0...100 %
	Page(s):	222
10067	GasFuelLimitMaxTime	
	Level:	4 Max. permissible duration for gas limitation until the diesel speed governor is temporarily enabled (if 14076 <i>GasLimitReactionOn</i> = 1)
	Range:	0...100 s
	Page(s):	211
10069	GasMinToDieselDelay	
	Level:	4 Maximum permissible dwell time of the gas in dual fuel operation below 10065 <i>GasDecrAtDieselStart</i> before there is an automatic return to diesel (low gas value and diesel at the ignition oil quantity → no load request, potentially too much power due to diesel + gas)
	Range:	0...100 s
	Page(s):	198
10070	GasPowGovGain	<i>Integrated power governor</i>
	Level:	4 Gain for integrated power governor in dual fuel operation
	Range:	0...100 %
	Page(s):	214
10071	GasPowGovStability	<i>Integrated power governor</i>
	Level:	4 Stability for integrated power governor in dual fuel operation
	Range:	0...100 %
	Page(s):	214
10072	GasPowGovDerivative	<i>Integrated power governor</i>
	Level:	4 Derivative for integrated power governor in dual fuel operation
	Range:	0...100 %
	Page(s):	214
10075	GasPowGradThreshold	
	Level:	4 Threshold for detection of a major power jump in dual fuel operation (compare with 2029 <i>PowerGradientDTI</i>)
	Range:	0...100 % or 0...y kW y: Depending on application
	Page(s):	212, 213
10076	GasLoadingSpeedGrThr	
	Level:	4 Speed threshold for detection of a major load addition in dual fuel operation (compare with 2028 <i>SpeedGradientDTI</i>)
	Range:	0...2000 rpm/s
	Page(s):	213
10078	GasLoadRejSpeedGrThr	
	Level:	4 Speed threshold for detection of major load shedding in dual fuel operation (compare with 2028 <i>SpeedGradientDTI</i>)
	Range:	0...2000 rpm/s
	Page(s):	213

No.	Name	Meaning
10090	DslModeGasRPressMax	
	Level:	4 Conditions for combustion of residual gas:
	Range:	0...100 % Maximum permissible gas rail pressure at which
	Page(s):	232 residual gas combustion can be ended (at the latest after 10092 <i>GasBurnTimeMax</i>)
10091	DslModeGasFuelBurn	
	Level:	4 Conditions for combustion of residual gas:
	Range:	0...100 % Forced gas opening (Megasol, actuator) for combustion
	Page(s):	232 of residual gas with closed gas supply valves
10092	GasBurnTimeMax	
	Level:	4 Conditions for combustion of residual gas:
	Range:	0...100 s Max. permissible time for residual gas combustion (if
	Page(s):	233 gas supply valves do not close correctly)

Tab. 164: Dual fuel parameters (gas speed governor)

28.1.5.2 Diesel reduction governor

No.	Name	Meaning
10029	GasSetpointPC	
	Level:	4 Gas setpoint using PC
	Range:	0...100 %
	Page(s):	216
10030	DieselRedGain	
	Level:	2 Gain for diesel reduction governor
	Range:	0...100 %
	Page(s):	217
10031	DieselRedStability	
	Level:	2 Stability for diesel reduction governor
	Range:	0...100 %
	Page(s):	217
10032	DieselRedDerivative	
	Level:	2 Derivative for diesel reduction governor
	Range:	0...100 %
	Page(s):	217
10035	DslRedStatCorrFactor	
	Level:	2 Correction factor for gas PID values in static operation
	Range:	0...100 % of the diesel reduction governor
	Page(s):	217

No.	Name	Meaning
10036	DslRedStatCorrRange	
	Level:	2 Diesel range for correction factor for diesel reduction governor
	Range:	0...100 %
	Page(s):	218
10040	DieselDiffGasMin	
	Level:	2 Minimum gas position for checking for deactivated gas safety valve
	Range:	0...100 %
	Page(s):	197
10041	DieselDiffMax	
	Level:	2 Maximum permissible difference between setpoint and actual value for checking for deactivated gas safety valve
	Range:	0...100 %
	Page(s):	197
10042	DieselDiffDelay	
	Level:	2 Maximum permissible duration for difference between diesel setpoint and actual value for checking for deactivated gas safety valve
	Range:	0...100 s
	Page(s):	197
10050	FastDieselSetpRampUp	
	Level:	6 Fast upwards diesel setpoint ramp
	Range:	0...800%/s
	Page(s):	218
10051	DieselSetpRampUp	
	Level:	4 Upwards diesel setpoint ramp
	Range:	0...800%/s
	Page(s):	218
10052	DieselSetpRampDown	
	Level:	4 Downwards diesel setpoint ramp
	Range:	0...800 %/s
	Page(s):	218
10057	KnockDslSetpOffset	
	Level:	6 Gradual increase in diesel setpoint with Ariadne knock warning in dual fuel operation
	Range:	0...100 %
	Page(s):	200
10058	KnockDslSetpOffsMax	
	Level:	6 Max. cumulative offset for diesel setpoint
	Range:	0...100 %
	Page(s):	200
10059	KnockDslSetOffsDelay	
	Level:	6 Delay between two increases of the offset value for the diesel setpoint
	Range:	0...100 s
	Page(s):	200
10060	DieselSetpoint	
	Level:	6 Setpoint for diesel in dual fuel operation if not derived from map
	Range:	0...100 %
	Page(s):	216 Corresponds to ignition oil quantity

No.	Name	Meaning
10061	DieselHysteresis	
	Level:	6 Ignition oil quantity hysteresis to detect whether or not diesel is at ignition oil quantity
	Range:	0...100 %
	Page(s):	198
10062	GasPowerLimitMaxAbs	<i>Marine operation</i>
	Level:	4 Absolute gas power limitation
	Range:	0...x kW x: Depending on application
	Page(s):	185, 222
10063	GasFuelLimitMaxAbs	<i>Not marine operation</i>
	Level:	4 Absolute gas fuel quantity limit
	Range:	0...100 %
	Page(s):	223, 226
10066	GasFuelLimitForced	
	Level:	4 Gas fuel quantity limitation with power limitation enabled using 2813 <i>SwitchForcedLimit</i>
	Range:	0...100 %
	Page(s):	227
10091	DslModeGasFuelBurn	
	Level:	4 Conditions for combustion of residual gas:
	Range:	0...100 % Forced gas opening (Megasol, actuator) for combustion of residual gas with closed gas supply valves
	Page(s):	233
10092	GasBurnTimeMax	
	Level:	4 Conditions for combustion of residual gas:
	Range:	0...100 s Max. permissible time for residual gas combustion (if gas supply valves do not close correctly)
	Page(s):	233
10094	GasStartDelay	
	Level:	4 Delay time for gas activation if diesel comes from a position below the ignition oil quantity back above it
	Range:	0...100 s
	Page(s):	197

Tab. 165: Dual fuel parameters (diesel reduction governor)

28.1.6 ICENI

↑23.7 CAN protocol ^{ICENI}® (CANopen)

No.	Name	Meaning
21550	Iceni:Baudrate	
	Level:	4 Baud rate of ICENI CANopen network
	Range:	125,250,500,1000 kBaud
21551	Iceni:SlaveID	
	Level:	4 Node number of slave in ICENI CANopen network
	Range:	1...127

No.	Name	Meaning
21552	Iceni:ModulSendRate	
	Level:	4 Receive interval of messages from ICENI module
	Range:	0...100 s
21560	Iceni: AI1_RefLow	
ff	Iceni: AIx_RefLow	
	Level:	4 Lower reference for analogue input x
	Range:	0...100.0 % x = 1..20
21561	Iceni: AI1_RefHigh	
ff	Iceni: AIx_RefHigh	
	Level:	4 Upper reference for analogue input x
	Range:	0...100.0 % x = 1..20

Tab. 166: ICENI parameters

28.1.7 WAGO

↑ 23.6 CAN protocol WAGO® (CANopen) and AXIOMATIC® (CANopen)

No.	Name	Meaning
21550	Wago: AI13_RefLow	<i>If more than four TPDOs are possible</i>
ff	Wago: AIx_RefLow	
	Level:	4 Lower reference for analogue input x
	Range:	0...100.0 % x = 13..74
21561	Wago: AI13_RefHigh	
ff	Wago: AIx_RefHigh	
	Level:	4 Upper reference for analogue input x
	Range:	0...100.0 % x = 13..73
21680	Wago:SendRateAIx-x+3	
ff	Level:	4 Receive interval of messages from WAGO module
	Range:	0...100 s x = 13..74
21700	Wago:Baudrate	
	Level:	4 Baud rate of WAGO CANopen network
	Range:	125,250,500,1000 kBaud
21701	Wago:SlaveID	<i>If only four RPDOs are possible</i>
	Level:	4 Node number of slave in WAGO CANopen network
	Range:	1...127
21701	Wago:SlaveID+0_1	<i>If eight RPDOs are possible</i>
	Level:	4 Node number of slave in WAGO CANopen network
	Range:	1...127
21701	Wago:SlaveID+0_1_2	<i>If 12 RPDOs are possible</i>
	Level:	4 Node number of slave in WAGO CANopen network
	Range:	1...127

No.	Name	Meaning
21701	Wago:SlaveID+0_1_2_3	<i>If 16 RPDOs are possible</i>
	Level:	4 Node number of slave in WAGO CANopen network
	Range:	1..127
21701	Wago:SlaveID+0_1_2_3_4	<i>If 20 RPDOs are possible</i>
	Level:	4 Node number of slave in WAGO CANopen network
	Range:	1...127
21702	Wago:ModulSendRate	<i>If only four TPDOs are possible</i>
	Level:	4 Receive interval of messages from WAGO module
	Range:	0...100 s
21702	Wago:SendRateDI01-64	<i>If more than four TPDOs are possible</i>
	Level:	4 Receive interval of messages from WAGO module
	Range:	0...100 s
21703	Wago:SendRateAI01-04	<i>If more than four TPDOs are possible</i>
	Level:	4 Receive interval of messages from WAGO module
	Range:	0...100 s
21704	Wago:SendRateAI05-08	<i>If more than four TPDOs are possible</i>
	Level:	4 Receive interval of messages from WAGO module
	Range:	0...100 s
21705	Wago:SendRateAI09-12	<i>If more than four TPDOs are possible</i>
	Level:	4 Receive interval of messages from WAGO module
	Range:	0...100 s Further values see 21680
21710	Wago: AI1_RefLow	<i>If more than four TPDOs are possible</i>
ff	Wago: AIx_RefLow	
	Level:	4 Lower reference for analogue input x
	Range:	0...100.0 % x = 1...12, for more see 21550
21711	Wago: AI1_RefHigh	
ff	Wago: AIx_RefHigh	
	Level:	4 Upper reference for analogue input x
	Range:	0...100.0 % x = 1...12, for more see 21551
21734	Wago:DigOut1_Assign	<i>All except DC 8, DC 11, DC 12, XIOS</i>
ff	Wago:DigOutx_Assign	
	Level:	4 Assignment to binary output x on WAGO modules
	Range:	-29999...+29999 x = 1..16

Tab. 167: WAGO parameters

28.1.8 CANopen

↑ 23.4 CAN protocol CANopen and CANopen, Manual DG 06 002-e

No.	Name	Meaning
21750	CanOp:Baudrate	
	Level:	4 Baud rate of CANopen network
	Range:	125,250,500,1000 kBaud
21751	CanOp:MyNodeNo	
	Level:	4 Own node number in the CANopen network
	Range:	1...127
21752	CanOp:PartnerNodeNo	
	Level:	4 Master / partner node number in CANopen network
	Range:	0...127
21753	CanOp:TimeOutDelay	
	Level:	4 Time for which receiving telegram is suppressed –
	Range:	0...127 timeout monitoring after start-up of control unit
21754	CanOp:HBeatConsTime	
	Level:	4 Receiving interval for heartbeat
	Range:	0...100 s
21755	CanOp:HBeatProdTime	
	Level:	4 Sending interval for heartbeat
	Range:	0...100 s
21756	CanOp:GuardingTime	
	Level:	4 Receiving interval for node guarding
	Range:	0...100
21757	CanOp:LifeTimeFactor	
	Level:	4 Factor for receiving interval for node guarding
	Range:	0...255
21761	CanOp:ID_EMCPProd	
	Level:	4 Identifier of EMCY sending telegram
	Range:	0...255 Warning: 21751 <i>CanOp:MyNodeNo</i> is added
21762	CanOp:ID_HBeatCons	
	Level:	4 Identifier of life guarding or heartbeat receiving
	Range:	0...255 telegram LifeGuarding: 21751 <i>CanOp:MyNodeNo</i> is added Heartbeat: 21752 <i>CanOp:PartnerNodeNo</i> is added
21763	CanOp:ID_HBeatProd	
	Level:	4 Identifier of heartbeat sending telegram
	Range:	0...255 Warning: 21751 <i>CanOp:MyNodeNo</i> is added
21764	CanOp:ID_ClientSDO	
	Level:	4 Identifier of SDO receiving telegram
	Range:	0...255 Warning: 21751 <i>CanOp:MyNodeNo</i> is added
21765	CanOp:ID_ServerSDO	
	Level:	4 Identifier of SDO sending telegram
	Range:	0...255 Warning: 21751 <i>CanOp:MyNodeNo</i> is added

No.	Name	Meaning
21770	CanOp:RPDOID(x)	<i>If only 4 RPDOs are possible</i>
ff	Level:	4 Identifier of RPDOs
	Range:	0...255 Warning: 21751 <i>CanOp:MyNodeNo</i> is added x = 0..4 <i>See 21790 if more than 4 RPDOs are possible</i>
21774	CanOp:TPDOID(x)	
ff	Level:	4 Identifier of TPDOs
	Range:	0...255 Warning: 21751 <i>CanOp:MyNodeNo</i> is added to the first four standard TPDOs x = 0..15
21790	CanOp:RPDOID(x)	<i>If more than four RPDOs are possible</i>
ff	Level:	4 Identifier of RPDOs
	Range:	0...255 Warning: 21751 <i>CanOp:MyNodeNo</i> is added x = 0..9 <i>See 21770 if only 4 RPDOs are possible</i>

Tab. 168: CANopen parameters

28.1.9 Modbus

↑23.8 Serial protocol Modbus and Manual DG 05 002-e

No.	Name	Meaning
21800	Modb:Baudrate	
	Level:	4 Baud rate, changes only become effective after reset
	Range:	9600, 19200 kBaud
21801	Modb:SlaveID	
	Level:	4 Own device address as slave
	Range:	1...24
21820	Modb:RxTimeOut	
	Level:	4 Receiving time limit for requests to write binary values
	Range:	0...60 s / sensor values

Tab. 169: Modbus parameters

28.1.10 DeviceNet

↑23.5 CAN protocol DeviceNet and Manual DG 06 003-e

No.	Name	Meaning
21850	DNet:Baudrate	
	Level:	4 Baud rate of DeviceNet system
	Range:	125, 250, 500 kBaud
21851	DNet:MacId	
	Level:	4 Own identifier in DeviceNet system
	Range:	0...63
21852	DNet:NoOfRxBytes	
	Level:	4 Number of expected bytes via polled message, standard:
	Range:	0...32 2 bytes switching functions, 15 words sensors

Tab. 170: DeviceNet parameters

28.1.11 SAE J1939

↑23.3 CAN protocol SAE J1939 and Manual DG 06 004-e

No.	Name	Meaning
21900	J1939:Baudrate	
	Level:	4 Baud rate in SAE J1939 bus system
	Range:	125, 250, 500 kBaud
21901	J1939:MyNodeNumber	
	Level:	4 Own node number in SAE J1939 bus system
	Range:	1...31
21902	J1939:StartTOutDelay	
	Level:	4 Time for which receiving telegram is suppressed –
	Range:	0...100 s timeout monitoring after start-up of control unit
21909	J1939:LossFuelOffset	<i>EEC3</i>
	Level:	4 Offset for speed and temperature dependent torque
	Range:	0...100 % friction, defined loss due to pumps etc.
21910	J1939:RefEngTorque	<i>EC1</i>
	Level:	4 Maximum engine torque
	Range:	0...64255 Nm
21911	J1939:TorqueMinFuel	<i>EC1, EEC1, EEC2, EEC3</i>
	Level:	4 Fuel quantity at zero-fuel
	Range:	0...100 %
21912	J1939:TorqueMaxFuel	<i>EC1, EEC1, EEC2, EEC3</i>
	Level:	4 Fuel quantity at full load
	Range:	0...100 %
21913	J1939:SpeedPoint4	<i>EC1</i>

No.	Name	Meaning
	Level: 4 Range: 0...4000 rpm	Speed point 4 (for EngineConfiguration telegram)
21914	J1939:SpeedPoint5	<i>ECI</i>
	Level: 4 Range: 0...4000 rpm	Speed point 5 (for EngineConfiguration telegram)
21915	J1939:SpeedPoint4_2	<i>ECI</i>
	Level: 4 Range: 0...4000 rpm	Speed point 4 for second envelope curve (for EngineConfiguration telegram)
21916	J1939:SpeedPoint5_2	<i>ECI</i>
	Level: 4 Range: 0...4000 rpm	Speed point 5 for second envelope curve (for EngineConfiguration telegram)

Tab. 171: SAE J1939 parameters

28.1.12 HZM-CAN customer module

↑ 23.2 CAN protocol HZM-CAN customer module and Manual DG 05007-e

No.	Name	Meaning
21950	CMRxTelxTimeout	
ff	Level: 4 Range: 0...100 s	Receiving telegram x timeout x = 10..25
21960	CMTxTelxSendRate	
ff	Level: 4 Range: 0...100 s	Send rate of sending telegram x x = 20..58

Tab. 172: HZM-CAN customer module parameters

	Level:	1	Monitoring of speed pickups
	Range:	0/1	0 = Pickup 1 active
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	1 = Pickup 2 active

2009	SpeedCamIndex		
	Level:	1	Speed signal from camshaft index sensor
	Range:	0...4000 rpm	
	Page(s):	Fehler! Textmarke nicht definiert.	

2014	PickUpSpeedDiff		
	Level:	1	Current difference between 2001 <i>SpeedPickUp1</i> and
	Range:	0...4000 rpm	2002 <i>SpeedPickUp2</i>
	Page(s):	Fehler! Textmarke nicht definiert.	

2022	SpeedGradientPickUp1		
	Level:	4	Current unfiltered change in speed per second at speed
	Range:	-4000...+4000 rpm	pickup 1
	Page(s):	Fehler! Textmarke nicht definiert.	

	Level:	1	Speed setpoint determined by external setpoint potentiometer or switch, such as idle speed or fixed speed
	Range:	0...4000 rpm	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
2035	SpeedSetpLimit		<i>See SAE J1939, Manual DG 06 004-e</i>
	Level:	1	Maximum speed
	Range:	0...4000 rpm	
	Page(s):	Fehler! Textmarke nicht definiert.	
2040	DroopOffset		
	Level:	1	Speed offset caused by droop
	Range:	-2000...+2000 rpm	
	Page(s):	Fehler! Textmarke nicht definiert.	
2041	DigitalPotOffset		
	Level:	1	Speed offset caused by digital potentiometer
	Range:	-4000...+4000 rpm	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
2042	GenSetOffset		
	Level:	1	Speed offset due to synchronisation and power control in generator operation
	Range:	-4000...+4000 rpm	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	

2050	SpeedVariance		
	Level:	1	Speed variation for detection of misfires
	Range:	0...65.535	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 413	
2051	VarianceElementx		
ff	Level:	1	Speed variation of single element
	Range:	-32.768...32.767	x = 1..24
	Page(s):	Fehler! Textmarke nicht definiert.	
2080	VarianceMaxAngle		
	Level:	1	Calculated angle with greatest variance
	Range:	0...720.0°crank	
	Page(s):		
2081	MisfireCylinderNo		
	Level:	1	Number of cylinder responsible for misfiring
	Range:	0...20	
	Page(s):	Fehler! Textmarke nicht definiert.	
2082	MisfireCylinderAngle		
	Level:	1	Angle of cylinder responsible for misfiring
	Range:	0...720.0°crank	
	Page(s):	Fehler! Textmarke nicht definiert.	
2083	NumberOfCylinders		
	Level:	1	Effective number of cylinders in engine, determined
	Range:	0...20	from ignition sequence starting from 6050
	Page(s):	Fehler! Textmarke nicht definiert. <i>AngleCylinder1</i>	
2090	SpeedSwitchxActive		
ff	Level:	1	Marker that the speed threshold 90..92 <i>SpeedSwitchx</i>
	Range:	0/1	has been exceeded
	Page(s):	Fehler! Textmarke nicht definiert. x = 1..3	

2100	PID_CorrFactor		
	Level:	1	Determined PID correction factor
	Range:	0...400 %	
	Page(s):	Fehler! Textmarke nicht definiert.	
2110	FuelSetpSpeedGov		
	Level:	3	Fuel quantity setpoint calculated by speed governor
	Range:	0...100 %	
	Page(s):	Fehler! Textmarke nicht definiert.	
2111	FuelSetpLoadGov		<i>Integrated power governor</i>
	Level:	3	Fuel quantity setpoint in mains operation
	Range:	0...100 %	
	Page(s):	Fehler! Textmarke nicht definiert.	
2114	FuelSetpUnlimited		
	Level:	3	Unlimited fuel quantity setpoint
	Range:	0...100 %	
	Page(s):	Fehler! Textmarke nicht definiert.	
2120	DroopPresent		
	Level:	1	Current droop used by control unit
	Range:	-100...+100 %	
	Page(s):	Fehler! Textmarke nicht definiert.	
2121	SpeedJumpActive		
	Level:	1	Speed jump detected
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
2122	PowerJumpActive		
	Level:	1	Load jump detected
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
2130	IMFuelSetp		
	Level:	1	Current fuel quantity setpoint from idle / maximum speed governor after ramp
	Range:	0...100 %	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
2131	IMFuelSetpUnlimited		<i>Speed governor</i>
	Level:	1	Unlimited fuel quantity setpoint from idle / maximum speed governor
	Range:	0...100 %	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	

2132 IMFuelSetpSelect

Level: 1 Current fuel quantity setpoint from idle / maximum
Range: 0...100 % speed governor based on speed-dependent map / zero
Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert. delivery characteristic

2133 IMFuelSetpExtern

Level: 1 Externally pre-set fuel quantity setpoint for idle /
Range: 0...100 % maximum speed governor
Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.

2140	GoverningAtMaxOrIdle		
	Level:	1	Indication of whether governing is at maximum or idle
	Range:	0/1	speed
	Page(s):	Fehler! Textmarke nicht definiert.	
2141	IMOrAllSpeedGov		
	Level:	1	Indication of whether idle / maximum speed governor
	Range:	0/1	or variable speed governor is active
	Page(s):	Fehler! Textmarke nicht definiert.	
2142	IMFuelSetOrGovernor		
	Level:	1	Indication of whether the fuel quantity adjuster or the
	Range:	0/1	speed governor is active in idle / maximum speed
	Page(s):	Fehler! Textmarke nicht definiert.	
2200	PEGasQuantity		<i>Use of MVC periphery module</i>
	Level:	1	Currently used fuel quantity for HZM-CAN periphery
	Range:	0...100 %	module
	Page(s):	172, 365	Previously 2305
2200ff	PEActPos(x)		<i>Use of actuator periphery module</i>
	Level:	1	Current actuator positions of HZM-CAN periphery
	Range:	0...100 %	modules (corresponds to 2300 <i>ActPos</i> in periphery
	Page(s):	172, 365	module) x = 0..2 Previously 2305
2210ff	PEActuatorOn(x)		<i>Use of actuator periphery module</i>
	Level:	1	Indication of whether actuators of HZM-CAN periphery
	Range:	0/1	modules are enabled (corresponds to 5910 <i>ActuatorOn</i>
	Page(s):	172, 365	in periphery module) x: Depending on application Previously 2320
2220ff	PEFuelSetp		<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 9, DC 10</i>
	Level:	2	Injection quantity setpoints for HZM-CAN periphery
	Range:	0...100 %	modules, current values of parameters assigned from
	Page(s):	Fehler! Textmarke nicht definiert.	
			9700 <i>PEFuelOut:Assign(x)</i> Previously from 2355
2250	EngineStartCounter		<i>All except DC 1 (DC 2 with additional PCB)</i>
	Level:	1	Number of engine starts since operational data memory
	Range:	0...65535	was last cancelled
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 380	
2300	ActxPos		

2302	Level:	1	Current actuator position
2303	Range:	0...100 %	x = 1..3
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
<hr/>			
2305	PEGasQuantity		<i>Use of MVC periphery module</i>
	Level:	1	Currently used fuel quantity for of HZM-CAN
	Range:	0...100 %	periphery module
	Page(s):	172	Outdated, now see 2200

	Level:	2	Fuel quantity setpoints for HZM-CAN periphery
	Range:	0...100 %	modules, current values of parameters assigned from
	Page(s):	Fehler! Textmarke nicht definiert.	9700 <i>PEFuelOut:Assign(x)</i>
			Outdated, now see 2220
2360	FuelQuantityLimited		
	Level:	1	Limited injection quantity before fuel temperature
	Range:	0...100 %	compensation
	Page(s):	Fehler! Textmarke nicht definiert.	
2380ff	PEActuatorError(x)		<i>Not XIOS</i>
	Level:	1	Error status of actuators on currently connected HZM-
	Range:	0...FFFF Hex	CAN periphery modules
	Page(s):	365	

2401	CanTxBufferState		<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	1	Status of HZM-CAN device type sending buffer
	Range:	0...FFFF Hex	Bit 0: DC Bit 4: MC
	Page(s):	416	Bit 1: GC Bit 5: AC
			Bit 2: PE Bit 6: CM
			Bit 3: IM Bit 7: PC
2402	CanRxBufferState		<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	1	Status of HZM-CAN device type receiving buffer
	Range:	0...FFFF Hex	Bits see 2401 <i>CanTxBufferState</i>
2403	CanRxTimeout		<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	1	Status of HZM-CAN device type receiving timeout
	Range:	0..FFFF Hex	monitoring
			Bits see 2401 <i>CanTxBufferState</i>
2404	CanTypeMismatch		<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	1	Status of HZM-CAN device type monitoring (double
	Range:	0/1	node numbers)
			Bits see 2401 <i>CanTxBufferState</i>
2405ff	CanxOnline		<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	1	Indication that HZM-CAN controller x is initialised and
	Range:	0/1	there is no bus error
			x = 1..2
2406	CanxState		<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	1	General status of HZM-CAN CAN controller x
	Range:	0/1	x = 1..2
2410ff	CanDCNodeState31to16 CanxxNodeState31to16		<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	1	HZM-CAN: Activity indicator node number 16..31
	Range:	0...FFFF Hex	xx =
			DC: Speed governor
			GC: Generator control units
			PE: Periphery modules
			IM: Inverter modules
			MC: Engine and hybrid control units
			AC: Add-on module
			CM: Customer module
			PC: PC, ARGOS, hand programmer
2411ff	CanDCNodeState15to01 CanxxNodeState15to01		<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	1	HZM-CAN: Activity indicator node number 1..15
	Range:	0...FFFF Hex	xx see 2410 <i>CanDCNodeState31to16</i>
2440ff	CanPEError(x)		<i>All except XIOS</i>
			<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	1	Error indication of HZM-CAN periphery module x
	Range:	0/1	x = 0..2

2443ff	CanACError(x)		<i>All except XIOS</i> <i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	1	Error indication of HZM-CAN add-on module x
	Range:	0/1	x = 0..4
2470ff	PEDigitalOutx		<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 9, DC 10</i> <i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	1	Indication of current value of binary output x of HZM-
	Range:	0/1	CAN periphery modules x: Depending on application
2475ff	PEPWMOutx		<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 9, DC 10</i> <i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	1	Indication of current value of PWM output x of HZM-
	Range:	0...100 %	CAN periphery modules x: Depending on application
2480ff	PEAnaOutx		<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 9, DC 10</i> <i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	1	Indication of current value of analogue output x of
	Range:	0...100 %	HZM-CAN periphery modules x: Depending on application
2489	PEModulesMax		<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	1	Indication of maximum number of HZM-CAN
	Range:	0...3	periphery modules that can be connected in this firmware version
2490ff	PEModulesMaxType(x)		<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	1	Indication of maximum admissible HZM-CAN
	Range:	0...3	periphery modules per module type in this firmware x = 0..18
			0 = PE 2 12 PE MVC03
			1 = PE 6-07 13 PE 11
			3 = PE 1-03 14 PE 10
			4 = PE 1-04 15 PE 8
			6 = PE MVC01 16 PE MVC04
			8 = PE XIOS 18 PE 12
			Only module types with a number not equal to 0 can be assigned as PE modules from 407 <i>CanPENodeType</i>
2541	ACModulesMax		<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	1	Indication of maximum number of HZM-CAN add-on
	Range:	0...5	modules that can be connected in this firmware
2550ff	ACModulesMaxType(x)		<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	1	Indication of the maximum admissible HZM-CAN add-
	Range:	0...5	on modules for each module type in this firmware x = 0..1
			0 = Undefined 1 = Elektra FlowControl
			Only module types with a number not equal to 0 can be assigned as AC modules from 435 <i>CanACNodeType</i>

2605	ExcitGovTrPowOrFuel	<i>Locomotive operation</i>
Level:	1	Indication of whether excitation signal is calculated
Range:	0/1	from traction power or fuel quantity control loop
Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 177, 182	
2630	ExcitPI_CorrFactor	<i>Locomotive operation</i>
Level:	1	Calculated PI correction factor for governing the
Range:	0...400 %	excitation signal
Page(s):	Fehler! Textmarke nicht definiert.	
2630	PitchPI_CorrFactor	<i>Marine operation</i>
Level:	1	Calculated PI correction factor for governing adjustable
Range:	0...400 %	propeller signal
Page(s):	Fehler! Textmarke nicht definiert.	
2640	ExcitLimitMaxActive	<i>Locomotive operation</i>
Level:	1	Indication of whether excitation signal is being limited
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert.	
2640	PitchLimitMaxActive	<i>Marine operation</i>
Level:	1	Indication of whether adjustable propeller signal is
Range:	0/1	being limited
Page(s):	Fehler! Textmarke nicht definiert.	

2641	ExcitFuelLimActive		<i>Locomotive operation</i>
	Level:	1	Indication of whether actual fuel value for calculation of excitation signal is being limited (= fuel quantity setpoint from speed control loop)
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
2641	PitchSpeedLimActive		<i>Marine operation</i>
	Level:	1	Indication of whether adjustable propeller signal is being limited depending on speed
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
2642	ExcitForceLim1Active		<i>Locomotive operation</i>
	Level:	1	Indication of whether excitation signal is being limited by switching function, "1st excitation signal limitation"
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
2642	PitchLimitSpeed		<i>Marine operation</i>
	Level:	1	Current speed-dependent limit value for adjustable propeller signal
	Range:	0...100 %	
	Page(s):	Fehler! Textmarke nicht definiert.	
2643	ExcitForceLim2Active		<i>Locomotive operation</i>
	Level:	1	Indication of whether excitation signal is being limited by switching function, "2nd excitation signal limitation"
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
2644	ExcitSlideLimActive		<i>Locomotive operation</i>
	Level:	1	Indication of whether excitation signal is being limited by slide protection
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
2645	ExcitTempLimActive		<i>Locomotive operation</i>
	Level:	1	Indication of whether excitation signal is being limited by temperature
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
2646	ExcitBoostLimActive		<i>Locomotive operation</i>
	Level:	1	Indication of whether excitation signal is being limited by boost pressure
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
2647	ExcitSpeedLimActive		<i>Locomotive operation</i>

	Level:	1	Indication of whether excitation signal is being limited
	Range:	0/1	depending on speed
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.		
2648	ExcitTractLimActive		<i>Locomotive operation</i>
	Level:	1	Indication of whether excitation signal is being limited
	Range:	0/1	depending on traction voltage or current
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.		
2650	ExcitFuelLimitTemp		<i>Locomotive operation</i>
	Level:	1	Current fuel quantity setpoint for excitation signal by
	Range:	0...100 %	temperature dependent fuel quantity reduction
	Page(s): Fehler! Textmarke nicht definiert.		

2655	ExcitFuelLimitBoost	<i>Locomotive operation</i>
Level:	1	Current fuel quantity setpoint for excitation signal by boost pressure dependent fuel quantity limitation
Range:	0...100 %	
Page(s):	Fehler! Textmarke nicht definiert.	
2656	ExcitationLimitSpeed	<i>Locomotive operation</i>
Level:	1	Current speed-dependent limit value for excitation signal
Range:	0...100 %	
Page(s):	Fehler! Textmarke nicht definiert.	
2657	ExcitationLimitVolt	<i>Locomotive operation</i>
Level:	1	Current speed-dependent limit for the traction voltage
Range:	0...x V	x: Depending on application
Page(s):		
2658	ExcitationLimitCurr	<i>Locomotive operation</i>
Level:	1	Current speed-dependent limit for the traction current
Range:	0...x A	x: Depending on application
Page(s):		
2670	ExcitTrPowLimitTemp	<i>Locomotive operation</i>
Level:	1	Temperature dependent limitation of traction power setpoint
Range:	0...x kW	
Page (s):	Fehler! Textmarke nicht definiert.	x: Depending on application
2675	ExcitTrPowLimitBoost	<i>Locomotive operation</i>
Level:	1	Boost pressure dependent limitation of traction power setpoint
Range:	0..x kW	
Page (s):	Fehler! Textmarke nicht definiert.	x: Depending on application
2676	ExcitTrPowLimitVolt	<i>Locomotive operation</i>
Level:	1	Current speed and traction voltage dependent limit value for traction power
Range:	0..x kW	
Page (s):	Fehler! Textmarke nicht definiert.	x: Depending on application
2677	ExcitTrPowLimitCurr	<i>Locomotive operation</i>
Level:	1	Current speed and traction current dependent limit value for traction power
Range:	0..x kW	
Page (s):	Fehler! Textmarke nicht definiert.	x: Depending on application
2680	EGRActive	
Level:	1	Indication that exhaust gas recirculation is active
Range:	0/1	(on request)
Page(s):		
2681ff	EGRValveSetpoint(x)	

Level: 1 Exhaust gas recirculation setpoint
Range: 0...100 % (on request)
Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert. x = 0..1

2683 InletAirActive

Level: 1 Indication that inlet air throttle valve is active
Range: 0/1 (on request)
Page(s):

2684	InlAirThrottleSetp	Level: 1	Inlet air throttle valve setpoint
		Range: 0...100 %	(on request)
		Page(s):	
2685	Wastegate	Level: 1	Wastegate setpoint
		Range: 0...100 %	(on request)
		Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.
2686	BypassValve	Level: 1	Bypass valve setpoint
		Range: 0...100 %	(on request)
		Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.
2687ff	EGRValvePosition(x)	Level: 1	Current position of EGR valve (Sonceboz)
		Range: 0...100 %	(on request)
		Page(s):	x = 0..1
2689ff	EGRValveStatus(x)	Level: 1	Current status of EGR valve (Sonceboz)
		Range: 0...255	(on request)
		Page(s):	x = 0..1
2691ff	EGRValveFaultCode(x)	Level: 1	Current error code of EGR valve (Sonceboz) (on request)
		Range: 0...255	(on request)
		Page(s):	x = 0..1
2701	FuelLimitMax	Level: 1	Current upper fuel limit
		Range: 0...100 %	
		Page(s):	Fehler! Textmarke nicht definiert.
2702	FuelLimitStart	Level: 1	Current fuel limit by starting fuel limitation
		Range: 0...100 %	
		Page(s):	Fehler! Textmarke nicht definiert.
2703	FuelLimitSpeed	Level: 1	Current fuel quantity limit using speed dependent fuel quantity limitation
		Range: 0...100 %	
		Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 220
2704	FuelLimitBoost		

Level: 1 Current fuel quantity limit using boost pressure
Range: 0...100 % dependent fuel quantity limitation
Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.

2705 FuelLimitForced

Level: 1 Current fuel limit by external specification
Range: 0...100 %
Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.

2706	FuelLimitPower		<i>Not XIOS</i>
	Level:	1	Current fuel limit by power limitation
	Range:	0...100 %	<i>XIOS see 2727 FuelLimitPower</i>
	Page(s):	Fehler! Textmarke nicht definiert., 225	
2706	FuelRedCoolantTemp		<i>XIOS</i>
	Level:	1	Current reduction value for speed dependent fuel quantity limitation using coolant temperature
	Range:	0...100 %	
	Page(s):	96	
2707	FuelRedChargeAirTemp		<i>XIOS</i>
	Level:	1	Current reduction value for speed dependent fuel quantity limitation using charge air temperature
	Range:	0...100 %	
	Page(s):	97	
2708	FuelRedFuelTemp		<i>XIOS</i>
	Level:	1	Current reduction value for speed dependent fuel quantity limitation using fuel temperature
	Range:	0...100 %	
	Page(s):	97	
2709	FuelRedAmbientPress		<i>XIOS</i>
	Level:	1	Current reduction value for speed dependent fuel quantity limitation using ambient pressure
	Range:	0...100 %	
	Page(s):	98	
2710	FuelLimitMinActive		
	Level:	1	Indication of whether fuel is at lower limit
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 377	
2711	FuelLimitMaxActive		
	Level:	1	Indication of whether fuel is at upper limit
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 211, 219, Fehler! Textmarke nicht definiert., 377	
2712	StartLimitActive		
	Level:	1	Indication of whether fuel is limited by starting fuel limitation
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
2713	SpeedLimitActive		
	Level:	1	Indication of whether fuel quantity is limited by speed-dependent fuel quantity limitation
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 220	

2716	PowerLimitActive	<i>Not XIOS</i>
Level:	1	Indication of whether fuel is limited depending on
Range:	0/1	power
Page(s):	221	
		<i>XIOS see 2728 PowerLimitActive</i>
2716	CoolantTempRedActive	<i>XIOS</i>
Level:	1	Indication of whether speed-dependent fuel quantity
Range:	0/1	limitation is reduced using coolant temperature
Page(s):	95	
2717	ChAirTempRedActive	<i>XIOS</i>
Level:	1	Indication of whether speed-dependent fuel quantity
Range:	0/1	limitation is reduced using charge air temperature
Page(s):	95	
2718	FuelTempRedActive	<i>XIOS</i>
Level:	1	Indication of whether speed-dependent fuel quantity
Range:	0/1	limitation is reduced using fuel temperature
Page(s):	95, 97	
2719	AmbPressRedActive	<i>XIOS</i>
Level:	1	Indication of whether speed-dependent fuel quantity
Range:	0/1	limitation is reduced using ambient pressure
Page(s):	95, 98	
2720	FuelLimitExtActive	
Level:	1	Indication of whether fuel is limited by external
Range:	0/1	specification
Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
2721	AsymmLoadLimitActive	<i>Marine operation twin-engine system</i>
Level:	1	Indication of whether fuel is limited by asymmetric load
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
2722	FuelLimitAsymmLoad	<i>Marine operation twin-engine system</i>
Level:	1	Current fuel limit by starting asymmetric load limitation
Range:	0...100 %	
Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
2724	NearFuelLimitActive	
Level:	1	Indication that the engine is being operated at the power
Range:	0/1	limit
Page(s):	Fehler! Textmarke nicht definiert.	
2725	FuelRedExhaustTemp	<i>XIOS</i>

Level:	1	Current reduction value for speed-dependent fuel
Range:	0...100 %	quantity limitation using exhaust temperature
Page(s):	98	
2726	ExhaustTempRedActive	XIOS
Level:	1	Indication of whether speed-dependent fuel quantity
Range:	0/1	limitation is reduced using exhaust temperature
Page(s):	95, 98	

2727	FuelLimitPower	<i>XIOS</i>
Level:	1	Current fuel limit by power limitation
Range:	0...100 %	<i>Otherwise see 2705 FuelLimitPower</i>
Page(s): Fehler! Textmarke nicht definiert. , 225		
2728	PowerLimitActive	<i>XIOS</i>
Level:	1	Indication of whether fuel is limited depending on
Range:	0/1	power
Page(s): Fehler! Textmarke nicht definiert. , 226		
<i>Otherwise see 2716 PowerLimitActive</i>		
2730	SetpLimitExtActive	
Level:	1	Indication of whether speed setpoint is limited by
Range:	0/1	external specification 2035 <i>SpeedSetpLimit</i>
Page(s): Fehler! Textmarke nicht definiert.		
2750	FuelTempCorrOffset	<i>XIOS</i>
Level:	1	Fuel temperature dependent target quantity correction:
Range:	-100...+100 %	offset evaluated with factor
Page(s): Fehler! Textmarke nicht definiert.		
2751	FuelTempCorrMap	<i>XIOS</i>
Level:	1	Fuel temperature dependent target quantity correction
Range:	-100...+100 %	Correction offset from map
Page(s): Fehler! Textmarke nicht definiert.		
2810	SwitchEngineStop	
Level:	1	State of "Engine stop" switching function
Range:	0/1	
Page(s): Fehler! Textmarke nicht definiert. , Fehler! Textmarke nicht definiert. , Fehler! Textmarke nicht definiert. , 232, 248, 251, 256, 259, 364, Fehler! Textmarke nicht definiert. , Fehler! Textmarke nicht definiert.		
2811	SwitchIdleSpeed	
Level:	1	State of "Idle speed" switching function
Range:	0/1	
Page(s): Fehler! Textmarke nicht definiert. , Fehler! Textmarke nicht definiert. , Fehler! Textmarke nicht definiert. , 249		
2812	SwitchDroop2Or1	

Level: 1 State of switching function "Droop 1/2"
 Range: 0/1 1 = Droop2 or Droop on
 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 249

2813 SwitchForcedLimit

Level: 1 State of "Load limitation" switching function
 Range: 0/1
 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 221, 227, 249

2814 SwitchSpeedRange2Or1

Level: 1 State of switching function "Speed range 1/2"
 Range: 0/1 1 = SpeedRange2
 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 249

2815	SwitchSpeedFix1		
	Level:	1	State of "Fixed speed 1" switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 249, 253	
2816	SwitchSpeedFix2		
	Level:	1	State of "Fixed speed 2" switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 249	
2817	SwitchSpeedLimit2Or1		
	Level:	1	State of "SpeedLimit 1/2" switching function
	Range:	0/1	1 = SpeedLimit2
	Page(s):	Fehler! Textmarke nicht definiert., 249 0 = SpeedLimit1	
2818	SwitchKnock		<i>Generator operation</i>
	Level:	1	State of "Knocking" switching function in generator
	Range:	0/1	operation
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 249	
2818	SwitchSlide		<i>Locomotive operation</i>
	Level:	1	State of "Sliding wheels" switching function in
	Range:	0/1	locomotive operation
	Page(s):	Fehler! Textmarke nicht definiert., 249	
2819	SwitchNotch3		
	Level:	1	State of "Speed notch 3" switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., 249	
2820	SwitchNotch2		
	Level:	1	State of "Speed notch 2" switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., 249	
2821	SwitchNotch1		<i>Locomotive operation</i>
	Level:	1	State of "Speed notch 1" switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., 249	
2821	SwitchBackwards		<i>Marine operation</i>

Level: 1 State of “Backwards” switching function
 Range: 0/1
 Page(s): **Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 249**

2822 SwitchNotch0

Level: 1 State of “Speed notch 0” switching function
 Range: 0/1
 Page(s): **Fehler! Textmarke nicht definiert., 249**

2822 SwitchForwards
Marine operation

Level: 1 State of “Forwards” switching function
 Range: 0/1
 Page(s): **Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 249**

	Level:	1	State of “Speed setpoint adjuster 1/2” switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 249	
2828	SwitchErrorReset		
	Level:	1	State of “Error reset” switching function
	Range:	0/1	
	Page(s):	250, 373	
2829	SwitchFreezeSetp1		
	Level:	1	State of “Freeze setpoint 1” switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 250	
2830	SwitchFreezeSetp2		
	Level:	1	State of “Freeze setpoint 2” switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 250	
2831	SwitchIMOrAllSpeed		Previously <i>SwitchGovernorMode</i>
	Level:	1	State of “IMOrAllSpeed” switching function
	Range:	0/1	1 = Idle / maximum speed governor
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 250	
2833	SwitchForcedStart		
	Level:	1	State of “Forced actuator opening when engine is still” switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., 250, 364	

2834	SwitchSyncEnable		
	Level:	1	State of “Synchronization enabled” switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 250	
2835	SwitchLoadEnable		
	Level:	1	State of “Load control enabled” switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 250	
2836	SwitchAutoOrManual		
	Level:	1	State of “Switch generator operation” switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 250	1 = Automatic operation 0 = Manual operation
2837	SwitchGasOrDiesel		<i>Dual fuel</i>
	Level:	1	State of “Switch gas / diesel operation” switching function
	Range:	0/1	
	Page(s):	174, 175, 178, 182, 213, 232, 250	1 = Dual fuel operation 0 = Diesel operation
2838	SwitchFastToDiesel		<i>Dual fuel</i>
	Level:	1	State of “Fast switch back to diesel” switching function
	Range:	0/1	
	Page(s):	174, 175, 178, 210, 232, 250	

2839	SwitchGasPosState		<i>Dual fuel</i>
	Level:	1	State of “Gas positioner OK” switching function
	Range:	0/1	
	Page(s):	203, 250	
2840	SwitchExcitationOn		
	Level:	1	State of “Excitation signal” switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., 250	
2840	SwitchPitchOn		
	Level:	1	State of “Adjustable propeller signal” switching
	Range:	0/1	function
	Page(s):	Fehler! Textmarke nicht definiert., 250	
2841	SwitchLowIdleOn		<i>Locomotive operation</i>
	Level:	1	State of “Low idle speed” switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., 250	
2841	SwitchMasterOrSlave		<i>Marine operation twin-engine system</i>
	Level:	1	State of “Master or Slave” switching function
	Range:	0/1	1 = Master
	Page(s):	Fehler! Textmarke nicht definiert., 250	0 = Slave

2842	SwitchPID2Or1		<i>Generator operation</i>
	Level:	1	State of “PID parameter set 2 or 1” switching function
	Range:	0/1	1 = PID set 2
	Page(s):	Fehler! Textmarke nicht definiert., 250	0 = PID set 1
2842	SwitchLoadTransfer		<i>Marine operation twin-engine system</i>
	Level:	1	State of “Load transfer” switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 250	
2842	SwitchCommand		<i>Marine operation multi-engine system</i>
	Level:	1	State of “Command” switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., 250	
2843	SwitchClutch		<i>Marine operation twin-engine system</i>
	Level:	1	State of “Clutch” switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 250	
2843	SwitchSynchro		<i>Marine operation multi-engine system</i>
	Level:	1	State of “Synchro” switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., 250	
2844	SwitchAsymLoadEnable		<i>Marine operation twin-engine system</i>
	Level:	1	State of “Asymmetric load” switching function
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 250	
2844	SwitchEngineRelease		<i>Dual fuel, not XIOS</i>
	Level:	1	State of “Start enable” switching function
	Range:	0/1	
	Page:	Fehler! Textmarke nicht definiert., 250	
2845	SwitchAutoAdjust		
	Level:	1	State of “Automatic actuator calibration” switching function
	Range:	0/1	
	Page(s):	250, 354	
2845	SwitchGasPressReady		<i>Dual fuel, not XIOS</i>
	Level:	1	State of “Gas pressure built up” switching function
	Range:	0/1	<i>XIOS see 2870</i>
	Page(s):	177, 179, 195, 250	
2846	SwitchGenBreaker		

Level: 1 State of “Breaker” switching function
Range: 0/1 Generator or mains breaker
Page(s): **Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 178, 236, 250**

2847 SwitchAlternator *XIOS*

Level: 1 State of “Alternator signal” switching function
Range: 0/1
Page(s): **Fehler! Textmarke nicht definiert., 250**

2847	SwitchExternGasAlarm	<i>Dual fuel, not XIOS</i>
	Level:	1 State of “External gas alarm” switching function
	Range:	0/1 <i>XIOS see 2871</i>
	Page(s):	175, 178, 201, 210, 250
2848	SwitchExternGasReady	<i>Dual fuel, not XIOS</i>
	Level:	1 State of “External gas ready” switching function
	Range:	0/1 <i>XIOS see 2872</i>
	Page(s):	179, 184, 251
2849	SwitchStartEngine	<i>DC 5, XIOS</i>
	Level:	1 State of “Engine start” switching function
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert. , 251
2849	SwitchEmergencyStop	<i>Dual fuel, not XIOS</i>
	Level:	1 State of “Emergency shutdown” switching function
	Range:	0/1 <i>XIOS see 2873</i>
	Page(s):	Fehler! Textmarke nicht definiert. , 174, 178, 251, Fehler! Textmarke nicht definiert.
2870	SwitchGasPressReady	<i>Dual fuel, XIOS</i>
	Level:	1 State of “Gas pressure built up” switching function
	Range:	0/1 <i>Otherwise see 2845</i>
	Page(s):	177, 251
2871	SwitchExternGasAlarm	<i>Dual fuel, XIOS</i>
	Level:	1 State of “External gas alarm” switching function
	Range:	0/1 <i>Otherwise see 2847</i>
	Page(s):	175, 201, 210, 251
2872	SwitchExternGasReady	<i>Dual fuel, XIOS</i>
	Level:	1 State of “External gas ready” switching function
	Range:	0/1 <i>Otherwise see 2848</i>
	Page(s):	184, 210, 251
2873	SwitchEmergencyStop	<i>Dual fuel, XIOS</i>
	Level:	1 State of “Emergency shutdown” switching function
	Range:	0/1 <i>Otherwise see 2849</i>
	Page(s):	174, 251, 251
2851ff	DigitalOutx	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 9, DC 10</i>
	Level:	1 State of binary output x:
	Range:	0/1 DC 1-03: 1..3 DC 6: 1..2
	Page(s):	Fehler! Textmarke nicht definiert. DC 1-04: 1..5 DC 7: 1..7
		DC 2: 1..5 DC 9: 1
		DC 5: 1..11 DC 10: 1
2900	Setpoint1Extern	

	Level:	1	Current (first or only) boost pressure value
	Range:	0...5 bar	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 193, 231, 234	
2905	OilPressure		
	Level:	1	Current oil pressure value
	Range:	0...20 bar	
	Page(s):	Fehler! Textmarke nicht definiert., 192, 234	
2906	AmbientPressure		
	Level:	1	Current ambient pressure value
	Range:	0...2000 mbar	
	Page(s):	98, 234	
2907	CoolantTemp		
	Level:	1	Current coolant temperature value
	Range:	-100...+1000 °C	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 96, Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 189, 229, 234	
2908	ChargeAirTemp		
	Level:	1	Current charge air temperature value
	Range:	-100...+1000 °C	
	Page(s):	97, Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 190, 228, 235	
2909	OilTemp		
	Level:	1	Current oil temperature value
	Range:	-100...+1000 °C	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 235	
2910	FuelTemp		
	Level:	1	Current fuel temperature value
	Range:	-100...+1000 °C	
	Page(s):	97, Fehler! Textmarke nicht definiert., 235	
2910	GasTemp		<i>Dual fuel, not XIOS</i>

	Level:	1	Current gas temperature value
	Range:	-100...+1000 °C	<i>XIOS see 2926</i>
	Page(s):	191, 230, 235	
2911	ExhaustTemp		
	Level:	1	Current exhaust temperature value
	Range:	-100...+1000 °C	
	Page(s):	97, Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.,	
		186, 229, 235	
2911	ExhaustTempMax		<i>Dual fuel, not XIOS</i>
	Level:	1	Maximum exhaust temperature value
	Range:	-100...+1000 °C	
	Page(s):	97, Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.,	<i>XIOS see 12573</i>
		186, 229, 235	
2912	ExhaustTempMin		<i>Dual fuel, not XIOS</i>
	Level:	1	Minimum exhaust temperature value
	Range:	-100...+1000 °C	
	Page(s):	187	<i>XIOS see 12572</i>
2913	ExhaustTempAverage		<i>Dual fuel, not XIOS</i>
	Level:	1	Average exhaust temperature value
	Range:	-100...+1000 °C	
	Page(s):	187, 229	<i>XIOS see 12570</i>
2914	SlideExcitReduction		
	Level:	1	Current value for reduction of excitation signal for slide protection in locomotive operation
	Range:	0...100 %	
	Page(s):	Fehler! Textmarke nicht definiert., 235	
2915	SlideSpeedReduction		
	Level:	1	Current value for reduction of speed setpoint for slide protection in locomotive operation
	Range:	0...4000 rpm	
	Page(s):	Fehler! Textmarke nicht definiert., 235	
2915	AlternatorVoltage		<i>DC 5</i>
	Level:	1	Current alternator voltage value
	Range:	0...37.2 V	
	Page(s):	Fehler! Textmarke nicht definiert., 235	<i>XIOS see 2936</i>
2916	CoolantPressure		<i>Locomotive operation</i>
	Level:	1	Current value of coolant pressure
	Range:	0...5 bar	
	Page(s):	Fehler! Textmarke nicht definiert., 235	
2916	GasPosition		<i>Dual fuel, not XIOS</i>

	Level:	1	Current gas position value (external actuator with connection via analogue or PWM input and output)
	Range:	0...100 %	
	Page(s):	203, 235	<i>XIOS see 2927</i>
2917	AsymmetricLoad		<i>Marine operation twin-engine system</i>
	Level:	1	Current value of asymmetric load
	Range:	0...100 %	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 235	
2918	MeasuredPower		<i>Generator operation</i>
	Level:	1	Current power signal value
	Range:	0...100 % or 0...x kW	x: Depending on application
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 160, 221, 225, 235, 242	
2918	TractionVoltage		<i>Locomotive operation</i>
	Level:	1	Current traction voltage value
	Range:	0...x V	x: Depending on application
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 166, 235	
2919	PowerSetpoint		<i>Generator operation</i>
	Level:	1	Current power setpoint signal value
	Range:	0...100 % or 0...x kW	x: Depending on application
	Page(s):	Fehler! Textmarke nicht definiert., 235, 242	
2919	TractionCurrent		<i>Locomotive operation</i>
	Level:	1	Current traction current value
	Range:	0...x A	x: Depending on application
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 166, 235	
2920	TurboOilTemp		
	Level:	1	Current value of turbocharger oil temperature
	Range:	-100...1000 °C	
	Page(s):	Fehler! Textmarke nicht definiert., 235	
2921	FuelPressure		

	Level:	1	Current value of fuel pressure
	Range:	0...10 bar	
	Page(s):	Fehler! Textmarke nicht definiert., 236	
2921	GasRailPressure		<i>Dual fuel, not XIOS</i>
	Level:	1	Current gas rail pressure value
	Range:	0...10 bar	<i>XIOS see 2928</i>
	Page(s):	230, 232, 236	
2922	OilLevel		
	Level:	1	Current oil level value
	Range:	0...100 %	
	Page(s):	Fehler! Textmarke nicht definiert., 236	
2923	FuelLimitExtern		
	Level:	1	Current external fuel quantity limitation value
	Range:	0...100 %	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 236	
2924	TransmissionOilPress		
	Level:	1	Current transmission oil pressure value
	Range:	0...40 bar	
	Page(s):	Fehler! Textmarke nicht definiert., 236	

2925	AirMass		
	Level:	1	Current air mass sensor value
	Range:	0..1000 kg/h	
	Page(s):	236	
2925	GasDiffPressure		<i>Dual fuel, not XIOS</i>
	Level:	1	Gas differential pressure, relative gas pressure
	Range:	0...10 bar	
	Page(s):	179, 194, 237	<i>XIOS see 2942</i>
2926	GasTemp		<i>Dual fuel, XIOS</i>
	Level:	1	Current gas temperature value
	Range:	-100...+1000 °C	
	Page(s):	191, 230, 236	<i>Otherwise see 2910</i>
2927	GasPosition		<i>Dual fuel, XIOS</i>
	Level:	1	Current gas position value (external actuator with connection via analogue or PWM input and output)
	Range:	0...100 %	
	Page(s):	203, 236	<i>Otherwise see 2916</i>
2928	GasRailPressure		<i>Dual fuel, XIOS</i>
	Level:	1	Current gas rail pressure value
	Range:	0...10 bar	
	Page(s):	230, 236	<i>Otherwise see 2921</i>
2931	BoostPressure2		
	Level:	1	Current value of second boost pressure sensor
	Range:	0...5 bar	
	Page(s):	Fehler! Textmarke nicht definiert., 236	
2932	Lambda1		
	Level:	1	Current value of first lambda sensor
	Range:	0...30	
	Page(s):	236	
2933	Lambda2		
	Level:	1	Current value of second lambda sensor
	Range:	0...30	
	Page(s):	236	
2934	NOx		
	Level:	1	Current nitrogen oxide content value
	Range:	0...5000 ppm	
	Page(s):	236	
2935	O2		
	Level:	1	Current oxygen content value
	Range:	0...100 %	
	Page(s):	236	
2936	AlternatorVoltage		<i>XIOS</i>
	Level:	1	Current alternator voltage value
	Range:	0...36 V	
	Page(s):	Fehler! Textmarke nicht definiert., 236 <i>DC 5: see 2915</i>	

2940	BoostPressRelative		
	Level:	1	Relative boost pressure
	Range:	0...5 bar	
	Page(s):	237	
2941	AbsoluteAltitude		
	Level:	1	Height above sea level
	Range:	-5000...+5000 m	
	Page(s):	237	
2942	GasDiffPressure		<i>Dual fuel, XIOS</i>
	Level:	1	Gas differential pressure, relative gas pressure
	Range:	0...10 bar	
	Page(s):	194, 237	<i>Not XIOS see 2925</i>
2943	LambdaCalculated		
	Level:	1	Lambda (calculated from 2935 O2)
	Range:	0...30	
	Page(s):	237	
3000	ConfigurationError		
	Level:	1	Displays configuration errors
	Range:	0...65535	
	Page(s):	297, Fehler! Textmarke nicht definiert., 421, Fehler! Textmarke nicht definiert.	
3001	ErrPickup1		
	Level:	1	Error indication for speed sensor 1
	Range:	0/1	
		or 0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 377, Fehler! Textmarke nicht definiert., 409, Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3002	ErrPickup2		

Level: 1 Error indication for speed sensor 21
 Range: 0/1
 or 0000..FFFF Hex
 Page(s): **Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 378, Fehler! Textmarke nicht definiert., 409, Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.**

3003 ErrCamIndex

Level: 1 Error indication for camshaft sensor
 Range: 0/1
 or 0000...FFFF Hex
 Page(s): **Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.**

3004 ErrOverSpeed

Level: 1 Error indication for overspeed
 Range: 0/1
 or 0000...FFFF Hex
 Page(s): **Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 410, Fehler! Textmarke nicht definiert.**

3005	ErrSetpoint1Extern		
	Level:	1	Error indication for speed setpoint adjuster 1
	Range:	0/1	
		or 0000...FFFF Hex	
	Page(s):	411, Fehler! Textmarke nicht definiert.	
3006	ErrSetpoint2Extern		
	Level:	1	Error indication for speed setpoint adjuster 2
	Range:	0/1	
		or 0000...FFFF Hex	
	Page(s):	411, Fehler! Textmarke nicht definiert.	
3007	ErrLoadCtrlInput		
	Level:	1	Error indication for load control input
	Range:	0/	
		or 0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 411, Fehler! Textmarke nicht definiert.	
3008	ErrSyncInput		
	Level:	1	Error indication for synchronizing signal
	Range:	0/1	
		0000..FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 411, Fehler! Textmarke nicht definiert.	
3009	ErrBoostPressure(1)		
	Level:	1	Error indication for first or only boost pressure sensor
	Range:	0/1	
		or 0000...FFFF Hex	
	Page(s):	411, Fehler! Textmarke nicht definiert.	
3010	ErrOilPressure		
	Level:	1	Error indication for oil pressure sensor
	Range:	0/1	
		or 0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert., 193, Fehler! Textmarke nicht definiert., 411, Fehler! Textmarke nicht definiert.	
3011	ErrAmbientPressure		

Level: 1 Error indication for ambient pressure sensor
Range: 0/1
or 0000...FFFF Hex
Page(s): 411, **Fehler! Textmarke nicht definiert.**

3012 ErrCoolantTemp

Level: 1 Error indication for coolant temperature sensor
Range: 0/1
or 0000...FFFF Hex
Page(s): **Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 411, Fehler! Textmarke nicht definiert.**

3013 ErrChargeAirTemp

Level: 1 Error indication for charge air temperature sensor
Range: 0/1
or 0000...FFFF Hex
Page(s): **Fehler! Textmarke nicht definiert., 411, Fehler! Textmarke nicht definiert.**

3014	ErrOilTemp		
	Level:	1	Error indication for oil temperature sensor
	Range:	0/1	
		or 0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 411, Fehler! Textmarke nicht definiert.	
3015	ErrFuelTemp		
	Level:	1	Error indication for fuel temperature sensor
	Range:	0/1	
		or 0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert., 411, Fehler! Textmarke nicht definiert.	
3015	ErrGasTemp		<i>Dual fuel, not XIOS</i>
	Level:	1	Error indication for gas temperature sensor
	Range:	0/1	<i>XIOS see 13071</i>
	Page(s):	Fehler! Textmarke nicht definiert.	
3016	ErrExhaustTemp		
	Level:	1	Error indication for exhaust temperature sensor
	Range:	0/1	
		or 0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert., 411, Fehler! Textmarke nicht definiert.	
3019	ErrExcitReduct		
	Level:	1	Error indication for reduction value for excitation signal
	Range:	0/1	for slide protection in locomotive operation
		or 0000...FFFF Hex	
	Page(s):	411, Fehler! Textmarke nicht definiert.	
3020	ErrSpeedReduct		<i>Locomotive</i>
	Level:	1	Error indication for reduction value for speed setpoint
	Range:	0/1	for slide protection in locomotive operation
		or 0000...FFFF Hex	
	Page(s):	411, Fehler! Textmarke nicht definiert.	
3020	ErrAlternator		<i>DC 5, vehicle</i>
	Level:	1	Error indication for alternator
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3021	ErrCoolantPressure		

	Level:	1	Error indication for coolant pressure sensor
	Range:	0/1 or 0000...FFFF Hex	
	Page(s): 411, Fehler! Textmarke nicht definiert.		
3021	ErrGasPosition		<i>Dual fuel, not XIOS</i>
	Level:	1	Error indication for external gas position
	Range:	0/1	
	Page(s): Fehler! Textmarke nicht definiert. <i>XIOS see 13072</i>		
3022	ErrAsymmetricLoad		<i>Marine operation twin-engine system</i>
	Level:	1	Error indication for asymmetric load
	Range:	0/1 or 0000...FFFF Hex	
	Page(s): 411, Fehler! Textmarke nicht definiert.		
3023	ErrMeasuredPower		<i>Generator operation</i>
	Level:	1	Error indication for measured power
	Range:	0/1 or 0000...FFFF Hex	
	Page(s): Fehler! Textmarke nicht definiert., 411, Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.		
3023	ErrTractionVoltage		<i>Locomotive operation</i>
	Level:	1	Error indication for traction voltage
	Range:	0/1 or 0000...FFFF Hex	
	Page(s): 411, Fehler! Textmarke nicht definiert.		
3024	ErrPowerSetpoint		<i>Generator operation</i>
	Level:	1	Error indication for power setpoint sensor
	Range:	0/1 or 0000...FFFF Hex	
	Page(s): Fehler! Textmarke nicht definiert., 411, Fehler! Textmarke nicht definiert.		
3024	ErrTractionCurrent		<i>Locomotive operation</i>
	Level:	1	Error indication for traction current
	Range:	0/1 or 0000...FFFF Hex	
	Page(s): 411, Fehler! Textmarke nicht definiert.		
3025	ErrTurboOilTemp		

	Level:	1	Error indication for turbocharger oil temperature sensor
	Range:	0/1 or 0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert., 411, Fehler! Textmarke nicht definiert.	
3026	ErrFuelPressure		
	Level:	1	Error indication for fuel pressure sensor
	Range:	0/1 or 0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert., 411, Fehler! Textmarke nicht definiert.	
3026	ErrGasRailPressure		<i>Dual fuel, not XIOS</i>
	Level:	1	Error indication for gas pressure sensor
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert. <i>XIOS see 13073</i>	
3027	ErrOilLevel		
	Level:	1	Error indication for oil level sensor
	Range:	0/1 or 0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert., 411, Fehler! Textmarke nicht definiert.	
3028	ErrFuelLimitExtern		
	Level:	1	Error indication for external fuel quantity limitation sensor
	Range:	0/1 or 0000...FFFF Hex	
	Page(s):	411, Fehler! Textmarke nicht definiert.	

3029	ErrTransOilPressure		
	Level:	1	Error indication for transmission oil pressure sensor
	Range:	0/1	
		or 0000...FFFF Hex	
	Page(s): Fehler! Textmarke nicht definiert., 411, Fehler! Textmarke nicht definiert.		
3030	ErrOilPressWarn		<i>All except XIOS</i>
	Level:	1	Indication of oil pressure warning
	Range:	0/1	
	Page(s): Fehler! Textmarke nicht definiert., 193, Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 573		
3031	ErrOilPressEcy		<i>All except XIOS</i>
	Level:	1	Indication of oil pressure emergency shutdown
	Range:	0/1	
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.		
3032	ErrCoolantTempWarn		<i>All except XIOS</i>
	Level:	1	Indication of coolant temperature warning
	Range:	0/1	
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.		
3033	ErrChargeAirTempWarn		<i>All except XIOS</i>
	Level:	1	Indication of charge air temperature warning
	Range:	0/1	
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.		
3034	ErrOilTempWarn		<i>All except XIOS</i>
	Level:	1	Indication of oil temperature warning
	Range:	0/1	
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.		

3040	ErrAlternatorWarn	<i>DC 5</i>
	Level:	1 Indication of alternator warning
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.
3041	ErrExhaustTempWarn	<i>All except XIOS</i>
	Level:	1 Indication of exhaust temperature warning
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.
3043	ErrACCommonAlarm	<i>All except XIOS</i>
	Level:	1 Indication of common alarms in one of the add-on
	Range:	0/1 modules
	Page(s):	Fehler! Textmarke nicht definiert.
3044	ErrCoolPressWarn	<i>All except XIOS</i>
	Level:	1 Indication of coolant pressure warning
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.
3045	ErrFailedToStart	<i>Vehicle operation (DC 5)</i>
	Level:	1 Indication of start abort
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert.
3045	ErrCoolPressIdle	<i>Locomotive operation (all except XIOS)</i>
	Level:	1 Indication of forced idle speed due to low coolant
	Range:	0/1 pressure
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.
3045	ErrPowerPercentCan	<i>Generator operation (all except XIOS)</i>
	Level:	1 The relative power was either not received via the
	Range:	0/1 HMZ-CAN bus or a sensor error has occurred on the
	Page(s):	Fehler! Textmarke nicht definiert. sender side.
3046	ErrMisfireWarn	<i>Generator operation (all except XIOS)</i>
	Level:	1 Indication of misfire warning
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert., 175

3047	ErrMisfireDetection	<i>Generator operation (XIOS)</i>
	Level: 1	Indication of errors due to misfiring
	Range: 0000...FFFF Hex	
	Page(s): Fehler! Textmarke nicht definiert., 175, 180, Fehler! Textmarke nicht definiert., 413	
3047	ErrMisfireEcy	<i>Generator operation (all except XIOS)</i>
	Level: 1	Indication of emergency shutdown due to misfiring
	Range: 0/1	
	Page(s): Fehler! Textmarke nicht definiert., 175, 180, Fehler! Textmarke nicht definiert.	
3048	ErrPowerGovernor	<i>Generator operation (XIOS)</i>
	Level: 1	Indication of errors in integrated power governor
	Range: 0000...FFFF Hex	
	Page(s): Fehler! Textmarke nicht definiert., 414	
3048	ErrPowerDifference	<i>Generator operation (all except XIOS)</i>
	Level: 1	Excessive difference between power setpoint and measured power
	Range: 0/1	
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3048	ErrTwinEngine	<i>Marine operation twin-engine system</i>
	Level: 1	Error in master / slave operation
	Range: 0/1	
	or 0000...FFFF Hex	
	Page(s): Fehler! Textmarke nicht definiert., 413, Fehler! Textmarke nicht definiert.	
3048	ErrVelocity	<i>Vehicle or locomotive operation (all except XIOS)</i>
	Level: 1	Error in velocity measurement
	Range: 0/1	
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3049	ErrPECommonAlarm	<i>All except XIOS</i>
	Level: 1	At least one of the HZM-CAN periphery modules is reporting a common alarm
	Range: 0/1	
	Page(s): Fehler! Textmarke nicht definiert. See 2440 <i>CanPEError(x)</i> for more detailed information	
3050	ErrActuatorx	<i>XIOS</i>
3051	Level: 1	Error on actuator x
3052	Range: 0...FFFF Hex	x = 1..3
	Page(s): 202, 355, 357, Fehler! Textmarke nicht definiert.	

3050	ErrFeedbackx		<i>All except XIOS (3051/3052 only DC 1-04)</i>
3051	Level:	1	Error in feedback from actuator x
3052	Range:	0/1	x = 1..3
	Page(s):	357, 376, Fehler!	
	Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.		
3053	ErrActuatorDiffx		<i>All except XIOS (3054/3055 only DC 1-04)</i>
3054	Level:	1	Too great a difference in set actuator travel and actual
3055	Range:	0/1	actuator travel in actuator x
	Page(s):	376, Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	x = 1..3
3056	ErrFeedbackRef		<i>DC 2, DC 5, DC 6, DC 7, DC 9, DC 10, DC 12</i>
	Level:	1	Error in reference value for digital actuator feedback
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3057	ErrBrakeStatus		<i>DC 1, control unit with brake function</i>
	Level:	1	Error in brake status
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3059	ErrFeedbackAdjustx		<i>All except XIOS (3060/61 only DC 1-04)</i>
3060	Level:	1	Error during auto-adjustment of actuator x or input of
3061	Range:	0/1	feedback reference values
	Page(s):	355, 376, Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	x = 1..3
3060	ErrAmplifier		<i>All except DC 1, DC 2, and XIOS</i>
	Level:	1	Error indication for amplifier
	Range:	0/1	
	Page(s):	364, Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3070ff	ErrCanBusx		

Level: 1 Error indication for CAN bus
 Range: 0/1 x = 1..2
 or 0000...FFFF Hex
 Page(s): **Fehler! Textmarke nicht definiert.**, 202, 413,
 Fehler! Textmarke nicht definiert., **Fehler! Textmarke nicht definiert.**, **Fehler! Textmarke nicht definiert.**

3071ff ErrHzmCanCommx *HZM-CAN*
 Level: 1 Error indication for CAN communication
 Range: 0/1 See 2401 *CanTxBufferState*, 2402 *CanRxBufferState*,
 or 0000...FFFF Hex 2403 *CanRxTimeout* and 2404 *CanTypeMismatch*
 Page(s): **Fehler! Textmarke nicht definiert.**, 202, 413,
 Fehler! Textmarke nicht definiert., **Fehler! Textmarke nicht definiert.**, **Fehler! Textmarke nicht definiert.**, **Fehler! Textmarke nicht definiert.**

3071 ErrWagoCanComm *WAGO, not XIOS*
 Level: 1 Error indication for WAGO-CAN communication
 Range: 0/1 without HZM-CAN communication, *Otherwise 23013 XIOS see 23013*

3071 ErrCANopenComm *CANopen, not XIOS*
 Level: 1 Error indication for CANopen communication without
 Range: 0/1 HZM-CAN communication, *others 23000 XIOS see 23000*

3071	ErrIceniCanComm		<i>ICENI, not XIOS</i>
	Level:	1	Error indication for ICENI-CAN communication
	Range:	0/1	without HZM-CAN communication, <i>others 23015 XIOS see 23015</i>
3071	ErrSAEJ1939Comm		<i>SAE J1939, not XIOS</i>
	Level:	1	Error indication for SAE J1939-CAN communication
	Range:	0/1	
3071	ErrDeviceNetComm		<i>DeviceNet, not XIOS</i>
	Level:	1	Error indication for DeviceNet-CAN communication
	Range:	0/1	
3074	ErrModbusComm		<i>Modbus, not XIOS</i>
	Level:	1	Error indication for Modbus communication
	Range:	0/1	<i>XIOS see 23001</i>
3075	ErrACFatalError		<i>DC 5</i>
	Level:	1	Error indication for fatal error in one of the add-on
	Range:	0/1	modules
	Page(s): Fehler! Textmarke nicht definiert.		
3075	ErrClearFlash		<i>DC 1, DC 2</i>
	Level:	1	Error indication for clearing the read-only memory
	Range:	0/1	
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.		
3076	ErrParamStore		
	Level:	1	Error indication for programming the read-only
	Range:	0/1	memory
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.		
3077	ErrProgramTest		
	Level:	1	Error indication for checking the checksum for the
	Range:	0/1	firmware program
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.		
3078	ErrRAMTest		
	Level:	1	Error indication for the RAM test
	Range:	0/1	
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.		
3080	ff		<i>Hardware-specific errors are described in the associated subchapters</i>

3080	ErrACFatalError	<i>DC 10</i>
	Level:	1 Error indication for fatal error in one of the add-on
	Range:	0/1 modules
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3084	ErrACFatalError	<i>DC 1, DC 2, DC 6. DC 7, DC 12</i>
	Level:	1 Error indication for fatal error in one of the add-on
	Range:	0/1 modules
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	

3087	ErrMainChecksum		<i>(only visible in boot loader)</i>
	Level:	1	Checksum for control unit program is wrong
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3087	ErrEEPROM		<i>XIOS</i>
	Level:	1	Indication of erroneous E ² PROM pages
	Range:	0000...FFFF Hex	<i>Otherwise see 3099 EEPROMErrorCode</i>
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 418, Fehler! Textmarke nicht definiert., 527	
3088	ErrACFatalError		<i>DC 11</i>
	Level:	1	Error indication for fatal error in one of the HZM-CAN
	Range:	0/1	add-on modules
	Page(s):		
3089	ErrPEFatalError		
	Level:	1	Error indication for fatal error in one of the HZM-CAN
	Range:	0/1	periphery modules
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3089	ErrWatchdog		<i>(only visible in boot loader)</i>
	Level:	1	Internal so-called "Watchdog error"
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., 382, Fehler! Textmarke nicht definiert.	
3090	ErrData		
	Level:	1	Error indication for the data record
	Range:	0/1	
	Page(s):	376, Fehler! Textmarke nicht definiert.	
3091	ErrEngine		<i>XIOS</i>
	Level:	1	Error indication for engine (alternator, starter)
	Range:	0000..FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert., 420	
3092	ErrConfiguration		
	Level:	1	Configuration errors
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., 421, Fehler! Textmarke nicht definiert.	
3093	ErrStack		

	Level:	1	Error indication for the "Stack Overflow" error
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3094	ErrIntern		
	Level:	1	Error indication for internal software error
	Range:	0/1	further information from 3095/3195
		or 0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 376, Fehler! Textmarke nicht definiert., 421, Fehler! Textmarke nicht definiert.	
3095	ExceptionNumber		<i>DC 1, DC 2</i>
	Level:	1	Error number for software error
	Range:	0...255	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3096	ExceptionAddr1High		<i>DC 1, DC 2</i>
	Level:	1	Upper extended error number 1 for software error
	Range:	0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert.	
3097	ExceptionAddr1Low		<i>DC 1, DC 2</i>
	Level:	1	Lower extended error number 1 for software error
	Range:	0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert.	
3098	ExceptionAddr2High		<i>DC 1, DC 2</i>
	Level:	1	Upper extended error number 2 for software error
	Range:	0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert.	
3099	ExceptionAddr2Low		<i>DC 1, DC 2</i>
	Level:	1	Lower extended error number 2 for software error
	Range:	0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3099	EEPROMErrorCode		<i>All except DC 1, DC 2, and XIOS</i>

	Level:	1	Indication of erroneous E ² PROM pages
	Range:	0000...FFFF Hex	<i>XIOS see 3087ErrEEPROM</i>
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3101	SErr...		<i>All except XIOS</i>
...	Level:	1	Error marker / error counter
3194	Range:	0/1 or 0...255	Related current errors see 3001 ff
3190	ExceptionNumber		<i>XIOS</i>
	Level:	1	Error marker: Error number for software error
	Range:	0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert., 421	
3191	ExceptionAddr1High		<i>XIOS</i>
	Level:	1	Error marker: Upper extended error number 1
	Range:	0000...FFFF Hex	for software error
	Page(s):	421	
3192	ExceptionAddr1Low		<i>XIOS</i>
	Level:	1	Error marker: Lower extended error number 1
	Range:	0000...FFFF Hex	for software error
	Page(s):	421	
3193	ExceptionAddr2High		<i>XIOS</i>
	Level:	1	Error marker: Upper extended error number 2
	Range:	0000...FFFF Hex	for software error
	Page(s):	421	
3194	ExceptionAddr2Low		<i>XIOS</i>
	Level:	1	Error marker: Lower extended error number 2
	Range:	0000...FFFF Hex	for software error
	Page(s):	421	

3195	ExceptionInfo1High	<i>XIOS</i>
	Level: 1	Error marker: Upper error identifier 1 for software error
	Range: 0000...FFFF Hex	
	Page(s): 421	
3195ff	SException...	<i>DC 1 and DC 2</i>
	Level: 1	Error marker
	Range: 0...1 or 0...255	Related current errors see 3095 ff
	Page(s): Fehler! Textmarke nicht definiert.	
3195	SExceptionNumber	<i>All except DC 1, DC 2, and XIOS</i>
	Level: 1	Error number for software error
	Range: 0...255	
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3196	SExceptionAddrLow	<i>All except DC 1, DC 2, and XIOS</i>
	Level: 1	Error marker: Lower extended error number for software error
	Range: 0000...FFFF Hex	
	Page(s): Fehler! Textmarke nicht definiert.	
3196	ExceptionInfo1Low	<i>XIOS</i>
	Level: 1	Error marker: Lower error identifier 1 for software error
	Range: 0000...FFFF Hex	
	Page(s): 421	
3197	SExceptionAddrHigh	<i>All except DC 1, DC 2, and XIOS</i>
	Level: 1	Error marker: Upper extended error number for software error
	Range: 0000...FFFF Hex	
	Page(s): Fehler! Textmarke nicht definiert.	
3197	ExceptionInfo2High	<i>XIOS</i>
	Level: 1	Error marker: Upper error identifier 2 for software error
	Range: 0000...FFFF Hex	
	Page(s): 421	
3198	SExceptionFlag	<i>All except DC 1, DC 2, and XIOS</i>
	Level: 1	Error marker: Error identifier for software error
	Range: 0000...FFFF Hex	
	Page(s): Fehler! Textmarke nicht definiert.	
3198	ExceptionInfo2Low	<i>XIOS</i>
	Level: 1	Error marker: Lower error identifier 2 for software error
	Range: 0000...FFFF Hex	
	Page(s): 421	
3200	GenCtrlMainsOrIsland	

Level: 1 0: Island operation
Range: 0/1 1: Mains parallel operation
Page(s): **Fehler! Textmarke nicht definiert.** in generator sets

3201 GenCtrlAutoOrManual

Level: 1 0: Manual mode
Range: 0/1 1: Automatic mode
Page(s): **Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.** in generator sets

3231	RelativePowerSetp		<i>Generator operation, integrated power governor</i>
	Level:	1	Power setpoint relative to nominal power 1232
	Range:	0...200 %	<i>RatedPower</i>
	Page(s):	243	
3231	TractionPower		<i>Locomotive operation</i>
	Level:	1	Traction power
	Range:	0...x kW	x: Depending on application
	Page(s):	Fehler! Textmarke nicht definiert. , 160, 166, 186, 193, 225, 237	
3231	EnginePower		<i>Dual fuel Marine operation</i>
	Level:	1	Engine power
	Range:	0...x kW	x: Depending on application
	Page(s):	169	
3232	RelativePower		<i>Generator operation</i>
	Level:	1	Relative power in relation to nominal power 1232
	Range:	0...200 %	<i>RatedPower</i>
	Page(s):	Fehler! Textmarke nicht definiert. , 160, 185, 193, 243	
3232	RelativTractionPower		<i>Locomotive operation</i>
	Level:	1	Relative traction power in relation to maximum traction power 1232 <i>TractionPowerHigh</i>
	Range:	0...200 %	
	Page(s):	Fehler! Textmarke nicht definiert. , 167	
3233	PowerSetpEffective		<i>Integrated power governor</i>
	Level:	1	Effective power setpoint after ramp
	Range:	0...200 %	
	Page(s):	Fehler! Textmarke nicht definiert. , Fehler! Textmarke nicht definiert.	
3234	GovernorPowerOrSpeed		<i>Integrated power governor</i>
	Level:	1	Power governor is active (1) or not active (0)
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3235	PowerPIDCorrFactor		<i>Integrated power governor</i>
	Level:	1	Correction factor for integrated power governor
	Range:	0...400 %	
	Page(s):	Fehler! Textmarke nicht definiert.	
3245	KnockPowerRedActive		<i>Integrated power governor</i>
	Level:	1	Power reduction due to knocking is active
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3247	JetAssistActive		

Level: 1 Boost signal is active
Range: 0/1
Page(s): Fehler! Textmarke nicht definiert., 465

3248 JetAstCurrBoostDiff

Level: 2 Current difference between minimum boost pressure
Range: 0...5 bar curve and 2904 *BoostPressure*
Page(s): Fehler! Textmarke nicht definiert.

3250	TwinEnginePhase		<i>Marine operation twin-engine system</i>
	Level:	1	Phase of master / slave operation
	Range:	0...5	
	Page(s):	Fehler! Textmarke nicht definiert.	
3250	LeverSetpoint		<i>Marine operation multi-engine system</i>
	Level:	1	Setpoint after evaluation of directional information
	Range:	0...100 %	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3251	CloseClutchPossible		<i>Marine operation twin-engine system</i>
	Level:	1	0→1: Closing clutch is possible
	Range:	0/1	1→0: Opening clutch is possible
	Page(s):	Fehler! Textmarke nicht definiert.	
3251	SetpointNeutralPos		<i>Marine operation multi-engine system</i>
	Level:	1	0: Throttle lever is not in neutral position
	Range:	0/1	1: Throttle lever is in neutral position
	Page(s):	Fehler! Textmarke nicht definiert.	
3252	PositionerOrGovernor		<i>Marine operation twin-engine system</i>
	Level:	1	0: Speed governor
	Range:	0/1	1: Slave in positioning mode
	Page(s):	Fehler! Textmarke nicht definiert.	
3252	SetpBackwOrForw		<i>Marine operation multi-engine system</i>
	Level:	1	0: Lever in forward direction
	Range:	0/1	1: Lever in reverse direction
	Page(s):	Fehler! Textmarke nicht definiert. if not in neutral position	
3253	MyLoadSetpoint		<i>Marine operation twin-engine system</i>
	Level:	1	Current load setpoint
	Range:	0...100 %	
	Page(s):	Fehler! Textmarke nicht definiert.	
3253	GearShiftingOff		<i>Marine operation multi-engine system</i>
	Level:	1	1: Gear shifting is disabled
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3254	OtherLoadSetpoint		<i>Marine operation twin-engine system</i>
	Level:	1	Load setpoint of other engine
	Range:	0...100 %	
	Page(s):	Fehler! Textmarke nicht definiert.	
3254	SetpointPositionI		<i>Marine operation multi-engine system</i>

Level:	1	Lever in position I (engage forward gear)
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert.	

3255	SlaveFuelSetpoint	<i>Marine operation twin-engine system</i>
Level:	1	Fuel quantity setpoint for slave
Range:	0...100 %	
Page(s):	Fehler! Textmarke nicht definiert.	

3255	SetpointPosition0		<i>Marine operation multi-engine system</i>
	Level:	1	Lever in position 0 (neutral)
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3256	Slave&MasterLimited		<i>Marine operation twin-engine system</i>
	Level:	1	Slave and master are in fuel quantity limitation
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3256	SetpointPositionIII		<i>Marine operation multi-engine system</i>
	Level:	1	Lever in position III (engage reverse gear)
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3257	SetpointCommandActiv		<i>Marine operation multi-engine system</i>
	Level:	1	COMMAND button pressed on this lever
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3258	SetpointSynchroActiv		<i>Marine operation multi-engine system</i>
	Level:	1	SYNCHRO button pressed on this lever
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3259	SetpointActive		<i>Marine operation multi-engine system</i>
	Level:	1	This lever determines setpoint for multiple engines
	Range:	0/1	(active setpoint adjuster)
	Page(s):	Fehler! Textmarke nicht definiert.	
3260ff	CanSetpxSetpoint		<i>Marine operation multi-engine system</i>
	Level:	1	Setpoint of lever x after evaluation of directional
	Range:	0...100 %	information
	Page(s):	Fehler! Textmarke nicht definiert. x = 2..4, see 3250 <i>LeverSetpoint</i>	
3261ff	CanSetpxNeutralPos		<i>Marine operation multi-engine system</i>
	Level:	1	0: Lever x is not in neutral position
	Range:	0/1	1: Lever x is in neutral position
			x = 2..4, see 3251 <i>SetpointNeutralPos</i>
3262ff	CanSetpxBackwOrForw		<i>Marine operation multi-engine system</i>
	Level:	1	0: Lever in forward direction
	Range:	0/1	1: Lever in backward direction
			if not in neutral position, x = 2..4, see 3252
3263ff	CanSetpxGearShiftOff		<i>Marine operation multi-engine system</i>

Level:	1	1: Gear shifting on lever x is disabled
Range:	0/1	x = 2..4, see 3253 <i>GearShiftingOff</i>

3264ff CanSetpxPositionI*Marine operation multi-engine system*

Level:	1	Lever x in position I (engage forward gear)
Range:	0/1	x = 2..4, see 3254 <i>SetpointPositionI</i>

3265ff	CanSetpxPosition0		<i>Marine operation multi-engine system</i>
	Level:	1	Lever x in position 0 (neutral)
	Range:	0/1	x = 2..4, see 3255 <i>SetpointPosition0</i>
3266ff	CanSetpxPositionIII		<i>Marine operation multi-engine system</i>
	Level:	1	Lever x in position III (engage reverse gear)
	Range:	0/1	x = 2..4, see 3256 <i>SetpointPositionIII</i>
3267ff	CanSetpxCommandActiv		<i>Marine operation multi-engine system</i>
	Level:	1	COMMAND button pressed on lever x
	Range:	0/1	x = 2..4, see 3257 <i>SetpointCommandActiv</i>
3268ff	CanSetpxSynchroActiv		<i>Marine operation multi-engine system</i>
	Level:	1	SYNCHRO button pressed on lever x
	Range:	0/1	x = 2..4, see 3258 <i>SetpointSynchroActiv</i>
3269ff	CanSetpxActive		<i>Marine operation multi-engine system</i>
	Level:	1	Lever x determines setpoint for multiple engines (active setpoint adjuster)
	Range:	0/1	x = 2..4, see 3259 <i>SetpointActive</i>
3290	CommonLeverSetpoint		<i>Marine operation multi-engine system</i>
	Level:	1	Resulting setpoint
	Range:	0...100 %	
	Page(s):	Fehler! Textmarke nicht definiert.	
3291	CommandLED		<i>Marine operation multi-engine system</i>
	Level:	1	State of COMMAND-LED on throttle lever
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3292	SynchroLED		<i>Marine operation multi-engine system</i>
	Level:	1	State of SYNCHRO-LED on throttle lever
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3295	ForwardGearValve		<i>Marine operation multi-engine system</i>
	Level:	1	Forward gear
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3296	BackwardGearValve		<i>Marine operation multi-engine system</i>
	Level:	1	Reverse gear
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3300	Velocity		

Level: 1 Travel speed
Range: 0...x km/h x: Depending on application
Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.

3301 Velocity_Value

Level: 1 Unfiltered travel speed
Range: 0...x km/h x: Depending on application
Page(s): Fehler! Textmarke nicht definiert.

3302 VeloGov:FuelLimit
 Level: 1 Speed governor: current fuel quantity limitation
 Range: 0...100 %
 Page(s): **Fehler! Textmarke nicht definiert.**

3350 Notch
 Level: 1 Current speed notch in locomotive operation
 Range: 0...15
 Page(s): **Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.**

3500ff PWMInx
 Level: 1 Current value of PWM input x:
 Range: 0...100 % DC 1-03: 1
 Page(s): **Fehler! Textmarke nicht definiert.** DC 1-04: 1..2
 DC 2: 1..4
 DC 5: 1
 DC 6: 1..3
 DC 7: 1..2
 DC 8: 1..2
 DC 9: 1
 DC 10: 1
 DC 11: 1..3
 DC 12: 1

3501ff FrequencyInx
 Level: 1 Current frequency at PWM input x
 Range: 0...1000 Hz *DC 1, DC 2*
 or 0...500 Hz *DC 5, DC 6, DC 7, DC 8, DC 9, DC 11, DC 12*
 Page(s): **Fehler! Textmarke nicht definiert.** (x: See 3500 *PWMInx*)

**3510ff AnalogInx
TempIny**

Level:	1	Standardised value of analogue input x
Range:	0...100 %	DC 1-03: 1..5
	-100...1000 °C	DC 1-04: 1..8
Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	DC 2: 1..4
		DC 5: 1..6
		DC 6: 1..3
		DC 7: 1..4
		DC 8: 1..6
		DC 9: 1..2
		DC 10: 1..6
		DC 11: 1..5
		DC 12: 1..3

Standardised value of temperature input y:

DC 1:	1..2
DC 2:	1..2
DC 5:	1..4
DC 6:	1
DC 7:	1..3
DC 8:	1..2
DC 10:	1
DC 11:	1
DC 12:	1..2

**3511ff AnalogInx_Value
TempIny_Value**

Level:	1	Raw value of analogue input x
Range:	0...65535	Current range z:
	or 0...5 V	DC 5: 25 mA
	or 0...10 V	Others: 22.7 mA
	or 0...37.2 V	
	or 0...z mA	Raw value of temperature input y
	or 0...65535	Resistance range w:
	or 0...w Ω	DC 10: 65000 Ω
Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 256	Others: 60000 Ω
		(x: See 3510 <i>AnalogInx</i> , y: See 3510 <i>TempIny</i>)

**3600
ff**

These hardware-specific parameters are described in the associated subchapters

3799 CommandWarning

XIOS

Level:	1	Indication that all errors in 3801 <i>CommonAlarm</i> are only warnings
Range:	0/1	
Page(s):	374	

3800 Emergency Alarm

	Level:	1	Display of the emergency alarm
	Range:	0/1	
	Page(s):	175, 178, 232, 374, 378, Fehler! Textmarke nicht definiert.	
3801	CommonAlarm		
	Level:	1	Display of the common alarm
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 374, 376, 378	
3802	EngineStopRequest		
	Level:	1	Indication that the engine is being stopped by an
	Range:	0/1	internal or external engine stop (engine stop request is
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 210, 252	active)
3803	EngineStopped		
	Level:	1	Indication that engine has stopped
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 252	
3804	EngineStarting		
	Level:	1	Indication that engine is being started
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3805	EngineRunning		
	Level:	1	Indication that engine is running
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 175	
3806	EngineReleased		
	Level:	1	Indication that fuel quantity has been released
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3808	EngineStarterActive		<i>DC 5, XIOS</i>

	Level:	1	Version number of the control unit hardware
	Range:	00.00...99.99	
	Page(s):	Fehler! Textmarke nicht definiert.	
3842	SoftwareVersion		
	Level:	1	Version number of software (firmware)
	Range:	00.0.00...64.9.99 or 0000.00.00...6552.99.99 and 6553.00.00...6553.59.99	2 digits customer number, 1 digit variant, 2 digits modification index or
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
		4 digits customer number, 2 digits variant, 2 digits modification index	
3843	BootSoftwareVersion		
	Level:	1	Version number of the boot loader software
	Range:	65.0.00...65.5.35	
	Page(s):	Fehler! Textmarke nicht definiert.	
3844	SerialDate		
	Level:	1	Serial date of the control unit hardware
	Range:	0000...9912	
	Page(s):	Fehler! Textmarke nicht definiert.	
3845	SerialNumber		
	Level:	1	Serial number of the control unit hardware
	Range:	00000...65535	
	Page(s):	Fehler! Textmarke nicht definiert.	
3850	Identifier		
	Level:	1	Current identification number of the PC software (dongle) or hand programmer
	Range:	0...65535	
	Page(s):	Fehler! Textmarke nicht definiert.	
3851	LastIdentifier		
	Level:	1	Identification number of the PC software (dongle) or hand programmer at last save operation
	Range:	0...65535	
	Page(s):	Fehler! Textmarke nicht definiert.	
3857	CompileTime		
	Level:	1	Compilation time of currently loaded firmware
	Range:	00.00...23.59	
	Page(s):	Fehler! Textmarke nicht definiert.	
3858	CompileDate		

	Level:	1	Compilation date of currently loaded firmware:
	Range:	01.01...31.12	Day.Month
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3859	CompileYear		
	Level:	1	Compilation year of currently loaded firmware
	Range:	2000...3000	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3860	Flash250ms		
	Level:	1	4 Hz indicator, can be assigned to a multiple binary
	Range:	0/1	output or a BitCollection
	Page(s):	Fehler! Textmarke nicht definiert.	
3861	Flash500ms		
	Level:	1	2 Hz indicator, can be assigned to a multiple binary
	Range:	0/1	output or a BitCollection
	Page(s):	Fehler! Textmarke nicht definiert.	
3862	Flash1000ms		
	Level:	1	1 Hz indicator, can be assigned to a multiple binary
	Range:	0/1	output or a BitCollection
	Page(s):	Fehler! Textmarke nicht definiert.	
3865	CalculationTime		
	Level:	1	Required processing time for main loop
	Range:	0...15.625 ms	<i>DC 1, DC 2</i>
		or 0...16.384 ms	<i>DC 5, DC 6, DC 7, DC 8, DC 9, DC 10, DC 11, DC 12</i>
		or 0...10 ms	<i>XIOS</i>
	Page(s):	Fehler! Textmarke nicht definiert.	
3870	Timer		
	Level:	1	Internal millisecond timer
	Range:	0...65.535 s	
	Page(s):	Fehler! Textmarke nicht definiert.	
3871	OperatingHourMeter		<i>All except DC 1, DC 2 only on request</i>
	Level:	1	Number of operating hours of running engine
	Range:	0...65535 h	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 380	
3872	OperatingSecondMeter		<i>All except DC 1, DC 2 only on request</i>

	Level:	1	Seconds of running engine to next full operating hour
	Range:	0...3599 s	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 380	
3895	RAMTestAddrHigh		
	Level:	6	Upper value of currently tested RAM address
	Range:	0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert., 422, Fehler! Textmarke nicht definiert.	
3896	RAMTestAddrLow		
	Level:	6	Lower value of currently tested RAM address
	Range:	0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert., 422	
3897ff	StackTestFreeBytes		<i>DC 1, DC 2, XIOS</i>
	C/ISStackTestFreeBytes		<i>DC 5, DC 6, DC 7, DC 8, DC 9, DC 10, DC 11, DC 12</i>
	Level:	6	Indication of free bytes in relevant stack memory
	Range:	0000...FFFF Hex	
	Page(s):	421, Fehler! Textmarke nicht definiert.	
3905	ServoxPIDCorr		
3934	Level:	6	Correction factor for servo loop PID parameters
3944	Range:	0...400 %	x = 1..3
	Page(s):	361	
3913	ServoxCurrentLimit		
3933	Level:	1	Limit for the current through the actuator
3934	Range:	-100...100 %	<i>DC 1, DC 2, XIOS</i>
		or 0...100 %	<i>DC 7, DC 10</i>
		or -8...8 A	<i>DC 8, DC 11, DC 12</i>
		or -12.5...12.5 A	<i>DC 6, DC 9</i>
		or 0...12.5 A	<i>DC 5</i>
	Page(s):	x = 1..3	
3916	ServoxCurrentSetpoint		
3936	Level:	1	Current setpoint for amplifier (current through the actuator)
3946	Range:	-100...100 %	<i>DC 1, DC 2, XIOS</i>
		or 0...100 %	<i>DC 7, DC 10</i>
		or -8...8 A	<i>DC 8, DC 11, DC 12</i>
		or -12.5...12.5 A	<i>DC 6, DC 9</i>
		or 0...12.5 A	<i>DC 5</i>
		or 0...200 mA	<i>DC 6 with 200 mA amplifier</i>
		or 0...1000 mA	<i>DC 8 with 1 A amplifier</i>
	Page(s):	361, 363, 367 x = 1..3	
3917	ServoxCurrentCorr		

3937	Level:	1	Current setpoint corrected by voltage for actuator x
3947	Range:	-100...100 % or 0...100 %	<i>DC 1, DC 2, XIOS</i> <i>DC 7, DC 10</i> x = 1..3
	Page(s):	363	
3918	ServoxCurrentShutOff		
3938	Level:	1	Indication that current shutoff is active
3948	Range:	0/1	x = 1..3
	Page(s):	Fehler! Textmarke nicht definiert.	
3920	ServoCurrLowSidePos		<i>DC 8, DC 11, DC 12</i>
	Level:	1	Current amplifier current LowSide positive
	Range:	-8.000...+8.000 V	
	Page(s):	362	
3921	ServoCurrLowSideNeg		<i>DC 8, DC 11, DC 12</i>
	Level:	1	Current amplifier current LowSide negative
	Range:	-8.000...+8.000 V	
	Page(s):	362	

3922	ServoCurrHighSide		<i>DC 8, DC 11, DC 12</i>
	Level:	1	Current amplifier current HighSide
	Range:	-8.000...+8.000 V	
	Page(s):	362	
3950	Feedbackx		
3960	Level:	1	Raw value of feedback for actuator x
3970	Range:	0...65535	x = 1..3
	Page(s):	353	
3951	FeedbackCorrection		<i>DC 2, DC 5, DC 6, DC 7, DC 9, DC 10, DC 12</i>
	Level:	1	Digital feedback value corrected by reference
	Range:	0...65535	
	Page(s):	353	
3955	FeedbackReference		<i>DC 2, DC 5, DC 6, DC 7, DC 9, DC 10, DC 12</i>
	Level:	1	Raw value for reference coil for digital feedback
	Range:	0...65535	
	Page(s):	353	
12000			<i>Dual fuel parameters are described in the subchapter</i>
ff			
12570	ExhaustTempAverage		<i>XIOS</i>
	Level:	1	Average value of exhaust temperatures
	Range:	-100...+1000 °C	Others see 2913
	Page(s):	187, 237	
12572	ExhaustTempMin		<i>XIOS</i>
	Level:	1	Minimum exhaust temperature value
	Range:	-100...+1000 °C	Otherwise see 2912
	Page(s):	187, 237	
12573	ExhaustTempMax		<i>XIOS</i>
	Level:	1	Maximum exhaust temperature value
	Range:	-100...+1000 °C	Otherwise see 2911
	Page(s):	97, 187, 229, 237, 237	
12900	ExhaustTempCylx		<i>XIOS</i>
ff	Level:	1	Current value from exhaust temperature sensors
	Range:	-100...+1000 °C	x = 1..24
	Page(s):	236	
13033	ErrSNSNOx		<i>XIOS</i>
	Level:	1	Extended error indication for NO _x sensor
	Range:	0000...FFFF Hex	
	Page(s):	427	
13034	ErrSNSO2		<i>XIOS</i>
	Level:	1	Extended error indication for O ₂ sensor
	Range:	0000...FFFF Hex	
	Page(s):	427	
13039	ErrExhaustTempMax		<i>XIOS</i>
	Level:	1	Error indication for maximum exhaust temperature
	Range:	0000...FFFF Hex	
	Page(s):	427	

13040	ErrExhaustTempCylx		<i>XIOS</i>
ff	Level:	1	Error indication for exhaust temperature x
	Range:	0000...FFFF Hex	x = 1...24
	Page(s):	411	
13064	ErrAirMass		<i>XIOS</i>
	Level:	1	Error indication for air mass sensor
	Range:	0000...FFFF Hex	
	Page(s):	411	
13065	ErrAlternatorVoltage		<i>XIOS</i>
	Level:	1	Error indication for alternator voltage
	Range:	0000...FFFF Hex	
	Page(s):	Fehler! Textmarke nicht definiert., 411	
13066	ErrBoostPressure2		<i>XIOS</i>
	Level:	1	Error indication for second boost pressure sensor
	Range:	0000...FFFF Hex	
	Page(s):	411	
13067	ErrLambda1		<i>XIOS</i>
	Level:	1	Error indication for lambda sensor 1
	Range:	0000...FFFF Hex	
	Page(s):	411	
13068	ErrLambda2		<i>XIOS</i>
	Level:	1	Error indication for lambda sensor 2
	Range:	0000...FFFF Hex	
	Page(s):	411	
13069	ErrNOx		<i>XIOS</i>
	Level:	1	Error indication for nitrogen oxide sensor
	Range:	0000...FFFF Hex	
	Page(s):	411	
13070	ErrO2		<i>XIOS</i>
	Level:	1	Error indication for oxygen content measurement
	Range:	0000...FFFF Hex	
	Page(s):	411	
13400	Out1:Value		<i>DC 8, DC 11, DC 12, XIOS</i>
ff	Outx:Value		
	Level:	1	Indication of current output value for Out x in
	Range:	0...100.0 %	percentage of output parameter
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	x = 1..120 or lower, application-specific, by default total of outputs on own hardware and all connected communication modules
13520	DOColl_1		<i>DC 8, DC 11, DC 12, XIOS</i>
ff	DOColl_x		
	Level:	1	Indication of current value for DO collection x
	Range:	0/1	x = 1..25 or lower, application-specific
	Page(s):	Fehler! Textmarke nicht definiert.	

23000	ErrCANopen		<i>CANopen, XIOS</i>
	Level:	1	CANopen error status
	Range:	0...FFFF Hex	
23001	ErrModbus		<i>Modbus, XIOS</i>
	Level:	1	Modbus error status
	Range:	0...FFFF Hex	
23002	ErrCanPEX		<i>XIOS</i>
23020	Level:	1	HZM-CAN periphery module error status
ff	Range:	0...FFFF Hex	23002 ff with up to three periphery modules
	Page(s):	Fehler! Textmarke nicht definiert.	23020 ff with more than 3 periphery modules
23005	ErrSAEJ1939		<i>SAE J1939, XIOS</i>
	Level:	1	SAE J1939 error status
	Range:	0...FFFF Hex	
23006	ErrCanACx		<i>XIOS</i>
ff	Level:	1	HZM-CAN add-on module error status
	Range:	0...FFFF Hex	x = 1..5
	Page(s):	Fehler! Textmarke nicht definiert.	
23013	ErrWagoCan		<i>WAGO, XIOS</i>
	Level:	1	Wago error status
	Range:	0...FFFF Hex	
23013	ErrWagoCanComm		<i>WAGO, not XIOS</i>
	Level:	1	Error indication for WAGO-CAN communication, if
	Range:	0/1	HZM-CAN is running on same bus (otherwise 3071)
			<i>XIOS see 23013</i>
23014	ErrCANopenComm		<i>CANopen, not XIOS</i>
	Level:	1	Error indication for CANopen communication, if HZM-
	Range:	0/1	CAN is running on same bus (otherwise 3071)
			<i>XIOS see 23000</i>
23015	ErrIceniCan		<i>ICENI, XIOS</i>
	Level:	1	ICENI error status
	Range:	0...FFFF Hex	
23015	ErrIceniCanComm		<i>ICENI, not XIOS</i>
	Level:	1	Error indication for ICENI-CAN communication if
	Range:	0/1	HZM-CAN is running on the same bus (otherwise
			3071)
23680	ErrorState(x)		<i>XIOS</i>
ff			<i>DeviceNet, Manual DG 06 003-e</i>
			<i>Modbus, Manual DG 05 002-e</i>

Level:	1	Summary of error structures (1 bit per structure) from
Range:	0...FFFF Hex	3001 to 3099, 13000 to 13099, 23000 to 23099,
Page(s):	345	33000..33099, 43000..43099 and 53000..53011 for transmission via DeviceNet or Modbus x = 0..31 (max.) Bit 0 of index 0 is always 0 Error 3001 appears at bit 1 of index 0
23700	ErrorState(x)	<i>All except XIOS</i>
ff		<i>DeviceNet, Manual DG 06 003-e</i> <i>Modbus, Manual DG 05 002-e</i>
Level:	1	Summary of error bits from 3001 to 3094, 13000 to
Range:	0...FFFF Hex	13094, 23000 to 23094 for transmission via DeviceNet
Page(s):	345	or Modbus x = 0..17 (max.) Bit 0 of Index 0 is always 0 Error 3001 appears at bit 1 of index 0
23720	BitCollection(x)	<i>HZM CAN Customer Module, Manual DG 05007-e</i>
ff		<i>CANopen, Manual DG 06 002-e</i> <i>DeviceNet, Manual DG 06 003-e</i> <i>Modbus, Manual DG 05 002-e</i>
Level:	1	Collection of bit states based on definition starting at
Range:	0...FFFF Hex	29900 <i>BitCollParamSet(x)</i>
Page(s):	344	<i>x = 0..1</i>

Tab. 173: Measured values and display values

28.2.1 DC 1

Here, measured values and display values are described which are only available in DC 1 type control units due to the special hardware requirements.

No.	Name	Meaning
2800	RotarySwitch	
Level:	1	Indication of current value of rotary switch on PCB
Range:	0...15	
Page(s):	Fehler! Textmarke nicht definiert.	
3085	ErrPowerSupply	
Level:	1	Error indication for voltage supply
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 376, Fehler! Textmarke nicht definiert.	
3086	ErrPowerSupplyExt	<i>DC 1-04</i>

Level: 1 Error indication for voltage supply to additional PCB
Range: 0/1
Page(s): Fehler! Textmarke nicht definiert., 376, Fehler! Textmarke nicht definiert.

3087 ErrCPU2

Level: 1 Error indication for CPU 2
Range: 0/1
Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.

3091 ErrLogical

Level: 1 Error indication for data set structure
Range: 0/1
Page(s): Fehler! Textmarke nicht definiert., 376, Fehler! Textmarke nicht definiert.

3600	PowerSupply		
	Level:	1	Current value of filtered supply voltage
	Range:	0...50 V	
	Page(s):	Fehler! Textmarke nicht definiert., 363	
3601	PowerSupplyExt		<i>DC 1-04</i>
	Level:	1	Current value of filtered supply voltage for additional
	Range:	0..50 V	PCB
	Page(s):	Fehler! Textmarke nicht definiert., 363	
3821	LED_CPU		
	Level:	1	Indication that main processor is working
	Range:	0/1	
	Page(s):	376	
3822	LED_SpeedPickup1Off		
	Level:	1	Indication that no pulses are coming from speed pickup
	Range:	0/1	1
	Page(s):	376	
3823	LED_SpeedPickup2Off		
	Level:	1	Indication that no pulses are coming from speed pickup
	Range:	0/1	2
	Page(s):	376	
3824	LED_ActuatorError		
	Level:	1	Indication of actuator error
	Range:	0/1	
	Page(s):	376	
3825	LED_PowerSupply		
	Level:	1	Indication of error in supply voltage
	Range:	0/1	
	Page(s):	376	
3826	LED_CommonAlarm		
	Level:	1	Indication that at least 1 error is present
	Range:	0/1	
	Page(s):	376	
3827	LED_BoostLimit		
	Level:	1	Indication that fuel quantity is limited by boost pressure
	Range:	0/1	dependent fuel quantity limitation
	Page(s):	376	
3828	LED_FuelLimitMax		
	Level:	1	Indication that fuel quantity is limited by speed-
	Range:	0/1	dependent fuel quantity limitation
	Page(s):	377	
3829	LED_FuelLimitMin		
	Level:	1	Indication that fuel quantity setpoint = 0 %
	Range:	0/1	
	Page(s):	377	

Tab. 174: DC 1 measured values and display values

28.2.2 DC 2

Here, measured values and display values are described which are only available in DC 2 type control units due to the special hardware requirements.

No.	Name	Meaning
3061ff	ErrDigiIOx	
	Level:	1 Error indication at port DigiIO x
	Range:	0/1 x = 1..4
	Page(s):	Fehler! Textmarke nicht definiert.
3065	ErrISOCCommLine	
	Level:	1 Error indication for interface connection
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert.
3085	ErrPowerSupply	
	Level:	1 Error indication for voltage supply
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 376, Fehler! Textmarke nicht definiert.
3091	ErrLogical	
	Level:	1 Error indication for data set structure
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert., 376, Fehler! Textmarke nicht definiert.
3600	PowerSupply	
	Level:	1 Current value of filtered supply voltage
	Range:	0... 83.6 V
	Page(s):	Fehler! Textmarke nicht definiert., 363
3821	LED_CPU	
	Level:	1 Indication that main processor is working
	Range:	0/1
	Page(s):	377
3822	LED_SpeedPickup1Off	
	Level:	1 Indication that no pulses are detected at speed pickup 1
	Range:	0/1
	Page(s):	377
3823	LED_SpeedPickup2Off	
	Level:	1 Indication that no pulses are detected at speed pickup 2
	Range:	0/1
	Page(s):	377
3824	LED_ActuatorError	

Level:	1	Indication of actuator error
Range:	0/1	
Page(s):	377	

3825 LED_CommonAlarm

Level:	1	Indication that at least 1 error is present
Range:	0/1	
Page(s):	377	

Tab. 175: DC 2 measured values and display values**28.2.3 DC 5**

Here, measured values and display values are described which are only available in DC 5 type control units due to the special hardware requirements.

No.	Name	Meaning
3079	ErrDigitalOut	
	Level:	1 Error indication for binary outputs
	Range:	0/1 See 3631 <i>DigitalOutx:ErrType</i> for detailed error indication
	Page(s):	Fehler! Textmarke nicht definiert.
3080	ErrPowerSupply	
	Level:	1 Error indication for voltage supply
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert.
3081	ErrSupply7.5V	
	Level:	1 Error indication for 7.5 V rail
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert.
3082	ErrPowerSupplyEDCFb	
	Level:	1 Error indication for EDC feedback voltage supply
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert.
3083ff	Err5VSensorSupplyx	
	Level:	1 Error indication for sensor supply voltages
	Range:	0/1 x = 1..4
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.
3087ff	ErrInternTempx	
	Level:	1 Error indication for internal temperature x
	Range:	0/1 x = 1..2
	Page(s):	Fehler! Textmarke nicht definiert.
3600	PowerSupply	

	Level:	1	Current value of filtered supply voltage
	Range:	0...55 V	
	Page(s):	Fehler! Textmarke nicht definiert.	
3601	Supply7.5V		
	Level:	1	Current value of 7.5 V voltage
	Range:	0...10 V	
	Page(s):	Fehler! Textmarke nicht definiert.	
3602	PowerSupplyEDCFeedb		
	Level:	1	Current value of amplifier supply voltage
	Range:	0...10 V	
	Page(s):	Fehler! Textmarke nicht definiert.	
3603ff	5VSensorSupplyx		
	Level:	1	Current value of sensor reference voltages
	Range:	0...7.35 V	x = 1..4
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3607ff	InternTempInx		
	Level:	1	Current value of internal temperature x
	Range:	-50 ... 150 °C	x = 1..2
	Page(s):	Fehler! Textmarke nicht definiert.	
3611ff	DigitalOutx:Feedback		
	Level:	1	Current value of feedback for binary output x
	Range:	0/1	x = 1..11
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3622	DiagnosePort:Feedbck		
	Level:	1	Current value of feedback for diagnostic port
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3631ff	DigitalOutx:ErrType		
	Level:	1	Error type at binary output x
	Range:	0...FF	x = 1..11
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3642	DiagnosePort:ErrType		

Level: 1 Error type at diagnostic port
Range: 0...FF
Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.

Tab. 176: DC 5 measured values and display values

28.2.4 DC 6

Here, measured values and display values are described which are only available in DC 6 type control units due to the special hardware requirements.

No.	Name	Meaning
3064	ErrAmplCurrent	<i>With 200 mA amplifier</i>
	Level:	1 Error indication for amplifier current
	Range:	0/1
	Page(s): 367, Fehler! Textmarke nicht definiert.	
3066	ErrAmplTempWarn	<i>With 200 mA amplifier</i>
	Level:	1 Error indication for amplifier temperature, warning
	Range:	0/1 level exceeded
	Page(s): 368, Fehler! Textmarke nicht definiert.	
3067	ErrAmplTemp	<i>With 200 mA amplifier</i>
	Level:	1 Error indication for amplifier temperature
	Range:	0/1
	Page(s): 368, Fehler! Textmarke nicht definiert.	
3068	ErrAmplSupply	<i>With 200 mA amplifier</i>
	Level:	1 Error indication for amplifier supply voltage
	Range:	0/1
	Page(s): 368, Fehler! Textmarke nicht definiert.	
3069	ErrInt13V	<i>With 200 mA amplifier</i>
	Level:	1 Error indication for 13V rail
	Range:	0/1
	Page(s): 368, Fehler! Textmarke nicht definiert.	
3085	ErrPowerSupply	
	Level:	1 Error indication for voltage supply
	Range:	0/1
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 376, Fehler! Textmarke nicht definiert.	
3081	Err5VSensorSupply	
	Level:	1 Error indication for 5V sensor supply voltage
	Range:	0/1
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3600	PowerSupply	

	Level:	1	Current value of filtered supply voltage
	Range:	0...55 V	
	Page(s):	Fehler! Textmarke nicht definiert.	
3601	AmplifierTemp		<i>With 200 mA amplifier</i>
	Level:	1	Current amplifier temperature value
	Range:	-100...1000 °C	
	Page(s):	368, Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3602	AmplifierSupply		<i>With 200 mA amplifier</i>
	Level:	1	Current amplifier supply voltage value
	Range:	0..75 V	
	Page(s):	368	

3604	Int13V		<i>With 200 mA amplifier</i>
	Level:	1	Current value of 13 V bar
	Range:	0..75 V	
	Page(s):	368	
3605	AmplifierVoltage		<i>With 200 mA amplifier</i>
	Level:	1	Amplifier voltage back measurement
	Range:	0..75 V	
	Page(s):	368	
3920	ServoCurrHighSide		<i>With 200 mA amplifier</i>
	Level:	1	HighSide current
	Range:	0...200 mA	
	Page(s):	367	
3921	ServoCurrLowSide		<i>With 200 mA amplifier</i>
	Level:	1	LowSide current
	Range:	0...200 mA	
	Page(s):	367	

Tab. 177: DC 6 measured values and display values

28.2.5 DC 7

Here, measured values and display values are described which are only available in DC 7 type control units due to the special hardware requirements.

No.	Name	Meaning
2861	StatusDigitalOutx	
	Level:	6 Status of binary outputs
	Range:	0...4000 rpm x = 1..7
	Page(s):	Fehler! Textmarke nicht definiert.
3079	ErrInternTemp	
	Level:	1 Error indication for internal temperature
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert.
3080	Err5VSensorSupplyx	
	Level:	1 Error indication for sensor supply voltage x
	Range:	0/1 x = 1, 2, 4
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.
3085	ErrPowerSupply	

Level: 1 Error indication for voltage supply

Range: 0/1

Page(s):**Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 376, Fehler! Textmarke nicht definiert.**

3083 ErrInternSupply_7V

Level: 1 Error indication for 7V rail

Range: 0/1

Page(s):**Fehler! Textmarke nicht definiert.**

3512ff	5VSensorSupplyx	Level: 1	Current sensor supply voltage value
		Range: 0...10.000 V	x = 1, 2, 4
		Page(s): Fehler! Textmarke nicht definiert.	
3600	PowerSupply	Level: 1	Current value of filtered supply voltage
		Range: 0...55 V	
		Page(s): Fehler! Textmarke nicht definiert., 363	
3601	InternTempIn	Level: 1	Current value of the internal temperature
		Range: -100...+1000 °C	
		Page(s): Fehler! Textmarke nicht definiert.	
3603	Reference7V	Level: 1	Current value of 7V bar
		Range: 0...10.000 V	
		Page(s): Fehler! Textmarke nicht definiert.	

Tab. 178: DC 7 measured values and display values

28.2.6 DC 8

Here, measured values and display values are described which are only available in DC 8 type control units due to the special hardware requirements.

No.	Name	Meaning	
2858	LED_PowerSupply	Level: 1	Voltage supply
		Range: 0/1	Flashing: one of the voltage supplies is interrupted
		Page(s): 377	
2859	LED_SpeedPickUp1	Level: 1	Indication that pulses are detected at speed pickup 1
		Range: 0/1	
		Page(s): 377	
2860	LED_SpeedPickUp2	Level: 1	Indication that pulses are detected at speed pickup 2
		Range: 0/1	
		Page(s): 377	
2861	LED_OverTemp		

Level:	1	Indication of excess temperature (PCB temperature)
Range:	0/1	
Page(s):	378	

2862	LED_Feedback		
	Level:	1	Actuator error
	Range:	0/1	Off: No error
	Page(s):	378	Flashing: Setpoint and actual value differ Lit: Feedback error
2863	LED_Alarm		
	Level:	1	Indication that there is at least one error
	Range:	0/1	Flashing: CommonAlarm
	Page(s):	378	Lit: Fatal error
3064	ErrAmplCurrent		<i>With 1 A amplifier</i>
	Level:	1	Error indication for amplifier current
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3069	ErrInternalBus1		
	Level:	1	Error indication for UART interface
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3081	Err5VSensorSupply		
	Level:	1	Error indication for 5 V sensor supply
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3082	ErrInternVoltage		
	Level:	1	Error indication for internal voltages
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3083	ErrUZKVoltage		
	Level:	1	Error indication for intermediate circuit voltage
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3085	ErrPowerSupply1		
	Level:	1	Error indication for 1st voltage supply
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3086	ErrPowerSupply2		

Level: 1 Error indication for 2nd voltage supply

Range: 0/1

Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.

3087 ErrInternTemp

Level: 1 Error indication for PCB temperature

Range: 0/1

Page(s): Fehler! Textmarke nicht definiert.

3088 Err24VSensorSupply

Level: 1 Error indication for 24 V sensor supply

Range: 0/1

Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.

3600	PowerSupply_1	Level: 1	Current value of filtered supply voltage
		Range: 0..75 V	
		Page(s): Fehler! Textmarke nicht definiert.	
3601	PowerSupply_2	Level: 1	Current value of filtered 2nd supply voltage
		Range: 0..75 V	
		Page(s): Fehler! Textmarke nicht definiert.	
3602	UZK_In	Level: 1	Intermediate circuit voltage
		Range: 0/1	
		Page(s): Fehler! Textmarke nicht definiert.	
3603	Int24V	Level: 1	24 V rail
		Range: 0/1	
		Page(s): Fehler! Textmarke nicht definiert.	
3604	Int12V	Level: 1	12 V rail
		Range: 0/1	
		Page(s): Fehler! Textmarke nicht definiert.	
3605	Int5V	Level: 1	5 V rail
		Range: 0/1	
		Page(s): Fehler! Textmarke nicht definiert.	
3606	Int3.3V	Level: 1	3.3 V rail
		Range: 0/1	
		Page(s): Fehler! Textmarke nicht definiert.	
3607	5VSensorSupply	Level: 1	5 V sensor supply voltage
		Range: 0/1	
		Page(s): Fehler! Textmarke nicht definiert.	
3608	24VSensorSupply1	Level: 1	24 V sensor supply voltage 1
		Range: 0/1	
		Page(s): Fehler! Textmarke nicht definiert.	
3609	24VSensorSupply2		

Level: 1 24 V sensor supply voltage 2
Range: 0/1
Page(s): Fehler! Textmarke nicht definiert.

3612 Int2.5V

Level: 1 2.5 V rail
Range: 0/1
Page(s): Fehler! Textmarke nicht definiert.

3613	PCB Temperature		
	Level:	1	PBC temperature
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
3920	ReadBackAmpl1000		<i>DC 8 with 1 A amplifier</i>
	Level:	1	Current amplifier current bach measurement
	Range:	-8.000 ... +8.000 V	
	Page(s):	538	

Tab. 179: DC 8 measured values and display values

28.2.7 DC 9

Here, measured values and display values are described which are only available in DC 9 type control units due to the special hardware requirements.

No.	Name		Meaning
3081	Err5VSensorSupply		
	Level:	1	Error indication for 5 V sensor supply
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
3085	ErrPowerSupply		
	Level:	1	Error indication for voltage supply
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 376, Fehler! Textmarke nicht definiert.	
3600	PowerSupply		
	Level:	1	Current value of filtered supply voltage
	Range:	0...55 V	
	Page(s):	Fehler! Textmarke nicht definiert.	
3603	5VSensorSupply		
	Level:	1	Current value of sensor supply voltage
	Range:	0...10 V	
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	

Tab. 180: DC 9 measured values and display values

28.2.8 DC 10

Here, measured values and display values are described which are only available in DC 10 type control units due to the special hardware requirements.

No.	Name	Meaning
3061	ErrOverCurLowSide	
	Level:	1 Error indication for amplifier
	Range:	0/1 Hardware detects low side overcurrent
	Page(s):	Fehler! Textmarke nicht definiert.
3062	ErrOverCurHighSide	
	Level:	1 Error indication for amplifier
	Range:	0/1 Hardware detects high side overcurrent
	Page(s):	Fehler! Textmarke nicht definiert.
3081	Err5VSensorSupply	
	Level:	1 Error indication for sensor supply voltage
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert.
3082	ErrInternalTemp	
	Level:	1 Error indication for internal temperature
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert.
3084	ErrLowSideCurrent	
	Level:	1 Error indication for amplifier
	Range:	0/1 Software detects low side overcurrent
	Page(s):	364, Fehler! Textmarke nicht definiert.
3085	ErrPowerSupply	
	Level:	1 Error indication for voltage supply
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 376, Fehler! Textmarke nicht definiert.
3086	ErrDOShortToGnd	
	Level:	1 Binary output error indication
	Range:	0/1 Short circuit to ground
	Page(s):	Fehler! Textmarke nicht definiert.
3087	ErrDOShortToPower	

Level: 1 Binary output error indication
Range: 0/1 Short circuit to battery positive
Page(s): **Fehler! Textmarke nicht definiert.**

3600 PowerSupply

Level: 1 Current value of filtered supply voltage
Range: 0...55 V
Page(s): **Fehler! Textmarke nicht definiert.**

3601 InternalTemp

Level: 1 Current value of the internal temperature
Range: -50...150 °C
Page(s): **Fehler! Textmarke nicht definiert.**

3603	5VSensorSupply	Level: 1 Range: 0...10.000 V Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Current sensor supply voltage value
3609	ServoCurrentLowSide	Level: 1 Range: 0...8.000 A Page(s): 362	Current amplifier current value (low side)
3615	DigitalOut_Feedback	Level: 1 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	Current value of feedback for binary output
3833	TempInAvailable	Level: 1 Range: 0/1 Page(s):	1: Hardware contains temperature input
3834	CanBusAvailable	Level: 1 Range: 0/1 Page(s):	1: Hardware contains CAN controller
3835	ActuatorAvailable	Level: 1 Range: 0/1 Page(s):	1: Hardware controls actuator
3836	FeedbDigitalOrAnalog	Level: 1 Range: 0/1 Page(s):	0: Analogue actuator feedback 1: Digital actuator feedback
3837	LedAvailable	Level: 1 Range: 0/1 Page(s):	1: Hardware controls status LED
3838	Port5Pull-upAvailable	Level: 1 Range: 0/1 Page(s):	1: Pull-up resistance at port 5 can be connected using 4808 <i>Port5_Pull-up5VOn</i>
3839	Port6Available	Level: 1 Range: 0/1 Page(s):	1: Multi-function port 6 can be used as analogue input, digital input or pickup 1

Tab. 181: DC 10 measured values and display values

28.2.9 DC 11

Here, measured values and display values are described which are only available in DC 11 type control units due to the special hardware requirements.

No.	Name	Meaning
3058	ErrFeedbackVoltRef	
	Level:	1 Error indication for analogue feedback
	Range:	0/1
	Page(s):	
3061	ErrAmplLowSideNeg	
	Level:	1 Error indication for amplifier
	Range:	0/1 LowSide negative overcurrent
	Page(s):	Fehler! Textmarke nicht definiert.
3062	ErrAmplLowSidePos	
	Level:	1 Error indication for amplifier
	Range:	0/1 LowSide positive overcurrent
	Page(s):	Fehler! Textmarke nicht definiert.
3063	ErrAmplHighSide	
	Level:	1 Error indication for amplifier
	Range:	0/1 HighSide overcurrent
	Page(s):	Fehler! Textmarke nicht definiert.
3064	ErrAmplSupply	
	Level:	1 Error indication for amplifier
	Range:	0/1 Internal supply voltage too high
	Page(s):	Fehler! Textmarke nicht definiert.
3079	ErrInternalTemp	
	Level:	1 Error indication for internal temperature
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert.
3080	ErrInternSupply2.5V	
	Level:	1 Error indication for internal 2.5 V voltage
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert.
3081ff	Err5VSensorSupplyx	
	Level:	1 Error indication for 5 V reference voltages
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert.
3083	ErrInternSupply3.3V	

No.	Name	Meaning
	Level: 1 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	Error indication for internal 3.3 V voltage
3084	ErrInternSupply14V Level: 1 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	Error indication for internal 14 V voltage
3085	ErrPowerSupply Level: 1 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 376, Fehler! Textmarke nicht definiert.	Error indication for voltage supply
3086	ErrErrorOutVoltage Level: 1 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	Error indication for error output
3512ff	5VSensorSupplyx Level: 1 Range: 0...10.000 V Page(s): Fehler! Textmarke nicht definiert.	Current value of 5 V reference for analogue inputs 1...3 and the temperature input
3600	PowerSupply Level: 1 Range: 0...55 V Page(s): Fehler! Textmarke nicht definiert.	Current value of filtered supply voltage
3601	InternTempIn Level: 1 Range: -100.0...+1000.0 °C Page(s): Fehler! Textmarke nicht definiert.	Current value of filtered internal temperature measurement
3602	AmplifierSupply Level: 1 Range: 0...55.000 V Page(s): Fehler! Textmarke nicht definiert.	Current amplifier voltage value
3603	FeedbackSupply Level: 1 Range: 0...30.000 V Page(s): Fehler! Textmarke nicht definiert.	Current feedback voltage value

No.	Name	Meaning
3604	ErrorOutVoltage Level: 1 Range: 0...30.000 V Page(s): Fehler! Textmarke nicht definiert.	Current value of voltage at error output
3605	Reference14V Level: 1 Range: 0...30.000 V Page(s): Fehler! Textmarke nicht definiert.	Current value of internal 14 V voltage
3606	Reference2.5V Level: 1 Range: 0...5.000 V Page(s): Fehler! Textmarke nicht definiert.	Current value of internal 2.5 V voltage
3607	Reference3.3V Level: 1 Range: 0...5.000 V Page(s): Fehler! Textmarke nicht definiert.	Current value of internal 3.3 V voltage

No.	Name	Meaning
3608	InternTempIn_Value	
	Level:	1 Current resistance value for internal temperature
	Range:	0...60000 Ω measurement
	Page(s): Fehler! Textmarke nicht definiert.	

Tab. 182: DC 11 measured values and display values

28.2.10 DC 12

Here, measured values and display values are described which are only available in DC 12 type control units due to the special hardware requirements.

No.	Name	Meaning
3061	ErrAmplLowSideNeg	
	Level:	1 Error indication for amplifier
	Range:	0/1 LowSide negative overcurrent
	Page(s): Fehler! Textmarke nicht definiert.	
3062	ErrAmplLowSidePos	
	Level:	1 Error indication for amplifier
	Range:	0/1 LowSide positive overcurrent
	Page(s): Fehler! Textmarke nicht definiert.	
3063	ErrAmplHighSide	
	Level:	1 Error indication for amplifier
	Range:	0/1 HighSide overcurrent
	Page(s): Fehler! Textmarke nicht definiert.	
3064	ErrDigitalOut	
	Level:	1 Error indication for binary output
	Range:	0/1
	Page(s): Fehler! Textmarke nicht definiert.	
3079	ErrInternTemp	
	Level:	1 Error indication for internal temperature
	Range:	0/1
	Page(s): Fehler! Textmarke nicht definiert.	
3080	ErrInternSupply2.5V	
	Level:	1 Error indication for internal 2.5 V voltage
	Range:	0/1 not within [2, 3] V
	Page(s): Fehler! Textmarke nicht definiert.	

No.	Name	Meaning
3081	Err5VSensorSupply	
	Level:	1 Error indication for 5 V reference voltage
	Range:	0/1 not within [4.5, 5.5] V
	Page(s): Fehler! Textmarke nicht definiert.	

No.	Name	Meaning
3082	ErrInternSupply14V	
	Level:	1 Error indication for internal 14 V voltage
	Range:	0/1 not within [10, 16] V
	Page(s):	Fehler! Textmarke nicht definiert.
3085	ErrPowerSupply	
	Level:	1 Error indication for voltage supply
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 376, Fehler! Textmarke nicht definiert.
3600	PowerSupply	
	Level:	1 Current value of filtered supply voltage
	Range:	0...55 V
	Page(s):	Fehler! Textmarke nicht definiert.
3601	InternalTempIn	
	Level:	1 Current value for internal temperature measurement
	Range:	-100.0...+1000.0 °C
	Page(s):	Fehler! Textmarke nicht definiert.
3603	5VSensorSupply	
	Level:	1 Current value of 5V reference for temperature inputs
	Range:	0...10.000 V
	Page(s):	Fehler! Textmarke nicht definiert.
3605	Int14V	
	Level:	1 Current value of internal 14 V voltage
	Range:	0...30.000 V
	Page(s):	Fehler! Textmarke nicht definiert.
3606	Int2.5V	
	Level:	1 Current value of internal 2.5 V voltage
	Range:	0...5.000 V
	Page(s):	Fehler! Textmarke nicht definiert.

Tab. 183: DC 12 measured values and display values

28.2.11 XIOS

Here, measured values and display values are described which are only available in type XIOS control units due to the special hardware requirements.

No.	Name	Meaning
3079	ErrInternTemp	
	Level:	1 Error indication for internal temperature
	Range:	0000...FFFF Hex
	Page(s):	

3080	ErrEthernetA	Level: 1	Error indication at Ethernet node A
		Range: 0000...FFFF Hex	
		Page(s):	
3081	ErrEthernetAComm	Level: 1	Error indication for communication at Ethernet node A
		Range: 0000...FFFF Hex	
		Page(s):	
3082	ErrEthernetB	Level: 1	Error indication at Ethernet node B
		Range: 0000...FFFF Hex	
		Page(s):	
3083	ErrEthernetBComm	Level: 1	Error indication for communication at Ethernet node B
		Range: 0000...FFFF Hex	
		Page(s):	
3085	ErrPowerSupply	Level: 1	Error indication for voltage supply
		Range: 0...FFFF Hex	
		Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 417	
3087	ErrEEPROM	Level: 1	Indication of incorrect E ² PROM pages
		Range: 0000...FFFF Hex	
		Page(s):	
3088	ErrFilesys	Level: 1	File system error indication
		Range: 0000...FFFF Hex	
		Page(s):	
3089	ErrUSBHost	Level: 1	USB host error indication
		Range: 0000...FFFF Hex	
		Page(s):	
3090	ErrFPGA	Level: 1	FPGA error indication
		Range: 0000...FFFF Hex	
		Page(s):	
3199	SMXError	Level: 1	Operating system error indication
		Range: 0000...FFFF Hex	
		Page(s):	
3600	PowerSupply		

Level: 1 Current value of filtered supply voltage
Range: 0...50.50 V
Page(s):

3601	InternTemperature	Level: 1	Current value of the internal temperature
		Range: -100...1000 °C	
		Page(s):	
3602	BoardVoltage3.3V	Level: 1	Current value of 3.3 V bar
		Range: 0...5.00 V	
		Page(s):	
3603	BoardVoltage5V	Level: 1	Current value of 5 V bar
		Range: 0...10.00 V	
		Page(s):	
3604	BoardVoltage1.5V	Level: 1	Current value of 1.5 V bar
		Range: 0...2.50 V	
		Page(s):	
3605	BoardVoltage12V	Level: 1	Current value of 12 V bar
		Range: 0...20.16	
		Page(s):	
3606	BoardVoltage5V_REF	Level: 1	Current value of 5V reference voltage
		Range: 0...6.25V	
		Page(s):	
3607	BoardVoltageVBAT	Level: 1	Current value of the supply voltage
		Range: 0...36.00V	
		Page(s):	
3608	BoardCurrentSupply	Level: 1	Current total current value
		Range: 0...32.50A	
		Page(s):	
3609	BoardMessVBAT	Level: 1	Current value for supply voltage at terminal
		Range: 0...50.50V	
		Page(s):	
3610	BoardMessVBAT_P	Level: 1	Current value for power supply at terminal
		Range: 0...50.50V	
		Page(s):	
3611	SensorSupplyStgA	Level: 1	Current sensor supply value for actuator at slot 1
		Range: 0...10.00V	
		Page(s):	

3612	SensorSupplyStgB	Level: 1	Current sensor supply value for actuator at slot 2
		Range: 0...10.00V	
		Page(s):	
3613	SensorSupplyStgC	Level: 1	Current sensor supply value for actuator at slot 5
		Range: 0...10.00V	
		Page(s):	
3614	SensorSupply_+12V_L	Level: 1	Current voltage value at sensor supply 12V L
		Range: 0...20.16V	
		Page(s):	
3615	SensorSupply_+5V_L	Level: 1	Current voltage value at sensor supply 5V L
		Range: 0...20.16V	
		Page(s):	
3616	SensorSupply_12V_R	Level: 1	Current voltage value at sensor supply 12V R
		Range: 0...20.16V	
		Page(s):	
3617	SensorSupply_5V_R	Level: 1	Current voltage value at sensor supply 5V R
		Range: 0...20.16V	
		Page(s):	
3618	SensorSupply_HIA1	Level: 1	Current voltage value at sensor supply HIA1
		Range: 0...20.16V	
		Page(s):	
3619	SensorSupply_HIA2	Level: 1	Current voltage value at sensor supply HIA1
		Range: 0...20.16V	
		Page(s):	
3609	ColdJunctionTemp1	Level: 1	Current value
		Range:	
		Page(s):	
3610	ColdJunctionTemp2	Level: 1	Current value
		Range:	
		Page(s):	
3611	ColdJunctionTemp3	Level: 1	Current value
		Range:	
		Page(s):	

3612	ColdJunctionTemp4	Level:	1	Current value
		Range:		
		Page(s):		
3613	ColdJunctionTemp5	Level:	1	Current value
		Range:		
		Page(s):		
3614	ColdJunctionTemp6	Level:	1	Current value
		Range:		
		Page(s):		
3615	ColdJunctionTemp7	Level:	1	Current value
		Range:		
		Page(s):		
3616	ColdJunctionTemp8	Level:	1	Current value
		Range:		
		Page(s):		
3617	ColdJunctionTemp9	Level:	1	Current value
		Range:		
		Page(s):		
3618	ColdJunctionTemp10	Level:	1	Current value
		Range:		
		Page(s):		
3619	ColdJunctionTemp11	Level:	1	Current value
		Range:		
		Page(s):		
3620	ColdJunctionResist1	Level:	1	Current value
		Range:		
		Page(s):		
3621	ColdJunctionResist2	Level:	1	Current value
		Range:		
		Page(s):		
3622	ColdJunctionResist3	Level:	1	Current value
		Range:		
		Page(s):		

3623	ColdJunctionResist4		
	Level:	1	Current value
	Range:		
	Page(s):		
3624	ColdJunctionResist5		
	Level:	1	Current value
	Range:		
	Page(s):		
3625	ColdJunctionResist6		
	Level:	1	Current value
	Range:		
	Page(s):		
3626	ColdJunctionResist7		
	Level:	1	Current value
	Range:		
	Page(s):		
3627	ColdJunctionResist8		
	Level:	1	Current value
	Range:		
	Page(s):		
3628	ColdJunctionResist9		
	Level:	1	Current value
	Range:		
	Page(s):		
3629	ColdJunctionResist10		
	Level:	1	Current value
	Range:		
	Page(s):		
3630	ColdJunctionResist11		
	Level:	1	Current value
	Range:		
	Page(s):		
3790	IgnitionOn		
	Level:	1	State of the terminal 15
	Range:	0/1	
	Page(s):		
3847	DownloadCounter		
	Level:	1	Number of firmware downloads
	Range:	0...65535	
	Page(s):		
12400	AmplifierxCurrentSetp		
12405	Level:	1	Current output setpoint for current controlled
12410	Range:	0...1.000 A	proportional valve on hydraulic adjusters
	Page(s):	368	x = 1..3

12401	AmplifierxCurrent		
12406	Level:	1	Current back measured actual current
12411	Range:	0...12.500 A	
	Page(s):	368	x = 1..3
12402	AmplifierxVoltage		
12407	Level:	1	Current back measured actual voltage
12412	Range:	0...25.000 V	
	Page(s):	368	x = 1..3
12403	AmplifierxCurrentDiff		
12408	Level:	1	Current difference between current setpoint and actual
12413	Range:	0...1.000 A	value
	Page(s):	369	x = 1..3
13080	ErrAmplifierx		
13081	Level:	1	Error at current output
13082	Range:	0000...FFFF Hex	
	Page(s):	369, Fehler! Textmarke nicht definiert.	
13800	EthernetA_MAC_Address		
ff	Level:	1	MAC address Ethernet node A
	Range:	00...FF Hex	
	Page(s):		
13810	EthernetB_MAC_Address		
ff	Level:	1	MAC address Ethernet node B
	Range:	00...FF Hex	
	Page(s):		
22000	P001_(SL1.1)_Function Px_(SLy.z)_ Function		
	Level:	1	Internally determined function of ports on module C
	Range:	0...38	and D
	Page(s):		x = 1..88 y = 1..11 z = 1..8
22040	P041_(D1.1)_Function Px_(Dy.z)_ Function		
	Level:	1	Internally determined function of ports on module C
	Range:	0...38	x = 41..88
	Page(s):		y = 1..6 z = 1..8
22088	P089_(MC.DI1)_Function		
22089	P090_(MC.DI2)_Function		
	Level:	1	Internally determined function of the binary input ports
	Range:	0...38	on module C
	Page(s):		

22090	P091_(MC.DO1)_Function		
22091	P092_(MC.DO2)_Function		
	Level:	1	Internally determined function of the binary output
	Range:	0...38	ports on module C
	Page(s):		
22092	P093_(MC.AI1)_Function		
ff	Px_(MC.AIy)_Function		
	Level:	1	Internally determined function of the analogue input
	Range:	0...38	ports on module C
	Page(s):		x = 93..103 y = 1..11
22103	P104_(MD.DI1)_Function		
ff	Px_(MD.DIy)_Function		
	Level:	1	Internally determined function of the binary input ports
	Range:	0...38	on module D
	Page(s):		x = 104..106 y = 1..4
22107	P104_(MD.DO1)_Function		
22108	P104_(MD.DO2)_Function		
	Level:	1	Internally determined function of the binary output
	Range:	0...38	ports on module D
	Page(s):		
22109	P110_(MD.AI1)_Function		
ff	Px_(MD.AIy)_Function		
	Level:	1	Internally determined function of the analogue input
	Range:	0...38	ports on module D
	Page(s):		x = 110..117 y = 1..8
22120	SlotSL1_TypeModulA		
ff	SlotSLx_TypeModulA		
	Level:	1	Type of A-modules at slots on module C and D
	Range:	0...15	x = 1..11
	Page(s):		
22131	ModulDAvailable		
	Level:	1	FPGA configuration: Module D is equipped
	Range:	0/1	
	Page(s):		
22132	ElysonAvailable		
	Level:	1	FPGA configuration: Port 104 and 105 on module D 0:
	Range:	0/1	can be used for speed/frequency/binary inputs
	Page(s):		1: can be used for Elyson PWM feedback

22150	P001_(SL1.1)_DO_State Px_(SLy.z)_DO_State		
	Level:	1	Value of the output at port x on C and D module if used
	Range:	0/1	as binary output
	Page(s):		x = 1..4, 9..12, 17..20, 25..28, 33..36, 41..44, 49..52, 57..60, 65..68, 73..76, 81..84 y = 1..11 z = 1..4
22240	P091_(MC.DO1)_DO_State		
22241	P092_(MC.DO2)_DO_State		
	Level:	1	Value of the output on port 91, 92 of the C-module if
	Range:	0/1	used as a binary output
	Page(s):		
22257	P108_(MD.DO1)_DO_State		
22258	P109_(MD.DO2)_DO_State		
	Level:	1	Value of the output on port 108, 109 of the D module if
	Range:	0/1	used as a binary output
	Page(s):		

Tab. 184: Measured values and display values XIOS

↑ 16 Speed control for dual fuel engines (ARTEMIS) and separate ARTEMIS manuals

No.	Name		Meaning
12020	GasActPos GasFuelActual		
	Level:	1	Current position of gas actuators or current gas fuel
	Range:	0..100 %	quantity in electronic fuel injection
	Page(s):	202, 202	from actuator or HEINZMANN-CAN periphery modules
12021	GasActSetpoint(x)		
ff	Level:	1	Current setpoint for own gas actuators, corresponding to
	Range:	0...100 %	12023 <i>GasFuelQuantity</i> or 12026
	Page(s):	170, 173	<i>GasFuelQuantityBankx</i> , if not also stored in characteristic 16210/16225
12032	PromptReturnToDiesel		
	Level:	1	Indication: Immediate return to diesel, can only be
	Range:	0/1	cleared if the gas switch is opened
	Page(s):	175, 178, 183	
12033	FastReturnToDiesel		
	Level:	1	Indication: Return to diesel using fast ramp
	Range:	0/1	
	Page(s):	183	

12034	GasConsumptionActive	Level: 1	Indication: gas is being consumed
		Range: 0/1	12023 <i>GasFuelSetpoint</i> > 0%
		Page(s): 174, 207, 209	
12035	GasValvexOpen	Level: 1	x = 1..2: Double gas valves are operated individually
ff	GasValvesOpen	Range: 0/1	Otherwise: Double gas valves are operated together
		Page(s): 184, 232, 232, 233, 233	
12050	DieselPower	Level: 1	Indication of current diesel power proportion
		Range: 0...100 % or 0...x kW	x: Depending on application
		Page(s): 166, 168, 222, 226	
12051	GasPower	Level: 1	Indication of current gas power proportion
		Range: 0...100 % or 0...x kW	x: Depending on application
		Page(s): 166, 169	
12055	PilotDslAbsMinimum	Level: 1	Minimum ignition oil quantity, which must be met
		Range: 0...100 %	
		Page(s): 165, 169, 197, 233	
12068	EngStopRequWithGas	Level: 1	Indication: Engine stop request is delayed due to activation in dual fuel operation until gas has reached 0 % and any residual gas combustion has been performed
		Range: 0/1	
		Page(s): 180, 232	
12080	GasValveCheckDelay	Level: 1	<i>External gas section monitoring</i> Progression of delay time before signal has to be received to confirm that the gas section is OK
		Range: 0...600 s or 0...1000 s	<i>XIOS</i> <i>Others</i>
		Page(s): 184	
12081	GasValveCheckActive	Level: 1	Indicates that gas valve test is active
		Range: 0/1	
		Page(s): 184	
12082	GasTrainReady	Level: 1	Indicates that gas section test has completed successfully
		Range: 0/1	
		Page(s): 176, 184	
12084	GasConditionStatHigh	Level: 1	Compressed indication of the gas conditions status (high proportion)
		Range: 0...FFFF Hex	
		Page(s): 204	

12085	GasConditionStateLow		
	Level:	1	Compressed indication of gas conditions status
	Range:	0...FFFF Hex	(low proportion)
	Page(s):	204	
12086	DualFuelState1High		
	Level:	1	Compressed indication of dual fuel status, word 1
	Range:	0...FFFF Hex	(high proportion)
	Page(s):	204	
12087	DualFuelState1Low		
	Level:	1	Compressed indication of dual fuel status, word 1
	Range:	0...FFFF Hex	(low proportion)
	Page(s):	205	
12088	DualFuelState2High		
	Level:	1	Compressed indication of dual fuel status, word 2
	Range:	0...FFFF Hex	(high proportion)
	Page(s):		
12089	DualFuelState2Low		
	Level:	1	Compressed indication of dual fuel status, word 2
	Range:	0...FFFF Hex	(low proportion)
	Page(s):		
12090	AriadneKnockControl		
	Level:	1	Indication that Ariadne knock detection module is
	Range:	0/1	configured in dual fuel control unit
	Page(s):	199	
12091	ADPWMGasPositioner		
	Level:	1	Gas positioner enabled via analogue or PWM output
	Range:	0/1	
	Page(s):	173	
12091	CanGasFlowControl		<i>Marine operation</i>
	Level:	1	Indication that Elektra FlowControl is configured in
	Range:	0/1	dual fuel control unit
	Page(s):	173	
12092	ActuatGasPositioner		
	Level:	1	Gas positioner is enabled by its own actuator
	Range:	0/1	
	Page(s):	170, 201	
12093	ActuatGasPositioner2		
	Level:	1	Gas positioner is also enabled by a second own actuator
	Range:	0/1	(V motor)
	Page(s):	170, 201	
12094	CanGasPositioner		
	Level:	1	Gas positioner on HZM-CAN actuator periphery
	Range:	0/1	module enabled
	Page(s):	172	

12095	EFIGasPositioner		
	Level:	1	Gas positioner on HZM-CAN EFI periphery module
	Range:	0/1	enabled
	Page(s):	172	
12096	CanGasPositioner2		
	Level:	1	Gas positioner on second HZM-CAN actuator periphery
	Range:	0/1	module enabled (V motor)
	Page(s):	172	
12097	EFIGasPositioner2		
	Level:	1	Gas positioner on second HZM-CAN EFI periphery
	Range:	0/1	module enabled
	Page(s):	172	
13000	ErrGasConditions		<i>Not XIOS</i>
	Level:	1	Conditions for dual fuel operation are not met
	Range:	0/1	
	Page(s):	Fehler! Textmarke nicht definiert.	
13001	ErrGasPositioner		<i>Not XIOS</i>
	Level:	1	Error on gas positioner
	Range:	0/1	
	Page(s):	175, 179, 202, Fehler! Textmarke nicht definiert.	
13007	ErrHeavyKnocking		<i>Not XIOS</i>
	Level:	1	Ariadne reporting heavy knocking
	Range:	0/1	
	Page(s):	179, 199, Fehler! Textmarke nicht definiert.	
13008	ErrGasPressTooLow		<i>Not XIOS</i>
	Level:	1	Gas pressure too low
	Range:	0/1	
	Page(s):	195, Fehler! Textmarke nicht definiert.	
13009	ErrKnockControlOff		<i>Not XIOS</i>
	Level:	1	ARIADNE knock monitoring system is out of service
	Range:	0/1	
	Page(s):	175, 179, 199, Fehler! Textmarke nicht definiert.	
13010	ErrGasTrain		<i>Not XIOS</i>
	Level:	1	Gas section not OK
	Range:	0/1	
	Page(s):	184, Fehler! Textmarke nicht definiert.	
13011	ErrLightKnocking		<i>Not XIOS</i>
	Level:	1	Ariadne reporting light knocking
	Range:	0/1	
	Page(s):	182, 199, 201	

13017	ErrGasPrRangeForGas	<i>Not XIOS</i>
Level:	1	Gas pressure is not in range for dual fuel operation
Range:	0/1	see 10005-10007
Page(s):	177, 179, Fehler!	
Textmarke nicht definiert.		

13022	ErrEFIGasPosDiff	<i>Not XIOS</i>
Level:	1	MEGASOL gas positioner is not synchronised,
Range:	0/1	actual gas value is 0 for 1 s, although a gas setpoint has
Page(s):	175, 179, 202, Fehler!	been set
	Textmarke nicht definiert.	
13024	ErrExternGasAlarm	<i>Not XIOS</i>
Level:	1	“External gas alarm” switching function is active
Range:	0/1	
Page(s):	178, 201, Fehler!	
	Textmarke nicht definiert.	
13026	ErrGasTRangeForGas	<i>Not XIOS</i>
Level:	1	Gas temperature is not in range for dual fuel operation
Range:	0/1	see 10023-10025
Page(s):	178, 201, Fehler!	
	Textmarke nicht definiert.	
13030	ErrGasRailStatus	<i>XIOS</i>
Level:	1	Error status of the gas section
Range:	0000...FFFF Hex	
Page(s):	178, 184, 191, 201, 206, 422	
13031	ErrGasConditions	<i>XIOS</i>
Level:	1	Error status of the conditions for dual fuel operation
Range:	0000...FFFF Hex	
Page(s):	175, 179, 182, 185,187, 188, 192, 196, 197, 200, 206, 423	
13032	ErrDualFuelStatus	<i>XIOS</i>
Level:	1	Error status of dual fuel operation
Range:	0000...FFFF Hex	
Page(s):	175, 179, 202, 206, 426	
13071	ErrGasTemp	<i>XIOS</i>
Level:	1	Error indication for gas temperature sensor
Range:	0000...FFFF Hex	
Page(s):	411	
13072	ErrGasPosition	<i>XIOS</i>
Level:	1	Error indication for external gas position
Range:	0000...FFFF Hex	
Page(s):	411	
13073	ErrGasRailPressure	<i>XIOS</i>
Level:	1	Error indication for gas pressure sensor
Range:	0000...FFFF Hex	
Page(s):	411	
13074	ErrGasValveCheckPr	<i>XIOS</i>
Level:	1	Gas section test: Error indication for valve test sensor
Range:	0000...FFFF Hex	(absolute pressure sensor in pressure compensation
Page(s):	411	chamber)

13075	ErrPilotFuelOffset	<i>XIOS</i>	
	Level:	1	Ignition oil quantity offset error indication
	Range:	0000...FFFF Hex	
	Page(s):	411	
13100	SErrGasConditions	<i>Not XIOS</i>	
ff	Level:	1	Error marker / error counter
	Range:	0/1 or 0...255	Related current errors see 13000 ff
	Page(s):		

Tab. 185: Measured values and display values for dual fuel (general)

28.2.11.1 Gas speed governor

No.	Name	Meaning
12023	GasFuelQuantity	
	Level:	1 Fuel quantity setpoint for gas actuator or gas valve
	Range:	0..100 %
	Page(s):	170, 173, 202, 208, 211, 219, 230, Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.
12024	GasFuelQuantUncorr	
	Level:	1 Gas injection quantity not yet corrected by gas pressure and gas temperature
	Range:	0..100 %
	Page(s):	208, 212, 219, 230
12025	GasFuelSetpUnlimited	
	Level:	1 Gas injection quantity before limitation
	Range:	0..100 %
	Page(s):	208, 211, 219, 231
12030	DieselGovernorActive	
	Level:	1 Indicates that diesel controller is active
	Range:	0/1
	Page(s):	174, 207, 209, 212
12031	GasGovernorActive	
	Level:	1 Indicates that gas governor is active, diesel only
	Range:	0/1 ignition oil quantity
	Page(s):	174, 207, 209, 211, 220
12059	DieselKnockOffset	
	Level:	1 Offset for the ignition oil quantity to rectify light
	Range:	0..100 % knocking (increase of diesel proportion)
	Page(s):	200, 200
12060	PilotDieselPresent	
	Level:	1 Current ignition oil quantity
	Range:	0...100 %
	Page(s):	165, 196

12061	DieselAtPilotActive	Level: 1	Indication: diesel request <= ignition oil quantity
		Range: 0/1	
		Page(s): 197	
12062	GasFuelLimitMax	Level: 1	Current gas fuel quantity limitation
		Range: 0...100 %	
		Page(s): 208, 211, 219, 231	
12063	GasAtUpperLimit	Level: 1	Diesel support active because gas is at upper limit
		Range: 0/1	
		Page(s): 211	
12064	DieselSupportActive	Level: 1	Indication that diesel support is active, gas is held – for
		Range: 0/1	whatever reason
		Page(s): 212	
12069	RemainGasBurning	Level: 1	Indicates that residual gas combustion is in progress
		Range: 0/1	
		Page(s): 233	
12075	GasLoadingActive	Level: 1	Load addition in dual fuel operation
		Range: 0/1	
		Page(s): 213	
12076	GasLoadingReactionOn	Level: 1	Reaction to load addition in dual fuel operation active
		Range: 0/1	(diesel support)
		Page(s): 213	
12077	GasLoadRejectActive	Level: 1	Load shedding in dual fuel operation
		Range: 0/1	
		Page(s): 213	
12078	GasLoadRejReactionOn	Level: 1	Reaction to load shedding in dual fuel operation active
		Range: 0/1	
		Page(s): 214	
12083	ReadyForChangeOver	Level: 1	Indicates that gas conditions are met, switch to gas can
		Range: 0/1	be made
		Page(s): 218	
12089	RemainGasBurning	Level: 1	Indication that residual gas combustion is active
		Range: 0/1	
		Page(s):	

13012	ErrSpeedRangeForGas	<i>Not XIOS</i>
Level:	1	Speed is not in range for dual fuel operation
Range:	0/1	see 10010-10012
Page(s):	177, 181, 196, Fehler!	
	Textmarke nicht definiert.	
13013	ErrPowerRangeForGas	<i>Not XIOS</i>
Level:	1	Power is not in range for dual fuel operation
Range:	0/1	see 10013-10015
Page(s):	176, 180, 185, Fehler!	
	Textmarke nicht definiert.	
13014	ErrFuelRangeForGas	<i>Not XIOS</i>
Level:	1	Diesel fuel quantity is below PilotFuel, which means it
Range:	0/1	is not possible to switch to dual fuel operation
Page(s):	177, 196, Fehler!	see 12060 <i>PilotFuelPresent</i>
	Textmarke nicht definiert.	
13015	ErrBoostRangeForGas	<i>Not XIOS</i>
Level:	1	Boost pressure is not in range for dual fuel operation
Range:	0/1	see 16100/16115/10016
Page(s):	177, 181, 193, Fehler!	
	Textmarke nicht definiert.	
13016	ErrOilPrRangeForGas	<i>Not XIOS</i>
Level:	1	Oil pressure is not in range for dual fuel operation
Range:	0/1	Oil pressure warning is active, see 3010 <i>ErrOilPressure</i>
Page(s):	181, 192, Fehler!	(XIOS) or 3030 <i>ErrOilPressWarn</i> (others)
	Textmarke nicht definiert.	
13018	ErrCoolTRangeForGas	<i>Not XIOS</i>
Level:	1	Coolant temperature is not in range for dual fuel
Range:	0/1	operation
Page(s):	176, 181, 189, Fehler!	see 10020-10022
	Textmarke nicht definiert.	
13019	ErrExhTRangeForGas	<i>Not XIOS</i>
Level:	1	Exhaust temperature is not in range for dual fuel
Range:	0/1	operation
Page(s):	176, 180, 187, 188, Fehler!	see 10017-10018
	Textmarke nicht definiert.	
13020	ErrExhTDRangeForGas	<i>Not XIOS</i>
Level:	1	Exhaust temperature difference between coldest and
Range:	0/1	hottest cylinder is not in range for dual fuel operation
Page(s):	176, 181, 188, Fehler!	See 10019
	Textmarke nicht definiert.	
13021	ErrChAirTRangeForGas	<i>Not XIOS</i>
Level:	1	Charge air temperature is not in the range for dual fuel
Range:	0/1	operation
Page(s):	176, 181, 190, Fehler!	see 10002-10004
	Textmarke nicht definiert.	
13023	ErrBelowPilotFuel	<i>Not XIOS</i>

Level:	1	Diesel fuel quantity is below PilotFuel, which means it
Range:	0/1	is necessary to terminate dual fuel operation
Page(s):	179, 179, 197, Fehler!	see 12060 <i>PilotFuelPresent</i>
Textmarke nicht definiert.		

Tab. 186: Measured and display values for dual fuel (gas speed governor)

28.2.11.2 Diesel reduction governor

No.	Name	Meaning
12002	ChAirTInRangeForGas	
	Level:	1 Charge air temperature in range for dual fuel operation
	Range:	0/1
	Page(s):	176, 181, 191
12005	GasPresInRangeForGas	
	Level:	1 Gas pressure in range for dual fuel operation
	Range:	0/1
	Page(s):	177, 195
12006	GasPosNotActive	<i>Marine operation</i>
	Level:	1 ELEKTRA FlowControl is not active
	Range:	0/1
	Page(s):	177, 182, 203
12010	SpeedInRangeForGas	
	Level:	1 Speed in range for dual fuel operation
	Range:	0/1
	Page(s):	177, 181, 196
12011	DieselBelowPilotFuel	
	Level:	1 Diesel fuel quantity is below ignition oil quantity
	Range:	0/1
	Page(s):	179
12012	DieselInRangeForGas	
	Level:	1 Diesel fuel quantity in range for dual fuel operation
	Range:	0/1
	Page(s):	177, 198
12013	PowerInRangeForGas	
	Level:	1 Power in range for dual fuel operation
	Range:	0/1
	Page(s):	176, 180, 185
12014	LightKnocking	
	Level:	1 Ariadne reporting light knocking
	Range:	0/1
	Page(s):	182, 201
12015	OilPresInRangeForGas	

Level: 1 Oil pressure in range for dual fuel operation
Range: 0/1
Page(s): 176, 181, 192

12016 BoostPrInRangeForGas

Level: 1 Boost pressure in range for dual fuel operation
Range: 0/1
Page(s): 177, 181, 193

12017	ExhTInRangeForGas		
	Level:	1	Exhaust temperature in range for dual fuel operation
	Range:	0/1	
	Page(s):	176, 180, 187, 189	
12018	ExhTDInRangeForGas		
	Level:	1	Exhaust temperature difference between hottest and coldest cylinder is not in range for dual fuel operation
	Range:	0/1	
	Page(s):	176, 181, 189	
12019	CoolTInRangForGas		
	Level:	1	Coolant temperature in range for dual fuel operation
	Range:	0/1	
	Page(s):	176, 181, 190	
12023	GasFuelQuantity		<i>Locomotive operation</i>
	Level:	1	Fuel quantity setpoint for gas actuator or gas valve
	Range:	0...100 %	
	Page(s):	170, 202, 208, 211, 215, 217, 219, 225, 230, Fehler!	
		Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
12023	GasPowerSetpoint		<i>Marine operation</i>
	Level:	1	Power setpoint for Elektra FlowControl
	Range:	0...x kW	
	Page(s):	173, 222	
12024	GasFuelQuantUncorr		<i>Locomotive operation</i>
	Level:	1	Gas injection quantity not yet corrected by gas pressure and gas temperature
	Range:	0...100 %	
	Page(s):	208, 212, 217, 219, 230	
12024	GasPowerUncorr		<i>Marine operation</i>
	Level:	1	Power setpoint for Elektra FlowControl not yet corrected by gas pressure and gas temperature
	Range:	0...100 %	
	Page(s):	222	
12025	GasFuelSetpUnlimited		<i>Locomotive operation</i>
	Level:	1	Gas injection quantity before limitation
	Range:	0...100 %	
	Page(s):	208, 211, 219, 231	
12031	GasActive		
	Level:	1	Indication that gas is being added
	Range:	0/1	
	Page(s):	174, 207, 209, 211, 220	
12039	RampToDieselActive		
	Level:	1	Indication: Ramped return to diesel
	Range:	0/1	
	Page(s):	219	
12048	PowerMax		<i>Locomotive operation</i>

28 Parameter description

Level:	1	Indication of speed-dependent maximum traction power
Range:	0...x kW	x: depending on application
Page(s):	166, 225, 226	

12049	DieselPowerMap		<i>Locomotive operation</i>
	Level:	1	Indication of diesel power from speed and fuel quantity
	Range:	0...x kW	dependent map
	Page (s):	167	x: Depending on application
12049	NegDieselPower		<i>Marine operation, at request of engine manufacturers</i>
	Level:	1	Indication of negative diesel power in dual fuel
	Range:	0...x kW	operation if PilotFuel is below zero power curve
	Page (s):	222	x: Depending on application
12052	GasPowerMax		<i>Locomotive and generator operation</i>
	Level:	1	Indication of maximum permissible gas power
	Range:	0...x kW	x: Depending on application
	Page (s):	226	
12052	DF:EnginePowerLimit		<i>Marine operation</i>
	Level:	1	Indication of maximum permissible engine power in
	Range:	0...x kW	dual fuel operation
	Page (s):	222	x: Depending on application
12053	RelativeDieselPower		<i>Locomotive operation</i>
	Level:	1	Indication of diesel power relative to nominal power
	Range:	0...100 %	1232 <i>TractionPowerHigh</i>
	Page(s):	167	
12059	DieselKnockOffset		
	Level:	1	Offset for the diesel quantity setpoint to rectify light
	Range:	0...100 %	knocking (increase of diesel proportion)
	Page(s):	200	
12060	DieselRedGovSetp		
	Level:	1	Current diesel setpoint
	Range:	0...100 %	
	Page(s):	165, 196, 197, 215, 217	
12061	DieselRedGovActive		
	Level:	1	Indication: Diesel reduction governor is active
	Range:	0/1	
	Page(s):	197	
12062	GasFuelLimitMax		<i>Locomotive and generator operation</i>
	Level:	1	Current gas fuel quantity limitation
	Range:	0...100 %	
	Page(s):	217, 222, 223, 231	
12062	GasPowerLimitMax		<i>Marine operation</i>
	Level:	1	Current gas power limit
	Range:	0...x kW	x: Depending on application
	Page(s):	223	
12063	GasFuelLimitSpeed		<i>Locomotive and generator operation</i>
	Level:	1	Speed-dependent gas fuel quantity limitation
	Range:	0...100 %	
	Page(s):	224	

12063	GasPowerLimitSpeed		<i>Marine operation</i>
	Level:	1	Speed-dependent gas power limit
	Range:	0...x kW	x: Depending on application
	Page (s):	222	
12064	GasFuelLimitPower		<i>Locomotive and generator operation</i>
	Level:	1	Traction power dependent gas fuel quantity limitation
	Range:	0...100 %	
	Page(s):	221, 226	
12065	GasSpeedLimitActive		
	Level:	1	Indicates that speed-dependent gas power limitation is active
	Range:	0/1	
	Page(s):	222, 224	
12066	GasPowerLimitActive		<i>Locomotive and generator operation</i>
	Level:	1	Indicates that (traction) power dependent gas power limitation is active
	Range:	0/1	
	Page(s):	226	
12067	GasForcedLimitActive		<i>Locomotive operation</i>
	Level:	1	Indicates that gas power limitation using the switching function 2813 <i>SwitchForcedLimit</i> is active
	Range:	0/1	
	Page(s):	227	
12069	RemainGasBurning		
	Level:	1	Indicates that residual gas combustion is in progress
	Range:	0/1	
	Page(s):	233	
12083	GasReleased		
	Level:	1	Indicates that gas is released
	Range:	0/1	
	Page(s):	218	
13025	ErrGasPosFatal		<i>Not XIOS</i>
	Level:	1	Fatal error on the gas positioner
	Range:	0/1	
	Page(s):	179, 202, Fehler!	
	Textmarke nicht definiert.		
13027	ErrGasNoPower		<i>Not XIOS</i>
	Level:	1	Gas does not produce any power proportion
	Range:	0/1	
	Page(s):	182, 197, Fehler!	
	Textmarke nicht definiert.		

Tab. 187: Measured and display values for dual fuel (diesel reduction governor)

28.2.12 CANopen

↑ 23.4 CAN protocol CANopen and CANopen, Manual DG 06 002-e

No.	Name	Meaning
23750	CanOp:Init	
	Level:	1 CANopen state Init
	Range:	0/1
23751	CanOp: PreOperational	
	Level:	1 CANopen state Preoperational
	Range:	0/1
23752	CanOp: Operational	
	Level:	1 CANopen state Operational
	Range:	0/1
23753	CanOp: Stopped	
	Level:	1 CANopen state Stopped
	Range:	0/1
23754	CanOp:HBeatConsumer	
	Level:	1 Heartbeat consumer is enabled
	Range:	0/1
23755	CanOp:HBeatProducer	
	Level:	1 Heartbeat producer is enabled
	Range:	0..1
23756	CanOp:LifeGuarding	
	Level:	1 Life guarding is enabled
	Range:	0..1
23757	CanOp:ErrLifeSign	
	Level:	1 Life sign error
	Range:	0/1
23758	CanOp:ErrRPDOTimeOut	
	Level:	1 At least one RPDO has timed out
	Range:	0/1
23759	CanOp:RxIRCount	
	Level:	1 Counter for receive interrupts (receiving telegrams)
	Range:	0...65535
23760	CanOp:SwitchMask(x)	
ff	Level:	4 Mask for receiving switching functions resulting from assignments in 20810 <i>Comm..</i> and 24810 <i>ChanTyp.</i> = 4 (for comparison with sender)
	Range:	0...FFFF Hex
		x = 0: Switching functions 16...1
		x = 1: Switching functions 32...17
		x = 2: Switching functions 48...33
		x = 3: Switching functions 64...49

No.	Name	Meaning
23764	CanOp:SensorMask(x)	
ff	Level: 4 Range: 0...0F Hex	Mask for receiving sensors resulting from assignments in 900 <i>Assign...</i> and 4900 <i>ChanTyp...</i> = 4 (for comparison with sender) x = 0: Sensors 4...1 x = 1: Sensors 8...5 x = 2: Sensors 12...9
23770	CanOp:RPDOTelLen(x)	
ff	Level: 4 Range: 0...8	Expected telegram length of RPDO x+1 x = 0...3 or x = 0...9
23774	CanOp:TPDOTelLen(x)	<i>If only 4 RPDOs are possible</i>
ff	Level: 4 Range: 0...8	Expected telegram length of TPDO x+1 x = 0...15
23780	CanOp:TPDOTelLen(x)	<i>If more than 4 RPDOs are possible</i>
ff	Level: 4 Range: 0...8	Expected telegram length of TPDO x+1 x = 0...15
23790	CanOp:TxCount	<i>If only 4 RPDOs are possible</i>
	Level: 1 Range: 0...65535	Counter for transmissions (transmit telegrams)
23796	CanOp:TxCount	<i>If more than 4 RPDOs are possible</i>
	Level: 1 Range: 0...65535	Counter for transmissions (transmit telegrams)
23799	CanOp:MaxLevel	
	Level: 1 Range: 0...65535	Maximum level for configuration using CANopen if this is permitted in the firmware
23799	CanOp:MaxLevelTPDO	
	Level: 1 Range: 0...65535	Maximum level for configuration of the TPDOs if general configuration using CANopen is not permitted in the firmware

Tab. 188: Measured and display values for CANopen

28.2.13 Modbus

↑23.8 Serial protocol Modbus and Manual DG 05 002-e

No.	Name	Meaning
23800	Modb:Baudrate	
	Level: 4 Range: 9600, 19200 Baud	Display value for set baud rate
23801	Modb:BusMessageCnt	
	Level: 4 Range: 0...65535	Number of valid received messages

No.	Name	Meaning
23802	Modb:CommErrorCnt	
	Level:	4
	Range:	0...65535
		Number of erroneous received messages
23803	Modb:ExceptErrCnt	
	Level:	4
	Range:	0...65535
		Number of sent exception messages
23804	Modb:SlaveMessageCnt	
	Level:	4
	Range:	0...65535
		Number of sent messages
23805	Modb:SlaveNoRespCnt	
	Level:	4
	Range:	0...65535
		Number of received messages that require no answering message (here: send-only message from master)
23806	Modb:BusCharOvrCnt	
	Level:	4
	Range:	0...65535
		Number of messages that were not received correctly due to character overrun
23810	Modb:NoOfTxParams	
	Level:	4
	Range:	0...100
		Number of valid parameter numbers that are entered in the data field for read access 29200 <i>Modb:TxParamSet(x)</i>
23820	Modb:RxBinary(x)	
ff	Level:	4
	Range:	0...FF Hex
		Received values for switching functions
23822	Modb:RxSensor(x)	
ff	Level:	4
	Range:	0...100 %
		Received sensor values

Tab. 189: Measured and display values for Modbus

28.2.14 DeviceNet

↑ 23.5 CAN protocol DeviceNet and Manual DG 06 003-e

No.	Name	Meaning
23850	DNet:LED_Green	
	Level:	1
	Range:	0/1
		Current value of green LED
23851	DNet:LED_Red	
	Level:	1
	Range:	0/1
		Current value of red LED
23852	DNet:Flag	
	Level:	1
	Range:	0...FF Hex
		State flag

No.	Name	Meaning
23853	DNet:Status	
	Level:	1 Status indicator
	Range:	0...FF Hex
23860	DNet:NoOfPollParams	
	Level:	4 Number of send parameters via polled message
	Range:	0...100
23861	DNet:Baudrate	
	Level:	4 Current baud rate
	Range:	125,250,500
23862	DNet:RxBinary(x)	
ff	Level:	4 Received values for switching functions
	Range:	0...FF Hex
23864	DNet:RxSensor(x)	
ff	Level:	4 Received sensor values
	Range:	0...65535

Tab. 190: Measured and display values for DeviceNet

28.2.15 SAE J1939

↑23.3 CAN protocol SAE J1939 and Manual DG 06 004-e

No.	Name	Meaning
23900	J1939:Online	
	Level:	1 General state SAE J1939
	Range:	0/1
23903	J1939:TSC1RxBufOvfl	<i>TSC1</i>
	Level:	1 Receive buffer overflow for TSC1 messages
	Range:	0/1
23904	J1939:RxBufOvfl	
	Level:	1 General receive buffer overflow
	Range:	0/1
23905	J1939:TxBufOvfl	
	Level:	1 Send buffer overflow
	Range:	0/1
23906	J1939:RxTimeout	
	Level:	1 Indication of receiving telegrams in timeout state
	Range:	0...FFFF Hex
23907	J1939:MsgStatus	
	Level:	1 Indication of receiving telegrams in OK state
	Range:	0...FFFF Hex

No.	Name	Meaning
23908	J1939:Active Level: 1 Range: 0...FFFF Hex	Indication of whether SAE J1939 communication is active (only if address claim was successful)
23910	J1939:EEC1TorqueMode Level: 4 Range: 0...15	<i>EEC1</i> Torque mode
23911	J1939:EEC1TorqueSetp Level: 4 Range: 0...100 %	<i>EEC1</i> Current torque setpoint relative to the maximum torque limitation
23912	J1939:EEC1TorqueMax Level: 4 Range: 0...100 %	<i>EEC1</i> Current torque relative to the maximum torque limitation
23913	J1939:EEC2PercntLoad Level: 4 Range: 0...100 %	<i>EEC2</i> Percentage load at current speed
23914	J1939:EEC3Friction Level: 4 Range: 0...100 %	<i>EEC3</i> Torque friction
23920	J1939:TSC1Status Level: 4 Range: 0...0F	<i>TSC1</i> Activity status of TSC1 telegrams
23921	J1939:TSC1IMOrAllGov Level: 4 Range: 0/1	<i>TSC1</i> Governor mode resulting from TSC1 telegrams
23922	J1939:TSC1SpeedSet Level: 4 Range: 0...100 %	<i>TSC1</i> Speed setpoint resulting from TSC1 telegrams
23923	J1939:TSC1SpeedLim Level: 4 Range: 0...100 %	<i>TSC1</i> Speed limit setpoint resulting from TSC1 telegrams
23924	J1939:TSC1FuelLim Level: 4 Range: 0...100 %	<i>TSC1</i> Fuel quantity limit resulting from TSC1 telegrams

Tab. 191: Measured and display values for SAE J1939

28.3 List 3: Functions

Name	Meaning
4000 Pickup1On Level: 4 Enable/disable first speed pickup as redundant speed Range: 0/1 signal (RESET) Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 301	
4001 PickupFilter2Or1Rev Level: 1 Filtering of speed signals Range: 0/1 0: Over one crankshaft revolution Page(s): Fehler! Textmarke nicht definiert. 1: Over two crankshaft revolutions (RESET)	
4002 Pickup2On Level: 4 Enable/disable second speed pickup as redundant speed Range: 0/1 signal (RESET) Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 301	
4003 Pickup2AtAlternator Level: 4 Redundant speed signal (2nd speed pickup input) is Range: 0/1 taken from alternator Page(s): Fehler! Textmarke nicht definiert. (RESET)	
4005 CamIndexOn Level: 4 Enable/disable camshaft index sensor for individual Range: 0/1 cylinder identification with misfire monitoring at Page(s): Fehler! Textmarke nicht definiert. pickup 2 (only if 4002 <i>Pickup2On</i> = 0) (RESET)	
4010 Pickup1AtCamOrCrank Level: 4 The first speed pickup is connected to the camshaft (1) Range: 0/1 or to the crankshaft (0) Page(s): Fehler! Textmarke nicht definiert. (RESET)	
4011 Pickup2AtCamOrCrank	

Name		Meaning
Level:	4	The second speed pickup is connected to the camshaft
Range:	0/1	(1) or to the crankshaft (0)
Page(s): Fehler! Textmarke nicht definiert.		(RESET)
4014	CheckPickUpDiffOn	
Level:	4	Enable / disable reciprocal pickup monitoring
Range:	0/1	
Page(s): Fehler! Textmarke nicht definiert.		
4020	SpeedSetpPCOn	
Level:	2	Enable /disable speed setpoint specification by PC
Range:	0/1	
Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.		

Name		Meaning
4025	SpeedGradientOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	Enable speed gradient monitoring
4028	SpeedGradientDT1On Level: 2 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert., 213, 213	Enable /disable DT1-factor during speed jump recognition
4029	PowerGradientDT1On Level: 2 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert., 213, 213	Enable /disable DT1-factor during load jump recognition
4050	SpeedVarDetectOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	Enable /disable detection of speed variance
4055	MisfireWarnCurveOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert., 413	Enable / disable misfire warning curve
4056	MisfireEcyCurveOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert., 413	Enable misfire emergency shutdown curve
4060	SpeedMinTempOn Level: 2 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	Enable temperature dependent idle speed
4100	PIDMapOn Level: 3 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	Enable / disable PID map for speed governor
4101	PIDMapPowerOrFuel PIDMapSpGovPowOrFuel	<i>If integrated power governor is available</i>

Name		Meaning
Level:	3	Stability map for speed control loop
Range:	0/1	0: Speed and fuel quantity dependent
Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	1: Speed and power dependent

4110	StaticCorrOn	
Level:	2	Enable / disable PID correction for static operation
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert.	

Name	Meaning
4120 DroopOn	
Level:	2 Enable / disable droop
Range:	0/1
Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.
4121 DroopPowerOrFuel	
Level:	2 Droop calculation
Range:	0/1 0: Based on fuel reference
Page(s):	Fehler! Textmarke nicht definiert., 243 1: Based on power measurement
4122 Droop@ZeroOrFullLoad	
Level:	2 Droop calculation
Range:	0/1 0: At full load reference point
Page(s):	Fehler! Textmarke nicht definiert. 1: At zero load reference point
4130 IMGovernorOn	
Level:	2 Enable / disable idle / maximum speed governor
Range:	0/1
Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.
4131 IMFuelRampOn	
Level:	2 Enable / disable fuel ramp for idle / maximum speed
Range:	0/1 governor
Page(s):	Fehler! Textmarke nicht definiert.
4132 IMDriveMapOn	
Level:	2 Enable / disable drive map
Range:	0/1
Page(s):	Fehler! Textmarke nicht definiert.
4160 PIDTempOn	
Level:	3 Enable / disable temperature dependent speed governor
Range:	0/1 PID correction
Page(s):	Fehler! Textmarke nicht definiert.
4230 SpeedRampOn	

Name	Meaning
Level: 2 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Enable / disable speed ramp
4232 SectionalOrFixedRamp	
Level: 2 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Selection of speed ramp 0 = Simple fixed speed ramp 1 = Sectional speed ramp
4240 StartSpeedRampOn	
Level: 3 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	Enable / disable separate speed ramp for engine start

Name		Meaning
4300	InjectorPumpMapOn	<i>At request of engine manufacturers</i>
	Level:	6 Enable / disable pump map
	Range:	0/1
	Page(s):	359
4320	CurrentShutOffOn ActxCurrentShutOffOn	
4323	Level:	6 Enable /disable current shutoff on actuator x
4326	Range:	0/1 x = 1...3
	Page(s):	Fehler! Textmarke nicht definiert. Only applies for speed governor actuator
4330	AllSendSpeedOn	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4 Enable / disable sending of current speed 2000 <i>Speed</i>
	Range:	0/1 via HZM_CAN_ALL
4332	AllSendPowPercentOn	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4 Enable / disable sending of current relative power 3232
	Range:	0/1 <i>RelativePower</i> via HZM_CAN_ALL
4335	AllSendStatusOn	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4 Enable /disable sending of current speed governor
	Range:	0/1 status via HZM_CAN_ALL
4336	AllSendSpeedSetpOn	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4 Enable /disable sending of current speed governor
	Range:	0/1 setpoint 2031 <i>SpeedSetp</i> via HZM_CAN_ALL
4338	AllSendBoostPressOn	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4 Enable /disable sending of current boost pressure 2904
	Range:	0/1 <i>BoostPressure</i> via HZM_CAN_ALL
4340	AllSendAutoResetOn	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4 Enable /disable sending of AutoReset request via
	Range:	0/1 HZM_CAN_ALL
4341	AllSendErrorResetOn	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4 Enable / disable sending of error clearing request via
	Range:	0/1 HZM_CAN_ALL
	Page(s):	
4342	AllSendExhaustTempOn	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4 Enable /disable sending of current exhaust temperature
	Range:	0/1 2911 <i>ExhaustTemp</i> or – if available – maximum exhaust temperature 12573 <i>ExhaustTempMax</i> via HZM_CAN_ALL
4344	AllSendFuelSetpOn	<i>See basic information HZM-CAN DG 13 002-d</i>
	Level:	4 Enable / disable sending of current fuel quantity
	Range:	0/1 setpoint 2350 <i>FuelQuantity</i> via HZM_CAN_ALL
4375	ACxSetpointOn	<i>See basic information HZM-CAN DG 13 002-d</i>
ff	Level:	4 HZM-CAN: Enable /disable transmission of setpoint to
	Range:	0/1 add-on module x (only relates to type 1 AC modules) x = 1...5

Name		Meaning	
4376	ACxMeasurementsOn	<i>See basic information HZM-CAN DG 13 002-d</i>	
ff	Level:	4	HZM-CAN: Enable / disable transmission of measured
	Range:	0/1	values to add-on module x (only relates to type 1 AC modules)
			x = 1...5
4377	ACxAutoResetOn	<i>See basic information HZM-CAN DG 13 002-d</i>	
ff	Level:	4	HZM-CAN: Enable /disable transmission of AutoReset
	Range:	0/1	command to add-on module x (only relates to type 1 AC modules)
			x = 1...5
4378	ACxErrorResetOn	<i>See basic information HZM-CAN DG 13 002-d</i>	
ff	Level:	4	HZM-CAN: Enable /disable transmission of error
	Range:	0/1	clearing command to add-on module x (only relates to type 1 AC modules)
			x = 1...5
4400ff	CanCommxxOn	<i>See basic information HZM-CAN DG 13 002-d</i>	
	Level:	6	HZM-CAN: Enable node type xx
	Range:	0/1	xx =
			DC: Speed governor
			GC: Generator control units
			PE: Periphery modules
			IM: Inverter modules
			MC: Engine and hybrid control units
			AC: Add-on module
			CM: Customer module
			PC: PC, ARGOS, hand programmer
4415	CanCommAllOn	<i>See basic information HZM-CAN DG 13 002-d</i>	
	Level:	6	HZM-CAN: Enable /disable sending to all or reception
	Range:	0/1	from all
			For reception it is also necessary to active the unit type from which to receive, see 4400 <i>CanCommDCOn</i>
4416ff	CanxSegmentOrBaud	<i>See basic information HZM-CAN DG 13 002-d</i>	
	Level:	4	HZM-CAN: Selection of baud rate configuration
	Range:	0/1	0: Direct baud rate specification (default)
			1: Baud rate setting derived from segment settings
			CAN controller x = 1...2
4430	ReceiveACErrorOn	<i>See basic information HZM-CAN DG 13 002-d</i>	
	Level:	6	HZM-CAN: Enable /disable reception of error status
	Range:	0/1	information for all connected add-on modules
			XIOS: see 23006 <i>ErrCanAC ff</i>
			Others: see 2443 <i>CanACError(x)</i>
4431	ReceiveStatusOn	<i>See basic information HZM-CAN DG 13 002-d</i>	
	Level:	6	HZM-CAN: Enable /disable reception of error status
	Range:	0/1	information for all connected add-on modules
			see 2541 <i>CanACStatus(x)</i>

Name		Meaning
4440ff	PExFuelSetpointOn	<i>See basic information HZM-CAN DG 13 002-d</i>
Level:	4	HZM-CAN: Enable / disable sending of fuel quantity
Range:	0/1	setpoint to periphery module x x = 1...3
4441ff	PExDigOutOn	<i>See basic information HZM-CAN DG 13 002-d</i>
Level:	4	HZM-CAN: Enable / disable transmission of binary
Range:	0/1	output values to periphery module x x = 1...3
4442ff	PExAnalogOutOn	<i>See basic information HZM-CAN DG 13 002-d</i>
Level:	4	HZM-CAN: Enable / disable transmission of analogue
Range:	0/1	output values to periphery module x x = 1...3
4443ff	PExPWMOutOn	<i>See basic information HZM-CAN DG 13 002-d</i>
Level:	4	HZM-CAN: Enable / disable transmission of PWM
Range:	0/1	output values to periphery module x x = 1...3
4444ff	PExErrorResetOn	<i>See basic information HZM-CAN DG 13 002-d</i>
Level:	4	HZM-CAN: Enable / disable transmission of error
Range:	0/1	clearing command to periphery module x x = 1...3
4445ff	PExAutoResetOn	<i>See basic information HZM-CAN DG 13 002-d</i>
Level:	4	HZM-CAN: Enable / disable transmission of
Range:	0/1	auto-reset command to periphery module x x = 1...3
4446ff	PExAutoAdjustOn	<i>See basic information HZM-CAN DG 13 002-d</i>
Level:	4	HZM-CAN: Enable / disable transmission of auto
Range:	0/1	adjust command to periphery module x x = 1...3
4447ff	PExMeasurementsOn	<i>See basic information HZM-CAN DG 13 002-d</i>
Level:	4	HZM-CAN: Enable / disable transmission of measured
Range:	0/1	values to periphery module x x = 1...3
4460ff	PEDigitalOutx_Logic	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 10</i> <i>See basic information HZM-CAN DG 13 002-d</i>
Level:	6	HZM-CAN: Logical link for multiple assignment to
Range:	0..7F Hex or 80 Hex	binary output x on periphery modules
Page(s):	Fehler! Textmarke nicht definiert.	Bit = 0: AND function
		Bit = 1: OR function
		or 80 Hex: Flashing
		x: Depending on application

Name		Meaning
4480ff	PEDigitalOutx_Prior	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 10</i> <i>See basic information HZM-CAN DG 13 002-d</i>
Level:	6	HZM-CAN: Priority assignment for multiple
Range:	0...FF Hex	assignment to binary output x on periphery modules
Page(s):	Fehler! Textmarke nicht definiert.	Bit = 0: Output flashing Bit = 1: Output is continuously active x: Depending on application
4500	OilPressWarnCurveOn	
Level:	4	Enable / disable oil pressure monitoring curve with oil
Range:	0/1	pressure warning
Page(s):	Fehler! Textmarke nicht definiert.	
4501	OilPressEcyCurveOn	
Level:	4	Enable / disable oil pressure monitoring curve with
Range:	0/1	engine stop
Page(s):	Fehler! Textmarke nicht definiert.	
4505	CoolPressSupviseOn	<i>XIOS</i>
Level:	4	Enable / disable coolant pressure monitoring
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert.	
4505	CoolPressWarnCurveOn	<i>Not XIOS</i>
Level:	4	Enable / disable coolant pressure monitoring curve
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert.	
4506	CoolPLim1RiseOrFall	<i>XIOS</i>
Level:	4	Coolant pressure monitoring: Monitoring for values
Range:	0/1	above (1) or below (0) threshold 1
Page(s):	Fehler! Textmarke nicht definiert.	
4506	CoolPressIdleCurveOn	<i>Not XIOS, locomotive operation</i>
Level:	4	Enable / disable coolant pressure monitoring curve with
Range:	0/1	forced idle speed in locomotive operation
Page(s):	Fehler! Textmarke nicht definiert.	
4507	CoolPLim1EcyOrWarn	<i>XIOS</i>
Level:	4	Coolant pressure monitoring: Value above or below
Range:	0/1	threshold 1 results in engine shutdown (1) or warning
Page(s):	Fehler! Textmarke nicht definiert.	(0)
4508	CoolPLim2RiseOrFall	<i>XIOS</i>

Name		Meaning
Level:	4	Coolant pressure monitoring: Monitoring for values
Range:	0/1	above (1) or below (0) threshold 2
Page(s):	Fehler! Textmarke nicht definiert.	In locomotive operation, threshold 2 can be used for a forced idle speed if 5362 <i>CoolPressWarnIdleOn</i> = 1
4509	CoolPLim2EcyOrWarn	<i>XIOS</i>
Level:	4	Coolant pressure monitoring: Value above or below
Range:	0/1	threshold 2 results in engine shutdown (1) or warning
Page(s):	Fehler! Textmarke nicht definiert.	(0)

	Name	Meaning
4510	CoolantTempWarnOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>All except XIOS</i> Enable / disable monitoring of coolant temperature
4511	CoolantTmpWarnIdleOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>Not XIOS, locomotive operation</i> Enable / disable forced idle speed in locomotive operation when coolant temperature is high
4515	ChargeAirTempWarnOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>Not XIOS</i> Enable / disable monitoring of charge air temperature
4520	OilTempWarnOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>All except XIOS</i> Enable / disable monitoring of oil temperature
4521	OilTempWarnIdleOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>All except XIOS, locomotive operation</i> Enable / disable forced idle speed in locomotive operation when oil temperature is high
4525	ExhaustTempWarnOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>All except XIOS</i> Enable / disable monitoring of exhaust temperature
4545	AlternatorSupviseOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Enable / disable alternator monitoring
4546	AlternLim1RiseOrFall Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Alternator monitoring: Monitoring for values above (1) or below (0) threshold 1
4547	AlternLim1EcyOrWarn	<i>XIOS</i>

Name		Meaning
Level:	4	Alternator monitoring: Value above or below threshold
Range:	0/1	1 results in engine shutdown (1) or warning (0)
Page(s): Fehler! Textmarke nicht definiert.		
4548	AlternLim2RiseOrFall	<i>XIOS</i>
Level:	4	Alternator monitoring: Monitoring for values above (1)
Range:	0/1	or below (0) threshold 2
Page(s): Fehler! Textmarke nicht definiert.		
4549	AlternLim2EcyOrWarn	<i>XIOS</i>
Level:	4	Alternator monitoring: Value above or below threshold
Range:	0/1	2 results in engine shutdown (1) or warning (0)
Page(s): Fehler! Textmarke nicht definiert.		

Name	Meaning
4550 CoolantTempSupviseOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Enable / disable coolant temperature monitoring
4551 CoolTLim1RiseOrFall Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Coolant temperature monitoring: Monitoring for values above (1) or below (0) threshold 1
4552 CoolTLim1EcyOrWarn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Coolant temperature monitoring: Value above or below threshold 1 results in engine shutdown (1) or warning (0)
4553 CoolTLim2RiseOrFall Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>XIOS</i> Coolant temperature monitoring: Monitoring for values above (1) or below (0) threshold 2 In locomotive operation threshold 2 can be used for a forced idle speed if 5360 <i>CoolantTmpWarnIdleOn</i> = 1
4554 CoolTLim2EcyOrWarn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>XIOS</i> Coolant temperature monitoring: Value above or below threshold 2 results in engine shutdown (1) or warning (0)
4555 ChAirTempSupviseOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Enable / disable charge air temperature monitoring
4556 ChAirTLim1RiseOrFall Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Charge air temperature monitoring: Monitoring for values above (1) or below (0) threshold 1
4557 ChAirTLim1EcyOrWarn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Charge air temperature monitoring: Value above or below threshold 1 results in engine shutdown (1) or warning (0)
4558 ChAirTLim2RiseOrFall	<i>XIOS</i>

	Name	Meaning
	Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	Charge air temperature monitoring: Monitoring for values above (1) or below (0) threshold 2
4559	ChAirTLim2EcyOrWarn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Charge air temperature monitoring: Value above or below threshold 2 results in engine shutdown (1) or warning (0)
4560	OilTempSupviseOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Enable / disable oil temperature monitoring
4561	OilTLim1RiseOrFall Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Oil temperature monitoring: Monitoring for values above (1) or below (0) threshold 1
4562	OilTLim1EcyOrWarn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Oil temperature monitoring: Value above or below threshold 1 results in engine shutdown (1) or warning (0)
4563	OilTLim2RiseOrFall Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>XIOS</i> Oil temperature monitoring: Monitoring for values above (1) or below (0) threshold 2 In locomotive operation threshold 2 can be used for a forced idle speed if 5361 <i>OilTempWarnIdleOn</i> = 1
4564	OilTLim2EcyOrWarn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>XIOS</i> Oil temperature monitoring: Value above or below threshold 2 results in engine shutdown (1) or warning (0)
4565	FuelTempSupviseOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Enable / disable fuel temperature monitoring
4566	FuelTLim1RiseOrFall Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Fuel temperature monitoring: Monitoring for values above (1) or below (0) threshold 1

	Name	Meaning
4567	FuelTLim1EcyOrWarn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Fuel temperature monitoring: Value above or below threshold 1 results in engine shutdown (1) or warning (0)
4568	FuelTLim2RiseOrFall Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Fuel temperature monitoring: Monitoring for values above (1) or below (0) threshold 2
4569	FuelTLim2EcyOrWarn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Fuel temperature monitoring: Value above or below threshold 2 results in engine shutdown (1) or warning (0)
4570	ExhTempSupviseOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Enable / disable exhaust temperature monitoring
4571	ExhTLim1RiseOrFall Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Exhaust temperature monitoring: Monitoring for values above (1) or below (0) threshold 1
4572	ExhTLim1EcyOrWarn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Exhaust temperature monitoring: Value above or below threshold 1 results in engine shutdown (1) or warning (0)
4573	ExhTLim2RiseOrFall Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Exhaust temperature monitoring: Monitoring for values above (1) or below (0) threshold 2
4574	ExhTLim2EcyOrWarn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Exhaust temperature monitoring: Value above or below threshold 2 results in engine shutdown (1) or warning (0)
4575	TurbOilTempSupviseOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Enable / disable turbocharger oil temperature monitoring

	Name	Meaning
4576	TuOilTLim1RiseOrFall Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Turbocharger oil temperature monitoring: Monitoring for values above (1) or below (0) threshold 1
4577	TuOilTLim1EcyOrWarn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Turbocharger oil temperature monitoring: Value above or below threshold 1 results in engine shutdown (1) or warning (0)
4578	TuOilTLim2RiseOrFall Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Turbocharger oil temperature monitoring: Monitoring for values above (1) or below (0) threshold 2
4579	TuOilTLim2EcyOrWarn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Turbocharger oil temperature monitoring: Value above or below threshold 2 results in engine shutdown (1) or warning (0)
4580	FuelPressSupviseOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Enable / disable fuel pressure monitoring
4581	FuelPrLim1RiseOrFall Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Fuel pressure monitoring: Monitoring for values above (1) or below (0) threshold 1
4582	FuelPrLim1EcyOrWarn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Fuel pressure monitoring: Value above or below threshold 1 results in engine shutdown (1) or warning (0)

	Name	Meaning
4583	FuelPrLim2RiseOrFall Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Fuel pressure monitoring: Monitoring for values above (1) or below (0) threshold 2
4584	FuelPrLim2EcyOrWarn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Fuel pressure monitoring: Value above or below threshold 2 results in engine shutdown (1) or warning (0)
4585	OilLevelSupviseOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Enable / disable oil level monitoring
4586	OilLevLim1RiseOrFall Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Oil level monitoring: Monitoring for values above (1) or below (0) threshold 1
4587	OilLevLim1EcyOrWarn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Oil level monitoring: Value above or below threshold 1 results in engine shutdown (1) or warning (0)
4588	OilLevLim2RiseOrFall Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Oil level monitoring: Monitoring for values above (1) or below (0) threshold 2
4589	OilLevLim2EcyOrWarn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Oil level monitoring: Value above or below threshold 2 results in engine shutdown (1) or warning (0)
4590	TrOilPressSupviseOn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Enable / disable transmission oil pressure monitoring
4591	TrOilPLim1RiseOrFall Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Transmission oil pressure monitoring: Monitoring for values above (1) or below (0) threshold 1

	Name	Meaning
4592	TrOilPLim1EcyOrWarn	<i>XIOS</i>
	Level:	4
	Range:	0/1
	Page(s): Fehler! Textmarke nicht definiert.	Transmission oil pressure monitoring: Value above or below threshold 1 results in engine shutdown (1) or warning (0)
4593	TrOilPLim2RiseOrFall	<i>XIOS</i>
	Level:	4
	Range:	0/1
	Page(s): Fehler! Textmarke nicht definiert.	Transmission oil pressure monitoring: Monitoring for values above (1) or below (0) threshold 2

	Name	Meaning
4594	TrOilPLim2EcyOrWarn Level: 4 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS</i> Transmission oil pressure monitoring: Value above or below threshold 2 results in engine shutdown (1) or warning (0)
4600	ExcitationControlOn Level: 2 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Enable excitation control or excitation governing in locomotive operation
4600	PitchControlOn Level: 2 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation</i> Enable / disable adjustable propeller governing
4601	ExcitGovOrControl Level: 2 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Selection of excitation control/excitation governing 0 = Excitation control 1 = Excitation governing
4602	ExcitGovTrPowOrFuel Level: 2 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Selection of control loop for determining excitation signal 0 = Based on fuel 1 = Based on traction power
4603	ExcitGovFuelPossible Level: 2 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Indication that the diesel governor fuel is equivalent to power
4610	ExcitControlRampOn Level: 2 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Enable / disable ramp for excitation control
4620	DigSlideExcitCntrlOn Level: 2 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Enable / disable digital slide protection intervention in excitation signal
4621	AnaSlideExcitCntrlOn	<i>Locomotive operation</i>

Name		Meaning
Level:	2	Enable / disable analogue slide protection intervention in excitation signal
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert.	
4630	ExcitGovPICurveOn	<i>Locomotive operation</i>
Level:	3	Enable / disable PI correction characteristic for excitation governing
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert.	
4630	PitchGovPICurveOn	<i>Marine operation</i>
Level:	3	Enable / disable PI correction characteristic for adjustable propeller governing
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert.	
4635	ExcitationSetpPCOn	<i>Locomotive operation</i>
Level:	2	Enable /disable excitation value specification by PC
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
4635	PitchSetpPCOn	<i>Marine operation</i>
Level:	2	Enable / disable adjustable propeller value specification by PC
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert.	
4640	ExcitGovSetpRampOn	<i>Locomotive operation</i>
Level:	2	Enable / disable fuel or traction power ramp
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert.	
4640	PitchGovFuelRampOn	<i>Marine operation</i>
Level:	2	Enable / disable fuel ramp for adjustable propeller
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert.	
4642	PitchSpeedLimitOn	<i>Marine operation</i>
Level:	2	Enable / disable speed-dependent limitation for adjustable propeller
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert.	
4650	ExcitTempLimitOn	<i>Locomotive operation</i>
Level:	2	Enable / disable temperature dependent reduction of fuel quantity setpoint or traction power setpoint
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert.	
4655	ExcitBoostLimitOn	<i>Locomotive operation</i>

Name		Meaning
Level:	2	Enable / disable boost pressure dependent limitation of fuel quantity setpoint or traction power setpoint
Range:	0/1	
Page(s): Fehler! Textmarke nicht definiert.		
4656	ExcitSpeedLimitOn	<i>Locomotive operation</i>
Level:	2	Enable / disable speed-dependent limitation of excitation signal as control loop output value
Range:	0/1	
Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.		
4657	TractPowLimitVoltOn	<i>Locomotive operation</i>
Level:	2	Enable / disable speed-dependent limitation of traction power setpoint
Range:	0/1	
Page(s): Fehler! Textmarke nicht definiert.		
4658	TractPowLimitCurrOn	<i>Locomotive operation</i>
Level:	2	Enable / disable speed-dependent limitation of traction current setpoint
Range:	0/1	
Page(s): Fehler! Textmarke nicht definiert.		
4680	EGROn	
Level:	4	Enable / disable exhaust gas recirculation (on request)
Range:	0/1	
Page(s):		

	Name		Meaning
4681	EGRCoolTempSupviseOn		
	Level:	4	Enable / disable exhaust gas recirculation dependency
	Range:	0/1	on coolant temperature
	Page(s):		(on request)
4682	InletAirMapOn		
	Level:	4	Enable / disable inlet air throttle valve
	Range:	0/1	(on request)
	Page(s):		
4683	InlAirPowCurveOrMap		
	Level:	4	Setpoint for inlet air throttle valve derived from power-
	Range:	0/1	dependent curve (1) or from speed and fuel quantity
	Page(s):		dependent map (0) (on request)
4685	WasteGateMapOn		
	Level:	4	Enable /disable waste gate setpoint derived from speed
	Range:	0/1	and boost pressure dependent map
	Page(s):		(on request)
4686	BypassValveMapOn		
	Level:	4	Enable / disable bypass valve setpoint derived from
	Range:	0/1	speed and boost pressure dependent map
	Page(s):		(on request)
4690	SpeedLimitChAirTmpOn		<i>All except XIOS</i>
	Level:	4	Enable / disable charge air temperature dependent
	Range:	0/1	reduction of speed-dependent fuel quantity limitation
	Page(s):		Fehler! Textmarke nicht definiert.
4695	SpeedLimitExhTempOn		<i>All except XIOS</i>
	Level:	4	Enable / disable exhaust gas temperature dependent
	Range:	0/1	reduction of speed-dependent fuel quantity limitation
	Page(s):		Fehler! Textmarke nicht definiert.
4700	SpeedLimitOn		
	Level:	4	Enable / disable speed-dependent fuel quantity
	Range:	0/1	limitation
	Page(s):		Fehler! Textmarke nicht definiert.
4701	SpeedLimitTempOn SpeedLimitCoolTempOn		<i>All except XIOS</i>
	Level:	4	Enable / disable temperature dependent reduction of
	Range:	0/1	speed-dependent fuel quantity limitation
	Page(s):		Fehler! Textmarke nicht definiert.
4705	SpeedLimitOilTempOn		<i>All except XIOS</i>

Name		Meaning
Level:	4	Enable / disable oil temperature dependent reduction of speed-dependent fuel quantity limitation
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert.	
4705	FuelRedExhaustTempOn	
Level:	4	Enable / disable exhaust gas temperature dependent reduction of speed-dependent fuel quantity limitation
Range:	0/1	
Page(s):	98	
4706	FuelRedCoolTempOn	<i>XIOS</i>
Level:	4	Enable / disable coolant temperature dependent reduction of speed-dependent fuel quantity limitation
Range:	0/1	
Page(s):	96	
4707	FuelRedChAirTempOn	<i>XIOS</i>
Level:	4	Enable / disable charge air temperature dependent reduction of speed-dependent fuel quantity limitation
Range:	0/1	
Page(s):	97	
4708	FuelRedFuelTempOn	<i>XIOS</i>
Level:	4	Enable / disable fuel temperature dependent reduction of speed-dependent fuel quantity limitation
Range:	0/1	
Page(s):	97	
4709	FuelRedAmbPressOn	<i>XIOS</i>
Level:	4	Enable / disable ambient pressure dependent reduction of speed-dependent fuel quantity limitation
Range:	0/1	
Page(s):	98	
4710	BoostLimitOn	
Level:	4	Enable / disable boost pressure dependent fuel quantity limitation
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert.	
4720	ZeroFuelCurveOn	
Level:	4	Enable / disable zero delivery characteristic
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert.	
4721ff	FuelToActPosxCurveOn	
Level:	4	Enable / disable fuel quantity dependent actuator setpoint position for actuator x
Range:	0/1	
Page(s):	358	
4724	CheckFuelLimitOn	
Level:	4	Enable / disable indication that engine is operating at power limit
Range:	0/1	
Page(s):	Fehler! Textmarke nicht definiert.	
4750	FuelTempCorrOn	

Name		Meaning
Level:	4	Enable / disable fuel temperature dependent fuel
Range:	0/1	correction
Page(s):	Fehler! Textmarke nicht definiert.	
4800	<i>Hardware-specific configuration parameters are described in the associated subchapters</i>	
ff		
4810	StopImpulseOrSwitch	
Level:	2	Selection of function mode for engine stop:
Range:	0/1	0 = Engine stop active only as long as stop command is applied
Page(s):	252	1 = Engine stop active after single pulse until engine is stopped

Name		Meaning
4811	StopOpenOrClose	<i>DC 6</i>
Level:	2	Engine stop switch active if
Range:	0/1	0: Closed
Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	1: Open
		This function has a higher priority than the sign for 810 <i>FunctEngineStop</i> (RESET)
4849	StartImpulseOrSwitch	<i>DC 5, XIOS</i>
Level:	2	Selection of function mode for engine start switch:
Range:	0/1	0 = Engine start active only as long as start command is applied
Page(s):	Fehler! Textmarke nicht definiert., 251	1 = Engine start active after single switch pulse until engine is running
4851ff	DigitalOutx:Logic	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 9</i>
Level:	6	Logical link for multiple assignment to binary output x:
Range:	0...7F Hex or 80 Hex	DC 1-03: 1...3 DC 6: 1...2
Page(s):	Fehler! Textmarke nicht definiert.	DC 1-04: 1...5 DC 7: 1...7
		DC 2: 1...5 DC 9: 1
		DC 5: 1...11
		Bit = 0: AND function
		Bit = 1: OR function
		80 Hex: Flashing
4880ff	DigitalOutx:Prior	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 9</i>
Level:	6	Priority for multiple assignment to binary outputs
Range:	0...FF Hex	(x: see 4851 <i>DigitalOutx:Logic</i>)
Page(s):	Fehler! Textmarke nicht definiert.	Bit = 0: Output flashing
		Bit = 1: Output is continuously active
4900ff	ChanTyp...	
Level:	6	Configuration of input channel type for setpoint
Range:	0...10	adjusters and sensors
Page(s):	238	0 = Analogue
		1 = PWM
		2 = HZM-CAN periphery module
		3 = Custom CAN protocol
		4 = CANopen
		5 = DeviceNet
		6 = Modbus
		7 = SAE J1939
		8 = HZM-CAN customer module
		9 = HZM-CAN twin module
		10 = WAGO module
		13 = ICENI module
		14= HZM-CAN ALL
		15 = Frequency (XIOS only)
		16 = HZM-CAN add-on module
		Sensors see 2900 ff

Name		Meaning
4940	BoostSensorRelOrAbs	
Level:	4	Boost pressure sensor configuration
Range:	0/1	0: Absolute pressure sensor
Page(s):		1: Relative pressure sensor
4950ff	PEIx...	
Level:	6	Index of HZM-CAN periphery module in field 404
Range:	0...2	<i>CanPENodeNumber</i> , which provides the setpoint
Page(s):	238	adjuster or sensor Sensors see 2900 ff
5000ff	...SubstOrLast	
Level:	4	Selection of substitute value for setpoint adjusters and
Range:	0/1	sensors in case of error (0 = Last valid value, 1 =
Page(s):	245	Substitute value) Sensors see 2900 ff
5040ff	...HoldOrReset	
Level:	4	Selection whether error on setpoint adjuster /sensor
Range:	0/1	is to be cleared or retained after signal return
Page(s):	246	(0 = Error is cleared, 1 = Error is retained) Sensors see 2900 ff
5100	NoStoreSErrOn	
Level:	6	Suppresses the storage of errors in the error memory
Range:	0/1	until the control unit is restarted
Page(s):	379	
5101	CommAlarmWarnFlashOn	
Level:	2	Selection whether common alarm indicator should flash
Range:	0/1	when only warnings are output
Page(s):	374	
5102	CommonAlarmResetOn	
Level:	2	Selects whether the common alarm indication will be
Range:	0/1	briefly reset (edge change) when a new error is added
Page(s):	374	
5103	CommonAlarmResetBoth	
Level:	2	Selects whether the edge change (5102
Range:	0/1	<i>CommonAlarmResetOn</i> = 1) is also generated when an
Page(s):	374	error disappears (generally with every error change)
5150	EcyActuatorDiffxOn	<i>XIOS</i>
5151	Level:	6
5152	Range:	0/1
	Page(s):	360
		x = 1...3
5153	EcyActuatorDiffxOn	<i>Not XIOS</i>
5154	Level:	6
5155	Range:	0/1
	Page(s):	360
		x = 1...3

	Name	Meaning
5170	EcyCanBusOn Level: 6 Range: 0/1 Page(s):	<i>All except XIOS</i> Selects whether the CAN bus error is fatal (engine stop) <i>See basic information HZM-CAN DG 13 002-d</i>
5171	EcyCanCommOn Level: 6 Range: 0/1 Page(s):	<i>All except XIOS</i> Selects whether the CAN Comm error is fatal (engine stop) <i>See basic information HZM-CAN DG 13 002-d</i>
5184	EcyACFatalErrorOn Level: 6 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>All except XIOS</i> Selects whether fatal errors in one of the add-on modules is fatal for the speed governor (engine stop) <i>See basic information HZM-CAN DG 13 002-d</i>
5189	EcyPEFatalErrorOn Level: 6 Range: 0/1 Page(s): 366, Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>All except XIOS</i> Selects whether fatal errors in one of the periphery modules is fatal for the speed governor (engine stop) <i>See basic information HZM-CAN DG 13 002-d</i>
5210	SyncAnalogOrDigital Level: 2 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Synchronisation selection 0 = Digital potentiometer 1 = Analogue control signal (e.g., SyG 02)
5211	SyncInputOrHZM_SyG Level: 2 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 239	<i>DC 6</i> Synchronising signal type selection at multifunction port 2 0 = HZM SyG 02 1 = Device from other manufacturer (RESET)
5230	LoadControlOrPot	

	Name	Meaning
5234	OffsModeFuelOrSpeed	
	Level:	2 Selection of intervention mode with integrated power
	Range:	0/1 governor
	Page(s): Fehler! Textmarke nicht definiert.	0 = Speed offset for speed governor (island operation) 1 = Fuel offset (mains operation)
5235	PowerGovPIDCurveOn	
	Level:	2 Enable / disable PID characteristic for integrated power
	Range:	0/1 governor
	Page(s): Fehler! Textmarke nicht definiert.	
5239	SupvisePowerDiffOn	
	Level:	2 Enable / disable power difference monitoring in
	Range:	0/1 integrated power governor
	Page(s): Fehler! Textmarke nicht definiert.	
5241	PowerSetpRampOn	
	Level:	2 Enable / disable power setpoint ramp in integrated
	Range:	0/1 power governor
	Page(s): Fehler! Textmarke nicht definiert.	
5243	PowerSetpPCOn	
	Level:	2 Enable / disable setpoint specification by PC for
	Range:	0/1 integrated power governor
	Page(s): Fehler! Textmarke nicht definiert.	
5245	KnockControlOn	
	Level:	2 Enable / disable power reduction in integrated power
	Range:	0/1 governor in case of knocking
	Page(s): Fehler! Textmarke nicht definiert.	
5247	JetAssistOn	
	Level:	2 Enable / disable boost function
	Range:	0/1
	Page(s): Fehler! Textmarke nicht definiert.	
5250	ShipSetp2DigiOrAna	
	Level:	2 Selection of setpoint adjuster 2 for maritime application
	Range:	0/1 0 = Analogue signal
	Page(s): Fehler! Textmarke nicht definiert.	1 = Digital potentiometer
5251	TwinEngineEnable	
	Level:	2 Enable / disable master / slave mode in marine
	Range:	0/1 operation
	Page(s): Fehler! Textmarke nicht definiert., 413	

Name	Meaning
5252 NoDigPotAtSetp1Err	
Level:	2
Range:	0/1
Disable automatic selection of digital potentiometer in case of error on setpoint adjuster 1 in marine operation	
Page(s): Fehler! Textmarke nicht definiert., 246	

Name	Meaning
5253 ShipSetp1LeverOrPot	
Level: 2	Selection of type for setpoint adjuster 1 in marine
Range: 0/1	operation
Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	0: Without directional information (standard) 1: With directional information
5254 NeutralGearPoweredOn	
Level: 2	Selection of neutral gear type in marine operation
Range: 0/1	0: Unpowered
Page(s): Fehler! Textmarke nicht definiert.	1: Powered
5300 VelocityOn	<i>All except XIOS</i>
Level: 2	Enable / disable velocity measurement
Range: 0/1	
Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
5305 VelocityMaxGovOn	
Level: 2	Enable / disable maximum velocity governor for
Range: 0/1	velocity limitation
Page(s): Fehler! Textmarke nicht definiert.	
5309 VelocityStaticCorrOn	
Level: 2	Enable / disable static correction function in maximum
Range: 0/1	velocity governor
Page(s): Fehler! Textmarke nicht definiert.	
5315 CheckThrustOn	
Level: 2	Enable / disable thrust monitoring
Range: 0/1	
Page(s): Fehler! Textmarke nicht definiert.	
5350 LocoSetpoint1Mode	
Level: 2	Selection of setpoint adjuster 1 in locomotive operation
Range: 0/1	0 = Speed notch switch
Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	1 = Analogue signal 2 = Digital potentiometer
5351 DigSlideSpeedSetpOn	
Level: 2	Enable / disable slide protection intervention on speed
Range: 0/1	setpoint
Page(s): Fehler! Textmarke nicht definiert.	
5352 AnaSlideSpeedSetpOn	

Name		Meaning
Level:	2	Enable / disable slide protection intervention by
Range:	0/1	analogue slide signal
Page(s):	Fehler! Textmarke nicht definiert.	
<hr/>		
5353	NotchAssignOrBinary	
Level:	2	Selection whether speed notch corresponds directly to
Range:	0/1	binary value or is determined from a table.
Page(s):	Fehler! Textmarke nicht definiert., 251	

Name	Meaning
5360 CoolantTmpWarnIdleOn Level: 2 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS, locomotive operation</i> Enable / disable forced idle speed if coolant temperature warning 2 is triggered
5361 OilTempWarnIdleOn Level: 2 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS, locomotive operation</i> Enable / disable forced idle speed if oil temperature warning 2 is triggered
5362 CoolPressWarnIdleOn Level: 2 Range: 0/1 Page(s): Fehler! Textmarke nicht definiert.	<i>XIOS, locomotive operation</i> Enable / disable forced idle speed if coolant pressure warning 2 is triggered
5380ff ErrMaskPEActuator(x) Level: 1 Range: 0...3FFF Hex Page(s): 366	<i>Not XIOS</i> Mask for error states for actuators on currently connected HZM-CAN periphery modules that are important for the master x: Depending on application Bit = 0: Error is ignored Bit = 1: Error is observed <i>XIOS see 25030 ErrMaskPEActuator(x)</i>
5440ff ErrMaskPEModul(x) Level: 1 Range: 0...3FFF Hex Page(s): 366, Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>Not XIOS</i> Mask for error states for currently connected HZM-CAN periphery modules that are fatal for the master (engine shutdown) if 5189 <i>EcyPEFatalErrorOn</i> = 1 is set x = 0...2 Bit = 0: Error is ignored Bit = 1: Error is observed <i>XIOS see 25002 EcyMaskPEModul(x)</i>
5443ff ErrMaskACModul(x) Level: 1 Range: 0...3FFF Hex Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>Not XIOS</i> Mask for error states for currently connected HZM-CAN add-on modules that are fatal for the master (engine shutdown) if 5189 <i>EcyPEFatalErrorOn</i> = 1 is set x = 0...4 Bit = 0: Error is ignored Bit = 1: Error is observed <i>XIOS see 25006 EcyMaskACModul(x)</i>
5510 ff	<i>Hardware-specific configuration parameters are described in the associated subchapters</i>
5700 PositionerOn	

Name	Meaning
Level:	2 Control unit works as:
Range:	0/1 0 = Speed governor
Page(s): Fehler! Textmarke nicht definiert. , 365	1 = Positioner, see 1700 <i>PositionerSetpoint</i> (test mode, cannot be saved)

Name		Meaning
5701	PositionerMode	
	Level:	2 Selection of positioning mode for the actuator
	Range:	0...3 0 = Specification from 1700
	Page(s):	365 1 = Rectangular from 1700 ± 1701 2 = Delta from 1700 ± 1701 3 = Sinusoidal from 1700 ± 1701
5900	FeedbZeroPosAdjustOn ActxZeroPosAdjustOn	
5934	Level:	6 Enable / disable automatic actuator adjustment at each
5944	Range:	0/1 engine stop
	Page(s):	355 Accepted for only one actuator and only for the one to which the speed governor is assigned x = 1...3
5910	ActuatorxOn	
5930	Level:	6 Enable/disable servo loop for actuator x
5940	Range:	0/1 x = 1...3
	Page(s):	Fehler! Textmarke nicht definiert., 172, 351, 362
5911	Amplifier2QOr4Q	<i>All except DC 5, DC 7, DC 10</i>
5931	Level:	6 Amplifier operating principle
5941	Range:	0/1 0 = 4-quadrant (energizing in both directions)
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 351 1 = 2-quadrant (energizing towards 100 %)
5915	ServoxCurrentCorrOn	<i>DC 1, DC 2, DC 7, DC 10, XIOS</i>
5935	Level:	6 Enable / disable voltage dependent current correction
5945	Range:	0/1 of actuator current for actuator x
	Page(s):	363 x = 1...3
5916	ServoxCurrentPermOn	
5936	Level:	6 Enable / disable continuous energising of actuator x
5946	Range:	0/1 x = 1...3
	Page(s):	363
5920	ServoCurrentPCOn	
	Level:	6 Enable / disable actuator test mode to output the current
	Range:	0/1 from 1920 <i>ServoCurrentPC</i> to all enabled actuators as a
	Page(s):	362 test setpoint (test mode, cannot be saved)
5950	FeedbDigitalOrAnalog	<i>DC 2, DC 6, DC 9</i>
	Level:	6 Type of actuator feedback
	Range:	0/1 0 = DC voltage signal
	Page(s):	351 1 = coil feedback (RESET)
5951	FeedbxSlopeFallOrRise	
5961	Level:	6 Type of feedback signal slope for actuator x
5971	Range:	0/1 0 = Rising output signal with rising fuel quantity
	Page(s):	351 1 = Falling output signal with rising fuel quantity x = 1...3 (RESET)

Name		Meaning	
5952ff	FeedbackxLinearOn		
	Level:	6	Enable / disable linearisation characteristic for feedback
	Range:	0/1	from actuator x
	Page(s):	352	x = 1..3
14000ff			<i>Dual fuel parameters are described in the subchapter</i>
14900ff	ChanTypExhTempCylx		<i>XIOS</i>
	Level:	1	Configuration of input channel type for exhaust
	Range:	0...38	temperature sensors
	Page(s):	238	x = 1...24 Exhaust temperature sensors see 12900 ff Channel types see 4900 <i>ChanTyp...</i>
14950ff	PEIxExhTempCylx		<i>XIOS</i>
	Level:	6	Index of HZM-CAN periphery module in field 404
	Range:	0...2	<i>CanPENodeNumber</i> , which provides the exhaust
	Page(s):	238	temperature sensor x = 1..24, Exhaust temperature sensors see 12900 ff
15000	ExTmpCylxSubstOrLast		<i>XIOS</i>
	Level:	4	Selection of substitute value for exhaust temperature
	Range:	0/1	sensors in case of error (0 = Last valid value, 1 =
	Page(s):	246	Substitute value) x = 1..24, Exhaust temperature sensors see 2900 ff
15040	ExTmpCylxHoldOrReset		<i>XIOS</i>
	Level:	4	Selection whether error on exhaust temperature sensor
	Range:	0/1	is to be cleared or retained after signal return
	Page(s):	247	(0 = Error is cleared, 1 = Error is retained) x = 1...24, exhaust temperature sensors see 2900 ff
15400ff	Out1:Destination Outx:Destination		<i>DC 8, DC 11, DC 12, XIOS</i>
	Level:	6	Selection of target hardware for output x
	Range:	0...y	x = 1...120 or lower, application-specific,
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	by default total outputs in own hardware and all connected communication modules y = 0: Own hardware 2: HZM-CAN periphery module 10: WAGO module 13: ICENI module
15401ff	Out1:PEIx Outx:PEIx		<i>DC 8, DC 11, DC 12, XIOS</i>
	Level:	6	Index of associated periphery module in 404
	Range:	0...2	<i>CanPENodeNumber</i> if Outx:Destination = 2
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	x see 15400 <i>Outx:Destination</i>

	Name	Meaning
15402	Outx:OutputType	<i>DC 8, DC 11, DC 12, XIOS</i>
ff	Level: 6	Type of output on target hardware
	Range: 0...y	y =
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	0: Analogue output 1: PWM output 2: Binary output 3: Actuator output or solenoid valve control
15403	Outx:OutputNo	<i>DC 8, DC 11, DC 12, XIOS</i>
ff	Level: 6	Number of output corresponding to output type and target hardware
	Range: 0...x	x Application-specific, corresponds to maximum possible number for all output types on all possible target hardware variations
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
24000		<i>XIOS configuration parameters are described in the XIOS subchapter</i>
ff		
24810	ChanTyp...	
ff	Level: 6	Module type configuration if a switching function is received via a communication module
	Range: 0...15 or -15...+15	0..1: Not used
	Page(s): 248, 257, 258	2: HZM-CAN periphery module 3: Custom CAN protocol 4: CANopen 5: DeviceNet 6: Modbus 7: SAE J1939 8: HZM-CAN customer module 9: HZM-CAN twin module 10: WAGO module 13: ICENI module 14..15: Not used 16: HZM-CAN add-on module Switching functions see 2810 ff
24910	PEIx...	
ff	Level: 6	Index of HZM-CAN periphery module in field 404
	Range: 0...2	<i>CanPENodeNumber</i> , which provides the switching function
	Page(s): 248, 258	Switching functions see 2810 ff
25002	EcyMaskPEModul(x)	<i>XIOS</i>
ff	Level: 1	Mask for error states for currently connected HZM-CAN periphery modules that are fatal for the master (engine shutdown)
	Range: 0...3FFF Hex	x = 0...2
	Page(s): 366, Fehler! Textmarke nicht definiert.	Bit = 0: Error is ignored Bit = 1: Error is observed Not XIOS see 5440 <i>ErrMaskPEModul(x)</i>

25006	EcyMaskACModul(x)		<i>XIOS</i>
ff	Level:	1	Mask for error states for currently connected
	Range:	0...3FFF Hex	HZM-CAN add-on modules that are fatal for the master
	Page(s):	Fehler! Textmarke nicht definiert.	(engine shutdown)
			x = 0...4
			Bit = 0: Error is ignored
			Bit = 1: Error is observed
			Not XIOS see 5443 <i>ErrMaskACModul(x)</i>
25030	ErrMaskPEActuator(x)		<i>XIOS</i>
ff	Level:	1	Mask for error states for actuators on currently
	Range:	0...3FFF Hex	connected HZM-CAN periphery modules that are
	Page(s):	366	important for the master
			x: Depending on application
			Bit = 0: Error is ignored
			Bit = 1: Error is observed
			Not XIOS see 5380 <i>ErrMaskPEActuator(x)</i>

Tab. 192: Functions

28.3.1 DC 1

Here, the functions are described which are only available in DC 1 type control units due to the special hardware requirements.

No.	Name	Meaning
4801	PWMInOrDigitalIn11	
	Level:	6 Signal type of digital input channel 1
	Range:	0/1 0 = Binary input 11
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert. 1 = PWM input (RESET)
4802	PWMIn2OrDigitalIn12	<i>Not DC 1-04</i>
	Level:	6 Signal type of digital input channel 2
	Range:	0/1 0 = Binary input 12
	Page(s):	Fehler! Textmarke nicht definiert. 1 = PWM input 2 (RESET)
4803	PWMOut1OrDigitalOut1	
	Level:	6 Signal type of digital output channel 1
	Range:	0/1 0 = Binary output 1
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert. 1 = PWM output 1 (RESET)
4804	PWMOut2OrDigitalOut2	

No.	Name	Meaning
	Level:	6 Signal type of digital output channel 2
	Range:	0/1 0 = Binary output 2
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert. 1 = PWM output 2 (RESET)
4805	PWMOut3OrDigitalOut3	
	Level:	6 Signal type of digital output channel 3
	Range:	0/1 0 = Binary output 3
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert. 1 = PWM output 3 (RESET)

No.	Name	Meaning
4806	PWMIn1VelocityOrPWM	
	Level:	6 Signal type of digital input channel 1 if 4801
	Range:	0/1 PWMInOrDigitalIn1 = 1 (PWM)
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert. 0 = PWM input
		1 = Speed input (RESET)
4807	PWMIn2VelocityOrPWM	<i>Not DC 1-04</i>
	Level:	6 Signal type of digital input channel 2 if 4802
	Range:	0/1 PWMInOrDigitalIn2 = 1 (PWM)
	Page(s):	Fehler! Textmarke nicht definiert. 0 = PWM input
		1 = Speed input (RESET)
5512	AnalogInx_TempLin	
5522	Level:	4 Selection of linearisation curve for temperature sensor
5532	Range:	0...4 at analogue input x
5542	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert. x = 1...4
5590	TempInx_SensorType	
5595	Level:	4 Selection of linearisation curve for temperature input x
	Range:	0/1 (0 = Linearisation curve 1, 1 = Linearisation curve 2)
	Page(s):	Fehler! Textmarke nicht definiert. x = 1...2
5912	CheckBrakeOn	<i>Control unit with brake function</i>
	Level:	4 1: Brake status monitoring
	Range:	0/1
	Page(s):	Fehler! Textmarke nicht definiert.

Tab. 193: DC 1 functions

28.3.2 DC 2

Here, the functions are described which are only available in DC 2 type control units due to the special hardware requirements.

No.	Name	Meaning
4800	DigChannel1OutOrIn	
	Level:	6 Connection type of digital channel 1
	Range:	0/1 0 = Input
	Page(s):	Fehler! Textmarke nicht definiert. 1 = Output (RESET)
4801	DigChannel1PWMOrDIO	

No.	Name	Meaning
	Level:	6 Signal type of digital channel 1
	Range:	0/1 0 = Binary signal
	Page(s): Fehler! Textmarke nicht definiert.	1 = PWM signal (RESET)
4802	DigChannel2OutOrIn	
	Level:	6 Connection type of digital channel 2
	Range:	0/1 0 = Input
	Page(s): Fehler! Textmarke nicht definiert.	1 = Output (RESET)

No.	Name	Meaning
4803	DigChannel2PWMOOrDIO	
	Level:	6 Signal type of digital channel 2
	Range:	0/1 0 = Binary signal
	Page(s):	Fehler! Textmarke nicht definiert. 1 = PWM signal (RESET)
4804	DigChannel3OutOrIn	
	Level:	6 Connection type of digital channel 3
	Range:	0/1 0 = Input
	Page(s):	Fehler! Textmarke nicht definiert. 1 = Output (RESET)
4805	DigChannel3PWMOOrDIO	
	Level:	6 Signal type of digital channel 3
	Range:	0/1 0 = Binary signal
	Page(s):	Fehler! Textmarke nicht definiert. 1 = PWM signal (RESET)
4806	DigChannel4OutOrIn	
	Level:	6 Connection type of digital channel 4
	Range:	0/1 0 = Input
	Page(s):	Fehler! Textmarke nicht definiert. 1 = Output (RESET)
4807	DigChannel4PWMOOrDIO	
	Level:	6 Signal type of digital channel 4
	Range:	0/1 0 = Binary signal
	Page(s):	Fehler! Textmarke nicht definiert. 1 = PWM signal (RESET)
4809	DigChannel5PWMOOrDO	
	Level:	6 Signal type of digital channel 5
	Range:	0/1 0 = Binary
	Page(s):	Fehler! Textmarke nicht definiert. 1 = PWM signal (RESET)
5512	AnalogInx_TempLin	
5522	Level:	4 Selection of linearisation curve for temperature sensor
5532	Range:	0...4 at analogue input x
5542	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert. x = 1...4
5550	TempInx_SensorType	
5560	Level:	4 Selection of linearisation curve for temperature input 1
	Range:	0/1 (0 = Linearisation curve 1, 1 = Linearisation curve 2)
	Page(s):	Fehler! Textmarke nicht definiert. x = 1...2
5651	VoltOutxRange10Vor5V	
5656	Level:	4 Selection of range for voltage output x
	Range:	0/1 0 = 0...5 V
	Page(s):	Fehler! Textmarke nicht definiert. 1 = 0...10 V (RESET) x = 1...2

Tab. 194: DC 2 functions

28.3.3 DC 5

Here, the functions are described which are only available in DC 5 type control units due to the special hardware requirements.

No.	Name	Meaning
4800	PWMIn1OrDigitalIn1	
	Level:	6 Connection type of digital channel 1
	Range:	0/1 0 = Binary input 1
	Page(s): Fehler! Textmarke nicht definiert.	1 = PWM input 1 (RESET)
4801	FreqOut1OrDigOut8	
	Level:	6 Signal type of selectable channel OD8
	Range:	0/1 0 = Binary output 8
	Page(s): Fehler! Textmarke nicht definiert.	1 = Frequency output 1 (RESET)
4802	FreqOut2OrDigital	
	Level:	6 Connection type of selectable channel OD9
	Range:	0/1 0 = Binary output
	Page(s): Fehler! Textmarke nicht definiert.	1 = Frequency output 2 (RESET)
4803	PWMOut2OrDigOut9	
	Level:	6 Signal type for selectable channel OD9 if 4802
	Range:	0/1 <i>FreqOut2OrDigital</i> = 0
	Page(s): Fehler! Textmarke nicht definiert.	0 = Binary output 9 1 = PWM output 2 (RESET)
4804	PWMOut1OrDigOut10	
	Level:	6 Signal type of digital output channel
	Range:	0/1 0 = Binary output 10
	Page(s): Fehler! Textmarke nicht definiert.	1 = PWM output 1 (RESET)
5512	AIxWithSensorSupply	
5522	Level:	6 Selection of whether the sensor supply is used for
5532	Range:	0/1 analogue input x
5542	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	x = 1...4 (RESET)
5550	AnalogIn5_Type	
	Level:	4 Selection of signal type for analogue input 5
	Range:	1...2 1: 0...5 V
	Page(s): Fehler! Textmarke nicht definiert.	2: 0...25 mA (RESET)
5552	AnalogIn5_TempLin	

No.	Name	Meaning
	Level:	4 Selection of linearisation curve for temperature sensor
	Range:	0...4 at analogue input 5
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	
5570	TempInx_SensorType	
5575	Level:	4 Selection of linearisation curve for temperature input x
5580	Range:	0...3 x = 1...4
5585	Page(s): Fehler! Textmarke nicht definiert.	

No.	Name	Meaning
5640	AnalogOut_Type	
	Level:	4 Selection of signal type of analogue output
	Range:	3/4 3: 0...5 V
	Page(s): Fehler! Textmarke nicht definiert.	4: 0...25 mA (RESET)

Tab. 195: DC 5 functions

28.3.4 DC 6

Here, the functions are described which are only available in DC 6 type control units due to the special hardware requirements.

No.	Name	Meaning
4800	Port1Type	
	Level:	6 Signal type of multifunctional channel 1
	Range:	0/1 0 = Analogue
	Page(s): Fehler! Textmarke nicht definiert.	1 = PWM 2 = Binary (RESET)
4801	Port1OutOrIn	
	Level:	6 Connection type of multifunctional channel 1
	Range:	0/1 0 = Input
	Page(s): Fehler! Textmarke nicht definiert.	1 = Output (RESET)
4802	Port2Type	
	Level:	6 Signal type of multifunctional channel 2
	Range:	0/1 0 = Analogue
	Page(s): Fehler! Textmarke nicht definiert.	1 = PWM 2 = Binary (RESET)
4803	Port2OutOrIn	
	Level:	6 Connection type of multifunctional channel 2
	Range:	0/1 0 = Input
	Page(s): Fehler! Textmarke nicht definiert.	1 = Output (RESET)
4804	AnalogIn3OrDigIn3	
	Level:	6 Signal type of channel 3
	Range:	0/1 0 = Binary input 3
	Page(s): Fehler! Textmarke nicht definiert.	1 = Analogue input 3 (RESET)
4805	PUp2_PWMIn3OrDigIn5	
	Level:	6 Signal type of channel 5
	Range:	0/1 0 = Binary input 5
	Page(s): Fehler! Textmarke nicht definiert.	1 = Pickup2 or PWM input 3 If 1: Pickup 2 if 4002 <i>PickUp2On</i> = 1, Otherwise PWM input 3 (RESET)

No.	Name	Meaning
5510	AnalogInx_Type	
5520	Level:	2 Selection of signal type of analogue input x
5530	Range:	1...3 1: 0...5 V
	Page(s): Fehler! Textmarke nicht definiert.	2: 0...22.7 mA 3: 0...10 V (not with x = 3) x = 1...3 (RESET)
5513	AnalogInx_TempLin	
5523	Level:	4 Selection of linearisation curve for temperature sensor
5533	Range:	0...4 at analogue input x
	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	x = 1...3
5532	AI3WithSensorSupply	
	Level:	6 Selection of whether the sensor supply is used for
	Range:	0/1 analogue input 3
	Page(s): Fehler! Textmarke nicht definiert.	(RESET)
5540	TempIn_SensorType	
	Level:	2 Selection of linearisation curve for temperature sensor
	Range:	0/1 (0 = Linearisation curve 1, 1 = Linearisation curve 2)
	Page(s): Fehler! Textmarke nicht definiert.	

Tab. 196: DC 6 functions

28.3.5 DC 7

Here, the functions are described which are only available in DC 7 type control units due to the special hardware requirements.

No.	Name	Meaning
4800	F24_ANAIn1OrDigIn6	
	Level:	6 Signal type of input at vehicle connector pin 24
	Range:	0/1 0: Binary input 6
	Page(s): Fehler! Textmarke nicht definiert.	1: Analogue input 1 (RESET)
4801	M24_ANAIn2OrDigIn7	
	Level:	6 Signal type of input at engine connector pin 24
	Range:	0/1 0: Binary input 7
	Page(s): Fehler! Textmarke nicht definiert.	1: Analogue input 2 (RESET)
4802	F20_ANAIn3OrDigIn8	
	Level:	6 Signal type of input at vehicle connector pin 20
	Range:	0/1 0: Binary input 8
	Page(s): Fehler! Textmarke nicht definiert.	1: Analogue input 3 (RESET)

No.	Name	Meaning
4803	M21_ANAIn4OrDigIn9	
	Level:	6 Signal type of input at engine connector pin 21
	Range:	0/1 0: Binary input 9
	Page(s): Fehler! Textmarke nicht definiert.	1: Analogue input 4 (RESET)

No.	Name	Meaning
4804	F18_PWMIn1OrDigIn1	
	Level:	6 Signal type of input at vehicle connector pin 18
	Range:	0/1 0: Binary input 1
	Page(s): Fehler! Textmarke nicht definiert.	1: PWM input 1 (RESET)
4805	F21_PWMIn2OrDigIn2	
	Level:	6 Signal type of input at vehicle connector pin 21
	Range:	0/1 0: Binary input 2
	Page(s): Fehler! Textmarke nicht definiert.	1: PWM input 2 (RESET)
4806	F07_VELOInOrDigIn10	
	Level:	6 Signal type of input at vehicle connector pin 7
	Range:	0/1 0: Binary input 10
	Page(s): Fehler! Textmarke nicht definiert.	1: Speed input (RESET)
4807	F05_PWMOut1OrDigOut1	
	Level:	6 Signal type of output at vehicle connector pin 5
	Range:	0/1 0: Binary output 1
	Page(s): Fehler! Textmarke nicht definiert.	1: PWM output 1 (RESET)
4808	M07_PWMOut2OrDigOut6	
	Level:	6 Signal type of output at engine connector pin 7
	Range:	0/1 0: Binary output 6
	Page(s): Fehler! Textmarke nicht definiert.	1: PWM output 2 (RESET)
4809	F16SPEEDOutOrDigOut7	
	Level:	6 Signal type of output at vehicle connector pin 16
	Range:	0/1 0: Binary output 7
	Page(s): Fehler! Textmarke nicht definiert.	1: Speed output (RESET)
5512	AIxWithSensorSupplyy	
5522	Level:	6 Selection of whether the sensor supply y is used for
5532	Range:	0/1 analogue input x
5542	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	x = 1...4, y = 1, 2, 4 (RESET)
5550	TempInx_SensorType	
5555	Level:	6 Selection of linearisation curve for temperature sensor
5560	Range:	0...3 x = 1...3
	Page(s): Fehler! Textmarke nicht definiert.	

Tab. 197: DC 7 functions

28.3.6 DC 8

Here, the functions are described which are only available in DC 8 type control units due to the special hardware requirements.

No.	Name	Meaning
5542	AIxWithSensorSupply	
5552	Level:	6 Selection of whether the 5V sensor supply is used for
5562	Range:	0/1 analogue input x
	Page(s): Fehler! Textmarke nicht definiert.	x = 4...6
5570	TempInx_SensorType	
5580	Level:	6 Selection of linearisation curve for temperature sensor x
	Range:	0...3 x = 1...2
	Page(s): Fehler! Textmarke nicht definiert.	
5608ff	SensorSupplyx:On	
	Level:	6 Selection of whether the 24 V sensor supply x is used
	Range:	0/1 x = 1...2
	Page(s): Fehler! Textmarke nicht definiert.	

Tab. 198: DC 8 functions

28.3.7 DC 9

Here, the functions are described which are only available in DC 9 type control units due to the special hardware requirements.

No.	Name	Meaning
4804	AnalogIn1OrDigIn1	
	Level:	6 Signal type of channel 1
	Range:	0/1 0 = Binary input 1
	Page(s): Fehler! Textmarke nicht definiert.	1 = Analogue input 1 (RESET)
4805	PUp2_PWMInOrDigIn3	
	Level:	6 Signal type of channel 3
	Range:	0/1 0 = Binary input 3
	Page(s): Fehler! Textmarke nicht definiert.	1 = Pickup 2 or PWM input If 1: Pickup 2 if 4002 <i>PickUp2On</i> = 1, Otherwise PWM input (RESET)
4806	AnalogIn2OrDigIn4	
	Level:	6 Signal type of channel 4
	Range:	0/1 0 = Binary input 4
	Page(s): Fehler! Textmarke nicht definiert.	1 = Analogue input 2 (RESET)

No.	Name	Meaning
5510	AnalogIn1_Type	
	Level:	6 Selection of signal type of analogue input 1
	Range:	1/2 1: 0..5 V
	Page(s): Fehler! Textmarke nicht definiert.	2: 0..22.7 mA (RESET)

No.	Name	Meaning
5512	AI1WithSensorSupply	
	Level:	2 Selection of whether the 5V sensor supply is used for
	Range:	0/1 analogue input 1
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert. (RESET)

Tab. 199: DC 9 functions

28.3.8 DC 10

Here, the functions are described which are only available in DC 10 type control units due to the special hardware requirements.

No.	Name	Meaning
4800	Port1AnalogOrDigital	
	Level:	6 Signal type of multifunctional channel 1
	Range:	0/1 0 = Binary
	Page(s):	Fehler! Textmarke nicht definiert. 1 = Analogue (RESET)
4802	Port2AnalogOrDigital	
	Level:	6 Signal type of multifunctional channel 2
	Range:	0/1 0 = Binary input
	Page(s):	Fehler! Textmarke nicht definiert. 1 = Analogue input or output (RESET)
4803	Port2OutOrIn	
	Level:	6 Connection type of multifunctional channel 2, if used as
	Range:	0/1 analogue
	Page(s):	Fehler! Textmarke nicht definiert. 0 = Analogue input 1 = Analogue output (RESET)
4805	Port3AnalogOrDigital	
	Level:	6 Signal type of multifunctional channel 3 (input)
	Range:	0/1 0 = Binary
	Page(s):	Fehler! Textmarke nicht definiert. 1 = Analogue (RESET)
4806	Port4AnalogOrDigital	
	Level:	6 Signal type of multifunctional channel 4 (input)
	Range:	0/1 0 = Binary
	Page(s):	Fehler! Textmarke nicht definiert. 1 = Analogue (RESET)
4807	Port5Type	

No.	Name	Meaning
	Level:	6 Signal type of multifunctional channel 5 (input)
	Range:	0...4 0 = Analogue
	Page(s): Fehler! Textmarke nicht definiert.	1 = PWM
		2 = Binary
		3 = Pickup 2
		4 = Temperature (RESET)

No.	Name	Meaning
4808	Port5_PullUp5VOn	
	Level:	6 Signal type of multifunctional channel 5
	Range:	0/1 (RESET)
	Page(s):	Fehler! Textmarke nicht definiert.
4809	Port6Type	
	Level:	6 Signal type of multifunctional channel 6 (input)
	Range:	0...2 0 = Analogue
	Page(s):	Fehler! Textmarke nicht definiert. 1 = Binary
		2 = Pickup 1 (RESET)
5510	AnalogIn1_CurrOrVolt	
	Level:	2 Selection of signal type of analogue input 1
	Range:	0/1 0: 0..5 V
	Page(s):	Fehler! Textmarke nicht definiert. 1: 0..22.59 mA (RESET)
5520	AnalogIn2_10Vor5V	
	Level:	2 Selection of signal type of analogue input 2
	Range:	0/1 0: 0..5 V
	Page(s):	Fehler! Textmarke nicht definiert. 1: 0..10V (RESET)
5570	TempLin_SensorType	
	Level:	4 Selection of linearisation curve for temperature input:
	Range:	0...5 0: PT1000
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert. 1: Ni1000
		2: PT200
		3: Bosch DS-S2-TF (NTC)
		4: Jumo 2K3A1-25 (NTC)
		5: Freely configurable

Tab. 200: DC 10 functions

28.3.9 DC 11

Here, the functions are described which are only available in DC 11 type control units due to the special hardware requirements.

No.	Name	Meaning
4800	Port1_Type	
	Level:	6 Signal type of multifunctional channel 1
	Range:	0...2 0 = Analogue
	Page(s):	Fehler! Textmarke nicht definiert. 1 = PWM
		2 = Binary (RESET)
4801	Port1_OutputOrInput	

No.	Name	Meaning
	Level:	6 Connection type of multifunctional channel 1
	Range:	0/1 0 = Input
	Page(s): Fehler! Textmarke nicht definiert.	1 = Output (RESET)

No.	Name	Meaning
4802	Port2_Type	
	Level:	6 Signal type of multifunctional channel 2
	Range:	0...2 0 = Analogue
	Page(s): Fehler! Textmarke nicht definiert.	1 = PWM 2 = Binary (RESET)
4803	Port2_OutputOrInput	
	Level:	6 Connection type of multifunctional channel 2
	Range:	0/1 0 = Input
	Page(s): Fehler! Textmarke nicht definiert.	1 = Output (RESET)
4804	Port3_InputType	
	Level:	6 Signal type of multifunctional channel 3
	Range:	0...3 Input only
	Page(s): Fehler! Textmarke nicht definiert.	0 = Analogue 1 = PWM 2 = Binary 3 = Pickup 2 (if 4002 <i>PickUp2On</i> = 1) (RESET)
4805	Port4_InputAnaOrDig	
	Level:	6 Signal type of input channel 4
	Range:	0/1 0 = Binary
	Page(s): Fehler! Textmarke nicht definiert.	1 = Analogue (RESET)
4806	Port5_InputAnaOrDig	
	Level:	6 Signal type of input channel 5
	Range:	0/1 0 = Binary
	Page(s): Fehler! Textmarke nicht definiert.	1 = Analogue (RESET)
5510	AnalogInx_Type	
5520	Level:	2 Selection of signal type of analogue input x
5550	Range:	1...3 1: 0..5 V
	Page(s): Fehler! Textmarke nicht definiert.	2: 0...22.7 mA 3: 0...10 V (not with x = 5) x = 1, 2, 5 (RESET)
5512	AIxWithSensorSupplyy	
5522	Level:	2 Selection of whether the sensor supply y is used for
5532	Range:	0/1 analogue input x
5542	Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	x = 1...3, y = 1, 2 (RESET)
5513	Port1Resistor	
	Level:	2 Selection of whether a resistor is to be connected at
	Range:	0...2 analogue input 1
	Page(s): Fehler! Textmarke nicht definiert.	0 = No resistor used 1 = Select HEINZMANN LMG at this port 2 = Pull-up resistor (RESET)

No.	Name	Meaning
5523	Port2Resistor	
	Level:	2 Selection of whether a resistor is to be connected at
	Range:	0...2 analogue input 2
	Page(s):	Fehler! Textmarke nicht definiert. 0 = No resistor used
		1 = Select HEINZMANN SyG at this port
		2 = Pull-up resistor (RESET)
5533	PortxResistor	
5543	Level:	2 Selection of whether a resistor is to be connected at
	Range:	0...2 analogue input x
	Page(s):	Fehler! Textmarke nicht definiert. 0 = No resistor used
		1 = Pull-down resistor
		2 = Pull-up resistor
		x = 3..4 (RESET)

Tab. 201: DC 11 functions

28.3.10 XIOS

Here, the functions are described which are only available in type XIOS control units due to the special hardware requirements.

No.	Name	Meaning
4030	PickUp1PortNo	
	Level:	4 Port that the first speed pickup is connected to
	Range:	89...105 (port 89, 90, 104 or 105 possible) (RESET)
	Page(s):	301
4031	PickUp2PortNo	
	Level:	4 Port that the second speed pickup is connected to
	Range:	89...105 (port 89, 90, 104 or 105 possible) (RESET)
	Page(s):	301
14400	AmplifierxOn	
14405	Level:	6 Activate / deactivate current output for current
14410	Range:	0/1 controlled valve on hydraulic adjusters
	Page(s):	368 x = 1...3
14403	AmplifierxCurrDiffCheckOn	
14408	Level:	6 Activate / deactivate differential current monitoring of
14413	Range:	0/1 current output for current controlled valve on hydraulic
	Page(s):	369 adjusters
		x = 1...3
14404	EcyAmplifierxErrorOn	
14409	Level:	6 Selects whether a monitoring error on the current
14414	Range:	0/1 controlled valve on hydraulic adjusters is fatal for the
	Page(s):	370 speed governor (engine stop)
		x = 1...3

24000	P001_(SL1.1)_Config		
...			
24116	P117_(MD.AI8)_Config		
	Level:	1	Configuration of the ports
	Range:	0...39	
	Page(s):	295, 297, 303	

Tab. 202: Functions XIOS

28.3.11 Dual fuel

↑ 16 Speed control for dual fuel engines (ARTEMIS) and separate ARTEMIS manuals

No.	Name	Meaning
14000	DualFuelOn	
	Level:	4 Switching on/off of dual fuel operation type
	Range:	0/1
	Page(s):	173
14002	CheckChAirTmpInRange	
	Level:	4 Charge air temperature must be in permissible range for
	Range:	0/1 dual fuel operation
	Page(s):	190
14005	CheckGasPressInRange	
	Level:	4 Gas pressure must be in permissible range for dual fuel
	Range:	0/1 operation
	Page(s):	194
14010	CheckSpeedInRange	
	Level:	4 Speed must be in permissible range for dual fuel
	Range:	0/1 operation
	Page(s):	195
14012	CheckDieslAbovePilot	
	Level:	4 Speed must be in permissible range for dual fuel
	Range:	0/1 operation
	Page(s):	196
14013	CheckPowerInRange	
	Level:	4 Power must be in permissible range for dual fuel
	Range:	0/1 operation
	Page(s):	185, 226
14014	CheckKnocking	
	Level:	4 Enable / disable knock monitoring
	Range:	0/1
	Page(s):	199

No.	Name	Meaning
14015	CheckOilPressInRange	
	Level:	4 Oil pressure must be in permissible range for dual fuel
	Range:	0/1 operation
	Page(s):	192
14016	CheckBoostPrInRange	
	Level:	4 Boost pressure must be in permissible range for dual
	Range:	0/1 fuel operation
	Page(s):	193
14017	CheckExhTempInRange	
	Level:	4 Exhaust temperature must be in permissible range for
	Range:	0/1 dual fuel operation
	Page(s):	186
14020	CheckCoolTempInRange	
	Level:	4 Coolant temperature must be in permissible range for
	Range:	0/1 dual fuel operation
	Page(s):	189
14021	GasFuelToActPosCrvOn	
	Level:	4 Enable / disable linearisation characteristic for gas
	Range:	0/1 actuator setpoint (gas fuel quantity)
	Page(s):	170
14023	GasFuelLimitSpeedOn	
	Level:	4 Enable / disable speed-dependent gas fuel quantity
	Range:	0/1 limitation
	Page(s):	220, 224
14027	GasFuelLimitPowerOn	<i>Generator operation, locomotive operation</i>
	Level:	4 Enable / disable power-dependent gas fuel quantity
	Range:	0/1 limitation
	Page(s):	221, 226
14028	GasTempFactorOn	
	Level:	4 Enable / disable gas temperature dependent correction
	Range:	0/1 of gas fuel quantity
	Page(s):	231
14029	GasPressFactorOn	
	Level:	4 Enable / disable gas pressure dependent correction of
	Range:	0/1 gas fuel quantity
	Page(s):	231
14050	DieselPowerCurveOn	
	Level:	4 Determination of current power proportion for diesel
	Range:	0/1 and gas
	Page(s):	167
14055	PilotAbsMinCurveOn	
	Level:	4 Enable / disable the speed-dependent absolute minimum
	Range:	0/1 ignition oil quantity
	Page(s):	164

No.	Name	Meaning
14057	GasOff@AriadneFatal	
	Level:	4 Switch off gas if Ariadne reports fatal error because
	Range:	0/1 knock monitoring is not possible
	Page(s):	199
14070	GasPowGovPIDCurveOn	<i>Integrated power governor</i>
	Level:	4 Enable / disable PID curve for integrated power
	Range:	0/1 governor in dual fuel operation
	Page(s):	214
14080	CheckGasValveReady	<i>Gas section test</i>
	Level:	4 Enable / disable gas section test
	Range:	0/1
	Page(s):	184
14090	GasActuatorOn	<i>DC I-04</i>
	Level:	4 Enable / disable second actuator for gas setpoint
	Range:	0/1
	Page(s):	170
14091	GasDoubleActuatorOn	<i>DC I-04</i>
	Level:	4 Enable / disable third actuator parallel to second
	Range:	0/1 actuator for gas setpoint
	Page(s):	170
14100	GasReductChAirTmpOn	
	Level:	4 Enable / disable charge air temperature dependent
	Range:	0/1 reduction of gas limitation
	Page(s):	228
14103	GasReductExhTempOn	
	Level:	4 Enable / disable exhaust temperature dependent
	Range:	0/1 reduction of gas limitation
	Page(s):	229
14106	GasReductCoolTempOn	
	Level:	4 Enable / disable coolant temperature dependent
	Range:	0/1 reduction of gas limitation
	Page(s):	230

Tab. 203: Dual fuel functions (general)

28.3.12 ICENI

↑23.7 CAN protocol ^{ICENI}® (CANopen)

No.	Name	Meaning
25550	IceniCommOn	
	Level:	4 Enable / disable communication with ICENI modules
	Range:	0/1 (RESET)

Tab. 204: ICENI functions

28.3.13 WAGO

↑23.6 CAN protocol WAGO® (CANopen) and AXIOMATIC® (CANopen)

No.	Name	Meaning
25700	WagoCommOn	
	Level:	4 Enable / disable communication with WAGO modules
	Range:	0/1 (RESET)

Tab. 205: WAGO functions

28.3.14 CANopen

↑23.4 CAN protocol CANopen and CANopen, Manual DG 06 002-e

No.	Name	Meaning
25750	CanOpenOn	
	Level:	4 Enable / disable CANopen communication
	Range:	0/1 (RESET)
25753	CanOp:EMCYOn	
	Level:	4 Enable / disable sending of EMCY telegram
	Range:	0/1 (RESET)
25770	CanOp:RPDOxOn	<i>If only 4 RPDOS are possible</i>
ff	Level:	4 Enable / disable RPDO telegrams
	Range:	0/1 x = 1...4 <i>See 25790 if more than 4 RPDOS are possible</i> (RESET)
25775	CanOp:TPDOxOn	
ff	Level:	4 Enable / disable TPDO telegrams
	Range:	0/1 x = 1...16 (RESET)

No.	Name	Meaning
25790	CanOp:RPDOxOn	<i>If more than 4 RPDOs are possible</i>
ff	Level:	4 Enable / disable RPDO telegrams
	Range:	0/1 x = 1...10
		<i>See 25770 if only 4 RPDOs are possible</i> (RESET)

Tab. 206: CANopen functions

28.3.15 Modbus

↑23.8 Serial protocol Modbus and Manual DG 05 002-e

No.	Name	Meaning
25800	ModbusOn	
	Level:	4 Enable / disable Modbus communication
	Range:	0/1 (RESET)
25801	Modb:ParityBitOn	
	Level:	4 Selection of transmission type
	Range:	0/1 0 = Without parity bit 1 = With parity bit (RESET)
25802	Modb:ParityOddOrEven	
	Level:	4 Selection of parity when parity bit is enabled
	Range:	0/1 0 = Even parity 1 = Odd parity (RESET)
25803	Modb:OneOrTwoStopBit	
	Level:	4 Selection of stop bits
	Range:	0/1 0 = Two stop bits 1 = One stop bit (RESET)

Tab. 207: Modbus functions

28.3.16 DeviceNet

↑23.5 CAN protocol DeviceNet and Manual DG 06 003-e

No.	Name	Meaning
25850	DeviceNetOn	
	Level:	4 Enable / disable DeviceNet communication
	Range:	0/1 (RESET)

Tab. 208: DeviceNet functions

28.3.17 SAE J1939

↑ 23.3 CAN protocol SAE J1939 and Manual DG 06 004-e

No.	Name	Meaning
25900	SAE_J1939On	
	Level:	4 Enable / disable SAE J1939 communication
	Range:	0/1 (RESET)
25901	J1939:RxMsgTSC1_xOn	<i>TSC1</i>
ff	Level:	4 Enable / disable "Torque/Speed Control 1" receiving
	Range:	0/1 telegrams
		x = 1..4 (Standard 1) (RESET)
25902	J1939:RxMsgSNSOn	<i>ATI0G1</i>
	Level:	4 Enable / disable "Aftertreatment 1 Outlet Gas 1"
	Range:	0/1 receiving telegram (RESET)
25903	J1939:RxMsgEBC1On	<i>EBC1</i>
	Level:	4 Enable / disable "Electronic Brake Controller 1"
	Range:	0/1 receiving telegram (RESET)
25905	J1939:RxMsgEngTempOn	<i>ET1</i>
	Level:	4 Enable / disable "Engine Temperature 1" receiving
	Range:	0/1 telegram (RESET)
25906	J1939:RxMsgEngF1On	<i>EFL/P1</i>
	Level:	4 Enable / disable "Engine Fluid Level/Pressure 1"
	Range:	0/1 receiving telegram (RESET)
25907	J1939:RxMsgTFluidsOn	<i>TRF1</i>
	Level:	4 Enable / disable "Transmission Fluids 1" receiving
	Range:	0/1 telegram (RESET)
25908	J1939:RxMsgInlExhOn	<i>IC1</i>
	Level:	4 Enable / disable "Inlet/Exhaust Conditions 1" receiving
	Range:	0/1 telegram (RESET)
25910	J1939:RxMsgPTOOn	<i>PTO</i>
	Level:	4 Enable / disable "Power Takeoff Information" receiving
	Range:	0/1 telegram (RESET)
25915	J1939:RxMsgRequestOn	<i>RQST</i>
	Level:	4 Enable / disable request telegram(RESET)
	Range:	0/1
25916	J1939:RxClearErrorOn	<i>DM11</i>
	Level:	4 Enable / disable "Diagnostic Data Clear/Reset for
	Range:	0/1 Active DTCs" receiving telegram (RESET)
25917	J1939:RxClrErrMemOn	<i>DM03</i>
	Level:	4 Enable / disable "Diagnostic Data Clear/Reset for
	Range:	0/1 Previously Active DTCs" receiving telegram (RESET)

No.	Name	Meaning
25930	J1939:TxMsgEEC1On	<i>EEC1</i>
	Level:	4 Enable / disable "Electronic Engine Controller 1"
	Range:	0/1 receiving telegram (RESET)
25931	J1939:TxMsgEEC2On	<i>EEC2</i>
	Level:	4 Enable / disable "Electronic Engine Controller 2"
	Range:	0/1 receiving telegram (RESET)
25932	J1939:TxMsgEEC3On	<i>EEC3</i>
	Level:	4 Enable / disable "Electronic Engine Controller 3"
	Range:	0/1 receiving telegram (RESET)
25933	J1939:TxMsgEngTempOn	<i>ETI</i>
	Level:	4 Enable / disable "Engine Temperature 1" sending
	Range:	0/1 telegram (RESET)
25934	J1939:TxMsgFLevelOn	<i>EFL/P1</i>
	Level:	4 Enable / disable "Engine Fluid Level/Pressure 1"
	Range:	0/1 sending telegram (RESET)
25935	J1939:TxMsgTFluidsOn	<i>TRF1</i>
	Level:	4 Enable / disable "Transmission Fluids 1" sending
	Range:	0/1 telegram (RESET)
25936	J1939:TxMsgAmbientOn	<i>AMB</i>
	Level:	4 Enable / disable "Ambient Conditions" sending
	Range:	0/1 telegram (RESET)
25937	J1939:TxMsgInlExhOn	<i>ICI</i>
	Level:	4 Enable / disable "Inlet/Exhaust Conditions 1" sending
	Range:	0/1 telegram (RESET)
25938	J1939:TxMsgCCVehSpOn	<i>CCVSI</i>
	Level:	4 Enable / disable "Cruise Control/Vehicle Speed 1"
	Range:	0/1 sending telegram (RESET)
25939	J1939:TxMsgEngConfOn	<i>ECI</i>
	Level:	4 Enable / disable "Engine Configuration 1" sending
	Range:	0/1 telegram (RESET)
25942	J1939:TxMsgEngInfoOn	<i>EII</i>
	Level:	4 Enable / disable "Engine Information 1" sending
	Range:	0/1 telegram (RESET)
25944	J1939:TxMsgVEP1On	<i>VEP1</i>
	Level:	4 Enable / disable "Vehicle Electrical Power 1" sending
	Range:	0/1 telegram (RESET)
25945	J1939:TxMsgEngHourOn	<i>HOURS</i>
	Level:	4 Enable / disable "Engine Hours, Revolutions" sending
	Range:	0/1 telegram (RESET)
25946	J1939:TxMsgSoftwIdOn	<i>SOFT</i>
	Level:	4 Enable / disable "Software Identification" sending
	Range:	0/1 telegram (RESET)

No.	Name	Meaning
25947	J1939:TxMsgDM1On	<i>DM01</i>
	Level:	4 Enable / disable “Active Diagnostic Trouble Codes”
	Range:	0/1 sending telegram (RESET)
25948	J1939:TxMsgDM2On	<i>DM02</i>
	Level:	4 Enable / disable “Previously Active Diagnostic Trouble
	Range:	0/1 Codes” sending telegram (RESET)
25949	J1939:TxMsgDM4On	<i>DM04</i>
	Level:	4 Enable / disable “Freeze Frame Parameters” sending
	Range:	0/1 telegram (RESET)

Tab. 209: SAE J1939 functions

28.3.18 HZM-CAN customer module

↑ 23.2 CAN protocol HZM-CAN customer module and Manual DG 05007-e

No.	Name	Meaning
25960	CMTxTelxOn	
ff	Level:	4 Enable / disable sending telegram x
	Range:	0/1 x = 20...40, 50...58 and 41...45 (all except XIOS) 141...145 (XIOS only) (RESET)

Tab. 210: HZM-CAN customer module functions

28.4 List 4: Characteristics and maps

In the following tables, two or three-dimensional fields that belong together (x and y or x, y and z) are shown together in one colour.

	Name	Meaning
6000ff	MisfireWarn:P(x) Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert., 243	Load values for misfire warning
6010ff	MisfireWarn:nVar(x) Level: 4 Range: 0...65.535 Page(s): Fehler! Textmarke nicht definiert.	Speed variation values for misfire warning
6020ff	MisfireEcy:P(x) Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	Load grid points for misfire emergency shutdown
6030ff	MisfireEcy:nVar(x) Level: 4 Range: 0...65.535 Page(s): Fehler! Textmarke nicht definiert.	Speed variation values for misfire emergency shutdown
6050ff	AngleCylinderx Level: 4 Range: 0...720.0°crank Page(s): Fehler! Textmarke nicht definiert.	TDC angle of cylinders
6100ff	PIDMap:n(x) PIDMapSpGov:n(x) Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>If integrated power governor is available</i> Speed grid points for speed governor stability map
6150ff	PIDMap:f(x) PIDMapSpGov:f(x) Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>If integrated power governor is available</i> Fuel quantity values for the speed governor stability map
6200ff	PIDMap:Corr(x) PIDMapSpGov:Corr(x)	<i>If integrated power governor is available</i>

Name		Meaning
Level:	2	Correction values for the speed governor stability map
Range:	0...400 %	
Page(s): Fehler! Textmarke nicht definiert.		
<hr/>		
6300ff	PICrvPowGov:P(x)	
Level:	2	Power grid points for PID characteristic for integrated power governor for diesel and dual fuel operation
Range:	0...100 %	
Page(s): Fehler! Textmarke nicht definiert., 214, 640		

Name	Meaning
6310ff PICrvPowGov:Corr(x) Level: 2 Range: 0...400 % Page(s): Fehler! Textmarke nicht definiert.	Correction values for PID characteristic for integrated power governor for diesel operation
6350ff PIDMap:P(x) PIDMapSpGov:P(x) Level: 2 Range: 0...100 % or 0...y kW Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 243	<i>If integrated power governor is available</i> Power grid points for speed governor stability map y: Depending on application Speed grid points in 6100, correction values in 6200
6400ff BoostLimit:p(x) Level: 4 Range: 0...5 bar Page(s): Fehler! Textmarke nicht definiert.	Boost pressure grid points for boost pressure dependent fuel quantity limitation
6420ff BoostLimit:f(x) Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	Fuel quantity values for boost pressure dependent fuel quantity limitation
6440ff ExcitBoostLimit:p(x) Level: 2 Range: 0...5 bar Page(s): Fehler! Textmarke nicht definiert.	Boost pressure grid points for boost pressure dependent setpoint limitation in excitation control loop
6460ff ExcitBoostLimit:f(x) Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	Fuel quantity values for boost pressure dependent setpoint limitation in excitation control loop
6480ff JetAstBoostDiff:f(x) Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	Fuel quantity grid points for fuel quantity dependent minimum boost pressure for boost function
6490ff JetAstBoostDiff:p(x) Level: 2 Range: 0...5 bar Page(s): Fehler! Textmarke nicht definiert.	Boost pressure values for fuel quantity dependent minimum boost pressure for boost function
6500ff OilPressWarn:n(x)	

Name		Meaning
Level:	4	Speed grid points for oil pressure warning characteristic
Range:	0...4000 rpm	
Page(s):	Fehler! Textmarke nicht definiert.	

6520ff OilPressWarn:p(x)

Level:	4	Oil pressure values for oil pressure warning
Range:	0...10 bar	characteristic
Page(s):	Fehler! Textmarke nicht definiert.	

	Name	Meaning
6530ff	CoolPressLimit1:n(x)	<i>XIOS</i>
	CoolPressWarn:n(x)	<i>Others</i>
	Level:	4
	Range:	0...4000 rpm
	Page(s):	Fehler! Textmarke nicht definiert.
6540ff	CoolPressLimit1:p(x)	<i>XIOS</i>
	CoolPressWarn:p(x)	<i>Others</i>
	Level:	4
	Range:	0...5 bar
	Page(s):	Fehler! Textmarke nicht definiert.
6550ff	OilPressEcy:n(x)	
	Level:	4
	Range:	0...+4000 rpm
	Page(s):	Fehler! Textmarke nicht definiert.
6570ff	OilPressEcy:p(x)	
	Level:	4
	Range:	0...10 bar
	Page(s):	Fehler! Textmarke nicht definiert.
6580ff	CoolPressLimit2:n(x)	<i>XIOS</i>
	CoolPressIdle:n(x)	<i>Others</i>
	Level:	4
	Range:	0...4000 rpm
	Page(s):	Fehler! Textmarke nicht definiert. In XIOS this curve can trigger a forced idle speed if 5362 <i>CoolPressWarnIdleOn</i> = 1
6590ff	CoolPressLimit2:p(x)	<i>XIOS</i>
	CoolPressIdle:p(x)	<i>Others</i>
	Level:	4
	Range:	0...5 bar
	Page(s):	Fehler! Textmarke nicht definiert. In XIOS this curve can trigger a forced idle speed if 5362 <i>CoolPressWarnIdleOn</i> = 1
6600ff	ExcitControl:n(x)	<i>Locomotive operation</i>
	Level:	2
	Range:	0...4000 rpm
	Page(s):	Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.
6620ff	ExcitControl:f(x)	<i>Locomotive operation</i>

Name	Meaning
Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Fuel quantity grid points for excitation control or fuel quantity setpoints for excitation governing
6640ff ExcitControl:ES(x)	<i>Locomotive operation</i>
Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	Excitation signal setpoints for excitation control

	Name	Meaning
6600ff	PitchControl:n(x) Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>Marine operation</i> Speed grid points for adjustable propeller governing
6610ff	PitchControl:f(x) Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation</i> Fuel quantity setpoints for adjustable propeller governing
6620ff	PitchCtrlPI:f(x) Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>Marine operation</i> Fuel quantity grid points for fuel quantity dependent stability characteristic for adjustable propeller governing
6630ff	PitchCtrlPI:Corr(x) Level: 2 Range: 0...400 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation</i> Correction values for fuel quantity dependent stability characteristic for adjustable propeller governing
6640ff	PitchSpeedLim:n(x) Level: 2 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation</i> Speed grid points for speed-dependent fuel quantity setpoint limitation in adjustable propeller control loop
6650ff	PitchSpeedLim:PS(x) Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Marine operation</i> Signal values for speed-dependent limitation in adjustable propeller control loop
6660ff	ExcitGovPI:f(x) Level: 2 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Fuel quantity grid points for fuel quantity dependent stability characteristic for excitation governing
6680ff	ExcitGovPI:Corr(x) Level: 2 Range: 0...400 % Page(s): Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Correction values for fuel quantity dependent stability characteristic for excitation governing
6700ff	SpeedLimit1:n(x)	

Name	Meaning
Level: 4 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert. , 168, 221, 223	Speed grid points for first or only speed-dependent fuel quantity limitation curve
<hr/>	
6750ff SpeedLimit1:f(x)	
Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	Fuel quantity values for first or only speed-dependent fuel quantity limitation curve
<hr/>	
6800ff SpeedLimit2:n(x)	
Level: 4 Range: 0...4000 rpm Page(s): Fehler! Textmarke nicht definiert.	Speed grid points for second speed-dependent fuel quantity limitation curve

Name	Meaning
6850ff SpeedLimit2:f(x) Level: 4 Range: 0...100 % Page(s):Fehler! Textmarke nicht definiert.	Fuel quantity values for second speed-dependent fuel quantity limitation curve
6880ff LocoNotchAssign(x) Level: 2 Range: 0...255 Page(s):Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., 251	<i>Locomotive operation</i> Speed notch values per binary combination
6900ff LocoSpeedLevel(x) Level: 2 Range: 0...4000 rpm Page(s):Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Speed levels for selection using speed notches in variable speed governor mode
6916ff TractPowLimVolt(x) Level: 2 Range: 0...y V Page(s):Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Speed-dependent traction voltage limits Speed grid points for 6600 <i>ExcitControl:n(x)</i> y: Depending on application
6932ff TractPowLimCurr(x) Level: 2 Range: 0...y A Page(s):Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Speed-dependent traction current limits Speed grid points for 6600 <i>ExcitControl:n(x)</i> y: Depending on application
6950ff LocoFuelLevel(x) Level: 2 Range: 0...100 % Page(s):Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Fuel levels for selection using speed notches in idle/maximum speed governor mode
6966ff ExcitSpeedLim:n(x) Level: 2 Range: 0...4000 rpm Page(s):Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Speed grid points for speed-dependent fuel quantity setpoint limitation in excitation control loop
6982ff ExcitSpeedLim:ES(x) Level: 2 Range: 0...100 % Page(s):Fehler! Textmarke nicht definiert.	<i>Locomotive operation</i> Excitation signal values for speed-dependent limitation in excitation control loop
7000ff AmbPressRedMap:n(x) Level: 4 Range: 0...4000 rpm Page(s): 98	<i>XIOS</i> Speed grid points for speed and ambient pressure dependent power reduction

Name		Meaning
7010ff	AmbPressRedMap:p(x)	<i>XIOS</i>
	Level:	4
	Range:	0...2000 mbar
	Page(s):	98
7020ff	AmbPressRedMap:F(x)	
	Level:	4
	Range:	0...100 %
	Page(s):	98

Name		Meaning
7030ff	ExcitGovPI2:P(x) Level: 2 Range: 0...y kW Page (s): Fehler! Textmarke nicht definiert.	Traction power grid points for traction power dependent stability characteristic for excitation governing in locomotive operation y: Depending on application
7050ff	ExcitGovPI2:Corr(x) Level: 2 Range: 0...400 % Page(s): Fehler! Textmarke nicht definiert.	Correction values for traction power dependent stability characteristic for excitation governing in locomotive operation
7100ff	CoolTempReduce:T(x) Level: 4 Range: -100...+1000 °C Page(s): 96, 230	<i>XIOS</i> Coolant temperature grid points for coolant temperature dependent power reduction
7110ff	CoolTempReduce:F(x) Level: 4 Range: 0...100 % Page(s): 96	<i>XIOS</i> Reduction factor for coolant temperature dependent power reduction
7120ff	ChAirTempReduce:T(x) Level: 4 Range: -100...+1000 °C Page(s): 97, 228	<i>XIOS</i> Charge air temperature grid points for charge air temperature dependent power reduction
7130ff	ChAirTempReduce:F(x) Level: 4 Range: 0...100 % Page(s): 97	<i>XIOS</i> Reduction factor for charge air temperature dependent power reduction
7140ff	FuelTempReduce:T(x) Level: 4 Range: -100...+1000 °C Page(s): 97	<i>XIOS</i> Fuel temperature grid points for fuel temperature dependent power reduction
7150ff	FuelTempReduce:F(x) Level: 4 Range: 0...100 % Page(s): 97	<i>XIOS</i> Reduction factor for fuel temperature dependent power reduction
7160ff	ExhTempReduce:T(x) Level: 4 Range: -100...+1000 °C Page(s): 97, 229	<i>XIOS</i> Exhaust temperature grid points for exhaust temperature dependent power reduction
7170ff	ExhTempReduce:F(x) Level: 4 Range: 0...100 % Page(s): 98	<i>XIOS</i> Reduction factor for exhaust temperature dependent power reduction
7200ff	InjectorMap:n(x)	<i>At request of engine manufacturers</i>

Name		Meaning	
Level:	4	Speed grid points for pump map	
Range:	0...4000 rpm		
Page(s):	359		
7250ff	InjectorMap:f(x)	<i>At request of engine manufacturers</i>	
Level:	4	Fuel quantity grid points for pump map	
Range:	0...100 %		
Page(s):	359		
7300ff	InjectorMap:Pos(x)	<i>At request of engine manufacturers</i>	
Level:	6	Actuator position values for pump map	
Range:	0...100 %		
Page(s):	358		
7200ff	ZeroFuelCurve:n(x)	<i>Zero delivery characteristic</i>	
Level:	4	Speed grid points for zero delivery characteristic	
Range:	0...4000 rpm		
Page(s):	Fehler! Textmarke nicht definiert.		
7250ff	ZeroFuelCurve:Pos(x)	<i>Zero delivery characteristic</i>	
Level:	4	Actuator position values for zero delivery characteristic	
Range:	0...100 %		
Page(s):	Fehler! Textmarke nicht definiert.		
7300ff	FuelToActSpy:f(x)	<i>Position characteristic</i>	
7330ff	Level:	6	Grid points for fuel quantity dependent actuator position characteristic
7360ff	Range:	0...100 %	
	Page(s):	358	
7315ff	FuelToActSp:Pos(x)	<i>Position characteristic</i>	
7345ff	Level:	6	Position values for fuel quantity dependent actuator position characteristic
7375ff	Range:	0...100 %	
	Page(s):	358	
7400ff	ExcitBoostLimit:p(x)		
Level:	2	Traction power values for boost pressure dependent setpoint limitation in excitation control loop	
Range:	0...100 %		
Page(s):	Fehler! Textmarke nicht definiert.		
7500ff	FuelCorr:n(x)		
Level:	4	Speed values for fuel temperature dependent target quantity correction	
Range:	0...4000 rpm		
Page(s):	Fehler! Textmarke nicht definiert.		
7508ff	FuelCorr:f(x)		
Level:	4	Fuel quantity values for fuel temperature dependent target quantity correction	
Range:	0...100 %		
Page(s):	Fehler! Textmarke nicht definiert.		
7516ff	FuelCorr:df(x)		

Name	Meaning
Level: 4 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	Correction values for fuel temperature dependent target quantity correction
7580ff FuelCorr:T(x)	
Level: 6 Range: 0...65535 Page(s): Fehler! Textmarke nicht definiert.	Fuel temperature values for fuel temperature dependent target quantity correction

	Name	Meaning
7590ff	FuelCorrFact:F(x) Level: 6 Range: 0...100 % Page(s): Fehler! Textmarke nicht definiert.	Correction factor for fuel temperature dependent target quantity correction
7600ff	AirMassLin:In(x) Level: 6 Range: 0...5.000 V Page(s):	Analogue input values for air mass sensor (on request)
7610ff	AirMassLin:Out(x) Level: 6 Range: 0...1000.0 kg/h Page(s):	Mass values for air mass sensor (on request)
7660ff	Lambda1Lin:In(x) Level: 6 Range: 0...100.0 % Page(s):	Standardised analogue input values for lambda sensor 1 (on request)
7670ff	Lambda1Lin:Out(x) Level: 6 Range: 0...30.000 Page(s):	Lambda sensor 1 lambda values (on request)
7680ff	Lambda2Lin:In(x) Level: 6 Range: 0...100.0 % Page(s):	Standardised analogue input values for lambda sensor 2 (on request)
7690ff	Lambda2Lin:Out(x) Level: 6 Range: 0...30.000 Page(s):	Lambda sensor 2 lambda values (on request)
7900ff	TempLiny:digit(x) Level: 6 Range: 0...65535 Page(s): 299, Fehler! Textmarke nicht definiert.	<i>DC 1, DC 2, DC 5, DC 6</i> AD converter values for temperature linearisation characteristic y: y = 1...2
7900ff	TempLiny:Ohm(x) Level: 6 Range: 0...60000 Ω Page(s):	<i>Dc 7, DC 8, DC 10, DC 11, DC 12, XIOS</i> Resistance values for temperature linearisation characteristic y: y=1...4
7910ff	TempLiny:T(x) Level: 6 Range: -100...1000 °C Page(s): 299, Fehler! Textmarke nicht definiert.	Temperature values for temperature linearisation characteristic y y see 7900 <i>TempLin1:digit</i>
7980ff	Feedbacky:digit(x)	

	Name		Meaning
8000ff	Level:	6	Digit values for feedback linearisation for actuator y
8020ff	Range:	0...65535	
	Page(s):	352	

	Name		Meaning
7990ff	Feedbacky:Pos(x)		
8010ff	Level:	6	Position values for feedback linearisation for actuator y
8030ff	Range:	0...100 %	y = 1...3
	Page(s):	352	
8100ff	IMDriveMap:n(x)		
	Level:	4	Speed grid points for drive map
	Range:	0...4000 rpm	
	Page(s):	Fehler! Textmarke nicht definiert.	
8110ff	IMDriveMap: Pos(x)		
	Level:	4	Position grid points for drive map
	Range:	0...100 %	
	Page(s):	Fehler! Textmarke nicht definiert.	
8120ff	IMDriveMap:f(x)		
	Level:	4	Fuel quantity values for drive map
	Range:	0...100 %	
	Page(s):	Fehler! Textmarke nicht definiert.	
8300ff	EGROutput:n(x)		
	Level:	4	Speed values for speed and fuel quantity dependent
	Range:	0...4000 rpm	exhaust gas recirculation map
	Page(s):	(on request)	
8310ff	EGROutput:f(x)		
	Level:	4	Fuel quantity values for speed and fuel quantity
	Range:	0...100 %	dependent exhaust gas recirculation map
	Page(s):	(on request)	
8320ff	EGROutput:Pos(x)		
	Level:	4	Position values for speed and fuel quantity dependent
	Range:	0...100 %	exhaust gas recirculation map
	Page(s):	(on request)	
8420ff	InletAir:n(x)		
	Level:	4	Speed values for speed and fuel quantity dependent
	Range:	0...4000 rpm	inlet air throttle valve map
	Page(s):	(on request)	
8430ff	InletAir:f(x)		
	Level:	4	Fuel quantity values for speed and fuel quantity
	Range:	0...100 %	dependent inlet air throttle valve map
	Page(s):	(on request)	
8440ff	InletAir:Pos(x)		
	Level:	4	Position values for speed and fuel quantity dependent
	Range:	0...100 %	inlet air throttle valve map
	Page(s):	(on request)	
8540ff	WasteGate:n(x)		

Name		Meaning
Level:	4	Speed values for speed and fuel quantity dependent
Range:	0...4000 rpm	wastegate map
Page(s):		(on request)

Name	Meaning
8550ff WasteGate:f(x) Level: 4 Range: 0...100 % Page(s):	Fuel quantity values for speed and fuel quantity dependent wastegate map (on request)
8560ff WasteGate:Pos(x) Level: 4 Range: 0...100 % Page(s):	Position values for speed and fuel quantity dependent wastegate map (on request)
8660ff BypassValve:n(x) Level: 4 Range: 0...4000 rpm Page(s):	Speed values for speed and fuel quantity dependent bypass valve map (on request)
8670ff BypassValve:f(x) Level: 4 Range: 0...100 % Page(s):	Fuel quantity values for speed and fuel quantity dependent bypass valve map (on request)
8680ff BypassValve:Pos(x) Level: 4 Range: 0...100 % Page(s):	Position values for speed and fuel quantity dependent bypass valve map (on request)
8780ff InletAirPower:P(x) Level: 4 Range: 0...200 % Page(s):	Power values for power dependent inlet air throttle valve curve (on request)
8790ff InletAirPower:Pos(x) Level: 4 Range: 0...100 % Page(s):	Position values for power dependent inlet air throttle valve curve (on request)
8800ff DigitalOuty:Param(x) Level: 6 Range: -29999...29999 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 9, DC 10</i> Function assignment for multiple assignment to binary output y: DC 1-03: 1...3 DC 6: 1...2 DC 1-04: 1...5 DC 7: 1...7 DC 2: 1...5 DC 9: 1 DC 5: 1 DC 10: 1
9120ff PEDigOuty:Param(x) Level: 6 Range: -29999...29999 Page(s): Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert., Fehler! Textmarke nicht definiert.	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 10</i> HZM-CAN: Function assignment for multiple assignment to binary output y on periphery modules
9700ff PEFuelOut_Assign(x)	<i>DC 1, DC 2, DC 5, DC 6, DC 7, DC 10</i>

Name	Meaning
Level: 6 Range: -29999...29999	HZM-CAN: Assignment of fuel quantity setpoints for periphery modules
Page(s): Fehler! Textmarke nicht definiert.	(RESET)

Name		Meaning
9900ff	PIDMap2(x)	<i>PIDMapSpGov2(x)</i> <i>If integrated power governor is available</i>
	Level: 2	Correction values for second stability map for speed
	Range: 0...400 %	governor, x and y values see 6100/6150
	Page(s): Fehler! Textmarke nicht definiert.	Select with 2841 <i>SwitchPID2Or1</i>
1600ff		<i>Dual fuel parameters are described in the subchapter</i>
28500ff	DOColl_1:Par(x) DOColl_y:Par(x)	<i>DC 8, DC 11, DC 12, XIOS</i>
	Level: 6	Assignment of parameters for compressed output
	Range: 0...9999 or 0...29999 or 0...65535	x = 0...7 or lower, application-specific y = 0...25 or lower, application-specific
	Page(s): Fehler! Textmarke nicht definiert.	
28508ff	DOColl_1: Mask(x) DOColl_y: Mask(x)	<i>XIOS</i>
	Level: 6	Error bit mask if error parameters have been assigned
	Range: 0...FFFF Hex	x = 0...7 or lower, application-specific
	Page(s): Fehler! Textmarke nicht definiert.	y = 0...25 or lower, application-specific
28516ff	DOColl_1:Logic DOColl_x:Logic	<i>DC 8, DC 11, DC 12, XIOS</i>
	Level: 6	Logical link for DO_Collection x:
	Range: 0...7F Hex	Bit = 0: AND function
	Page(s): Fehler! Textmarke nicht definiert.	Bit = 1: OR function x = 0..25 or lower, application-specific
28517ff	DOColl_1:Polarity DOColl_x:Polarity	<i>DC 8, DC 11, DC 12, XIOS</i>
	Level: 6	Polarity of assigned parameters
	Range: 0...FF Hex	Bit = 0: Current value
	Page(s): Fehler! Textmarke nicht definiert.	Bit = 1: Inverted value x = 0..25 or lower, application-specific
29900ff	BitCollParamSet(x)	<i>HZM CAN customer module, Manual DG 05007-e</i> <i>CANopen Gateway, Manual DG 04 005-e</i> <i>DeviceNet, Manual DG 06 003-e</i> <i>Modbus, Manual DG 05 002-e</i>
	Level: 4	Assignment of bit parameters for compressed transmission via the relevant communication module
	Range: -29999...+29999 0...65535	<i>Others</i> <i>XIOS</i>
	Pages: 344	

	Name	Meaning
29932	BitCollParamInverted(y)	<i>XIOS</i>
ff	Level: 4	Identifier of parameters from 29900 <i>BitCollParamSet</i> ,
	Range: 0000...FFFF Hex	whose value is to be inverted and included in the
	Pages: 344	BitCollection
		The bit position corresponds to the index x in 29900 <i>BitCollParamSet(x)</i> y = 0..1
29950	ArgosLEDParamSet(x)	<i>XIOS</i>
ff	Level: 4	Assignment of bit parameters to the LEDs on the
		ARGOS display module
	Range: -29999...+29999	<i>Others</i>
	0...65535	<i>XIOS</i>
	Pages: Fehler! Textmarke nicht definiert.	
29958	ArgosLED0Invert(gr)	<i>XIOS</i>
	Level: 4	Identifier of whether a parameter assigned to LED 0 is
	Range: 0/1	to be displayed inverted
	Pages: Fehler! Textmarke nicht definiert.	
29959	ArgosLED1Invert(or)	<i>XIOS</i>
	Level: 4	Identifier of whether a parameter assigned to LED 1 is
	Range: 0/1	to be displayed inverted
	Pages: Fehler! Textmarke nicht definiert.	
29960	ArgosLED2Invert(gr)	<i>XIOS</i>
	Level: 4	Identifier of whether a parameter assigned to LED 2 is
	Range: 0/1	to be displayed inverted
	Pages: Fehler! Textmarke nicht definiert.	
29961	ArgosLED3Invert(gr)	<i>XIOS</i>
	Level: 4	Identifier of whether a parameter assigned to LED 3 is
	Range: 0/1	to be displayed inverted
	Pages: Fehler! Textmarke nicht definiert.	
29962	ArgosLED4Invert(gr)	<i>XIOS</i>
	Level: 4	Identifier of whether a parameter assigned to LED 4 is
	Range: 0/1	to be displayed inverted
	Pages: Fehler! Textmarke nicht definiert.	
29963	ArgosLED5Invert(rd)	<i>XIOS</i>
	Level: 4	Identifier of whether a parameter assigned to LED 5 is
	Range: 0/1	to be displayed inverted
	Pages: Fehler! Textmarke nicht definiert.	
29964	ArgosLED6Invert(gr)	<i>XIOS</i>

Name	Meaning
Level:	4
Range:	0/1
Pages: Fehler! Textmarke nicht definiert.	Identifier of whether a parameter assigned to LED 6 is to be displayed inverted

Name	Meaning
29965 ArgosLED7Invert(gr)	<i>XIOS</i>
Level:	4
Range:	0/1
Pages:	Fehler! Textmarke nicht definiert.

Tab. 211: Characteristics and maps

28.4.1 Dual fuel

↑ 16 Speed control for dual fuel engines (ARTEMIS) and separate ARTEMIS manuals

No.	Name	Meaning
16040	GasPICrvPGov:Corr(x)	<i>Integrated power governor</i>
ff	Level:	4
	Range:	0...400 %
	Page(s):	214
16100	GasModeBoostPr:P(x)	
ff	Level:	4
	Range:	0...200% or 0...y kW
	Page(s):	193
16115	GasModeBoostPr:p(x)	
ff	Level:	4
	Range:	0...5 bar
	Page(s):	193
16450	GasTempFactor:T(x)	
ff	Level:	4
	Range:	-100...1000 °C
	Page(s):	231
16460	GasTempFactor:F(x)	
ff	Level:	4
	Range:	-50...50 %
	Page(s):	231
16470	GasPressFactor:p(x)	
ff	Level:	4
	Range:	0...2 bar
	Page(s):	231
16480	GasPressFactor:F(x)	
ff	Level:	4
	Range:	-50...50 %
	Page(s):	231

No.	Name	Meaning
16670	GasLimColTmpRed:F(x)	<i>XIOS</i>
ff	Level: 4 Range: 0..100 % Page(s): 230	Factor for coolant temperature dependent reduction of speed or power dependent gas limitation Coolant temperature values in 7100 <i>CoolTempReduce:T(x)</i>
16680	GasLChAirTmpRed:F(x)	<i>XIOS</i>
ff	Level: 4 Range: 0..100 % Page(s): 228	Factor for charge air temperature dependent reduction of speed or power dependent gas limitation Charge air temperature values in 7120 <i>ChAirTempReduce:T(x)</i>
16700	GasLimExhTmpRed:F(x)	<i>XIOS</i>
ff	Level: 4 Range: 0..100 % Page(s): 229	Factor for exhaust temperature dependent reduction of speed or power dependent gas limitation Exhaust temperature values in 7160 <i>ExhTempReduce:T(x)</i>
16780	PilotDslAbsMin:n(x)	
ff	Level: 6 Range: 0...4000 rpm Page(s): 164	Speed grid points for the speed-dependent absolute minimum value of ignition oil quantity
16790	PilotDslAbsMin:Dsl(x)	
ff	Level: 6 Range: 0...100 % Page(s): 164	Speed-dependent absolute minimum value of ignition oil quantity

Tab. 212: Dual fuel characteristics and maps (general)

28.4.1.1 Gas speed governor

No.	Name	Meaning
16000	GasPIDCurve:n(x)	
ff	Level: 4 Range: 0...4000 rpm Page(s): 209	Speed grid points for PID correction
16010	GasPIDCurve:Gasf(x)	
ff	Level: 4 Range: 0..100 % Page(s): 209	Gas fuel quantity grid points for PID correction
16020	GasPIDCurve:P(x)	
ff	Level: 4 Range: 0..200 % Page(s): 209	Power grid points for PID correction
16030	GasPIDCurve:Corr(x)	
ff	Level: 4 Range: 0...400 % Page(s): 208	Correction values for PID correction

No.	Name	Meaning
16050	DieselPower:f(x)	
ff	Level: 4 Range: 0..100 % Page(s): 166	Diesel fuel quantity grid points for characteristic for determining the diesel power proportion
16065	DieselPower:P(x)	
ff	Level: 4 Range: 0...100 % or 0...y kW Page(s): 167	Diesel power values for characteristic for determining the diesel power proportion y: Depending on application
16130	GasSpeedLimit:f(x)	
ff	Level: 4 Range: 0...100 % Page(s): 168, 223, 224	Speed-dependent gas fuel quantity limitation Speed values in 6700 <i>SpeedLimit1:n(x)</i>
16150	GasPowerLimit:P(x)	
ff	Level: 4 Range: 0...200% or 0...y kW Page(s): 221	Power values for power-dependent gas fuel quantity limitation
16180	GasPowerLimit:f(x)	
ff	Level: 4 Range: 0..100 % Page(s): 221	Gas fuel quantity values for power-dependent gas fuel quantity limitation
16210	GasFToActSetp:f(x)	<i>DC 1-04, XIOS</i>
ff	Level: 4 Range: 0..100 % Page(s): 170	Grid points for fuel quantity dependent gas actuator position characteristic
16225	GasFToActSet:Pos(x)	<i>DC 1-04, XIOS</i>
ff	Level: 4 Range: 0...100 % Page(s): 170	Position values for fuel quantity dependent gas actuator position characteristic
16300	PilotDiesel:P(x)	
ff	Level: 4 Range: 0...200 % Page(s): 165	Power grid points for power-dependent ignition oil quantity
16310	PilotDiesel:Dsl(x)	
ff	Level: 4 Range: 0...100 % Page(s): 165	Ignition oil quantity for power-dependent ignition oil quantity

Tab. 213: Dual fuel characteristics and maps (gas speed governor)

28.4.1.2 Diesel reduction governor

No.	Name	Meaning
16050	MaxPower:n(x)	<i>Locomotive operation</i>
ff	Level: 4	Speed grid points for maximum permissible power
	Range: 0...100 %	characteristic
	Page(s): 166	
16060	MaxPower:P(x)	<i>Locomotive operation</i>
ff	Level: 4	Traction power values for maximum permissible power
	Range: 0...y kW	characteristic
	Page (s): 166	y: Depending on application
16130	DFSpeedLimit:P(x)	<i>Marine operation</i>
ff	Level: 4	Speed-dependent total power limitation
	Range: 0...y kW	Speed values in 6700 <i>SpeedLimit1:n(x)</i>
	Page(s): 168, 223	y: Depending on application
16130	GasSpeedLimit:f(x)	<i>Locomotive operation</i>
ff	Level: 4	Speed-dependent gas fuel quantity limitation
	Range: 0...100 %	Speed values for 6700 <i>SpeedLimit1:n(x)</i>
	Page(s): 224	
16150	GasPowerLimit:P(x)	<i>Locomotive operation</i>
ff	Level: 4	Traction power values for power dependent gas fuel
	Range: 0...y kW	quantity limitation
	Page (s): 226	y: Depending on application
16180	GasPowerLimit:f(x)	<i>Locomotive operation</i>
ff	Level: 4	Gas fuel quantity values for power-dependent gas fuel
	Range: 0...100 %	quantity limitation
	Page(s): 226	
16210	GasFToActSetp:f(x)	<i>Locomotive operation: DC 1-04, XIOS</i>
ff	Level: 4	Grid points for fuel quantity dependent gas actuator
	Range: 0...100 %	position characteristic
	Page(s): 170	
16225	GasFToActSet:Pos(x)	<i>Locomotive operation: DC 1-04, XIOS</i>
ff	Level: 4	Position values for fuel quantity dependent gas actuator
	Range: 0...100 %	position characteristic
	Page(s): 170	
16300	DieselSetpGas:P(x)	<i>Locomotive operation</i>
ff	Level: 4	Traction power grid points for power-dependent diesel
	Range: 0...y kW	setpoint
	Page (s): 216	y: Depending on application
16300	DieselSetpGas:n(x)	<i>Marine operation</i>
ff	Level: 4	Speed grid points for speed-dependent diesel setpoint
	Range: 0...4000 rpm	
	Page(s): 216	

No.	Name	Meaning
16310	DieselSetpGas:Dsl(x)	
ff	Level: 4 Range: 0...100 % Page(s): 216	Diesel setpoints for power or speed-dependent diesel fuel quantity setpoint
16490	DieselNegPow:f(x)	<i>At request of engine manufacturers</i>
ff	Level: 6 Range: 0...100 % Page(s): 169	Diesel fuel quantity grid points for speed and diesel fuel quantity dependent map for determining the negative power proportions for diesel if fuel quantity falls below the zero-fuel characteristic (ignition oil quantity below zero-fuel characteristic) Speed values in 16800 <i>DieselPower:n(x)</i>
16500	DieselNegPow:P(x)	<i>At request of engine manufacturers</i>
ff	Level: 6 Range: 0...y kW Page (s): 169	Negative power proportions for diesel if fuel quantity falls below zero-fuel characteristic (ignition oil quantity below zero-fuel characteristic) y: Depending on application
16800	DieselPower:n(x)	
ff	Level: 4 Range: 0...4000 rpm Page(s): 166, 168	Speed grid points for map for determining the diesel power proportion
16810	DieselPower:f(x)	
ff	Level: 4 Range: 0..100 % Page(s): 166, 168	Fuel quantity grid points for map for determining the diesel power proportion
16810	DieselPower:p(x)	<i>Engines with PT pump</i>
ff	Level: 4 Range: 0...40 bar Page(s): 166, 168	Diesel pressure grid points for map for determining the diesel power proportion
16835	DieselPower:P(x)	
ff	Level: 4 Range: 0...y kW Page(s): 166, 168	Diesel power values in map for determining diesel power proportion y: Depending on application

Tab. 214: Dual fuel characteristics and maps (diesel reduction governor)

28.4.2 CANopen

↑ 23.4 CAN protocol CANopen and CANopen, Manual DG 06 002-e

No.	Name	Meaning
29000	CanOp:RPDOEvtTim(x)	<i>If only 4 RPDOs are possible</i>
ff	Level: 4 Range: 0...50 s	Event time for RPDOs x = 0...3 <i>See 29180 if more than 4 RPDOs are possible</i>

No.	Name	Meaning
29004	CanOp:TPDOTxType(x)	
ff	Level: 4	Transmission type of TPDOs
	Range: 253/254	x = 0...15
29020	CanOp:TPDOEvtTim(x)	
ff	Level: 4	Event time for TPDOs
	Range: 0...50 s	x = 0...15
29036	CanOp:TPDOInhTim(x)	
ff	Level: 4	Inhibit time for TPDOs
	Range: 0...50 s	x = 0...15
29052	CanOp:TPDOyAssign(x)	
ff	Level: 4	Assignment of send parameters to TPDOs
	Range: 0...29999	x = 0...3, y = 1...16 (RESET)
29116	CanOp:TPDOyHyst(x)	
ff	Level: 4	Assignment of hysteresis values to send parameters for TPDOs
	Range: 0...100 %	x = 0...3, y = 1...16
29180	CanOp:RPDOEvtTim(x)	<i>If more than 4 RPDOs are possible</i>
ff	Level: 4	Event time for RPDOs
	Range: 0...50 s	x = 0...9 <i>See 29000 if only 4 RPDOs are possible</i>

Tab. 215: CANopen characteristics and maps

28.4.3 Modbus

↑ 23.8 Serial protocol Modbus and Manual DG 05 002-e

No.	Name	Meaning
29200	Modb:TxParamSet(x)	
ff	Level: 4	Data field for read access, the parameter and measured value numbers whose values are to be transmitted on request are to be entered
	Range: 0...29999	

Tab. 216: Modbus characteristics and maps

28.4.4 DeviceNet

↑23.5 CAN protocol DeviceNet and Manual DG 06 003-e

No.	Name	Meaning
29400	DNet:TxParamSet(x)	
ff	Level:	4 Assignment of send parameters to polled message
	Range:	0...29999

Tab. 217: DeviceNet characteristics and maps

28.4.5 SAE J1939

↑23.3 CAN protocol SAE J1939 and Manual DG 06 004-e

No.	Name	Meaning
29600	J1939:RxTSC1_y:Src(x)	<i>TSCI</i>
ff	Level:	4 Sender of “Torque/Speed Control 1” receiving telegram
	Range:	0...255 y = 1...4 (standard 1) (RESET)
29601	J1939:RxTSC1_y:Scan	<i>TSCI</i>
ff	Level:	4 Receive rate for “Torque/Speed Control 1” receiving telegram
	Range:	0...10 s y = 1.4 (standard 1) (RESET)
29602	J1939:RxSNS:Src	<i>ATI OGI</i>
	Level:	4 Sender of “Aftertreatment 1 Outlet Gas 1” receiving telegram
	Range:	0...255 (RESET)
29603	J1939:RxSNS:Scan	<i>ATI OGI</i>
	Level:	4 Receive rate of “Aftertreatment 1 Outlet Gas 1” receiving telegram
	Range:	0...10 s (RESET)
29604	J1939:RxEBC1:Src	<i>EBCI</i>
	Level:	4 Sender of “Electronic Brake Controller 1” receiving telegram
	Range:	0...255 (RESET)
29605	J1939:RxEBC1:Scan	<i>EBCI</i>
	Level:	4 Receive rate of “Electronic Brake Controller 1” receiving telegram
	Range:	0...10 s (RESET)
29608	J1939:RxEngTemp:Src	<i>ETI</i>
	Level:	4 Sender of “Engine Temperature 1” receiving telegram
	Range:	0...255 (RESET)
29609	J1939:RxEngTemp:Scan	<i>ETI</i>
	Level:	4 Receive rate of “Engine Temperature 1” receiving telegram
	Range:	0...10 s (RESET)
29610	J1939:RxFILevel:Src	<i>EFL/PI</i>
	Level:	4 Sender of “Engine Fluid Level/Pressure 1” receiving telegram
	Range:	0...255 (RESET)

No.	Name	Meaning
29611	J1939:RxFLLevel:Scan	<i>EFL/P1</i>
	Level:	4 Receive rate of "Engine Fluid Level/Pressure 1" receiving telegram
	Range:	0...255 (RESET)
29612	J1939:RxTFluids:Src	<i>TRF1</i>
	Level:	4 Sender of "Transmission Fluids 1" receiving telegram
	Range:	0...255 (RESET)
29613	J1939:RxTFluids:Scan	<i>TRF1</i>
	Level:	4 Receive rate of "Transmission Fluids 1" receiving telegram
	Range:	0...10 s (RESET)
29614	J1939:RxInlExh:Src	<i>ICI</i>
	Level:	4 Sender of "Intake/Exhaust Conditions 1" receiving telegram
	Range:	0...255 (RESET)
29615	J1939:RxInlExh:Scan	<i>ICI</i>
	Level:	4 Receive rate of "Intake/Exhaust Conditions 1" receiving telegram
	Range:	0...10 s (RESET)
29623	J1939:RxPTO:Src	<i>PTO</i>
	Level:	4 Sender of "Power Takeoff Information" receiving telegram
	Range:	0...255 (RESET)
29624	J1939:RxPTO:Scan	<i>PTO</i>
	Level:	4 Receive rate of "Power Takeoff Information" receiving telegram
	Range:	0...10 s (RESET)
29630	J1939:TxEEC1:Send	<i>EEC1</i>
	Level:	4 Send rate of "Electronic Engine Controller 1" sending telegram
	Range:	0...10 s (RESET)
29631	J1939:TxEEC2:Send	<i>EEC2</i>
	Level:	4 Send rate of "Electronic Engine Controller 2" sending telegram
	Range:	0...10 s (RESET)
29632	J1939:TxEEC3:Send	<i>EEC3</i>
	Level:	4 Send rate of "Electronic Engine Controller 3" sending telegram
	Range:	0...10 s (RESET)
29633	J1939:TxEngTemp:Send	<i>ETI</i>
	Level:	4 Send rate of "Engine Temperature 1" sending telegram
	Range:	0...10 s (RESET)
29634	J1939:TxFLLevel:Send	<i>EFL/P1</i>
	Level:	4 Send rate of "Engine Fluid Level/Pressure 1" sending telegram
	Range:	0...10 s (RESET)
29635	J1939:TxTFluids:Send	<i>TRF1</i>
	Level:	4 Send rate of "Transmission Fluids 1" sending telegram
	Range:	0...10 s (RESET)
29636	J1939:TxAmbCond:Send	<i>AMB</i>
	Level:	4 Send rate of "Ambient Conditions" sending telegram
	Range:	0...10 s (RESET)

No.	Name	Meaning
29637	J1939:TxInExh:Send	<i>ICI</i>
	Level: 4	Send rate of “Intake/Exhaust Conditions 1” sending telegram
	Range: 0...10 s	(RESET)
29638	J1939:TxCCVehSp:Send	<i>CCVSI</i>
	Level: 4	Send rate of “Cruise Control/Vehicle Speed 1” sending telegram
	Range: 0...10 s	(RESET)
29639	J1939:TxEngConf:Send	<i>ECI</i>
	Level: 4	Send rate of “Engine Configuration 1” sending telegram
	Range: 0...FFFF Hex	(RESET)
29642	J1939:TxEngInfo:Send	<i>EII</i>
	Level: 4	Send rate of “Engine Information 1” sending telegram
	Range: 0...FFFF Hex	(RESET)
29644	J1939:TxVEP1:Send	<i>VEP1</i>
	Level: 4	Send rate of “Vehicle Electrical Power 1” sending telegram
	Range: 0...10 s	(RESET)
29705	J1939:TorqFMap:n	<i>EEC3</i>
	Level: 4	Speed grid points for torque friction map
	Range: 0...4000 rpm	
29715	J1939:TorqFMap:T	<i>EEC3</i>
	Level: 4	Coolant temperature grid points for torque friction map
	Range: -100...1000 °C	
29720	J1939:TorqFMap:f	<i>EEC3</i>
	Level: 4	Torque friction values for torque friction map
	Range: 0...100 %	

Tab. 218: SAE J1939 characteristics and maps

28.4.6 HZM-CAN customer module

↑ 23.2 CAN protocol HZM-CAN customer module and Manual DG 05007-e

No.	Name	Meaning
29800	CMTelyParamSet(x)	
ff	Level: 4	Assignment of sending parameters to sending telegram
	Range: 0...29999	y on HZM-CAN customer module
		y = 50..58 (RESET)

Tab. 219: HZM-CAN customer module characteristics and maps

29 Illustrations

Fig. 1 Functional block diagram	9
Fig. 2: ARGOS front cover	17
Fig. 3: Fixed starting fuel limitation.....	40
Fig. 4: Variable starting fuel limitation.....	41
Fig. 5: Temperature dependent starting fuel	43
Fig. 6: Temperature dependent starting fuel limitation.....	44
Fig. 7: Starting behaviour when starting speed ramp is enabled.....	45
Fig. 8: Speed setpoint determination for general purposes	47
Fig. 9: Determination of speed setpoints for vehicle operation	50
Fig. 10: Determination of speed setpoints for locomotive operation.....	53
Fig. 11: Determination of speed setpoints for generator sets.....	57
Fig. 12: Determination of setpoints for marine operation	59
Fig. 13: Setpoint determination with directional information.....	61
Fig. 14: Temperature dependent idle speed	65
Fig. 15: Speed profile of sectional speed ramp	67
Fig. 16: Droop with full load reference.....	69
Fig. 17: Droop with zero load reference	69
Fig. 18: Speed dependent correction	74
Fig. 19: Load dependent correction in diesel engines.....	75
Fig. 20: Performance graph of gas engine in dependence of throttle valve position.....	76
Fig. 21: Load dependent correction in gas engines.....	77
Fig. 22: Stability map	78
Fig. 23: Temperature dependent correction of stability	80
Fig. 24: Correction for static operation	81
Fig. 25: Important limiting functions	85
Fig. 26: Speed dependent fuel limitation	87
Fig. 27: Temperature dependent reduction of full-load characteristic	89
Fig. 28: Boost pressure dependent fuel limitation.....	91
Fig. 29: Externally activated power limitation.....	93
Fig. 30: Zero fuel delivery characteristic	95

Fig. 31: Temperature dependent reduction of the full-load characteristic (XIOS)	96
Fig. 32: Oil pressure characteristics	103
Fig. 33: Coolant pressure characteristics.....	105
Fig. 34: Idle/maximum speed control	117
Fig. 35: Excitation control.....	127
Fig. 36: Slide protection	134
Fig. 37: Slide protection	135
Fig. 38: Load control by Setpoint Adjustment	144
Fig. 39: Calibration procedure	306
Fig. 40: Reading out a parameter via an analogue output	316
Fig. 41: Reading out a parameter via a PWM output.....	319
Fig. 42: Blinking signal	322
Fig. 48: Current reduction under static load.....	361
Fig. 49: Actuator errors on a periphery module	366

30 Tables

Table 1 Basic firmware variants.....	5
Table 2 Special firmware variants.....	6
Table 3 HELENOS basic Systems	7
Table 4 ORION basic systems	7
Table 5 PANDAROS basic systems	7
Table 6 PRIAMOS basic systems	7
Table 7 Dual-fuel basic systems.....	7
Table 8 Ordering information for digital controls.....	8
Table 9 Product overview sensors.....	8
Table 10 Communication programmes	8
Table 11: Map structure	20
Table 12 Maximum frequency	39
Table 13: Applications	44
Table 14: Speed setpoint switching functions 1.....	45
Table 15: Speed setpoint switching functions 2.....	45
Table 16: Limiting functions.....	86
Table 17: Speed notches from speed notch switches	120
Table 18: Extended notch table.....	121
Table 19: Excitation signal limitation	130
Table 20: HZM-CAN: Node numbers in multiple engine set.....	157
Table 21: Sensors	236
Table 22: Derived sensors	237
Table 23: Sensor sources.....	238
Table 24: Sensor measurement ranges	241
Table 25: Sensor substitution in case of error	246
Table 26: Sensor error with latching	247
Table 27: Switching function parameters.....	248
Table 28: Switch functions.....	251
Table 29: Communication modules as switching function sources (channel type)	257
Table 30: ARCHIMEDES: Variable connections.....	262

Table 31: ARCHIMEDES: Analogue inputs	263
Table 32: ARCHIMEDES: PWM input.....	263
Table 33: ARCHIMEDES: Digital inputs.....	264
Table 34: ARCHIMEDES: Analogue output.....	264
Table 35: ARCHIMEDES: PWM outputs	264
Table 36: ARCHIMEDES: Digital outputs.....	265
Table 37: HELENOS: Variable connections	267
Table 38: HELENOS: Analogue inputs	268
Table 39: HELENOS: PWM inputs	268
Table 40: HELENOS: Digital inputs	269
Table 41: HELENOS: Analogue outputs	269
Table 42: HELENOS: PWM outputs	270
Table 43: HELENOS: Digital outputs	270
Table 44: HELENOS: Fixed alarm outputs	271
Table 45: ORION: Variable connections	272
Table 46: ORION: Input for pickup 2	273
Table 47: ORION: Analogue inputs.....	273
Table 48: ORION: PWM input	273
Table 49: ORION: Digital inputs	274
Table 50: ORION: Digital outputs	274
Table 51: PANDAROS: Variable connections	275
Table 52: PANDAROS: Input for pickup2	276
Table 53: PANDAROS: Analogue inputs.....	276
Table 54: PANDAROS: PWM inputs.....	277
Table 55: PANDAROS: Digital inputs	277
Table 56: PANDAROS: Analogue outputs.....	277
Table 57: PANDAROS: PWM outputs.....	278
Table 58: PANDAROS: Digital outputs	278
Table 59: PRIAMOS: Variable connections	279
Table 60: PRIAMOS: Analogue inputs	280
Table 61: PRIAMOS: PWM inputs	280
Basic Information for Control Units with Conventional Injection, Level 6	761

Table 62: PRIAMOS: Digital inputs	281
Table 63: PRIAMOS: Analogue outputs	281
Table 64: PRIAMOS: PWM outputs	282
Table 65: PRIAMOS: Digital outputs	282
Table 66: PRIAMOS: Fixed alarm outputs	283
Table 67: PRIAMOS III: Variable connections	284
Table 68: PRIAMOS III : Analogue inputs	285
Table 69: PRIAMOS III: PWM input	285
Table 70: PRIAMOS III : Digital inputs	286
Table 71: PRIAMOS III : Analogue outputs	286
Table 72: PRIAMOS III: PWM outputs	287
Table 73: PRIAMOS III: Digital outputs	287
Table 74: PRIAMOS III: Fixed alarm outputs	288
Table 75: XIOS – module types	289
Table 76: XIOS - input A modules	291
Table 77: XIOS - output A modules	292
Table 78: XIOS – actuator module A9.....	292
Table 79: XIOS – maximum number of inputs.....	293
Table 80: XIOS – maximum number of outputs.....	293
Table 81: XIOS – maximum number of actuators	293
Table 82: XIOS - pin assignment A modules on slots	294
Table 83: XIOS - input channel types	296
Table 84: XIOS - output channel types	296
Table 85: XIOS – port configuration analogue inputs	297
Table 86: XIOS – port configuration temperature inputs	298
Table 87: XIOS – port configuration temperature sensors	299
Table 88: XIOS – port configuration PWM input.....	300
Table 89: XIOS – port configuration binary inputs	300
Table 90: XIOS – port configuration speed inputs	301
Table 91: XIOS – port assignment to pickup sensors	301
Table 92: XIOS – port configuration frequency inputs.....	302

Table 93: XIOS – port configuration analogue outputs	303
Table 94: XIOS – port configuration PWM outputs	303
Table 95: XIOS – port configuration binary outputs	304
Table 96: XIOS – port configuration actuator control	304
Table 97: XIOS – port configuration actuator feedback	305
Table 98: Parameters for analogue inputs	310
Table 99: Parameters for temperature inputs	311
Table 100: XIOS – parameters analogue inputs.....	312
Table 101: XIOS – parameter temperature inputs	313
Table 102: XIOS – parameter PWM input.....	313
Table 103: XIOS – parameters frequency inputs	314
Table 104: XIOS – analogue outputs	323
Table 105: XIOS – PWM outputs	324
Table 106: Bus interfaces	337
Table 107: Bus protocols.....	338
Table 108: Firmware variants with bus protocols.....	338
Table 109: Node types.....	339
Table 110: WAGO® analogue input modules	341
Table 111: AXIOMATIC® analogue input modules.....	341
Table 112: Cable types for CAN and Modbus systems	346
Tab. 201: Actuator control	347
Tab. 202: Linear actuator with 2Q control.....	348
Tab. 203: Actuators with rotary magnet and 2Q control.....	348
Tab. 204: Actuators with rotary magnet and 4Q control.....	349
Tab. 205: Actuators with servo motor and 4Q control.....	349
Tab. 206: Electrically commutated actuators with ElySION feedback	350
Tab. 207: Actuator feedback	351
Tab. 1: Error outputs of DC 1 and DC 2	375
Tab. 2: LED error indication DC 1	377
Tab. 3: LED error indication DC 2	377
Tab. 4: LED error indication DC 8	378
Basic Information for Control Units with Conventional Injection, Level 6	763

Tab. 5: LED error indication DC 10	378
Tab. 6: Bootloader: Watchdog test.....	381
Tab. 7: Bootloader: RAM test	381
Tab. 8: Bootloader: Internal RAM test.....	381
Tab. 9: Bootloader: Bootloader program test.....	382
Tab. 10: Bootloader: Control unit program test	382
Tab. 37: XIOS: General error status.....	409
Tab. 38: XIOS: Possible errors speed sensors.....	410
Tab. 39: XIOS: Possible errors overspeed	410
Tab. 40: XIOS: Possible errors adjusters and sensors.....	413
Tab. 41: XIOS: Possible errors misfire monitoring	413
Tab. 42: XIOS: Possible errors twin-engine applications (ship).....	414
Tab. 43: XIOS: Possible errors integrated power governor	414
Tab. 44: XIOS: Possible errors CAN bus	415
Tab. 45: XIOS: Possible errors CAN communication	416
Tab. 46: XIOS: Possible errors internal temperature measurement.....	416
Tab. 47: XIOS: Possible errors Ethernet.....	417
Tab. 49: XIOS: Possible errors voltage supply	417
Tab. 50: XIOS: Possible errors data storage	418
Tab. 51: XIOS: Possible errors file system	419
Tab. 52: XIOS: Possible errors USB host.....	419
Tab. 53: XIOS: Possible errors FPGA	420
Tab. 54: XIOS: Possible errors engine-specific errors.....	420
Tab. 55: XIOS: Possible errors configuration	421
Tab. 56: XIOS: Possible errors internal computing error	422
Tab. 57: XIOS: Possible errors gas section.....	423
Tab. 58: XIOS: Possible errors gas conditions	426
Tab. 59: XIOS: Possible errors dual fuel status	426
Tab. 60: XIOS: Possible errors Smart NO _x and O ₂ sensor.....	427
Tab. 61: XIOS: Possible errors maximum exhaust temperature	427
Tab. 61: XIOS: Possible errors maximum exhaust temperature	428

Tab. 155: Parameters.....	473
Tab. 156: DC 1 parameters	473
Tab. 157: DC 5 parameters	474
Tab. 158: DC 10 parameters	474
Tab. 159: Parameter XIOS	478
Tab. 160: Dual fuel parameters (general).....	482
Tab. 161: Dual fuel parameters (gas speed governor)	485
Tab. 162: Dual fuel parameters (diesel reduction governor)	487
Tab. 163: ICENI parameters	488
Tab. 164: WAGO parameters.....	489
Tab. 165: CANopen parameters.....	491
Tab. 166: Modbus parameters	491
Tab. 167: DeviceNet parameters	492
Tab. 168: SAE J1939 parameters	493
Tab. 169: HZM-CAN customer module parameters.....	493
Tab. 170: Measured values and display values	542
Tab. 171: DC 1 measured values and display values	543
Tab. 172: DC 2 measured values and display values	545
Tab. 173: DC 5 measured values and display values	546
Tab. 174: DC 6 measured values and display values	548
Tab. 175: DC 7 measured values and display values	549
Tab. 176: DC 8 measured values and display values	552
Tab. 177: DC 9 measured values and display values	552
Tab. 178: DC 10 measured values and display values	554
Tab. 179: DC 11 measured values and display values	557
Tab. 180: DC 12 measured values and display values	558
Tab. 181: Measured values and display values XIOS.....	566
Tab. 182: Measured values and display values for dual fuel (general).....	571
Tab. 183: Measured and display values for dual fuel (gas speed governor).....	573
Tab. 184: Measured and display values for dual fuel (diesel reduction governor).....	577
Tab. 185: Measured and display values for CANopen	579
Basic Information for Control Units with Conventional Injection, Level 6	765

Tab. 185: Measured and display values for Modbus	580
Tab. 187: Measured and display values for DeviceNet	581
Tab. 188: Measured and display values for SAE J1939	582
Tab. 189: Functions	608
Tab. 190: DC 1 functions	609
Tab. 191: DC 2 functions	610
Tab. 192: DC 5 functions	612
Tab. 310: DC 6 functions	613
Tab. 194: DC 7 functions	614
Tab. 195: DC 8 functions	615
Tab. 196: DC 9 functions	616
Tab. 197: DC 10 functions	617
Tab. 198: DC 11 functions	619
Tab. 199: Functions XIOS	620
Tab. 200: Dual fuel functions (general)	622
Tab. 201: ICENI functions	623
Tab. 202: WAGO functions	623
Tab. 203: CANopen functions	624
Tab. 204: Modbus functions.....	624
Tab. 205: DeviceNet functions.....	624
Tab. 206: SAE J1939 functions.....	627
Tab. 207: HZM-CAN customer module functions	627
Tab. 208: Characteristics and maps.....	640
Tab. 209: Dual fuel characteristics and maps (general)	641
Tab. 210: Dual fuel characteristics and maps (gas speed governor)	642
Tab. 211: Dual fuel characteristics and maps (diesel reduction governor)	644
Tab. 212: CANopen characteristics and maps	645
Tab. 213: Modbus characteristics and maps	645
Tab. 214: DeviceNet characteristics and maps	646
Tab. 334: SAE J1939 characteristics and maps	648
Tab. 335: HZM-CAN customer module characteristics and maps	648

31 Download of manuals

Technical manuals can be downloaded in pdf-format from our homepage:

www.heinzmann.com

If the desired manual should not be available there, send an e-mail to:

info@heinzmann.de

or write to:

HEINZMANN GmbH & Co. KG

Technische Redaktion

Am Haselbach 1

D-79677 Schönau/Germany

Please include the following information:

- your name
- name and address of your company
- e-mail or address where you want the manuals to be sent to (if different from above)
- item code (as on front page, bottom right) and title of the desired manual
or alternatively the technical data of your HEINZMANN equipment

We would be pleased to receive your comments about the contents and presentation of our publications. Send your comments to the e-mail or address shown above please.